INTERNATIONAL STANDARD

ISO 11525-1

Second edition 2020-01

Rough-terrain trucks — Safe use requirements —

Part 1: Variable-reach trucks

Chariots tout-terrain — Exigences pour l'utilisation en toute

iTeh STANDARD PREVIEW
Partie 1: Chariots à portée variable
(standards.iteh.ai)

ISO 11525-1:2020 https://standards.iteh.ai/catalog/standards/sist/532bd4f0-e3a7-4772-ba91-52dcca39fe95/iso-11525-1-2020



iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 11525-1:2020 https://standards.iteh.ai/catalog/standards/sist/532bd4f0-e3a7-4772-ba91-52dcca39fe95/iso-11525-1-2020



COPYRIGHT PROTECTED DOCUMENT

© ISO 2020

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office CP 401 • Ch. de Blandonnet 8 CH-1214 Vernier, Geneva Phone: +41 22 749 01 11 Fax: +41 22 749 09 47 Email: copyright@iso.org Website: www.iso.org Published in Switzerland

Contents		
Foreword		iv
1	Scope	1
2	Normative references	
3	Terms and definitions	
4	General requirements 4.1 Principles	2
	4.2 Operator's manual(s) 4.3 Modifications or alterations	3
	4.4 Manufacturer's bulletins4.5 Operator qualifications and training	4
	4.6 Inspection and maintenance	4
	4.6.3 Performance checks 4.6.4 Inspection and maintenance precautions	
	4.6.5 Inspection and maintenance requirements	6
5	Operating safety rules and precautions 5.1 Operator's responsibility for safety. D. P.R.E. V. E. V.	
	 5.2 Visual inspection and functional tests 5.3 General operating instructions rds.iteh.ai) 5.4 Travelling 	
	5.5 Picking and placing loads. <u>ISO 11525-1:2020</u> . 5.6 Using attachments teh-ai/catalog/standards/sist/532bd4f0-e3a7-4772-ba91-	11
Rihl	52dcca39fe95/iso-11525-1-2020	13

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see www.iso.org/iso/foreword.html. (standards.iteh.ai)

This document was prepared by Technical Committee ISO/TC 110, *Industrial trucks*, Subcommittee SC 4, *Rough-terrain trucks*. ISO 11525-1:2020 https://standards.iteh.ai/catalog/standards/sist/532bd4f0-e3a7-4772-ba91-

This second edition cancels and replaces the first edition (ISO 11525-1:2012) which has been technically revised.

The main changes compared to the previous edition are as follows:

- requirements related to training have been moved to ISO 23676¹;
- operator qualifications and requirements for an operator to be trained have been merged;
- requirements related to refuelling have been added.

A list of all parts in the ISO 11525 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

¹⁾ Under preparation. Stage at the time of publication: ISO/DIS 23676:2019.

Rough-terrain trucks — Safe use requirements —

Part 1:

Variable-reach trucks

1 Scope

This document specifies requirements for application, inspection, training, maintenance, repair and safe operation (herein referred to as safe use) of non-slewing variable-reach rough-terrain trucks (herein referred to as trucks), as defined in ISO 10896-1.

It is intended to achieve the following:

- the prevention of personal injuries, property damage and accidents;
- the establishment of criteria for inspection, maintenance and operation;
- the establishment of operator training requirements.

The safe use requirements for slewing trucks, the interface between rough-terrain trucks and integrated personnel work platforms that can be fitted to rough-terrain trucks and the handling of freely suspended loads with rough-terrain trucks are covered by the other parts of the ISO 11525 series.

The safe use requirements for non-integrated personnel work platforms are covered in ISO 18479-2.

This document is not applicable to lorry-mounted trucks. https://standards.itch.av.catalog/standards/sist/532bd4f0-e3a7-4772-ba91-

NOTE National or local requirements can apply -11525-1-2020

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 5057, Industrial trucks — Inspection and repair of fork arms in service on fork-lift trucks

ISO 10896-1, Rough-terrain trucks — Safety requirements and verification — Part 1: Variable-reach trucks

ISO 23676, Rough-terrain trucks — Operator training — Content and methods

3 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 10896-1 and the following apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at https://www.iso.org/obp
- IEC Electropedia: available at http://www.electropedia.org/

3.1

authorized person

person approved or assigned to perform a specific task or tasks at a specific location or locations at a worksite

ISO 11525-1:2020(E)

3.2

user

person or entity responsible for assigning an *operator* (3.3) to operate a truck and specifying the tasks to be performed

3.3

operator

person who controls the *operation* (3.8) of the truck

3.4

competent person

person who has acquired, through training, qualification, experience or a combination of these, the knowledge and skill enabling that person to correctly perform the required tasks

3.5

responsible entity

person or entity with responsibility for the design, specification, procurement, fabrication, manufacture, assembly, provision of information and testing of a truck

3.6

maintenance

act of upkeep, including inspection, lubrication, cleaning, adjustment and scheduled parts replacement

modification

change to the truck that affects its operation (3.8), stability (3.9), capacity or safety

3.8

(standards.iteh.ai)

operation

performance of functions of a truck within the scope of its specifications and in accordance with the manufacturer's instructions and work rules

https://standards.iteh.ai/catalog/standards/sist/532bd4f0-e3a7-4772-ba91-

3.9

52dcca39fe95/iso-11525-1-2020

stability

ability of the truck to withstand conditions that would cause it to overturn

Note 1 to entry: Conditions that can affect stability include ground and floor conditions, gradient, wind, speed, loading (trucks equipped with attachments behave as partially loaded trucks even when operated without a load on the attachment), dynamic and static forces and incorrect tyre inflation.

General requirements

4.1 Principles

This document shall be supplemented by good management practices, safety controls and application of sound principles of safety, training, inspection, maintenance, application selection and operation. All data available regarding the parameters of intended use and expected environment shall be considered. Those with direct control over the application and operation of the truck shall be responsible for ensuring good safety practices.

Different operating conditions can require additional safety precautions, training and special safe operating procedures.

The operation of any truck is subject to certain hazards that can be protected against only by the 4.1.2 exercise of care and common sense. It is essential to have competent persons trained in the intended use, safe operation, maintenance and service of the truck and any attachment(s).

- **4.1.3** The user shall ensure that the operator understands that safe operation of the truck is also the operator's responsibility.
- **4.1.4** The user shall take reasonable measures to ensure that the operator's mental or physical condition will not impair their ability to operate the truck.
- **4.1.5** In addition to specific training, application selection and operation of the truck, the user shall take the following characteristics for trucks into consideration:
- these trucks are primarily designed for handling supported loads on forks;
- other attachments can be fitted.
- **4.1.6** The user shall take reasonable measures to ensure that the safe use requirements are being applied during operation.

4.2 Operator's manual(s)

- **4.2.1** The user shall ensure that the operator's manual(s) and any additional safety manual(s) provided by the manufacturer with the truck are always available to the operator and maintenance personnel.
- **4.2.2** The user, the operator, or both shall refer to the responsible entity if doubt arises on either the use of the truck or the interpretation of the operator's manual.

4.3 Modifications or alterations ndards.iteh.ai)

- **4.3.1** Except as provided below, no modifications or alterations to a truck that can affect its capacity, stability or safe operation shall be made without the prior written approval of the original truck manufacturer or its successor. When the truck manufacturer or its successor approves a modification or alteration, the user shall be responsible, prior to operation, for ensuring that appropriate changes are made to information plate(s), documents, certificates, labels, tags, operator's manual(s) and any training, if required.
- **4.3.2** If the truck manufacturer is no longer in business and there is no successor, modifications or alterations to the truck shall be carried out under the following conditions:
- a) the design, testing and implementation of the modification or alteration is made in accordance with ISO 10896-1 by a competent person;
- b) a permanent record is kept of the design, tests and implementation of the modification or alteration;
- c) appropriate changes are made to the information plate(s), documents, certificates, labels, tags and operator's manual(s);
- d) a permanent and readily visible label is affixed to the truck stating the manner in which the truck has been modified or altered, together with the date of the modification or alteration, and the name of the person or organization responsible for the design, testing and implementation of the modifications.

4.4 Manufacturer's bulletins

The user shall comply with the applicable bulletins as directed by the responsible entity.

4.5 Operator qualifications and training

- **4.5.1** Users shall allow only competent and authorized persons to operate a truck and be responsible to ensure that the operator has been trained in accordance with ISO 23676.
- **4.5.2** The operator shall also have read, and be familiar with, the operator's manual(s) and any other safety information provided by the manufacturer and user on the particular truck being operated, the application and environment in which the truck is to be used and any attachments used.
- **4.5.3** The user shall ensure that the operator is familiar with worksite rules and layout, working conditions, handling of load found at the workplace and local emergency procedures.

4.6 Inspection and maintenance

4.6.1 General

- **4.6.1.1** The inspection and maintenance of trucks shall be performed in accordance with the manufacturer's and user's recommendations. This includes:
- a) a planned system for scheduled inspection, lubrication, maintenance and adjustment;
- b) verification that only competent and authorized persons are permitted to maintain, repair, rebuild, adjust and inspect trucks, in accordance with the manufacturer's recommendations.
- **4.6.1.2** The user shall ensure that inspections and maintenance operations are conducted in an authorized area where safe clearances exist.

ISO 11525-1:2020

4.6.2 Preparation for inspection or repair alog/standards/sist/532bd4f0-e3a7-4772-ba91-

52dcca39fe95/iso-11525-1-2020

In preparation for, and prior to, starting the inspection or repair of a truck:

- park the truck on a firm, level surface;
- set the direction control in neutral, apply the parking brake, switch off the engine or power system
 and remove the device (for example, key, magnetic card) that prevents starting without the use of
 such a device;
- apply means to ensure the truck remains stationary (for example, wheel chocks and setting of a park brake);
- implement manufacturer-approved methods/devices as outlined in the operator's manual(s) to prevent unintentional movement of the truck/components before working on or around it;
- eliminate the possibility of unintentional fluid escape before any part of that system is disconnected;
- disconnect the battery before working on the electrical system, as directed by the manufacturer;
- eliminate the possibility of an unintentional stored energy release (for example, from the accumulator or hydraulic system);
- use the appropriate personal protective equipment.

4.6.3 Performance checks

4.6.3.1 Prior to conducting the performance checks, the user shall ensure that the pre-operation inspection has been properly performed as per the manufacturer's instructions and a record kept of the check.

- **4.6.3.2** The user shall ensure that performance checks are conducted in an authorized area where safe clearances exist.
- **4.6.3.3** Before starting the performance check, the operator shall:
- a) check that no persons are placed at risk;
- b) be in the normal operating position using the operator restraint (for example, seat belt);
- c) apply service and parking brakes;
- d) disengage the clutch, if the truck is so equipped;
- e) place directional control(s) in neutral;
- f) start the engine or power system.
- **4.6.3.4** The operator shall check that all control systems (for example load-handling means, steering and brakes) and safety devices are functioning in accordance with the manufacturer's instructions.
- **4.6.3.5** Before exiting the truck, the operator shall:
- a) stop the truck;
- b) fully lower the load-handling means and place the fork tips on the ground to minimize the potential for tripping; iTeh STANDARD PREVIEW
- c) place directional control(s) in neutral ards.iteh.ai)
- d) apply the parking brake;

ISO 11525-1:2020

- e) shut down the engine or power system; and rds/sist/532bd4f0-e3a7-4772-ba91-52dcca39fe95/iso-11525-1-2020
- f) remove the device (for example, key, magnetic card) that prevents starting without the use of such device.

4.6.4 Inspection and maintenance precautions

The user shall ensure that the following precautions are taken when inspection and maintenance is performed.

- Avoid fire hazards and ensure that appropriate fire protection equipment is present in the work area. Do not use an open flame to check fluid levels or for leakage of fuel, battery electrolyte or other flammable liquids. Do not use open containers of fuel or flammable cleaning fluids for cleaning parts.
- Properly ventilate the work area, including engine exhaust fumes.
- Keep the work area clean and dry.
- Do not make repairs (for example, welding of structures) or adjustments unless specifically authorized to do so in accordance with 4.3.
- When refuelling, smoking in the area shall not be permitted, the engine shall be stopped and the operator shall not be in the truck.
- Spillage of oil or fuel shall be cleaned up appropriately.
- Replace the oil and fuel tank caps before restarting the engine.
- Avoid other potential hazards associated with the inspection and maintenance of the truck not addressed in this document or the operator's manual.