



# Standard Terminology of Fire Standards<sup>1</sup>

This standard is issued under the fixed designation E176; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reapproval.

## 1. Scope

1.1 This terminology covers terms, related definitions, and descriptions of terms used or likely to be used in fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards. Definitions of terms are special-purpose definitions that are consistent with the standard definitions but are written to ensure that a specific fire-test-response standard, fire-hazard-assessment standard, or fire-risk-assessment standard is properly understood and precisely interpreted.

NOTE 1—For additional information, refer to ASTM Policy on Fire Standards.<sup>2</sup> See also Annex A1 of Practice E535.

1.2 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of regulatory limitations prior to use.*

1.3 This fire standard cannot be used to provide quantitative measures.

1.4 *This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.*

## 2. Referenced Documents

### 2.1 ASTM Standards:<sup>3</sup>

[C1224 Specification for Reflective Insulation for Building Applications](#)

[C1313/C1313M Specification for Sheet Radiant Barriers for Building Construction Applications](#)

[D3675 Test Method for Surface Flammability of Flexible Cellular Materials Using a Radiant Heat Energy Source](#)

[D5865/D5865M Test Method for Gross Calorific Value of Coal and Coke](#)

[E84 Test Method for Surface Burning Characteristics of Building Materials](#)

[E119 Test Methods for Fire Tests of Building Construction and Materials](#)

[E136 Test Method for Assessing Combustibility of Materials Using a Vertical Tube Furnace at 750 °C](#)

[E152 Test Method for Fire Tests Of Door Assemblies \(Withdrawn 1995\)<sup>4</sup>](#)

[E162 Test Method for Surface Flammability of Materials Using a Radiant Heat Energy Source](#)

[E163 Test Method for Fire Tests Of Window Assemblies \(Withdrawn 1999\)<sup>4</sup>](#)

[E535 Practice for Preparation of Fire-Test-Response Standards](#)

[E603 Guide for Room Fire Experiments](#)

[E648 Test Method for Critical Radiant Flux of Floor-Covering Systems Using a Radiant Heat Energy Source](#)

[E800 Guide for Measurement of Gases Present or Generated During Fires](#)

[E814 Test Method for Fire Tests of Penetration Firestop Systems](#)

[E906/E906M Test Method for Heat and Visible Smoke Release Rates for Materials and Products Using a Thermopile Method](#)

[E970 Test Method for Critical Radiant Flux of Exposed Attic Floor Insulation Using a Radiant Heat Energy Source](#)

[E1317 Test Method for Flammability of Surface Finishes](#)

[E1321 Test Method for Determining Material Ignition and Flame Spread Properties](#)

[E1352 Test Method for Cigarette Ignition Resistance of Mock-Up Upholstered Furniture Assemblies \(Withdrawn 2022\)<sup>4</sup>](#)

[E1353 Test Methods for Cigarette Ignition Resistance of Components of Upholstered Furniture \(Withdrawn 2022\)<sup>4</sup>](#)

[E1354 Test Method for Heat and Visible Smoke Release Rates for Materials and Products Using an Oxygen Consumption Calorimeter](#)

<sup>1</sup> This terminology is under the jurisdiction of ASTM Committee E05 on Fire Standards and is the responsibility of Subcommittee E05.31 on Terminology and Editorial.

Current edition approved Jan. 1, 2024. Published January 2024. Originally approved in 1961. Last previous edition approved in 2021 as E176 –21a<sup>1</sup>. DOI: 10.1520/E0176-24.

<sup>2</sup> Available from ASTM Headquarters, 100 Barr Harbor Drive, West Conshohocken, PA 19428.

<sup>3</sup> For referenced ASTM standards, visit the ASTM website, [www.astm.org](http://www.astm.org), or contact ASTM Customer Service at [service@astm.org](mailto:service@astm.org). For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

<sup>4</sup> The last approved version of this historical standard is referenced on [www.astm.org](http://www.astm.org).

- E1355** Guide for Evaluating the Predictive Capability of Deterministic Fire Models
- E1474** Test Method for Determining the Heat Release Rate of Upholstered Furniture and Mattress Components or Composites Using a Bench Scale Oxygen Consumption Calorimeter
- E1509** Specification for Room Heaters, Pellet Fuel-Burning Type
- E1513/E1513M** Practice for Application of Sprayed Fire-Resistive Materials (SFRMs)
- E1529** Test Methods for Determining Effects of Large Hydrocarbon Pool Fires on Structural Members and Assemblies
- E1537** Test Method for Fire Testing of Upholstered Furniture
- E1546** Guide for Development of Fire-Hazard-Assessment Standards
- E1590** Test Method for Fire Testing of Mattresses
- E1623** Test Method for Determination of Fire and Thermal Parameters of Materials, Products, and Systems Using an Intermediate Scale Calorimeter (ICAL)
- E1678** Test Method for Measuring Smoke Toxicity for Use in Fire Hazard Analysis
- E1740** Test Method for Determining the Heat Release Rate and Other Fire-Test-Response Characteristics of Wall Covering or Ceiling Covering Composites Using a Cone Calorimeter
- E1822** Test Method for Fire Testing of Stacked Chairs
- E1995** Test Method for Measurement of Smoke Obscuration Using a Conical Radiant Source in a Single Closed Chamber, With the Test Specimen Oriented Horizontally
- E2032** Practice for Extension of Data From Fire Resistance Tests Conducted in Accordance with ASTM E 119
- E2058** Test Methods for Measurement of Material Flammability Using a Fire Propagation Apparatus (FPA)
- E2061** Guide for Fire Hazard Assessment of Rail Transportation Vehicles
- E2067** Practice for Full-Scale Oxygen Consumption Calorimetry Fire Tests
- E2102** Test Method for Measurement of Mass Loss and Ignitability for Screening Purposes Using a Conical Radiant Heater
- E2187** Test Method for Measuring the Ignition Strength of Cigarettes
- E2226** Practice for Application of Hose Stream
- E2230** Practice for Thermal Qualification of Type B Packages for Radioactive Material
- E2231** Practice for Specimen Preparation and Mounting of Pipe and Duct Insulation Materials to Assess Surface Burning Characteristics
- E2257** Test Method for Room Fire Test of Wall and Ceiling Materials and Assemblies
- E2280** Guide for Fire Hazard Assessment of the Effect of Upholstered Seating Furniture Within Patient Rooms of Health Care Facilities
- E2307** Test Method for Determining Fire Resistance of Perimeter Fire Barriers Using Intermediate-Scale, Multi-story Test Apparatus
- E2335** Guide for Laboratory Monitors
- E2336** Test Methods for Fire Resistive Grease Duct Enclosure Systems
- E2404** Practice for Specimen Preparation and Mounting of Textile, Paper or Polymeric (Including Vinyl) and Wood Wall or Ceiling Coverings, Facings and Veneers, to Assess Surface Burning Characteristics
- E2405** Test Method for Determination of Fire and Thermal Parameters of Materials Using an Intermediate Scale Test with Vertically Oriented Specimen (Withdrawn 2011)<sup>4</sup>
- E2536** Guide for Assessment of Measurement Uncertainty in Fire Tests
- E2573** Practice for Specimen Preparation and Mounting of Site-Fabricated Stretch Systems to Assess Surface Burning Characteristics
- E2574/E2574M** Test Method for Fire Testing of School Bus Seat Assemblies
- E2599** Practice for Specimen Preparation and Mounting of Reflective Insulation, Radiant Barrier and Vinyl Stretch Ceiling Materials for Building Applications to Assess Surface Burning Characteristics
- E2632/E2632M** Test Method for Evaluating the Under-Deck Fire Test Response of Deck Materials
- E2652** Test Method for Assessing Combustibility of Materials Using a Tube Furnace with a Cone-shaped Airflow Stabilizer, at 750 °C
- E2653** Practice for Conducting an Interlaboratory Study to Determine Precision Estimates for a Test Method with Fewer Than Six Participating Laboratories
- E2688** Practice for Specimen Preparation and Mounting of Tapes to Assess Surface Burning Characteristics
- E2690** Practice for Specimen Preparation and Mounting of Caulks and Sealants to Assess Surface Burning Characteristics
- E2707** Test Method for Determining Fire Penetration of Exterior Wall Assemblies Using a Direct Flame Impingement Exposure
- E2726/E2726M** Test Method for Evaluating the Fire-Test-Response of Deck Structures to Burning Brands
- E2749** Practice for Measuring the Uniformity of Furnace Exposure on Test Specimens
- E2816** Test Methods for Fire Resistive Metallic HVAC Duct Systems
- E2837** Test Method for Determining the Fire Resistance of Continuity Head-of-Wall Joint Systems Installed Between Rated Wall Assemblies and Nonrated Horizontal Assemblies
- E2874** Test Method for Determining the Fire-Test Response Characteristics of a Building Spandrel-Panel Assembly Due to External Spread of Fire
- E2886/E2886M** Test Method for Evaluating the Ability of Exterior Vents to Resist the Entry of Embers and Direct Flame Impingement
- E2912** Test Method for Fire Test of Non-Mechanical Fire Dampers Used in Vented Construction
- E2957** Test Method for Resistance to Wildfire Penetration of Eaves, Soffits and Other Projections

**E2965** Test Method for Determination of Low Levels of Heat Release Rate for Materials and Products Using an Oxygen Consumption Calorimeter

**E3048** Test Method for Determination of Time to Burn-Through Using the Intermediate Scale Calorimeter (ICAL) Radiant Panel

**E3082** Test Methods for Determining the Effectiveness of Fire Retardant Treatments for Natural Christmas Trees

**E3202** Practice for Specimen Preparation and Mounting of Plastic Composites for Use as Deck Boards, Stair Treads, Guards or Handrails to Assess Surface Burning Characteristics

2.2 *ISO Standards*.<sup>5</sup>

**ISO 1182** Fire Tests-Building Materials-Non-Combustibility Test

**ISO 13943** Fire Safety-Vocabulary

### 3. Significance and Use

3.1 *Definitions*—Terms and related definitions given in Section 4 are intended for use uniformly and consistently in all fire test standards and in all fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards in which they appear.

3.2 *Definitions of Terms Specific to This Standard*:

3.2.1 As indicated in Section 4, terms and their definitions are intended to provide a precise understanding and interpretation of fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards in which they appear.

3.2.2 A specific definition of a given term is applicable to the standard or standards in which the term is described and used.

3.2.3 Different definitions of the same term, appearing respectively in two or more standards, are acceptable provided each one is consistent with and not in conflict with the standard definition for the same term, that is, concept.

3.2.4 Each standard in which a term is used in a manner specially defined (see 1.1 and Section 5) shall list the term and its description under the subheading, Definitions of Terms.

3.3 Definitions for some terms associated with fire issues and not included in Terminology E176 are found in ISO 13943. When discrepancies exist, the definition in Terminology E176 shall prevail.

### 4. Terminology

4.1 Terms and their standard definitions within the scope of this standard are given in Section 4 in alphabetical order. **Annex A1** contains the definitions of terms from the section on “Definitions of Terms Specific to This Standard” from ASTM E05 standards.

4.2 Discussions associated with definitions are printed directly under the appropriate definition. The date following each

definition or discussion indicates the year of introduction or of latest revision of that particular definition or discussion.

4.3 *Definitions*:

**afterglow**, *n*—persistence of glowing combustion after both removal of the ignition source and the cessation of any flaming. (2005)<sup>6</sup>

**assembly**, *n*—a unit or structure composed of a combination of materials or products, or both. (1990)

**burn**, *v*—to undergo combustion. (1989)

**char**, *v*—to form carbonaceous residue during pyrolysis or during incomplete combustion. (1979)

**char**, *n*—a carbonaceous residue formed by pyrolysis or incomplete combustion. (1979)

**chimney effect**—upward movement of hot fire effluent caused by convection currents confined within an essentially vertical enclosure. (2006)

*DISCUSSION*—This usually draws more air into the fire. (2006)

**combustible**, *adj*—capable of undergoing combustion. (1985)

*DISCUSSION*—The term combustible is often delimited to specific fire-exposure conditions. For example, building materials are considered combustible if they are capable of undergoing combustion in air at pressures and temperatures that might occur during a fire in a building. Similarly, some materials that are not combustible under such conditions may be combustible when exposed to higher temperatures and pressures or to an oxygen-enriched environment. Materials that are not combustible in bulk form may be combustible in finely divided form. (1985)

**combustion**, *n*—a chemical process of oxidation that occurs at a rate fast enough to produce temperature rise and usually light either as a glow or flame. (See also **glow** and **smoldering**.) (1989)

**combustion products**, *n*—effluent produced when a material undergoes combustion (see also **smoke**; see also **combustion**). (2001)

*DISCUSSION*—The combustion process releases effluents that have mass, in gaseous, liquid, or solid form, and generates radiant energy, as heat or light, and sometimes sound. However, the common usage of the term *combustion products* in ASTM E05 standards is only for those which have mass. (2001)

**composite**, *n*—structured combination of two or more discrete materials. (2008)

**continuous**, *adj*—*as related to data acquisition in large-scale tests*, conducted at data collection intervals of 6 s or less. (2021)

**continuous**, *adj*—*as related to data acquisition in bench-scale tests*, conducted at data collection intervals of 5 s or less. (2021)

**effective heat of combustion**, *n*—the amount of heat generated per unit mass lost by a material, product or assembly, when exposed to specific fire test conditions (contrast **gross heat of combustion**) (2003).

<sup>5</sup> Available from International Organization for Standardization (ISO), ISO Central Secretariat, Chemin de Blandinnet 8, CP 401, 1214 Vernier, Geneva, Switzerland, <https://www.iso.org>.

<sup>6</sup> Date indicates year of introduction or latest review or revision.

**DISCUSSION**—The effective heat of combustion depends on the test method and is determined by dividing the measured heat release by the mass loss during a specified period of time under the specified test conditions. Typically, the specified fire test conditions are provided by the specifications of the fire test standard that cites effective heat of combustion as a quantity to be measured. For certain fire test conditions, involving very high heat and high oxygen concentrations under high pressure, the effective heat of combustion will approximate the gross heat of combustion. More often, the fire test conditions will represent or approximate certain real fire exposure conditions, and the effective heat of combustion is the appropriate measure. Typical units are kJ/g or MJ/kg. (2001)

**environment, *n***—as related to fire, the conditions and surroundings that may influence the behavior of a material, product, or assembly when it is exposed to ignition sources or fire. (1989)

**fire, *n***—destructive burning as manifested by any or all of the following: light, flame, heat, smoke. (1988)

**fire-characteristic profile, *n***—an array of fire-test-response characteristics, all measured using tests relevant to the same fire scenario, for a material, product, or assembly to address, collectively, the corresponding fire hazard. (See also **fire hazard, fire risk, and fire-test-response characteristic**.) (1993)

**DISCUSSION**—An array of fire-test-response characteristics in a set of data relevant to the assessment of fire hazard in a particular fire scenario. In other words, all the fire tests used would have a demonstrated validity for the fire scenario in question, for example by having comparable fire intensities. The fire-characteristic profile is intended as a collective guide to the potential fire hazard from a material, product, or assembly involved in a fire that could be represented by the laboratory test conditions. (1993)

**fire-door assembly, *n***—a fire door, combined with the corresponding frame, hardware, and other accessories, that has a fire protection rating. (2014)

**fire exposure, *n***—process by which or extent to which humans, animals, materials, products, or assemblies are subjected to the conditions created by fire. (1991)

**fire gases, *n***—the airborne products emitted by a material, product, or assembly undergoing pyrolysis or combustion, that exist in the gas phase at the relevant temperature. (1979)

**fire hazard, *n***—the potential for harm associated with fire. (1989)

**DISCUSSION**—A fire may pose one or more types of hazard to people, animals, or property. These hazards are associated with the environment and with a number of fire-test-response characteristics of materials, products, or assemblies including, but not limited to, ease of ignition, flame spread, rate of heat release, smoke generation and obscuration, toxicity of combustion products, and ease of extinguishment. (1989)

**fire model, *n***—a physical representation or set of mathematical equations that approximately simulate the dynamics of burning and associated processes. (1992)

**fire performance, *n***—response of a material, product, or assembly in a particular fire, other than in a fire test involving controlled conditions (different from **fire-test-response characteristic**). (1993)

**DISCUSSION**—The ASTM Policy on Fire Standards distinguishes between the response of materials, products, or assemblies to heat and flame under controlled conditions, which is fire-test-response characteristic, and under actual fire conditions, which is fire performance. Fire performance depends on the occasion or environment and may not be measurable. In view of the limited availability of fire-performance data, the response to one or more fire tests, appropriately recognized as representing end-use conditions, is generally used as a predictor of the fire performance of a material, product, or assembly. (1993)

**fire performance characteristic, *n***—this term is deprecated. (See **fire-test-response characteristic and fire performance** (q.v.).) (1990)

**fire performance test, *n***—this term is deprecated. (See **fire-test-response characteristic and fire performance** (q.v.).) (1990).

**fireproof, *adj***—an inappropriate and misleading term. Do not use. (See commentary in X1.)

**DISCUSSION**—This term was originally used to describe buildings having all noncombustible structural elements and some degree of fire resistance. However, the term has been misunderstood to mean an absolute or unconditional property, and therefore the use of the term, fireproof, is inappropriate and misleading. (1990)

**fire protection rating, *n***—a measure of the elapsed time during which a fire door assembly or a fire window assembly continues to exhibit fire resistance under specified exposure conditions. (2014)

**DISCUSSION**—In some jurisdictions the term fire protection rating may also be applied to other elements of building construction. (2014)

**fire resistance, *n***—the ability of a material, product, or assembly to withstand fire or give protection from it for a period of time. (Contrast **fire resistance rating**.) (2004)

**DISCUSSION**—As applied to elements of buildings, fire resistance is characterized by the ability to confine a fire or to continue to perform a given structural function, or both. More specific examples of this ability include retention of stability (loadbearing capacity), integrity or thermal insulation. Once a measure of time is defined for fire resistance, and exposure conditions specified for that measure, the result is a fire resistance rating. (2004)

**fire resistance rating, *n***—a measure of the elapsed time during which a material, product, or assembly continues to exhibit fire resistance under specified exposure conditions. (Contrast **fire resistance**.) (2004)

**DISCUSSION**—This term is defined because it is used in codes. As applied to elements of buildings, it is commonly measured by the methods and to the criteria defined in Test Methods E119 or Specification E1509. Fire protection rating is the term used for fire resistance ratings of fire door assemblies and fire window assemblies. (2014)

**fire resistant, *adj***—See **fire resistive**, the preferred term. (1983)

**fire resistive, *adj***—having fire resistance (TCG-01). (1983)

**fire retardant, *n***—a substance which, when added to a combustible material, inhibits combustion of the resulting substance or material when exposed to fire. (2015)

**fire retardant, *adj***—not a defined term. Use as a modifier only with defined compound terms: **fire-retardant barrier, fire-retardant chemical, fire-retardant coating, and fire-retardant treatment**. (1986)

**fire-retardant barrier**, *n*—a layer of material which, when secured to a combustible material or otherwise interposed between the material and a potential fire source, delays ignition and combustion of the material when the barrier is exposed to fire. (1986)

**fire-retardant chemical**, *n*—a chemical, which when added to a combustible material, delays ignition and combustion of the resulting material when exposed to fire. (1986)

DISCUSSION—A fire-retardant chemical can be a part of the molecular structure, an admixture, or an impregnant. (1986)

**fire-retardant coating**, *n*—a fluid-applied surface covering on a combustible material which delays ignition and combustion of the material when the coating is exposed to fire. (See also **flame-retardant coating**. Compare **fire-retardant barrier**.) (1986)

**fire-retardant treatment**, *n*—the use of a fire-retardant chemical or a fire-retardant coating. (See also **flame-retardant treatment**.) (1986)

**fire risk**, *n*—an estimation of expected fire loss that combines the potential for harm in various fire scenarios that can occur with the probabilities of occurrence of those scenarios. (1993)

DISCUSSION—Risk may be defined as the probability of having a certain type of fire, where the type of fire may be defined in whole or in part by the degree of potential harm associated with it, or as potential for harm weighted by associated probabilities. However it is defined, no risk scale implies a single value of acceptable risk. Different individuals presented with the same risk situation may have different opinions on its acceptability. (1993)

**fire scenario**, *n*—a detailed description of conditions, including environmental, of one or more of the stages from before ignition to the completion of combustion in an actual fire, or in a full scale simulation. (1998)

DISCUSSION—The conditions describing a fire scenario, or a group of fire scenarios, are those required for the testing, analysis, or assessment that is of interest. Typically they are those conditions that can create significant variation in the results. The degree of detail necessary will depend upon the intended use of the fire scenario. Environmental conditions may be included in a scenario definition but are not required in all cases. Fire scenarios often define conditions in the early stages of a fire while allowing analysis to calculate conditions in later stages. (1998)

**fire test exposure severity**, *n*—a measure of the degree of fire exposure; specifically in connection with Test Methods E119, E152, and E163, the ratio of the area under the curve of average furnace temperature to the area under the standard time/temperature curve, each from the start of the test to the end or time of failure, and above the base temperatures 68°F (20°C). (1976)

**fire-test-response characteristic**, *n*—a response characteristic of a material, product, or assembly, to a prescribed source of heat or flame, under controlled fire conditions; such response characteristics may include, but are not limited to, ease of ignition, flame spread, heat release, mass loss, smoke generation, fire resistance, and toxic potency of smoke. (1992)

DISCUSSION—A fire-test-response characteristic can be influenced by variable characteristics of the heat source, such as its intensity, or of the burning environment, such as ventilation, geometry of item or enclosure, humidity, or oxygen concentration. It is not an intrinsic property such as specific heat, thermal conductivity, or heat of combustion, where the value is independent of test variables. A fire-test-response characteristic may be described in one of several terms. Smoke generation, for example, may be described as smoke opacity, change of opacity with time, or smoke weight. No quantitative correlation need exist between values of a fire-test-response characteristic for different materials, products, or assemblies, as measured by different methods or tested under different sets of conditions for a given method. (2005)

**fire window assembly**, *n*—a window or glass block assembly which has a fire protection rating. (2015)

**flame**, *n*—a hot, usually luminous zone of gas produced by combustion. (2012)

DISCUSSION—The luminosity of a flame can be caused by the presence of suspended glowing particulate matter or radical species in the zone of hot gases. (2012)

**flame front**, *n*—the leading edge of a flame propagating through a gaseous mixture or across the surface of a liquid or solid. (1983)

**flameproof**, *adj*—an inappropriate and misleading term. Do not use. (1983)

DISCUSSION—This term was originally used to describe the treatment of textile fabrics or other organic products to make them resistant to ignition. However, the term has been misunderstood to mean an absolute or unconditional property, and therefore the use of the term, flameproof, is inappropriate and misleading. (1983)

**flame resistance**, *n*—the ability to withstand flame impingement or give protection from it. (1983)

**flame resistant**, *adj*—having flame resistance. (1983)

**flame resistive**, *n*—See **flame resistant**, the preferred term. (1983)

**flame retardant**, *n*—a substance which, when added to a combustible material, inhibits flame spread of the resulting substance or material when exposed to flame impingement. (2015)

**flame retardant**, *adj*—not a defined term. Use only as a modifier with defined compound terms: **flame-retardant chemical**, **flame-retardant coating**, and **flame-retardant treatment**. (1986)

**flame-retardant chemical**, *n*—a chemical, which when added to a combustible material, delays ignition and reduces flame spread of the resulting material when exposed to flame impingement. (See also **fire-retardant chemical**.) (1986)

**flame-retardant coating**, *n*—a fluid-applied surface covering on a combustible material which delays ignition and reduces flame spread when the covering is exposed to flame impingement. (See also **fire-retardant coating**.) (1986)

**flame-retardant treatment**, *n*—the use of a flame-retardant chemical or a flame-retardant coating. (See also **fire-retardant treatment**.) (1986)

**flame speed, *n***—the velocity of propagation of a flame front through a gaseous mixture (fuel and oxidizer) relative to a reference point. (1982)

**flame spread, *n***—propagation of a flame front (see **surface flame spread, volumetric flame spread**). (2005)

**flame spread index, *n***—a comparative measure expressed as a dimensionless number, derived from visual measurements of the spread of flame versus time in Test Method E84. (2001)

DISCUSSION—Classifications have been developed using these values. This index is different from that derived in Test Methods E162 or D3675. (2001)

**flaming debris, *n***—flaming material that separates and falls from the test specimen during the fire test and continues to burn with flame. (See also *flaming droplets*.) (2018)

DISCUSSION—The particular conditions under which continued flaming combustion is significant (such as for a particular duration or after striking a surface) may be different in different test methods. Where needed, such conditions should be specified in the test method or requirement. (2018)

**flaming droplets, *n***—flaming, liquefied material that separates and drips from the test specimen during the fire test and continues to burn with flame. (See also *flaming debris*.) (2018)

DISCUSSION—The particular conditions under which continued flaming combustion is significant (such as for a particular duration or after striking a surface) may be different in different test methods. Where needed, such conditions should be specified in the test method or requirement. (2018)

**flammable, *adj***—(1) capable of burning with a flame under specified conditions, or (2) when used to designate high hazard, subject to easy ignition and rapid flaming combustion. (1995)

DISCUSSION—The first definition is needed as it is the definition recognized by the principal international standardization bodies, the International Electrotechnical Commission (IEC) and the International Organization for Standardization (ISO). The second definition has been the ASTM Terminology E176 definition and is the principal definition recognized by the lay public. The terms in the second definition “easy ignition” and “rapid flaming combustion,” may seem insufficiently precise but are made precise in standards that use the terms in that way, such as standards on the fire hazards of materials (for example, NFPA 704; NFPA 321, on flammable liquids; and NFPA 55, on flammable gases). (1995)

**flashover, *n***—the rapid transition to a state of total surface involvement in a fire of combustible materials within an enclosure. (1997)

DISCUSSION—Flashover is a fluid-mechanical combustion instability within an enclosure that occurs when the surface temperatures of an enclosure and its contents rise rapidly, producing combustible gases and vapors, and the enclosure heat flux becomes sufficient to heat these gases and vapors to their ignition temperatures. At flashover, the volume occupied by hot combustion gases rapidly increases and ends up comprising more than 50% of the enclosure’s volume. Experimentally it is found that flashover occurs when the upper gas layer temperature surpasses 600°C or when the radiant heat flux at the floor surpasses 20 kW/m<sup>2</sup>. Visually, flashover often corresponds to a transition from flaming on a few surfaces to flames throughout the volume of the enclosure. (2002)

**gasification, *n***—transformation of a solid and/or liquid material into a gaseous state. (2001)

**glow, *n***—*as related to fire*, visible light emitted by a solid undergoing combustion. (See also **combustion** and **flame**.)

DISCUSSION—A solid undergoing combustion may itself glow or may produce a luminous flame consisting of hot gas with suspended glowing particulate matter. (2010)

**gross heat of combustion, *n***—the maximum amount of heat per unit mass that theoretically can be released by the combustion of a material, product, or assembly; it can be determined experimentally only under conditions of high pressure and in pure oxygen (contrast **effective heat of combustion**). (2003)

**heat flux, *n***—heat transfer to a surface per unit area, per unit time (see also **initial test heat flux**). (2008)

DISCUSSION—The heat flux from an energy source, such as a radiant heater, can be measured at the initiation of a test (such as Test Method E1354 or Test Method E906/E906M) and then reported as the initial test heat flux, with the understanding that the burning of the test specimen can generate additional heat flux to the specimen surface. The heat flux can also be measured at any time during a fire test, for example as described in Guide E603, on any surface, and with measurement devices responding to radiative and convective fluxes. Typical units are kW/m<sup>2</sup>, W/cm<sup>2</sup>, or BTU/(s ft<sup>2</sup>). (2009)

**heat release rate, *n***—the thermal energy released per unit time by an item during combustion under specified conditions. (2006)

DISCUSSION—Heat release rate is typically reported per unit area in small-scale or bench-scale tests.

**heat stress, *n***—(physiological) adverse condition caused by exposure to elevated temperature, radiant heat flux, or combinations of these factors. (1988)

**ignitability, *n***—the propensity for ignition, as measured by the time to sustained flaming, in seconds, at a specified heat flux. (2021)

**ignition, *n***—the initiation of combustion. (1989)

DISCUSSION—The combustion may be evidenced by glow, flame, detonation, or explosion. The combustion may be sustained or transient. (1989)

**ignition temperature, *n***—the lowest temperature at which sustained combustion of a material can be initiated under specified test conditions. (1990)

DISCUSSION—While the phenomenon of combustion may be transient or sustained, in fire testing practice, the ignition temperature is reached when combustion continues after the pilot source is removed. (1990)

**incandescence, *n***—emission of light produced by a material when intensely heated; it can be produced with or without combustion. (1997)

**initial test heat flux, *n***—the heat flux set on the test apparatus at the initiation of the test (see also **heat flux**). (2007)

DISCUSSION—The initial test heat flux is the heat flux value commonly used when describing or setting test conditions. (2007)

**integrity, *n***—*in fire resistance testing*, the ability of a test assembly, when exposed to fire from one side, to prevent the

- passage of flame or hot gases through it or the occurrence of flames on its unexposed side. (2013)
- mass burning rate**, *n*—mass loss per unit time by materials burning under specified conditions. (1989)
- noncombustible**, *adj*—not capable of undergoing combustion under specified conditions. (Contrast **combustible**.) (2018)  
DISCUSSION—In fire testing, noncombustibility is often assessed by means of Test Method E136, Test Method E2652, or ISO 1182. (2018)
- optical density of smoke**, *D*, *n*—a measure of the attenuation of a light beam passing through smoke, expressed as the common logarithm of the ratio of the incident flux,  $I_o$ , to the transmitted flux,  $I$ . ( $D = \log_{10} (I_o/I)$ ). (1989)
- orientation**, *n*—the plane in which the exposed face of the specimen is located during testing. (1977)  
DISCUSSION—The orientation may be vertical, horizontal or at an angle. In the latter two cases, the specimen may be facing up or down. (1977)
- oxygen consumption principle**, *n*—the expression of the relationship between the mass of oxygen consumed during combustion and the heat released. (1998)
- oxygen depletion**, *n*—*in a fire*, reduction of oxygen ( $O_2$ ) content of an atmosphere as a result of combustion. (1988)
- oxygen index**, *n*—minimum concentration of oxygen in a mixture of oxygen and nitrogen that will just support flaming combustion of a material under specified conditions. (2000)
- piloted ignition**, *n*—ignition of combustible gases or vapors by a pilot source of ignition (compare **spontaneous ignition**, **unpiloted ignition**). (1991)
- pilot source of ignition**, *n*—a discrete source of energy, such as, for example, a flame, spark, electrical arc, or glowing wire (compare **piloted ignition**, **unpiloted ignition**). (1991)
- pyrolysis**, *n*—process of simultaneous phase and chemical species change caused by heat (compare **smoldering**). (1991)
- reaction to fire**, *n*—response of a material in contributing by its own decomposition to a fire to which it is exposed, under specified conditions. (2002)  
DISCUSSION—In fire testing, it is usual to distinguish between two types of fire-test-response characteristics: those associated with “reaction to fire” and those associated with “fire resistance.” (2012)
- screening test**, *n*—*as related to fire*, a fire-response test performed to determine whether a material, product, or assembly (a) exhibits any unusual fire-related characteristics, (b) has certain expected fire-related characteristics, or (c) is capable of being preliminarily categorized according to the fire characteristic in question. (1993)
- self heating**, *n*—a rise in the temperature of a material, assemblage, or product caused by internal, exothermic chemical reaction. (1985)
- self ignition**, *n*—See **spontaneous ignition**, the preferred term. (1985)
- self-propagation of flame**, *n*—propagation of a flame front after the removal of any applied energy source. (2001)
- smoke**, *n*—the airborne solid and liquid particulates and gases evolved when a material undergoes pyrolysis or combustion. (1989)  
DISCUSSION—So-called chemical smokes are excluded from this definition. (1989)
- smoke developed index**, *n*—a comparative measure expressed as a dimensionless number, derived from measurements of smoke obscuration versus time in Test Method E84. (2001)  
DISCUSSION—Classifications have been developed using these values. (2001)
- smoke obscuration**, *n*—reduction of light transmission by smoke, as measured by light attenuation. (2001)
- smoke toxicity**, *n*—the propensity of smoke to produce adverse biochemical or physiological effects. (See **smoke**.) (1988)
- smoldering**, *n*—combustion of a solid without flame, often evidenced by visible smoke. (1979)  
DISCUSSION—Smoldering can be initiated by small sources of ignition, especially in dusts or fibrous or porous materials, and may persist for an extended period of time after which a flame may be produced. (1979)
- spontaneous ignition**, *n*—unpiloted ignition caused by an internal exothermic reaction (compare **piloted ignition**). (1991)
- standard temperature/time curve (standard time/temperature curve)**, *n*—*in fire testing*, a graphical representation derived from prescribed time-temperature relationships and used to control furnace temperature with progressing time. (1989)  
DISCUSSION—One example is found in Test Methods E119. (1989)
- superimposed load**, *n*—force applied to a specimen or structure other than that associated with its own mass. (1979)
- surface flame spread**, *n*—propagation of flame away from the source of ignition across a surface (see **flame spread** and compare **volumetric flame spread**). (2010)
- sustained flaming**, *n*—flame on or over the surface of a test specimen that lasts longer than a defined period of time (contrast **transitory flaming**). (2009)  
DISCUSSION—Typically, the same defined period is used to define “transitory flaming.” See the specific standard test method for applicable defined period of time. (2009)
- thermal decomposition**, *n*—process whereby the action of heat or elevated temperature on an item causes changes to the chemical composition (different from **thermal degradation**, q.v.; compare **pyrolysis**). (2006)
- thermal degradation**, *n*—process whereby the action of heat or elevated temperature on a material, product, or assembly causes an adverse change in one or more properties (contrast **thermal decomposition**, q.v.). (2007)  
DISCUSSION—Examples of properties that can be affected are physical, mechanical and electrical properties. Adverse change typically involves a loss in property. (2007)

**time to sustained flaming**, *n*—period of time from start of test to commencement of the first period of flaming lasting long enough to qualify as sustained flaming (see **sustained flaming**). (2009)

**time to transitory flaming**, *n*—period of time from start of test to commencement of the first period of flaming lasting long enough to qualify as transitory flaming but occurring before any period of flaming lasting long enough to qualify as sustained flaming (see **transitory flaming**). (2009)

**total heat released**, *n*—integrated value of the rate of heat release, for a specified time period. (2010)

**toxicity**, *n*—the propensity of a substance to produce adverse biochemical or physiological effects. (1988)

**toxic hazard**, *n*—*as related to fire*, the potential for physiological harm from toxic products of combustion. (1995)

DISCUSSION—Toxic hazard reflects both the quantity of toxic products and the quality of those products, which is given by toxic potency. Toxic hazard is not the only hazard associated with fire. Toxic hazard is not an intrinsic characteristic of a material or product but will depend upon the fire scenario, the condition of use of the material or product, and possibly other factors. (1995)

**toxic potency**, *n*—*as applied to inhalation of smoke or its component gases*, a quantitative expression relating concentration and exposure time to a particular degree of adverse physiological response, for example, death, on exposure of humans or animals. (1991)

DISCUSSION—The toxic potency of the smoke from any material, product, or assembly is related to the composition of that smoke which, in turn, is dependent upon the conditions under which the smoke is generated. (1991)

**transitory flaming**, *n*—flame on or over the surface of a test specimen that does not last longer than a defined period of time (contrast **sustained flaming**). (2009)

DISCUSSION—Typically, the same defined period of time is used to define “sustained flaming.” See the specific standard test method for applicable defined period of time. (2009)

**unpiloted ignition**, *n*—ignition caused by one or more sources of energy without the presence of a pilot source of ignition (compare **piloted ignition**, **spontaneous ignition**). (1991)

**upholstered**, *adj*—covered with material (as fabric or padding) to provide a soft surface. (1999)

**volumetric flame spread**, *n*—flame propagation through the volume of a gaseous mixture. (1989)

## iTeh Standards

### ANNEX

(<https://standards.itih.ai>)

(Mandatory Information)

#### A1. DEFINITIONS OF TERMS FROM E05 STANDARDS

A1.1.1 *Definitions*: Terms from the section on “Definitions of Terms Specific to This Standard” from ASTM E05 standards, their definitions, and the standard(s) to which they apply are given below in alphabetical order:

**accuracy of measurement**, *n*—closeness of the agreement between the result of a measurement and the true value of the measurand. (2009) **E2536**

**acoustical ceiling panel**, *n*—a form of a prefabricated sound absorbing ceiling element used with exposed suspension systems (see Specification E1264). (1999) **E2032**

**acoustical ceiling tile**, *n*—a form of a prefabricated sound absorbing ceiling element used with concealed or semi-exposed suspension systems, stapling, or adhesive bonding (see Specification E1264). (1999) **E2032**

**assembly**, *n*—a unit or structure composed of a combination of materials or products, or both. (2000) **E1995, E2102**

**backing board**, *n*—a noncombustible insulating board, mounted behind the specimen during actual testing to satisfy the theoretical analysis assumption of no heat loss through the specimen. It shall be roughly  $25 \pm 5$  mm thick with a density no greater than  $200 \pm 50$  kg/m<sup>3</sup>. (1997) **E1321**

**batch sampling**—sampling over some time period in such a way as to produce a single test sample for analysis. (1981) **E800**

**bead**, *n*—*in building construction*, a strip of applied sealant, glazing compound or putty. (2010) **E2690**

**beams**, *n*—all horizontally oriented structural members employed in building construction and known variously as beams, joists, or girders. (1999) **E2032**

**blackbody temperature**, *n*—the temperature of a perfect radiator—a surface with an emissivity of unity and, therefore, a reflectivity of zero. (1997) **E648**

**blockout**, *n*—a recess formed in the floor assembly to accommodate the installation of the perimeter joint protection, flush with the wearing surface of the floor assembly. (2010) **E2307**

**bolster**, *n*—pillow or similarly shaped unit containing upholstery material covered by upholstery cover material that may or may not be attached to the upholstered furniture item but is sold and delivered with it. (1994) **E1352**

**building element**, *n*—a component or assembly of materials using products manufactured as independent units capable of being joined with or placed within other components or assemblies to create a structure. (2002) **E2226**



- building envelope**, *n*—the boundary or barrier separating different environmental conditions within a building and from the outside environment. (2015) **E2957**
- burn-through**, *n*—occurrence of sustained flaming on the unexposed side of the test specimen. (2016) **E3048**
- carboxyhemoglobin saturation**, *n*—the percent of blood hemoglobin predominately converted to carboxyhemoglobin from reaction with inhaled carbon monoxide. (1996)  
 DISCUSSION—The chemical reaction between carbon monoxide and hemoglobin in blood is reversible. The effect of carbon monoxide on the exposed person may not be reversible. **E1678**
- ceiling protective membrane**, *n*—a ceiling membrane attached to or suspended from the structural members of the floor or ceiling assembly, usually by hanger wire or threaded rods, consisting of a grid suspension system with lay-in ceiling panels or a grid of steel furring channels to which the ceiling membrane is directly attached, intended to provide fire protection, acoustical and or aesthetic enhancements, or both. (1999) **E2032**
- Christmas trees**, *n*—*for the purpose of this standard*, a natural tree product intended to be decorated or displayed in a manner associated with Christmas, or other holiday season of the year. (2017) **E3082**
- closed state**, *n*—the sealed or closed condition of an opening in vented construction. (2013) **E2912**
- combined standard uncertainty**, *n*—standard uncertainty of the result of a measurement when that result is obtained from the values of a number of other quantities, equal to the positive square root of a sum of terms, the terms being the variances or covariances of these other quantities weighted according to how the measurement result varies with changes in these quantities. (2009) **E2536**
- combustion products**—airborne effluent from a material undergoing combustion; this may also include pyrolysates. (1981) **E800**
- compensating thermocouple**, *n*—a thermocouple for the purpose of generating an electrical signal representing long-term changes in the stack metal temperatures wherein a fraction of the signal generated is subtracted from the signal developed by the stack-gas thermocouples. (1997) **E1317**
- composite**, *n*—*as applied to loadbearing elements*, an interaction between structural components which is to be taken into account in the evaluation of load capacity. (1999) **E2032**
- composite**, *n*—*as related to a pipe or duct insulation*, see **duct insulation system** or **pipe insulation system**. (2002) **E2231**
- concentration-time curve**, *n*—a plot of the concentration of a gaseous toxicant as a function of time. (1996)  
 DISCUSSION—The concentration-time curve can also be used to represent the sum total of all combustion products instead of just a single one. **E1678**
- continuity**, *n*—maintaining the fire resistance rating of the *rated wall assembly* and the protected *joint opening* to the underside of the *nonrated horizontal assembly* by use of a *continuity head-of-wall joint system*, which achieves the same or greater fire resistance rating as the *rate wall assembly*. (2011)  
 DISCUSSION—This maintenance is achieved using materials or devices, or both, installed to extend and continue the fire resistance rating of the wall assembly to the underside of the *nonrated horizontal assembly* above. (2011) **E2837**
- continuity head-of-wall joint system**, *n*—materials or devices, or both, installed to resist the spread of fire for a prescribed period of time through the joint opening between a fire-resistance *rated wall assembly* below and *nonrated horizontal assembly* above. (2011) **E2837**
- continuous** (as related to data acquisition), *adj*—conducted at data collection intervals of 5 s or less. (2000) **E906/E906M, E1995, E2102**
- corridor**, *n*—an enclosed space connecting a room or compartment with an exit. The corridor includes normal extensions, such as lobbies and other enlarged spaces, where present. (1997) **E648**
- coverage factor**, *n*—numerical factor used as a multiplier of the combined standard uncertainty in order to obtain an expanded uncertainty. (2009) **E2536**
- critical flux at extinguishment**, *n*—a flux level at the specimen surface corresponding to the distance of farthest advance and subsequent self-extinguishment of the flame on the centerline of a specimen. (1997)  
 DISCUSSION—The flux reported is based on calibration tests with a special calibration dummy specimen. (1997) **E1317**
- critical heat flux for ignition**, *n*—the midpoint within the range of heat fluxes between the maximum (highest) heat flux that produces no ignition and the minimum (lowest) heat flux that produces ignition, for a specified exposure time. (2015) **E1354, E2102**
- critical radiant flux**, *n*—the level of incident radiant heat energy on the floor covering system at the most distant flame-out point. It is reported as  $W/cm^2$  ( $Btu/ft^2 \cdot s$ ). (1997) **E648**
- critical radiant flux**, *n*—the level of incident radiant heat energy on the attic floor insulation system at the most distant flame-out point. It is reported as  $W/cm^2$  (or  $Btu/ft^2 \cdot s$ ). (1996) **E970**
- Ct product**, *n*—the concentration-time product in  $(\mu L/L) \cdot \text{min}$  obtained by integration of the area under a concentration-time curve. (1996)  
 DISCUSSION—Values expressed using this unit are numerically equal to those using the previously cited unit, ppm, a term whose use is discouraged. **E1678**
- curtain wall assembly**, *n*—either a rated or non-rated, non-bearing exterior wall assembly secured to and supported by the structural members of the building. (2010) **E2307**
- deck**, *n*—*in upholstered furniture*, the upholstered support under the seat cushion in a loose-seat construction. (1994) **E1352, E1353**

- deck structure**, *n*—exterior structures comprised of deck boards or panels, stair treads, risers, and landings of decks, porches, and balconies. (2012) **E2726/E2726M**
- deck surface area**, *n*—the test specimen area defined by the overall specimen length and width after assembly. (2013) **E2632/E2632M**
- design load**, *n*—the intended maximum design load condition allowed by design under appropriate nationally recognized structural design criteria. (1999) **E2032**
- directly applied fire resistive coating**, *n*—materials that are normally sprayed onto substrates to provide fire-resistive protection of the substrates. (1999)  
 DISCUSSION—These coatings are called sprayed fire-resistive materials in Practice **E1513/E1513M** and related standards. **E2032**
- distal end**, *n*—the apex or tip of the tree branch. (2017) **E3082**
- duct**, *n*—*as related to heating ventilating, air conditioning or exhaust systems*, a passageway made of sheet metal or other suitable material used for conveying air or other gases. (2002) **E2231**
- duct insulation system**, *n*—*as related to fire testing*, system intended to insulate and cover, continuously for an extended length, the outside surface of a duct; the system shall have an insulation core, with or without a covering or vapor retarder facing which includes longitudinal closure systems (if used) and perhaps other duct insulation supplementary materials such as adhesives, fasteners, or tapes (if used). (2002)  
 DISCUSSION—Duct system components, including tapes, sealants, and fitting covers, that do not cover the duct continuously for an extended length, but which are associated with the duct insulation system are considered separately (see duct insulation supplementary materials). An extended length is not intended to imply a length of 25 ft, but a length of at least 3 ft. (2002) **E2231**
- duct insulation supplementary materials**, *n*—*as related to fire testing*, components, including tapes and sealants used for transverse joints as well as fitting covers that are intermittently spaced, as needed, within the duct insulation system, as well as adhesives used to bond the insulation to the duct substrate and that do not cover the duct continuously for an extended length. (2002) **E2231**
- duct lining**, *n*—material such as an insulation, coating or film, including adhesive, used to line the inside surface of a duct. (2002) **E2231**
- dummy specimen**, *n*—a noncombustible insulating board used for standardizing the operating condition of the equipment. (2020)  
 DISCUSSION—The dummy specimen is mounted in the apparatus in the position of the test specimen and removed only when a test specimen is to be inserted. (2020) **E1317**
- dummy specimen**, *n*—a noncombustible insulating board used for stabilizing the operating condition of the equipment, roughly  $20 \pm 5$  mm in thickness with a density of  $750 \pm 100$  kg/m<sup>3</sup>. (1997)  
 DISCUSSION—The dummy specimen is mounted in the apparatus in the position of the test specimen and removed only when the test specimen is to be inserted. For the ignition tests, the dummy specimen board shall have a hole at the 50-mm position for mounting the fluxmeter. (1997) **E1321**
- eave**, *n*—a projecting edge of a roof that extends beyond the building envelope. (2015) **E2957**
- effective area of the furnace opening**—furnace opening within the boundaries of the monitoring instrumentation. (2010) **E2749**
- effective thermal property**, *n*—thermal properties derived from heat-conduction theory applied to ignition/flame-spread data treating the material as homogenous in structure. (1997) **E1321**
- ember**, *n*—small burning or glowing pieces of vegetation or other cellulosic-based material. (2014) **E2886/E2886M**
- emissivity**, *n*—the ratio of the power per unit area radiated from a material's surface to that radiated from a black body at the same temperature. (1994) **E1623**
- enclosure material**, *n*—the product applied to the grease duct to provide fire resistance. (2014) **E2336**
- equivalent thickness**, *n*—the calculated solid thickness of concrete or masonry for purposes of determining fire resistance ratings of barrier elements on the basis of heat transmission end-point criteria. (1999) **E2032**
- error (of measurement)**, *n*—result of a measurement minus the true value of the measurand; error consists of two components: random error and systematic error. (2009) **E2536**
- essentially flat surface**, *n*—surface where the irregularity from a plane does not exceed  $\pm 1$  mm. (2000) **E1995, E2102**
- expanded uncertainty**, *n*—quantity defining an interval about the result of a measurement that may be expected to encompass a large fraction of the distribution of values that could reasonably be attributed to the measurand. (2009) **E2536**
- expanded vinyl wall or ceiling covering**, *n*—a wall or ceiling covering consisting of a woven textile backing, an expanded vinyl base coat layer (which is a homogeneous vinyl layer that contains a blowing agent), and a nonexpanded vinyl skin coat. (2010) **E2404**
- exposed area**—the total surface area of the test assembly that is subjected to the fire-resistance test including, when required, the supporting construction. (2010) **E2226**
- exposed surface**, *n*—that surface of the specimen subjected to the incident heat. (2000) **E906/E906M, E1995, E2102**
- exterior wall assembly**, *n*—a curtain wall or a loadbearing exterior wall that is either fire resistance rated or one that is not. (2010) **E2307**
- exterior wall assembly**, *n*—a non-load bearing or load bearing wall located on the exterior of a building that is either fire resistance rated or one that is not. (2020) **E2874**