

# SLOVENSKI STANDARD SIST ISO/TR 3313:2001

01-november-2001

# Measurement of fluid flow in closed conduits - Guidelines on the effects of flow pulsations on flow-measurement instruments

Measurement of fluid flow in closed conduits -- Guidelines on the effects of flow pulsations on flow-measurement instruments

# iTeh STANDARD PREVIEW

Mesure de débit des fluides dans les conduites fermées à Lignes directrices relatives aux effets des pulsations d'écoulement sur les instruments de mesure de débit

SIST ISO/TR 3313:2001

Ta slovenski standard je istoveten z: Sed Crada/sist-iso-tr-3313-2011998

ICS:

17.120.10 Pretok v zaprtih vodih

Flow in closed conduits

SIST ISO/TR 3313:2001

en



# iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST ISO/TR 3313:2001 https://standards.iteh.ai/catalog/standards/sist/e7f1fcd3-d413-4ea0-a695-5ed4c7cc7ada/sist-iso-tr-3313-2001

# TECHNICAL REPORT

# ISO/TR 3313

Third edition 1998-08-01

# Measurement of fluid flow in closed conduits — Guidelines on the effects of flow pulsations on flow-measurement instruments

Mesure de débit des fluides dans les conduites fermées — Lignes directrices relatives aux effets de puisations d'écoulement sur les instruments de mesure de débit (standards.iteh.ai)

<u>SIST ISO/TR 3313:2001</u> https://standards.iteh.ai/catalog/standards/sist/e7fl fcd3-d413-4ea0-a695-5ed4c7cc7ada/sist-iso-tr-3313-2001



#### SIST ISO/TR 3313:2001

### ISO/TR 3313:1998(E)

## Contents

1 Scope	1
2 Normative reference	1
3 Definitions	1
4 Symbols and subscripts	2
4.1 Symbols	2
4.2 Subscripts	4
5 Description and detection of pulsating flow	4
5.1 Nature of pipe flows	4
5.2 Threshold between steady and pulsating flow DARD PREVIEW	4
5.3 Causes of pulsation	6
5.4 Occurrence of pulsating flow conditions in industrial and laboratory flowmeter installations	6
5.5 Detection of pulsation and determination of frequency, amplitude and waveform	6
5ed4c7cc7ada/sist-iso-tr-3313-2001 6 Measurement of the mean flowrate of a pulsating flow	9
6.1 Orifice plate, nozzle, and Venturi tube	9
6.2 Turbine flowmeters	19
6.3 Vortex flowmeters	23
Annex A (informative) Orifice plates, nozzles and Venturis — Theoretical considerations	25
Annex B (informative) Orifice plates, nozzles and Venturis — Pulsation damping criteria	31
Annex C (informative) Turbine flowmeters — Theoretical background and experimental data	36
Annex D (informative) Bibliography	

© ISO 1998

International Organization for Standardization Case postale 56 • CH-1211 Genève 20 • Switzerland Internet iso@iso.ch

Printed in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

# Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The main task of technical committees is to prepare International Standards, but in exceptional circumstances a technical committee may propose the publication of a Technical Report of one of the following types:

- type 1, when the required support cannot be obtained for the publication of an International Standard, despite repeated efforts;
- type 2, when the subject is still under technical development or where for any other reason there is the future but not immediate possibility of an agreement on an International Standard;
- type 3, when a technical committee has collected data of a different kind from that which is normally published as an International Standard ("state of the art", for example).

Technical Reports of types and 2 are subject to review within three years of publication to decide whether they can be transformed into International Standards. Technical Reports of type 3 do not necessarily have to be reviewed until the data they provide are considered to be no longer valid or useful.

ISO/TR 3313, which is a Technical Report of type 2, was prepared by Technical Committee ISO/TC 30, *Measurement of fluid flow in closed conduits*, Subcommittee SC 2, *Pressure differential devices*.

This document is being issued in the Technical Report (type 2) series of publications (according to subclause G.3.2.2 of part 1 of ISO/IEC Directives, 1995) as a "prospective standard for provisional application" in the field of fluid flow in closed conduits because there is an urgent need for guidance on how standards in this field should be used to meet an identified need.

This document is not regarded as an "International Standard". It is proposed for provisional application so that information and experience of its use in practice may be gathered. Comments on the content of this document should be sent to the ISO Central Secretariat.

A review of this Technical Report (type 2) will be carried out not later than three years after its publication with the options of: extension for another three years; conversion into an International Standard; or withdrawal.

This third edition cancels and replaces the second edition (ISO/TR 3313:1992), of which it constitutes a technical revision.

Annexes A to D of this Technical Report are for information only.



# iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST ISO/TR 3313:2001 https://standards.iteh.ai/catalog/standards/sist/e7f1fcd3-d413-4ea0-a695-5ed4c7cc7ada/sist-iso-tr-3313-2001

# Measurement of fluid flow in closed conduits — Guidelines on the effects of flow pulsations on flow-measurement instruments

#### 1 Scope

This Technical Report defines pulsating flow, compares it with steady flow, indicates how it can be detected, and describes the effects it has on orifice plates, nozzles or Venturi tubes, turbine and vortex flowmeters when these devices are being used to measure fluid flow in a pipe. These particular flowmeter types feature in this Technical Report because they are amongst those types most susceptible to pulsation effects. Methods for correcting the flowmeter output signal for errors produced by these effects are described for those flowmeter types for which this is possible. When correction is not possible, measures to avoid or reduce the problem are indicated. Such measures include the installation of pulsation damping devices and/or choice of a flowmeter type which is less susceptible to pulsation effects.

This Technical Report applies to flow in which the pulsations are generated at a single source which is situated either upstream or downstream of the primary element of the flowmeter. Its applicability is restricted to conditions where the flow direction does not reverse in the measuring section but there is no restriction on the waveform of the flow pulsation. The recommendations within this Technical Report apply to both liquid and gas flows although with the latter the validity may be restricted to gas flows in which the density changes in the measuring section are small as indicated for the particular type of flowmeter under discussion.

https://standards.iteh.ai/catalog/standards/sist/e7fl fcd3-d413-4ea0-a695-5ed4c7cc7ada/sist-iso-tr-3313-2001

#### 2 Normative reference

The following standard contains provisions which, through reference in this text, constitute provisions of this Technical Report. At the time of publication the edition indicated was valid. All standards are subject to revision, and parties to agreements based on this Technical Report are encouraged to investigate the possibility of applying the most recent edition of the standard indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

ISO 5167-1:1991, Measurement of fluid flow by means of pressure differential devices — Part 1: Orifice plates, nozzles and Venturi tubes inserted in circular cross-section conduits running full.

### **3 Definitions**

For the purposes of this Technical Report, the following definitions apply.

#### 3.1

#### steady flow

flow in which parameters such as velocity, pressure, density and temperature do not vary significantly enough with time to prevent measurement to within the required uncertainty of measurement

#### 3.2

#### pulsating flow

flow in which the flowrate in a measuring section is a function of time but has a constant mean value when averaged over a sufficiently long period of time, which will depend on the regularity of the pulsation

### ISO/TR 3313:1998(E)

NOTE 1 Pulsating flow can be divided into two categories:

- periodic pulsating flow;
- randomly fluctuating flow.

NOTE 2 For further amplification of what constitutes steady or pulsating flow see 5.1 and 5.2.

NOTE 3 Unless otherwise stated in this Technical Report the term "pulsating flow" is always used to describe periodic pulsating flow.

### 4 Symbols and subscripts

#### 4.1 Symbols

Α	area
A <sub>d</sub>	area of the throat of a Venturi nozzle
A <sub>R</sub>	turbine blade aspect ratio
$a_r$ , $b_r$ , $c_r$	amplitude of the $r$ th harmonic component in the undamped or damped pulsation
В	$bf_{p}/q_{V}$ , dimensionless dynamic response parameter
b	turbine flowmeter dynamic response parameter
С	turbine blade chord length
C <sub>C</sub>	contraction coefficient (standards itch ai)
CD	discharge coefficient
$C_{v}$	velocity coefficient <u>SIST ISO/TR 3313:2001</u>
С	speed of sound 5ed4c7cc7ada/sist-iso-tr-3313-2001
D	internal diameter of the tube
d	throat bore of orifice, nozzle or Venturi
E <sub>R</sub>	residual error in time-mean flowrate when calculated using the quantity $\sqrt{\Delta p}$
Ε <sub>T</sub>	total error in the time-mean flowrate
f	turbine flowmeter output signal, proportional to volumetric flowrate
fp	pulsation frequency
$f_{r}$	resonant frequency
$f_{V}$	vortex-shedding frequency
Н	harmonic distortion factor
Но	Hodgson number
Ι	moment of inertia
I <sub>R</sub> , I <sub>F</sub>	moments of inertia of turbine rotor and fluid contained in rotor envelope respectively
k/D	relative roughness of pipe wall
L	turbine blade length
L <sub>e</sub>	effective axial length

### SIST ISO/TR 3313:2001

### © ISO

### ISO/TR 3313:1998(E)

l	impulse line length for differential pressure (DP) measurement device
$m = \beta^2$	orifice or nozzle throat to pipe area ratio
Ν	number of blades on turbine rotor
р	pressure (absolute)
$q_m$	mass flowrate
$q_V$	volume flowrate
R	turbine blade mean radius
Re	Reynolds number
r <sub>h</sub> , r <sub>t</sub>	turbine blade hub and tip radii respectively
Sr	Strouhal number
Sr <sub>d</sub>	Strouhal number based on orifice diameter
t	time
t <sub>b</sub>	turbine blade thickness
U	axial bulk-mean velocity
$U_d$	bulk-mean velocity based on orifice diameter PREVIEW
V	volume (standards.iteh.ai)
X	temporal inertia term for short pulsation wavelengths
α	$U'_{\text{rms}}/\overline{U}$ https://standards.iteh.ai/catalog/standards/sist/e7flfcd3-d413-4ea0-a695- 5ed4c7cc7ada/sist-iso-tr-3313-2001
β	orifice or nozzle throat to pipe diameter ratio
$\Delta p$	differential pressure
$\Delta \sigma$	pressure loss
$\mathcal{E}_{SS}$	expansibility factor for steady flow conditions
γ	ratio of specific thermal capacities ( $c_p/c_V$ )
η	blade 'airfoil efficiency'
К	isentropic index (= $\gamma$ for a perfect gas)
θ	phase angle
ρ	fluid density
$ ho_{b}$	turbine blade material density
$\tau = p_2 / p_1$	pressure ratio
$\omega = 2\pi f_{\rm p}$	angular pulsation frequency
ψ	maximum allowable relative error

#### ISO/TR 3313:1998(E)

#### 4.2 Subscripts

0	pulsation source
р	measured under pulsating flow conditions, possibly damped
ро	measured under pulsating flow conditions before damping
rms	root mean square
SS	measured under steady flow conditions
$\overline{U}$	an over-bar indicates the time-mean value
1,2	measuring sections
,	indicates fluctuating component about mean value, e.g. $U'$

### 5 Description and detection of pulsating flow

#### 5.1 Nature of pipe flows

Truly steady pipe flow is only found in laminar flow conditions which can normally only exist when the pipe Reynolds number, *Re*, is below about 2000. Most industrial pipe flows have higher Reynolds numbers and are turbulent which means that they are only statistically steady. Such flows contain continual irregular and random fluctuations in quantities such as velocity, pressure and temperature. Nevertheless, if the conditions are similar to those which are typical of fully developed turbulent pipe flow and there is no periodic pulsation, the provisions of such standards as ISO 5167-1 apply.

The magnitude of the turbulent fluctuations increases with pipe roughness and for this reason ISO 5167-1 stipulates a maximum allowable relative roughness, k/D, of the upstream pipe for each type of primary device covered by ISO 5167-1. https://standards.iteh.ai/catalog/standards/sist/e7fl fcd3-d413-4ea0-a695-

#### 5ed4c7cc7ada/sist-iso-tr-3313-2001

ISO 5167-1, however, cannot be applied to flows which contain any periodic flow variation or pulsation.

#### 5.2 Threshold between steady and pulsating flow

If the amplitude of the periodic flowrate variations is sufficiently small there should not be any error in the indicated flowrate greater than the normal measurement uncertainty. It is possible to define amplitude thresholds for both differential pressure (DP) type flowmeters and turbine flowmeters without reference to pulsation frequency. It is also possible to do this for vortex flowmeters but extreme caution is necessary if even the smallest amplitude is known to be present in the flow.

For DP-type flowmeters, the threshold is relevant when slow-response DP cells are being used. In the case of turbine flowmeters, the threshold value is relevant when there is any doubt about the ability of the rotor to respond to the periodic velocity fluctuations. In the case of a vortex flowmeter the pulsation frequency relative to the vortex-shedding frequency is a much more important parameter than the velocity pulsation amplitude.

#### 5.2.1 Differential pressure (DP) type flowmeters

The threshold can be defined in terms of the velocity pulsation amplitude such that the flow can be treated as steady if

$$\frac{U'_{\text{rms}}}{\overline{U}} \leq 0,05 \tag{1}$$

where U is the instantaneous bulk-mean axial velocity such that

$$U = U' + \overline{U} \qquad \dots (2)$$

#### © ISO

ISO/TR 3313:1998(E)

where

U' is the periodic velocity fluctuation;

 $\overline{U}$  is the time-mean value.

The threshold in terms of the equivalent DP pulsation amplitude is:

$$\frac{\Delta p'_{\rm p,rms}}{\overline{\Delta p}_{\rm p}} \leq 0,10 \tag{3}$$

where  $\Delta p_p$  is the instantaneous differential pressure across the tappings of the primary device such that

$$\Delta p_{\mathsf{p}} = \overline{\Delta p_{\mathsf{p}}} + \Delta p'_{\mathsf{p}} \qquad \dots \tag{4}$$

where

 $\Delta p_{p}$  is the time-mean value;

 $\Delta p'_{\rm D}$  is the periodic differential pressure fluctuation.

To determine the velocity pulsation amplitude it will be necessary to use one of the techniques described in 5.5 such as laser Doppler or thermal anemometry. To determine the DP pulsation amplitude it will be necessary to use a fast-response DP sensor and to observe the rules governing the design of the complete secondary instrumentation system as described in 6.1.3. (standards.iteh.ai)

#### 5.2.2 Turbine flowmeters

#### SIST ISO/TR 3313:2001

#### https://standards.iteh.ai/catalog/standards/sist/e7flfcd3-d413-4ea0-a695-

At a given velocity pulsation amplitude a turbine flowmeter will tend to read high as the frequency of pulsation increases and exceeds the frequency at which the turbine rotor can respond faithfully to the velocity fluctuations. The positive systematic error will reach a plateau value depending on the amplitude and thus the threshold amplitude can be defined such that the resulting maximum systematic error is still within the general measurement uncertainty. For example, if the overall measurement uncertainty is greater than or equal to 0,1 % then we can assume that a systematic error due to pulsation of 0,1 % or less will not significantly increase the overall measurement uncertainty.

The velocity amplitude of sinusoidal pulsation,  $U'_{rms}/\overline{U}$ , that will produce a systematic error of 0,1 % in a turbine flowmeter is 3,5 %. Thus the threshold for sinusoidal pulsation is given by:

$$\frac{U'_{\text{rms}}}{\overline{U}} \leq 0,035 \tag{5}$$

Techniques such as laser Doppler and thermal anemometry can be used to determine the velocity pulsation amplitude. If the flowmeter output is a pulse train at the blade passing frequency and if the rotor inertia is known, then signal analysis can be used to determine the flow pulsation amplitude as described in 6.2.

#### 5.2.3 Vortex flowmeters

A vortex flowmeter is subject to very large pulsation errors when the vortex-shedding process locks in to the flow pulsation. There is a danger of this happening when the pulsation frequency is near the vortex-shedding frequency. At a sufficiently low amplitude, locking-in does not occur and flow-metering errors due to pulsation will be negligible. This threshold amplitude, however, is only about 3 % of the mean velocity and is comparable to the velocity turbulence amplitude. The consequences of not detecting the pulsation or erroneously assuming the amplitude is below the threshold can be very serious. This issue is discussed further in 6.3.

#### SIST ISO/TR 3313:2001

#### ISO/TR 3313:1998(E)

#### 5.3 Causes of pulsation

Pulsation occurs commonly in industrial pipe flows. They may be generated by rotary or reciprocating positive displacement engines, compressors, blowers and pumps. Rotodynamic machines may also induce small pulsation at blade passing frequencies. Pulsation can also be produced by positive-displacement flowmeters. Vibration, particularly at resonance, of pipe runs and flow control equipment is also a potential source of flow pulsation, as are periodic actions of flow controllers, e.g. valve "hunting" and governor oscillations. Pulsation may also be generated by flow separation within pipe fittings, valves, or rotary machines (e.g. compressor surge).

Flow pulsation can also be due to hydrodynamic oscillations generated by geometrical features of the flow system and multiphase flows (e.g. slugging). Vortex shedding from bluff bodies such as thermometer wells, or trash grids, or vortex-shedding flowmeters fall into this category. Self-excited flow oscillations at tee-branch connections are another example.

#### 5.4 Occurrence of pulsating flow conditions in industrial and laboratory flowmeter installations

In industrial flows, there is often no obvious indication of the presence of pulsation, and the associated errors, because of the slow-response times and heavy damping of the pressure and flow instrumentation commonly used. Whenever factors such as those indicated in 5.3 are present, there is the possibility of flow pulsation occurring. It should also be appreciated that pulsation can travel upstream as well as downstream and thus possible pulsation sources could be on either side of the flowmeter installation. However, amplitudes may be small and, depending on the distance from pulsation source to flowmeter, may be attenuated by compressibility effects (in both liquids and gases) to undetectable levels at the flowmeter location. Pulsation frequencies range from fractions of a hertz to a few hundred hertz; pulsation amplitudes relative to mean flow vary from a few percent to 100 % or larger. At low percentage amplitudes the question arises of discrimination between pulsation and turbulence.

Flow pulsation can be expected to occur in various situations in petrochemical and process industries, natural gas distribution flows at end-user locations and internal combustion engine flow systems. Flow-metering calibration systems may also experience pulsation arising from, for example, totodynamic pump blade passing effects and the effects of rotary positive-displacement flowmeters. talog/standards/sist/e7flfcd3-d413-4ea0-a695-

5ed4c7cc7ada/sist-iso-tr-3313-2001

#### 5.5 Detection of pulsation and determination of frequency, amplitude and waveform

If the presence of pulsation is suspected then there are various techniques available to determine the flow pulsation characteristics.

#### 5.5.1 Characteristics of the ideal pulsation sensor

The ideal sensor would be non-intrusive, would measure mass flowrate, or bulk flow velocity, and would have a bandwidth from decihertz to several kilohertz. The sensor would respond to both liquids and gases and not require any supplementary flow seeding. The technique would not require optical transparency or constant fluid temperature. The sensor would be uninfluenced by pipe wall material, transparency or thickness. The device would have no moving parts, its response would be linear, its calibration reliable and unaffected by changes in ambient temperature.

#### 5.5.2 Non-intrusive techniques

#### 5.5.2.1 Optical: laser Doppler anemometry (LDA)

This technology is readily available, but expensive. Measurement of point velocity on the tube axis will allow an estimate only of bulk flow pulsation amplitude and waveform but, for constant frequency pulsation, accurate frequency measurements can be made. Optical access to an optically transparent fluid is either by provision of a transparent tube section, or insertion of a probe with fibre-optic coupling. With the exception of detecting low frequency pulsation, supplementary seeding of the flow would probably be required to produce an adequate bandwidth. LDA characteristics are comprehensively described in reference [1] (see annex D).

#### 5.5.2.2 Acoustic: Doppler shift; transit time

Non-intrusive acoustic techniques are suitable for liquid flows only, because for gas flows there is poor acoustic-impedance match between the pipe wall and flowing gases. For the externally mounted transmitter and receiver, usually close-coupled to the tube wall, an acoustically transparent signal path is essential. The Doppler shift technique may require flow seeding to provide adequate scattering. Instruments for point velocity measurements are available which, as for the LDA, allow only an estimate of bulk flow pulsation amplitude and waveform. More recently, Doppler derived "instantaneous" full-velocity profile instruments [2] allow much closer estimates of bulk flow pulsation characteristics. Transit time instruments measure an average velocity, most commonly along a diagonal path across the flow. All acoustic techniques are limited in bandwidth by the requirement that reflections from one pulse of ultrasound must decay before transmission of the next pulse. It should be noted that many commercial instruments do not provide the signal processing required to resolve unsteady flow components. A recent investigation by Hakansson [3] on a transit time, intrusive-type ultrasonic flowmeter for gases subjected to pulsating flows showed that only small shifts in the calibration took place and that these were attributable to the changing velocity profile.

#### 5.5.2.3 Electromagnetic flowmeters

When the existing flowmeter installation is an electromagnetic device, then, if it is of the pulsed d.c. field type (likely maximum d.c. pulse frequency a few hundred hertz), there is the capability to resolve flow pulsation up to frequencies approximately five times below the excitation frequency. This technique is only suitable for liquids with an adequate electrical conductivity. It provides a measure of bulk flow pulsation, although there is some dependence upon velocity profile shape [4].

#### 5.5.3 Insertion devices

# iTeh STANDARD PREVIEW

#### 5.5.3.1 Thermal anemometry

# (standards.iteh.ai)

The probes used measure point velocity and relatively rugged (e.g. fibre-film) sensors are available for industrial flows. These probes generally have an adequate bandwidth, but the amplitude response is inherently non-linear. As with other point velocity techniques, pulsation amplitude and waveform can only be estimated. Estimates of pulsation velocity amplitude relative to mean velocity may be made without calibration. The r.m.s. value of the fluctuating velocity component can be determined by using a *true* r.m.s. flowmeter to measure the fluctuating component of the linearized anemometer output voltage. Mean-sensing r.m.s. flowmeters should not be used as these will only read correctly for sinusoidal waveforms. Accurate frequency measurements from spectral analysis can be made for constant frequency pulsation.

Applications are limited to clean, relatively cool, non-flammable and non-hostile fluids. Cleanness of flow is very important; even nominally clean flows can result in rapid fouling of probes with a consequent dramatic loss of response. A constant temperature flow is desirable although a slowly varying fluid temperature can be accommodated.

#### 5.5.3.2 Other techniques

Insertion versions of both acoustic and electromagnetic flowmeters are available. Transit-time acoustic measurements can be made in gas flows when the transmitter and receiver are directly coupled to the flow [5], although this may require a permanent insertion. Again there is the limitation of a lack of commercially available instrumentation with the necessary signal processing to resolve time-varying velocity components.

Insertion electromagnetic flowmeters are not widely available and are subject to the same bandwidth limitations as the tube version, due to the maximum sampling frequency of the signal.

#### 5.5.4 Signal analysis on existing flowmeter outputs: software tools

#### 5.5.4.1 Orifice plate with fast-response DP sensor

A fast-response secondary measurement system is capable of correctly following the time-varying pressure difference produced by the primary instrument provided the rules given in 6.1.3.2 can be followed. In principle, a