



SLOVENSKI STANDARD

SIST ISO 9555-4:2013

01-april-2013

Meritve pretoka tekočin v odprtih kanalih - Metode z redčenjem markerja za merjenje enakomernega pretoka - 4. del: Fluorescenčni markerji

Measurement of liquid flow in open channels - Tracer dilution methods for the measurement of steady flow - Part 4: Fluorescent tracers

iTeh STANDARD PREVIEW

Mesure de débit des liquides dans les canaux découverts - Méthodes de dilution en régime permanent utilisant des traceurs - Partie 4: Traceurs fluorescents

[SIST ISO 9555-4:2013](https://standards.itih.ai/catalog/standards/sist/8496c2ac-f34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013)

Ta slovenski standard je istoveten z: [ISO 9555-4:1992](https://standards.itih.ai/catalog/standards/sist/8496c2ac-f34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013)

ICS:

17.120.20 Pretok v odprtih kanalih Flow in open channels

SIST ISO 9555-4:2013

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ISO 9555-4:2013

<https://standards.iteh.ai/catalog/standards/sist/8496c2ac-ff34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013>

INTERNATIONAL STANDARD

ISO
9555-4

First edition
1992-11-01

Measurement of liquid flow in open channels — Tracer dilution methods for the measurement of steady flow —

Part 4: Fluorescent tracers

<https://standards.iteh.ai/SIST-ISO-9555-4-2013>
*Mesure de débit des liquides dans les canaux découverts — Méthodes
de dilution en régime permanent utilisant des traceurs --
Partie 4: Traceurs fluorescents*



Reference number
ISO 9555-4:1992(E)

Contents

	Page
1 Scope	1
2 Normative reference	1
3 Definitions	1
4 Tracers used	1
4.1 General	1
4.2 Fluorescein	2
4.3 Rhodamine B	2
4.4 Acid yellow 7	2
4.5 Sulfo rhodamine B	2
4.6 Pyranine	2
4.7 Rhodamine WT	2
5 Tracer measurement	2
5.1 Principles	2
5.2 Field measurement	5
5.3 Laboratory measurements	5
6 Environmental factors affecting tracers	6
6.1 Chemical factors	6
6.2 Physical factors	6
6.3 Biological factors	7
7 Techniques for tracer injection	7
8 Sampling techniques	7
9 Analysis and computations	8
10 Special requirements	8

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ISO 9555-4:2013

<https://standards.iteh.ai/catalog/standards/sist/8496c2a2-ff34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013>

© ISO 1992

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

International Organization for Standardization
Case Postale 56 • CH-1211 Genève 20 • Switzerland

Printed in Switzerland

Annex

A General characteristics of commonly used fluorescent tracers **9**

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST ISO 9555-4:2013](https://standards.iteh.ai/catalog/standards/sist/8496c2ac-ff34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013)

<https://standards.iteh.ai/catalog/standards/sist/8496c2ac-ff34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013>

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

International Standard ISO 9555-4 was prepared by Technical Committee ISO/TC 113, *Measurement of liquid flow in open channels*, Subcommittee SC 4, *Dilution methods*.

ISO 9555 consists of the following parts, under the general title *Measurement of liquid flow in open channels - Tracer dilution methods for the measurement of steady flow*:

- Part 1: *General*
- Part 2: *Radioactive tracers*
- Part 3: *Chemical tracers*
- Part 4: *Fluorescent tracers*

Annex A forms an integral part of this part of ISO 9555.

Introduction

The former standard series ISO 555 was subdivided into parts on the basis of the method of field measurement, i.e. constant-rate injection method and integration (sudden injection) method. Since the choice of the type of tracer to be used in a field measurement will often depend on the expertise and the laboratory facilities available, this new series of standards ISO 9555 is divided into parts based on the type of tracer used. This revision has enabled the unnecessary repetition of text of the various parts to be avoided and will, it is hoped, prove to be a more convenient form of presentation for the user.

ISO 9555 deals with the measurement of steady flow in open channels by dilution methods using tracers. The methods described may also be applied to the measurement of slowly varying flow, but they may only be used when flow conditions ensure adequate mixing of the injected solution throughout the flow.

For the measurement of very large flows, tracer methods can be onerous in terms of tracer costs and measurement times. However, the use of tracers often reduces danger to personnel during flood periods.

ISO 9555-1 presents the general principles of the methods of constant-rate injection and integration (sudden injection). ISO 9555-2, ISO 9555-3 and ISO 9555-4 deal with the specific aspects of the use of radioactive, chemical and fluorescent tracers, respectively, as well as specific analytical procedures.

This approach has been adopted for the following reasons:

- to facilitate subsequent updating, additions or revisions which concern only ISO 9555-2, ISO 9555-3 or ISO 9555-4;
- to provide a more practical document for the user, who is often obliged to choose the tracer best suited to the available analytical equipment.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

This page intentionally left blank

[SIST ISO 9555-4:2013](#)

<https://standards.iteh.ai/catalog/standards/sist/8496c2ac-ff34-48cd-a7a8-68c52247a424/sist-iso-9555-4-2013>

Measurement of liquid flow in open channels — Tracer dilution methods for the measurement of steady flow —

Part 4: Fluorescent tracers

1 Scope

This part of ISO 9555 deals with the use of fluorescent tracers in discharge measurements by the dilution method. Apparatus and methods of general application are set out in ISO 9555-1 and are not repeated here, with the exception of those relating specifically to fluorescent tracers.

The use of fluorescent tracers is attractive because of the small amounts of tracer needed to make a discharge measurement. Certain fluorescent tracers can be measured at concentrations of less than 1 µg/l. Fluorescent tracers are easy to handle and their concentrations can be readily determined.

2 Normative reference

The following standard contains provisions which, through reference in this text, constitute provisions of this part of ISO 9555. At the time of publication, the edition indicated was valid. All standards are subject to revision, and parties to agreements based on this part of ISO 9555 are encouraged to investigate the possibility of applying the most recent edition of the standard indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

ISO 772:1988, *Liquid flow measurement in open channels — Vocabulary and symbols*.

3 Definitions

For the purposes of this part of ISO 9555, the definitions given in ISO 772:1988 and the following definitions apply.

3.1 fluorescence: The emission of electromagnetic waves of characteristic energy when atoms or molecules decay from an excited state to a lower energy state. The excitation may be induced by subjecting the substance to radiation of slightly higher energy (shorter wavelength) than that of the characteristic emission, and it ceases as soon as the external source is removed.

3.2 fluorimeter; filter fluorimeter: Instrument equipped with a lamp or other means of exciting fluorescent radiation in a sample, with filters and with a detector to measure relative fluorescent intensities caused by variations in concentration of the substance under examination. If the wavelengths are determined using a monochromator, the instrument is called a spectrofluorimeter.

3.3 fluorescence quenching: The reduction of fluorescence intensity, due to an interaction of the dye molecules with other chemicals present in the water. Concentration quenching is a phenomenon which appears to be similar to fluorescence quenching but is not a true quenching. Instead, it is a reduction in the rate of increase of the flowmeter readout with increasing dye concentration due to the increasing optical density of the dye itself. Concentration quenching occurs only at very high concentrations.

4 Tracers used

4.1 General

A number of fluorescent dyes have been used as tracers for measuring open-channel flow. Stream waters generally have lower background fluorescence in the orange than in the green and blue wavelengths. Consequently, the orange wavebands