# INTERNATIONAL STANDARD

ISO 18115-1

First edition 2010-07-15

# Surface chemical analysis — Vocabulary —

Part 1: General terms and terms used in spectroscopy

Teh ST Analyse chimique des surfaces — Vocabulaire —

Partie 1: Termes généraux et termes utilisés en spectroscopie

ISO 18115-1:2010 https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-8591a14d7166/iso-18115-1-2010



#### PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

# iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 18115-1:2010 https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-8591a14d7166/iso-18115-1-2010



# **COPYRIGHT PROTECTED DOCUMENT**

# © ISO 2010

The reproduction of the terms and definitions contained in this International Standard is permitted in teaching manuals, instruction booklets, technical publications and journals for strictly educational or implementation purposes. The conditions for such reproduction are: that no modifications are made to the terms and definitions; that such reproduction is not permitted for dictionaries or similar publications offered for sale; and that this International Standard is referenced as the source document.

With the sole exceptions noted above, no other part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Con	ntents	Page
ForewordIntroduction		iv
		v
1	Scope	1
2	Abbreviations	1
3 3.1 3.2 3.3	Format Use of terms printed boldface in definitions	3 3
4	Definitions of the surface analysis methods	3
5	Definitions of terms for surface analysis	7
6	Definitions of terms for multivariate analysis	81
	ex A (informative) Extract from IEC 60050-111, International Electrotechnical Vocabulary — Chapter 111: Physics and chemistry <sup>[11]</sup>	
Biblic	ographyiTch STANDARD PREVIEW	91
Index	c of terms in this part of ISO 18115	92
Index	c of terms in this part of ISO 18115	100

ISO 18115-1:2010 https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-8591a14d7166/iso-18115-1-2010

Contents

# **Foreword**

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 18115-1 was prepared by Technical Committee ISO/TC 201, *Surface chemical analysis*, Subcommittee SC 1, *Terminology*.

Together with Part 2 (see below), it cancels and replaces ISO 18115:2001, which has been split into two parts and at the same time technically revised. The two parts also incorporate the Amendments ISO 18115:2001/Amd.1:2006 and ISO 18115:2001/Amd.2:2007.

ISO 18115 consists of the following parts, under the general title Surface chemical analysis — Vocabulary:

- Part 1: General terms and terms used in spectroscopy -18115-1-2010
- Part 2: Terms used in scanning-probe microscopy

# Introduction

Surface chemical analysis is an important area which involves interactions between people with different backgrounds and from different fields. Those conducting surface chemical analysis might be materials scientists, chemists or physicists and might have a background that is primarily experimental or primarily theoretical. Those making use of the surface chemical data extend beyond this group into other disciplines.

With the present techniques of surface chemical analysis, compositional information is obtained for regions close to a surface (generally within 20 nm) and composition-versus-depth information is obtained with surface analytical techniques as surface layers are removed. The surface analytical terms covered in this part of ISO 18115 extend from the techniques of electron spectroscopy and mass spectrometry to optical spectrometry and X-ray analysis. The terms covered in Part 2 relate to scanning-probe microscopy. Concepts for these techniques derive from disciplines as widely ranging as nuclear physics and radiation science to physical chemistry and optics.

The wide range of disciplines and the individualities of national usages have led to different meanings being attributed to particular terms and, again, different terms being used to describe the same concept. To avoid the consequent misunderstandings and to facilitate the exchange of information, it is essential to clarify the concepts, to establish the correct terms for use and to establish their definitions.

The terms and definitions in the two parts of ISO 18115 have been prepared in conformance with the principles and style defined in ISO 1087-1:2000, *Terminology work — Vocabulary — Part 1: Theory and application*, and ISO 10241:1992, *International terminology standards — Preparation and layout*. Essential aspects of these standards appear in Subclauses 3.1 to 3.3. The terms are given in alphabetical order, classified under three headings:

ISO 18115-1:2010

Clause 4: Definitions of the surface analysis methods.8bff6-7fc6-472a-8b20-

8591a14d7166/iso-18115-1-2010

Clause 5: Definitions of terms for surface analysis.

Clause 6: Definitions of terms for multivariate analysis.

Additional terms, important for surface analysis, are given in an extract from IEC 60050-111 in Annex A.

A single alphabetical index to this part of ISO 18115 is given after the Bibliography. To help users, a second index is provided for the terms in Part 2 covering scanning-probe microscopy. To assist retrieval, compound terms can be found in the indexes in both natural and reverse word order.

This part of ISO 18115 contains new terms in addition to those previously published in ISO 18115:2001, ISO 18115:2001/Amd.1 chemical analvsis — Vocabulary, and those ISO 18115:2001/Amd.2 that did not involve scanning-probe microscopy. Those terms in ISO 18115:2001/Amd.2 that did involve scanning-probe microscopy now appear in ISO 18115-2.

# iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 18115-1:2010 https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-8591a14d7166/iso-18115-1-2010

# Surface chemical analysis — Vocabulary —

# Part 1:

# General terms and terms used in spectroscopy

#### 1 Scope

ISO 18115 defines terms for surface chemical analysis. This part covers general terms and those used in spectroscopy while Part 2 covers terms used in scanning-probe microscopy.

# **Abbreviations**

**AES** Auger electron spectroscopy

**AMRSF** average matrix relative sensitivity factor) PRFVIEW

**ARAES** angle-resolved Auger electron spectroscopy

**AREPES** angle-resolved elastic peak electron spectroscopy

angle-resolved X-ray photoelectron specific scopy **ARXPS** 

CDP compositional depth profile

CRM certified reference material

DA/DFA discriminant analysis/discriminant function analysis

dc direct current

DESI desorption electrospray ionization

eV electron volts

**EELS** electron energy loss spectroscopy

ΕIA energetic-ion analysis

**EPES** elastic peak electron spectroscopy

**EPMA** electron probe microanalysis

**ESCA** electron spectroscopy for chemical analysis

**FABMS** fast atom bombardment mass spectrometry

FIB focussed ion beam system

# ISO 18115-1:2010(E)

**FWHM** full width at half maximum

**GDMS** glow discharge mass spectrometry

**GDOES** glow discharge optical emission spectrometry

**GDS** glow discharge spectrometry

HSA hemispherical sector analyser

**IBA** ion beam analysis

ISS ion-scattering spectrometry

LB Langmuir-Blodgett

LEIS(S) low-energy ion scattering spectrometry

**LMIG** liquid-metal ion gun

**LMIS** liquid-metal ion source

MAF analysis maximum autocorrelation factor analysis

MALDI

matrix-assisted laser desorption/ionization mass spectrometry

**MCR** multivariate curve resolution standards.iteh.ai)

MEIS(S) medium-energy ion scattering spectrometry

ISO 18115-1:2010

MVA multivariate analysis and ards. iteh. ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-

8591a14d7166/iso-18115-1-2010

PCA principal-component analysis

**PERSF** pure-element relative sensitivity factor

**PLS** partial least squares

**RBS** Rutherford backscattering spectrometry

**REELS** reflection electron energy loss spectroscopy

relative instrument spectral response function RISR

rf radio-frequency

RM reference material

**RSF** relative sensitivity factor

SAM self-assembled monolayer

SAXS small-angle X-ray scattering

SDP sputter depth profile

SEM scanning electron microscope

SEP surface excitation parameter SIMS secondary-ion mass spectrometry

SNMS sputtered neutral mass spectrometry

SSA spherical sector analyser

TOF or ToF time of flight

TXRF total-reflection X-ray fluorescence spectroscopy

UPS ultra-violet photoelectron spectroscopy

XPS X-ray photoelectron spectroscopy

# 3 Format

# 3.1 Use of terms printed boldface in definitions

A term printed boldface in a definition or a note is defined in another entry in this part of ISO 18115. However, the term is printed boldface only the first time it occurs in each entry.

# 3.2 Non-preferred and deprecated terms

A term listed lightface is non-preferred or deprecated. The preferred term is listed boldface.

# 3.3 Subject fields

(standards.iteh.ai)

Where a term designates several concepts steel is necessary to indicate the subject field to which each concept belongs. The field is shown lightface, between angle brackets, preceding the definition, on the same line.

8591a14d7166/iso-18115-1-2010

# 4 Definitions of the surface analysis methods

## 4.1

# Auger electron spectroscopy

#### **AES**

a method in which an **electron spectrometer** is used to measure the energy distribution of **Auger electrons** emitted from a **surface** 

NOTE An electron beam in the energy range 2 keV to 30 keV is often used for excitation of the Auger electrons. Auger electrons can also be excited with X-rays, ions and other sources but the term Auger electron spectroscopy, without additional qualifiers, is usually reserved for electron-beam-induced excitation. Where an X-ray source is used, the Auger electron energies are referenced to the **Fermi level** but, where an electron beam is used, the reference may either be the Fermi level or the **vacuum level**. Spectra conventionally may be presented in the **direct** or **differential** forms.

## 4.2

# desorption electrospray ionization

a method in which a mass spectrometer is used to measure the mass-to-charge quotient and abundance of ionized entities emitted from a sample in air as a result of the bombardment by ionized solvent droplets generated by pneumatically assisted electrospray ionization

NOTE 1 Water and methanol are often used as the solvents to create the droplets. Acids and alkalis are added to control the solution pH.

NOTE 2 DESI is one of the few surface analysis methods designed to analyse materials without exposure to vacuum. It is used for complex molecules, organic molecules and biomolecules. *In vivo* analysis is claimed to be possible.

# dynamic SIMS

**SIMS** in which the material **surface** is sputtered at a sufficiently rapid rate that the original surface cannot be regarded as undamaged during the analysis

- NOTE 1 Dynamic SIMS is often simply termed SIMS.
- NOTE 2 The ion **areic dose** during measurement is usually more than 10<sup>16</sup> ions/m<sup>2</sup>.

#### 4.4

# elastic peak electron spectroscopy

#### **EPES**

a method in which an **electron spectrometer** is used to measure the energy, intensity and/or energy broadening distribution of quasi-elastically scattered electrons from a solid or liquid **surface** 

# cf. recoil effect, reflected electron energy loss spectroscopy, REELS

- NOTE 1 An electron beam in the energy range 100 eV to 3 keV is often used for this kind of spectroscopy.
- NOTE 2 In general, electron sources with energy spreads that are less than 1 eV are required to provide adequate information.
- NOTE 3 EPES is often an auxiliary method of **AES** and **REELS**, providing information on the composition of the surface layer. EPES is suitable for the experimental determination of the **inelastic mean free path**, the electron **differential elastic scattering cross section** and the **surface excitation parameter**.

# 4.5 iTeh STANDARD PREVIEW

electron spectroscopy for chemical analysis (deprecated) ESCA (deprecated) (Standards.iteh.ai)

a method encompassing both **AES** and **XPS** 

ISO 18115-1:2010

NOTE The term ESCA has fallen out of use as in practice, it was only used to describe situations more clearly defined by the term X-ray photoelectron spectroscopy (XPS). Since 1980, the latter term has been preferred.

# 4.6

# fast atom bombardment mass spectrometry FABMS

FAB (deprecated)

a method in which a mass spectrometer is used to measure the mass-to-charge quotient and abundance of **secondary ions** emitted from a sample as a result of the bombardment by fast neutral atoms

# 4.7

## G-SIMS

variant of **static SIMS** in which the intensities for each mass in two spectra from the same area, recorded with different beam energies or different bombarding ions, are ratioed to each other and the result is used to scale one of the spectra to generate a new spectrum

- NOTE 1 As with static SIMS, the ion **areic dose** during measurement is restricted to less than  $10^{16}$  ions/m<sup>2</sup> to an extent that depends on both the material of the sample and the size of the **molecular fragments** being analysed.
- NOTE 2 The G-SIMS spectrum enables the mass of whole molecules on the **surface** to be determined more readily than in static SIMS.
- NOTE 3 The "G" in G-SIMS originally indicated the gentleness of the process generated.

### 4.8

# glow discharge mass spectrometry

## **GDMS**

a method in which a mass spectrometer is used to measure the mass-to-charge quotient and abundance of ions from a **glow discharge** generated at a **surface** 

# glow discharge optical emission spectrometry **GDOES**

a method in which an optical emission spectrometer is used to measure the wavelength and intensity of light emitted from a glow discharge generated at a surface

## 4.10

# glow discharge spectrometry

### **GDS**

a method in which a spectrometer is used to measure relevant intensities emitted from a glow discharge generated at a surface

NOTE This is a general term that encompasses **GDOES** and **GDMS**.

#### 4.11

# ion beam analysis

#### **IBA**

a method, designed to elucidate composition and structure of the near-surface atomic layers of a solid material, in which principally monoenergetic, singly charged probe ions scattered from the surface are detected and recorded as a function of their energy or angle of scattering, or both

LEIS(S), MEIS(S) and RBS are all forms of IBA in which the probe ion energies are typically in the ranges 0,1 keV to 10 keV, 100 keV to 200 keV and 1 MeV to 2 MeV, respectively. These classifications represent three ranges in which fundamentally different physics is involved.

# low-energy ion scattering spectrometry PREVIEW 4.12

# LEIS(S)

a method, designed to elucidate composition and structure of the very outermost atomic layers of a solid material, in which principally monoenergetic, singly charged probe ions scattered from the surface are detected and recorded as a function of their energy for angle of scattering, or both

https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-

NOTE 1 LEIS(S) is a form of IBA in which the probe igns. It voically (He or Ne. have energies in the range 0.1 keV to 10 keV.

NOTE 2 The acronym usually has only one "S".

#### 4.13

# medium-energy ion scattering spectrometry

MEIS(S)

a method, designed to elucidate composition and structure of the outermost atomic layers of a solid material, in which principally monoenergetic, singly charged probe ions scattered from the surface are detected and recorded as a function of their energy or angle of scattering, or both

NOTE 1 MEIS is a form of IBA in which the probe ions, typically protons, have energies in the range 100 keV to 200 keV.

NOTF 2 By using channelling and aligning the incident-ion beam along a crystal axis, the scattering from the substrate may be suppressed so that enhanced signal quality and visibility are obtained for amorphous overlayers. By further aligning the detector along a second crystal axis, the double-alignment mode, the scattering from the substrate may be further suppressed, improving the signal quality and visibility for amorphous overlayers to a high level.

NOTE 3 In some cases, an angle-sensitive detector is used that allows extensive structure and depth profile information to be obtained.

NOTE 4 The acronym usually has only one "S".

# matrix-assisted laser desorption/ionization mass spectrometry MALDI

a method in which a time-of-flight mass spectrometer is used to measure the **mass-to-charge ratio** and abundance of ions emitted, as a result of a short pulse of laser illumination, from a sample whose analyte is contained in an ion-assisting matrix

NOTE 1 The matrix used for assisting the ion emission needs a strong absorbance at the laser wavelength and a low enough mass to be sublimable. Examples of matrices for 337 nm wavelength laser light are 2,5-dihydroxybenzoic acid (DHB), 3,5-dimethoxy-4-hydroxycinnamic acid (sinapinic acid) and  $\alpha$ -cyano-4-hydroxycinnamic acid (CHCA).

NOTE 2 MALDI is used to analyse non-volatile polar biological and organic macromolecules as well as polymers to masses of over 3 000 kDa.

#### 4.15

# Rutherford backscattering spectrometry RBS

a method, designed to elucidate composition and structure of layers at the **surface** of a solid material, in which principally monoenergetic, singly charged **probe ions** scattered from the surface with a **Rutherford cross section** are detected and recorded as a function of their energy or **angle of scattering**, or both

NOTE 1 RBS is a form of **IBA** in which the probe ions, typically He but sometimes H, have energies in the range 1 MeV to 2 MeV. In its traditional form, a solid-state energy-dispersive detector is used. In the form of high-resolution RBS, the energy can be reduced to 300 keV and a high-resolution (ion optical) spectrometer can be used.

NOTE 2 By using **channelling** and aligning the incident-ion beam along a crystal axis, the scattering from the substrate can be suppressed so that enhanced signal quality and visibility are obtained for amorphous overlayers.

# 4.16 (standards.iteh.ai)

# reflection electron energy loss spectroscopy

REELS

a method in which an **electron spectrometer** is used to measure the energy distribution of electrons quasi-elastically scattered by atoms at or in a surface layer and the associated **electron energy loss spectrum** 

cf. elastic peak electron spectroscopy, EPES

# 4.17

# secondary-ion mass spectrometry SIMS

a method in which a mass spectrometer is used to measure the mass-to-charge quotient and abundance of **secondary ions** emitted from a sample as a result of bombardment by energetic ions

# cf. dynamic SIMS, static SIMS, G-SIMS

NOTE SIMS is, by convention, generally classified as dynamic, in which the material surface layers are continually removed as they are being measured, and static, in which the ion **areic dose** during measurement is restricted to less than 10<sup>16</sup> ions/m<sup>2</sup> in order to retain the **surface** in an essentially undamaged state.

### 4.18

# small-angle X-ray scattering SAXS

a method in which the elastically scattered intensity of X-rays is measured for small-angle deflections

NOTE 1 The angular scattering is usually measured within the range 0,1° to 10°. This provides structural information on macromolecules as well as periodicity on length scales typically larger than 5 nm and less than 200 nm for ordered or partially ordered systems.

NOTE 2 Wide-angle X-ray scattering (WAXS) is an analogous technique, similar to X-ray crystallography, in which scattering at larger angles, which is sensitive to periodicity on smaller length scales, is measured.

The X-ray source may be a synchrotron, in which case the term synchrotron radiation small-angle X-ray scattering (SRXAS) is occasionally encountered.

#### 4.19

# sputtered neutral mass spectrometry SNMS

a method in which a mass spectrometer is used to measure the mass-to-charge quotient and abundance of secondary ionized neutral species emitted from a sample as a result of particle bombardment

The neutral species may be detected by using **plasma**, electron or photon ionization methods.

# 4.20

## static SIMS

SIMS in which the material surface is sputtered at a sufficiently low rate that the original surface is insignificantly damaged during the analysis

### cf. dynamic SIMS

The ion areic dose during measurement is restricted to less than 10<sup>16</sup> ions/m<sup>2</sup> to an extent that depends on both the material of the sample and the size of the molecular fragments being analysed.

# total reflection X-ray fluorescence spectroscopy

#### **TXRF**

a method in which an X-ray spectrometer is used to measure the energy distribution of **fluorescence** X-rays emitted from a surface irradiated by primary X-rays under the condition of total reflection

# ultra-violet photoelectron spectroscopy (standards.iteh.ai)

### **UPS**

a method in which an electron spectrometer is used to measure the energy distribution of photoelectrons emitted from a surface irradiated by altria-wiolet photons ist/1 f58bff6-7fc6-472a-8b20-

8591a14d7166/iso-18115-1-2010

Ultra-violet sources in common use include various types of discharges that can generate the resonance lines of various gases (e.g. the He I and He II emission lines at energies of 21,2 eV and 40,8 eV, respectively). For variable energies, synchrotron radiation is used.

#### 4.23

# X-ray photoelectron spectroscopy

## **XPS**

a method in which an electron spectrometer is used to measure the energy distribution of photoelectrons and Auger electrons emitted from a surface irradiated by X-ray photons

X-ray sources in common use are unmonochromated Al K $\alpha$  and Mg K $\alpha$  X-rays at 1 486,6 eV and 1 253,6 eV, respectively. Modern instruments also use monochromated Al Kα X-rays. Some instruments make use of various X-ray sources with other anodes or of synchrotron radiation.

# **Definitions of terms for surface analysis**

# 5.1

absorption coefficient, linear linear attenuation coefficient

# absorption coefficient, mass attenuation coefficient, mass

 $\langle TXRF, XPS \rangle$  quantity  $\mu/\rho$  in the expression  $(\mu/\rho)\Delta(\rho x)$  for the fraction of a parallel beam of specified particles or radiation removed in passing through a thin layer of mass thickness  $\Delta(\rho x)$  of a substance in the limit as  $\Delta(\rho x)$  approaches zero, where  $\Delta(\rho x)$  is measured in the direction of the beam

# cf. attenuation length

- NOTE 1 The mass density of the substance is  $\rho$  and x is the distance in the direction of the beam.
- The intensity or number of particles in the beam decays as  $\exp(-\mu x)$  with the distance x. NOTE 2
- The mass attenuation (absorption) coefficient is the quotient of the linear attenuation (absorption) coefficient NOTE 3 by the mass density of the substance.

#### 5.3

# abundance sensitivity

 $\langle GDMS \rangle$  ratio of the maximum ion current recorded at a mass m to the ion current arising from the same species recorded at an adjacent mass  $(m \pm 1)$ 

[IUPAC[3]]

#### 5.4

# adventitious carbon referencing

(XPS) determining the charging potential of a particular sample from a comparison of the experimentally determined C 1s binding energy, arising from adsorbed hydrocarbons on the sample, with a standard binding energy value

# cf. Fermi level referencing, internal carbon referencing

A nominal value of 285,0 eV is often used for the binding energy of the relevant C 1s peak, although some analysts prefer specific values in the range 284,6 eV to 285,2 eV, depending on the nature of the substrate. This method does not determine the true charging potential since the true binding energy of the adsorbed hydrocarbons is not known.

standards.iteh.ai Different sample charging potentials can occur on different areas on the surface, or at different depths, arising, for example, from sample inhomogeneities or non-uniform intensity of the incident-radiation flux.

#### https://standards.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-5.5 8591a14d7166/iso-18115-1-2010

afterglow

(GDS) luminescence of the decaying plasma present in a glow discharge device after complete cessation of the sustaining discharge power

# 5.6 altered layer

(particle bombardment) surface region of a material under particle bombardment where the chemical state or physical structure is modified by the effects of the bombardment

- For silicon bombarded by 4 keV O<sub>2</sub><sup>+</sup> at near-normal incidence, after sputtering for a sufficient time to reach a steady state, the surface is converted to stoichiometric SiO<sub>2</sub> to a depth of around 15 nm with lower oxygen concentrations at greater depths. At 2 keV, this is reduced to 7 nm, these thicknesses being approximately twice the projected range.
- The depth resolution in SIMS may be greater or smaller than the altered-layer thickness, depending on the analyte and bombarding-ion species.

# 5.7

# analyser blanking

(SIMS) action to prevent **secondary ions** from travelling through the mass spectrometer and being detected

This action is usually made by pulsing one of the relevant electrode potentials in time-of-flight mass spectrometers to deflect ions of a selected mass range in which intense peaks occur, so that those masses are not detected and thus do not cause unwanted detector saturation.

#### 5.8

# analysis area

(sample) two-dimensional region of a sample surface measured in the plane of that surface from which the entire analytical signal or a specified percentage of that signal is detected

# analysis area

(spectrometer) two-dimensional region of a sample **surface** at the analytical point but set in the plane at right angles to the spectrometer axis from which the entire analytical signal or a specified percentage of that signal is detected

#### 5.10

#### analysis volume

(sample) three-dimensional region of a sample from which the entire analysis signal or a specified percentage of that signal is detected

#### 5.11

# analysis volume

(spectrometer) three-dimensional region within the spectrometer from which the entire analytical signal or a specified percentage of that signal can be detected

#### 5.12

# angle, critical

(TXRF) glancing angle at which the sample matrix X-ray fluorescence, when plotted against the glancing angle, is at the first point of inflection

#### 5.13

# angle, glancing

angle between the incident beam and the average surface plane

Angle of incidence and glancing angle are complementary. NOTE

#### 5.14

# (standards.iteh.ai)

# angle lapping

sample preparation in which a sample is mechanically polished at an angle to the original surface

s.iteh.ai/catalog/standards/sist/1f58bff6-7fc6-472a-8b20-

cf. ball cratering, radial sectioning 8591a14d7166/iso-18115-1-2010

NOTE This angle may often be less than 1° so that depth information with respect to the original surface is transformed to lateral information.

## 5.15

# angle, magic

(XPS) angle at which the spectrometer entrance axis is aligned at 54,7° to the direction of the X-rays at the sample surface

NOTE At the magic angle, using the simple dipole theory for the angular distribution of the photoelectrons emitted from an atom irradiated by unpolarized X-rays, it is predicted that the intensity per unit solid angle is the same as the intensity that would be obtained if the scattering were isotropic.

#### 5.16

# angle of emission

# emission angle

angle between the trajectory of a particle or photon as it leaves a surface and the local or average surface normal

NOTE The particular surface normal needs to be specified.

## 5.17

# angle of incidence

# incidence angle

angle between the incident beam and the local or average surface normal

The particular surface normal, such as the surface normal to an elementary portion of a rough surface or the normal to the average surface plane, needs to be specified.