



Designation: C679 – 03(Reapproved 2009)<sup>ε1</sup>

## Standard Test Method for Tack-Free Time of Elastomeric Sealants<sup>1</sup>

This standard is issued under the fixed designation C679; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reapproval.

*This standard has been approved for use by agencies of the Department of Defense.*

<sup>ε1</sup> NOTE—The term “standard conditions was added to 3.1 in March 2009.

### 1. Scope

1.1 This test method covers a procedure for the determination of the tack-free time property of single- and multi-component *elastomeric sealants* commonly used for sealing, *caulking*, and *glazing* in buildings and related construction.

1.2 This test method is applicable to *self-leveling* and *non-sag* grades of *sealant*. Sealants requiring slight heating to facilitate extrusion from the cartridge or gun are also described by this test method.

NOTE 1—See Specification C920 for type and grade definitions.

1.3 The values stated in metric units are to be regarded as the standard. The values given in parentheses are provided for information purposes only.

1.4 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

NOTE 2—Currently, there is no ISO standard similar to this specification.

### 2. Referenced Documents

2.1 *ASTM Standards*:<sup>2</sup>

C717 Terminology of Building Seals and Sealants

C920 Specification for Elastomeric Joint Sealants

### 3. Terminology

3.1 *Definitions*—See Terminology C717 for definitions of the following terms used in this test method: caulking,

<sup>1</sup> This test method is under the jurisdiction of ASTM Committee C24 on Building Seals and Sealants and is the direct responsibility of Subcommittee C24.20 on General Test Methods.

Current edition approved Jan. 1, 2009. Published March 2009. Originally approved in 1971. Last previous edition approved in 2003 as C679 – 03. DOI: 10.1520/C0679-03R09E01.

<sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

compound, cure, elastomeric, glazing, non-sag sealant, sealant, self-leveling sealant, and standard conditions.

### 4. Summary of Test Method

4.1 The test consists of lightly touching a surface of a curing sealant with a polyethylene film at regular intervals until the sealant does not attach itself to the film and the film appears clean when peeled from the surface.

4.2 More specifically a strip of polyethylene film is placed on the surface of the curing sealant and a 30-g (1.06-oz) weight is placed on the film. The weight is left in place for 30 s, then removed and the polyethylene strip is removed and examined for sealant attachment to the film. The length of time from when the sealant was first applied and tooled into the template until the time the sealant is no longer picked up by the film is called tack-free time.

4.3 With some sealants, interpretation of the end point is confusing in that a very thin film of sealant or oil will transfer to the film. For consistency of data, record the point where the bulk sealant is no longer transferred to the plastic but ignore the very thin uniform film of sealant or the plasticizer transferred to the plastic test strip.

### 5. Significance and Use

5.1 The tack-free time is a measure of the surface cure time and may generally be correlated to a variety of useful parameters such as the time interval before the sealant (1) resists damage by touch or light surface contact, (2) resists job-site or airborne dirt pick-up, (3) resists impinging rainfall.

5.2 The tack-free time is sometimes used as an on-the-job quality assurance test. A quality product that is consistent and reproducible will generally fall within a maximum and minimum tack-free time.

5.3 This test for tack-free time can be used at any temperature and humidity. It is important that if a sealant will be used in a climate quite different than the standard conditions called out in this test method, then those conditions be used to test the sealant.