



**SLOVENSKI STANDARD**  
**oSIST prEN ISO 22017:2019**  
**01-september-2019**

---

**Kakovost vode - Navodilo za hitre meritve radioaktivnosti v nujnih primerih  
(ISO/DIS 22017:2019)**

Water quality - Guidance for rapid radioactivity measurements in nuclear or radiological emergency situation (ISO/DIS 22017:2019)

Wasserbeschaffenheit - Anleitung für Schnellverfahren zur Radioaktivitätsmessung (ISO/DIS 22017:2019)

Qualité de l'eau - Guide pour les mesurages rapides de radioactivité en situation d'urgence nucléaire ou radiologique (ISO/DIS 22017:2019)

**Ta slovenski standard je istoveten z: prEN ISO 22017**

---

**ICS:**

13.060.60	Preiskava fizikalnih lastnosti vode	Examination of physical properties of water
13.280	Varstvo pred sevanjem	Radiation protection
17.240	Merjenje sevanja	Radiation measurements

**oSIST prEN ISO 22017:2019**

**en,fr,de**



# DRAFT INTERNATIONAL STANDARD

## ISO/DIS 22017

ISO/TC 147/SC 3

Secretariat: **AFNOR**Voting begins on:  
**2019-07-09**Voting terminates on:  
**2019-10-01**

---

---

## Water quality - Guidance for rapid radioactivity measurements in nuclear or radiological emergency situation

*Qualité de l'eau — Guide pour les mesurages rapides de radioactivité en situation d'urgence nucléaire ou radiologique*

ICS: 13.060.60; 13.280; 17.240

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

[SIST EN ISO 22017:2021](https://standards.iteh.ai/catalog/standards/sist/726c3cc3-9f9b-4cf9-ac59-f43331357e2b/sist-en-iso-22017-2021)

<https://standards.iteh.ai/catalog/standards/sist/726c3cc3-9f9b-4cf9-ac59-f43331357e2b/sist-en-iso-22017-2021>

THIS DOCUMENT IS A DRAFT CIRCULATED FOR COMMENT AND APPROVAL. IT IS THEREFORE SUBJECT TO CHANGE AND MAY NOT BE REFERRED TO AS AN INTERNATIONAL STANDARD UNTIL PUBLISHED AS SUCH.

IN ADDITION TO THEIR EVALUATION AS BEING ACCEPTABLE FOR INDUSTRIAL, TECHNOLOGICAL, COMMERCIAL AND USER PURPOSES, DRAFT INTERNATIONAL STANDARDS MAY ON OCCASION HAVE TO BE CONSIDERED IN THE LIGHT OF THEIR POTENTIAL TO BECOME STANDARDS TO WHICH REFERENCE MAY BE MADE IN NATIONAL REGULATIONS.

RECIPIENTS OF THIS DRAFT ARE INVITED TO SUBMIT, WITH THEIR COMMENTS, NOTIFICATION OF ANY RELEVANT PATENT RIGHTS OF WHICH THEY ARE AWARE AND TO PROVIDE SUPPORTING DOCUMENTATION.

This document is circulated as received from the committee secretariat.

**ISO/CEN PARALLEL PROCESSING**



Reference number  
ISO/DIS 22017:2019(E)

© ISO 2019

# iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST EN ISO 22017:2021

<https://standards.iteh.ai/catalog/standards/sist/726c3cc3-9f9b-4cf9-ac59-f43331357e2b/sist-en-iso-22017-2021>



## **COPYRIGHT PROTECTED DOCUMENT**

© ISO 2019

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
CP 401 • Ch. de Blandonnet 8  
CH-1214 Vernier, Geneva  
Phone: +41 22 749 01 11  
Fax: +41 22 749 09 47  
Email: [copyright@iso.org](mailto:copyright@iso.org)  
Website: [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

	Page
<b>Foreword</b> .....	<b>iv</b>
<b>Introduction</b> .....	<b>v</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>2</b>
<b>4 Specificity of emergency measurement</b> .....	<b>4</b>
4.1 Objective of a specific rapid measurement.....	4
4.2 Routine screening levels versus intervention levels.....	4
4.3 Operational intervention levels (OILs) from EU, USA and IAEA.....	5
<b>5 Rapid measurements</b> .....	<b>5</b>
5.1 Adaptation of the methods used.....	5
5.2 Sampling.....	6
5.3 Rapid test methods.....	6
5.3.1 Pre-screening: identification of highest contaminated samples.....	6
5.3.2 Selection of the analytical strategy.....	6
5.3.3 Appropriate sample volumes and counting times related to intervention levels ...	9
5.3.4 Gross-alpha and gross-beta determination and gamma spectrometry.....	10
5.3.5 Specific separations for alpha emitters or pure beta emitters measurement.....	11
<b>6 Laboratory management to perform rapid measurements</b> .....	<b>11</b>
6.1 Radioprotection of laboratory staff.....	11
6.2 Samples management.....	12
6.3 Material and staff.....	12
6.4 Quality management.....	12
6.5 Expression of results and test report.....	13
<b>Annex A (informative) World Health Organization Screening for radionuclides in drinking water</b> .....	<b>14</b>
<b>Annex B (informative) Operational Intervention Levels (OILs) from EU, US and IAEA</b> .....	<b>15</b>
<b>Annex C (informative) Overview of different types of rapid measurements during a nuclear or radiological emergency</b> .....	<b>16</b>
<b>Annex D (informative) Example of a decision scheme for rapid measurements in the early phase</b> .....	<b>17</b>
<b>Bibliography</b> .....	<b>18</b>

## ISO/DIS 22017:2019(E)

### Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see [www.iso.org/directives](http://www.iso.org/directives)).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see [www.iso.org/patents](http://www.iso.org/patents)).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation on the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see the following URL: [www.iso.org/iso/foreword.html](http://www.iso.org/iso/foreword.html).

This document was prepared by Technical Committee ISO/TC 147/SC3, *Water quality, SC 3, Radioactivity measurements*.

SIST EN ISO 22017:2021

<https://standards.iteh.ai/catalog/standards/sist/726c3cc3-9f9b-4cf9-ac59-f43331357e2b/sist-en-iso-22017-2021>

## Introduction

Radioactivity from several naturally-occurring and anthropogenic sources is present throughout the environment. Thus, water bodies (e.g. surface waters, ground waters, sea waters) can contain radionuclides of natural, human made, or both origins:

- Natural radionuclides, including  $^{40}\text{K}$ ,  $^3\text{H}$ ,  $^{14}\text{C}$ , and those originating from the thorium and uranium decay series, in particular  $^{226}\text{Ra}$ ,  $^{228}\text{Ra}$ ,  $^{234}\text{U}$ ,  $^{238}\text{U}$ ,  $^{210}\text{Po}$  and  $^{210}\text{Pb}$  can be found in water for natural reasons (e.g. desorption from the soil and washoff by rain water) or can be released from technological processes involving naturally occurring radioactive materials (e.g. the mining and processing of mineral sands or phosphate fertilizers production and use);
- Human-made radionuclides such as transuranium elements (americium, plutonium, neptunium and curium),  $^3\text{H}$ ,  $^{14}\text{C}$ ,  $^{90}\text{Sr}$ , and some gamma emitting radionuclides can also be found in natural waters. Small quantities of these radionuclides may be discharged from nuclear fuel cycle facilities into the environment as the result of authorized routine releases. Some of these radionuclides used for medical and industrial applications are also released into the environment after use. Anthropogenic radionuclides are also found in waters as the result of past fallout contaminations resulting from the explosion in the atmosphere of nuclear devices and accidents such as those that occurred in Chernobyl and Fukushima.

Radionuclide activity concentration in water bodies can vary according to local geological characteristics and climatic conditions and can be locally and temporally enhanced by releases from nuclear installation during planned, existing, and emergency exposure situations[[1]]. Drinking-water may thus contain radionuclides at activity concentrations which could present a risk to human health.

The radionuclides present in liquid effluents are usually controlled before being discharged into the environment [[2]] and water bodies. Drinking waters are monitored for their radioactivity as recommended by the World Health Organization (WHO)[[3]] so that proper actions can be taken to ensure that there is no adverse health effect to the public. Following these international recommendations, national regulations usually specify radionuclide authorized concentration limits for liquid effluent discharged to the environment and radionuclide guidance levels for waterbodies and drinking waters for planned, existing, and emergency exposure situations. Compliance with these limits can be assessed using measurement results with their associated uncertainties as requested by ISO/IEC Guide 98-3 and ISO 5667-20[4].

Depending of the exposure situation, there are different limits and guidance levels that would result in an action to reduce health risk.

NOTE 1 The guidance level is the activity concentration with an intake of 2 l/d of drinking water for one year, that results in an effective dose of 0,1 mSv/a for members of the public. This is an effective dose that represents a very low level of risk that is not expected to give rise to any detectable adverse health effect[3].

In the event of a nuclear emergency, the WHO Codex Guideline Levels[5] indicates the activity concentrations corresponding to operational intervention levels.

NOTE 2 The Codex guidelines levels (GLs) apply to radionuclides contained in foods destined for human consumption and traded internationally, which have been contaminated following a nuclear or radiological emergency. These GLs apply to food after reconstitution or as prepared for consumption, i.e. not to dried or concentrated foods, and are based on an intervention exemption level of 1 mSv in a year for members of the public (infant and adult)[5].

Thus, the test method can be adapted so that the characteristic limits, decision threshold and detection limit, and the uncertainties ensure that the radionuclide activity concentration test results can be verified to be below the guidance levels required by a national authority for either planned-existing situations or an emergency situation[6][7].

Usually, the test methods can be adjusted to measure the activity concentration of the radionuclide(s) in either wastewaters before storage or in liquid effluents before being discharged to the environment.

**ISO/DIS 22017:2019(E)**

The test results will enable the plant/installation operator to verify that, before their discharge, wastewaters/liquid effluent radioactive activity concentrations do not exceed authorized limits.

The test methods described in this document for emergency exposure situations may also be used during planned, existing exposure situations as well as for wastewaters and liquid effluents with specific modifications that could change the overall uncertainty, detection limit, and threshold.

The test method(s) may be used for water samples after proper sampling, sample handling, and test sample preparation (see the relevant part of ISO 5667- series).

This document has been developed to answer the need of test laboratories carrying out these measurements that may be required by national authorities during a nuclear or radiological emergency exposure situation.

This document is one of a set of International Standards on test methods dealing with the measurement of the activity concentration of radionuclides in water samples.

The ISO standards produced for radioactivity measurements in water are detailed methods. In most cases, these methods have been used in laboratory practice for a number of years and the analytical characteristics have been documented. However, these methods are generally time consuming and require well trained analysts to carry them out.

Over the last years, an increasing need was recognized for the addition of guidance on the use of so-called “rapid methods”. The nuclear accident at Fukushima in March 2011 accentuated the need for these rapid measurements. During the initial stages of such incidents, decision makers have had to deal with taking protective measures for the population, such as sheltering, evacuation, and the distribution of iodine prophylaxis. It has been found that time is critical and limited for taking these protective measures.

(standards.iteh.ai)

SIST EN ISO 22017:2021

<https://standards.iteh.ai/catalog/standards/sist/726c3cc3-9f9b-4cf9-ac59-f43331357e2b/sist-en-iso-22017-2021>



# Water quality - Guidance for rapid radioactivity measurements in nuclear or radiological emergency situation

## 1 Scope

This document provides guidelines to enable testing laboratory using rapid test methods on all types of water samples that may be contaminated following a nuclear or radiological emergency situation:

- taking into account the specific context for the tests to be performed, e.g. an unknown and potentially unusual high level of contamination;
- using or adjusting, when possible, radioactivity test method implemented during routine situation to obtain a result rapidly or applying specific rapid test methods previously validated by the laboratory, e.g. for  $^{89}\text{Sr}$  determination;
- preparing the test laboratory to measure a large number of potentially contaminated samples.

The aim of this document is to ensure decision makers have reliable results needed to take actions on time and minimize the dose to the public.

Measurements are performed in order to minimize the risk for the public in checking the water quality of water supplies. For emergency situations, test results are compared to operational intervention levels.

Note Operational intervention levels (OILs) are derived from IAEA Safety Standards<sup>[13]</sup> or national authorities<sup>[5]</sup>.

A key can be to use the usual and routine methods in a faster manner. The goal of these rapid measurements is often to check an unusual radioactivity level in the test sample, to identify the radionuclides and their activity concentration levels and to establish compliance of the sampled water with intervention levels<sup>[21]</sup>. It should be noted that in such circumstances validation parameters are not always valid (impossible use of standard measuring geometries for gamma spectrometry...) and thus uncertainties associated with the test results may increase.

The first steps of the analytical approach is usually based on gross alpha and gross beta test methods considered as screening methods (adaptation of ISO 10704 and ISO 11704) and gamma spectrometry (adaptation of ISO 20042, ISO 10703 and ISO 19581). Then, when necessary<sup>[3]</sup>, test method standards for specific radionuclides are adapted and applied (for example,  $^{90}\text{Sr}$  measurement following ISO 13160) as proposed in [Annex A](#).

This document refers to a set of already published ISO standards. When appropriate, this document also refers to national standards or other publically available documents.

Screening techniques that can be carried out directly in the field are not part of this document.

## 2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 5667-1, *Water quality— Sampling — Part 1: Guidance on the design of sampling programmes and sampling techniques*

ISO 5667-3, *Water quality — Sampling — Part 3: Preservation and handling of water samples*

**ISO/DIS 22017:2019(E)**

ISO 9696, *Water quality — Gross alpha activity — Test method using thick source*

ISO 9697, *Water quality — Gross beta activity — Test method using thick source*

ISO 9698, *Water quality — Tritium — Test method using liquid scintillation counting*

ISO 10703, *Water quality — Determination of the activity concentration of radionuclides — Method by high resolution gamma-ray spectrometry*

ISO 10704, *Water quality — Gross alpha and gross beta activity — Test method using thin source deposit*

ISO 11704, *Water quality — Gross alpha and gross beta activity — Test method using liquid scintillation counting*

ISO 17025, *General requirements for the competence of testing and calibration laboratories*

ISO 13160, *Water quality — Strontium 90 and strontium 89 — Test methods using liquid scintillation counting or proportional counting*

ISO 13161, *Water quality — Measurement of polonium 210 activity concentration in water by alpha spectrometry*

ISO 13162, *Water quality — Determination of carbon 14 activity — Liquid scintillation counting method*

ISO 13163, *Water quality — Lead-210 — Test method using liquid scintillation counting*

ISO 13165-1, *Water quality — Radium-226 — Part 1: Test method using liquid scintillation counting*

ISO 13165-2, *Water quality — Radium-226 — Part 2: Test method using emanometry*

ISO 13165-3, *Water quality — Radium-226 — Part 3: Test method using coprecipitation and gamma-spectrometry*

ISO 13166, *Water quality — Uranium isotopes — Test method using alpha-spectrometry*

ISO 13167, *Water quality — Plutonium, americium, curium and neptunium — Test method using alpha spectrometry*

ISO 13168, *Water quality — Simultaneous determination of tritium and carbon 14 activities — Test method using liquid scintillation counting*

ISO 17294-2, *Water quality — Application of inductively coupled plasma mass spectrometry (ICP-MS) — Part 2: Determination of selected elements including uranium isotopes*

ISO 19581, *Measurement of radioactivity — Gamma emitting radionuclides — Rapid screening method using scintillation detector gamma-ray spectrometry*

ISO 20042, *Measurement of radioactivity — Gamma-ray emitting radionuclides — Generic test method using gamma-ray spectrometry*

**3 Terms and definitions**

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at <http://www.iso.org/obp>
- IEC Electropedia: available at <http://www.electropedia.org/>

### 3.1 emergency situation

non-routine situation or event that necessitates prompt action, primarily to mitigate a hazard or adverse consequences for human health and safety, quality of life, property or the environment

Note 1 to entry: This includes nuclear and radiological emergencies and conventional emergencies such as fires, release of hazardous chemicals, storms or earthquakes. It includes situations for which prompt action is warranted to mitigate the effects of a perceived hazard<sup>[7]</sup>.

### 3.2 intervention

any protective action or countermeasure aimed at reducing, or averting, human exposure to radiation during a nuclear or radiological emergency

### 3.3 operational intervention level

OIL

set level of a measurable quantity that corresponds to a generic criterion

[SOURCE: IAEA safety glossary 2016 Rev. Mod]

Note 1 to entry: OILs are calculated levels, measured by instruments or determined by laboratory analysis that corresponds to an intervention level or action level. These are typically expressed in terms of dose rates or of activity of radioactive material released, time integrated air activity concentrations, ground or surface concentrations, or activity concentrations of radionuclides in environmental, food or water samples. OILs are used immediately and directly (without further assessment) to determine the appropriate protective actions on the basis of an environmental measurement [IAEA GS-R-7 (2015) *Preparedness and Response for a Nuclear or Radiological Emergency General Safety Requirements (Jointly sponsored by FAO, IAEA, ICAO, ILO, IMO, INTERPOL, OECD/NEA, PAHO, CTBTO, UNEP, OCHA, WHO, WMO)*]<sup>[7]</sup>.

### 3.4 reference level

level of dose or risk, in emergency or existing controllable exposure situations, above which it is judged to be inappropriate to plan to allow exposures to occur, and below which optimisation of protection should be implemented

Note 1 to entry: The chosen value for a reference level depends upon the prevailing circumstances of the exposure under consideration<sup>[1]</sup>.

### 3.5 screening level

SL

value that takes into account the characteristics of the measuring equipment and the test method to guarantee that the test result and its uncertainty obtained are fit for purpose for comparison with the operational intervention levels (OILs)

Note 1 to entry: For example, when the screening levels are not exceeded so are the OILs and the food is considered safe for consumption. If the screening level is exceeded so is the OIL and consumption of non-essential food should be stopped, and essential food should be replaced or the people should be relocated if replacements are not available<sup>[8]</sup>.

### 3.6 intervention level

radiation dose above which a specific protective action is generally justified

### 3.7 iodine prophylaxis

administration of stable iodine to limit the uptake of inhaled/ingested radioactive iodine into the thyroid gland