



Designation: E999 – 15

Standard Guide for Controlling the Quality of Industrial Radiographic Film Processing¹

This standard is issued under the fixed designation E999; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This guide² establishes guidelines that may be used for the control and maintenance of industrial radiographic film processing equipment and materials. Effective use of these guidelines aid in controlling the consistency and quality of industrial radiographic film processing.

1.2 Use of this guide is limited to the processing of films for industrial radiography. This guide includes procedures for wet-chemical processes and dry processing techniques.

1.3 The necessity of applying specific control procedures such as those described in this guide is dependent, to a certain extent, on the degree to which a facility adheres to good processing practices as a matter of routine procedure.

1.4 If a nondestructive testing agency as described in Practice [E543](#) is used to perform the examination, the testing agency shall meet the requirements of Practice [E543](#).

1.5 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of federal and local codes prior to use.*

2. Referenced Documents

2.1 ASTM Standards:³

[E94](#) Guide for Radiographic Examination

[E543](#) Specification for Agencies Performing Nondestructive Testing

[E1079](#) Practice for Calibration of Transmission Densitometers

[E1254](#) Guide for Storage of Radiographs and Unexposed Industrial Radiographic Films

[E1316](#) Terminology for Nondestructive Examinations

2.2 *ISO Standards:*⁴

[ISO 11699-2](#) Nondestructive testing—Industrial Radiographic Film—Part 2: Control of film processing by means of reference values.

[ISO 18917](#) Photography—Determination of residual thio-sulfate and other related chemicals in processed photographic materials—Methods using iodine amylose, methylene blue, and silver sulfide

2.3 *ANSI Standards:*

[IT 2.26](#) Photography—Photographic Materials—Determination of Safelight Conditions⁴

3. Terminology

3.1 *Definitions*—For definitions of terms used in this guide, see Terminology [E1316](#).

4. Significance and Use

4.1 The provisions in this guide are intended to control the reliability or quality of the image development process only. The acceptability or quality of industrial radiographic films processed in this manner as well as the materials or products radiographed remain at the discretion of the user, or inspector, or both. It is further intended that this guide be used as an adjunct to and not a replacement for Guide [E94](#).

5. Chemical Mixing for Manual and Automatic Processes

5.1 Any equipment that comes in contact with processing solutions should be made of glass, hard rubber, polyethylene, PVC, enameled steel, stainless steel, or other chemically inert materials. This includes materials such as plumbing, mixing impellers, and the cores of filter cartridges. Do not allow materials such as tin, copper, steel, brass, aluminum, or zinc to come into contact with processing solutions. These materials can cause solution contamination that may result in film fogging or rapid oxidation.

5.2 Mixing Chemicals:

⁴ Available from American National Standards Institute (ANSI), 25 W. 43rd St., 4th Floor, New York, NY 10036, <http://www.ansi.org>.

¹ This guide is under the jurisdiction of ASTM Committee [E07](#) on Nondestructive Testing and is the direct responsibility of Subcommittee [E07.01](#) on Radiology (X and Gamma) Method.

Current edition approved June 1, 2015. Published June 2015. Originally approved in 1990. Last previous edition approved in 2010 as E999–10. DOI: 10.1520/E0999-15.

² For ASME Boiler and Pressure Vessel Code applications see related Specification SE-999 in Section II of that Code.

³ For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

5.2.1 Do not mix powdered chemicals in processor tanks, since undissolved particles may be left in the square corners of the tank. Mix solutions in separate containers made from materials specified in 5.1.

5.2.2 Carefully follow the manufacturer's package directions or formulas for mixing the chemicals. Start with the correct volume of water at the temperature specified in the instructions, and add chemicals in the order listed. During the mixing and use of radiographic film processing chemicals, be sure to observe all precautionary information on chemical containers and in instructions.

5.2.3 Proper mixing of chemicals can be verified with measurements of pH and specific gravity.

5.3 *Contamination of Solutions:*

5.3.1 Thoroughly clean all mixing equipment immediately after use to avoid contamination when the next solution is mixed. When mixing fixer from powder, make sure to add the powder carefully to the water in the mixing tank so fixer dust does not get into other processing solutions. When mixing any chemical, protect nearby tank solutions with floating lids and dust covers. The use of a vent hood is recommended as a safety precaution.

5.3.2 The water supply should either be de-ionized or filtered to 50 microns or better, so it is clean and sediment-free.

5.3.3 If large tanks are used for mixing, carefully mark the volume levels to be certain that volumes are correct.

5.3.4 Use separate mixers for developer solution and for fixer solution. If only one mixer is available, thoroughly rinse the mixer after each mix to avoid cross-contamination of chemicals. Use of impeller-type mixers provides rapid, thorough mixing. When positioning the impeller special caution should be taken in choosing angle and depth to minimize the amount of air being drawn into the solution. Over-mixing of the solutions can cause oxidation, especially with developers, and should be avoided. Rinse the shaft, impeller, and mounting clamp with water after use.

5.4 *Maintaining Equipment:*

5.4.1 Immediately clean all mixing equipment after use.

5.4.2 In addition to cleaning equipment immediately after use, wash any mixing apparatus that has been idle for a long period of time to eliminate dust and dirt that may have accumulated.

5.4.3 Processing hangers and tanks should be free of corrosion and chemical deposits. Encrusted deposits that accumulate in tanks, trays, and processing equipment which are difficult to remove by conventional cleaning, can be removed by using the specially formulated cleaning agents recommended by the chemical or equipment manufacturer.

6. Storage of Solutions

6.1 *In Original Containers*—Follow the manufacturer's storage and capacity recommendations packaged with the chemicals. Do not use chemicals that have been stored longer than recommended.

6.2 *In Replenisher or Process Tanks*—Wherever possible, protect solutions in tanks with floating lids and dust covers. In addition to preventing contaminants from entering solutions,

floating lids and dust covers help to minimize oxidation and evaporation from the surface of the solutions. Evaporation can concentrate solutions and reduce temperatures causing precipitation of some of the solution constituents.

6.2.1 Store replenisher solutions for small volume operations in airtight containers. The caps of these containers should be free of corrosion and foreign particles that could prevent a tight fit.

6.3 *Temperature*—Store all solutions at normal room temperature, between 40 to 80°F (4 to 27°C). Storing solutions, particularly developer, at elevated temperatures can produce rapid oxidation resulting in loss of activity and a tendency to stain the film. Storage at too low a temperature, particularly of fixer solutions, can cause some solutions to crystallize, and the crystals may not redissolve even with heating and stirring.

6.4 *Deterioration*—Radiographic film processing chemicals can deteriorate either with age or with usage. Carefully follow the manufacturer's recommendations for storage life and useful capacity. Discard processing solutions when the recommended number of films has been processed or the recommended storage life of the prepared solution has been reached, whichever occurs first.

6.5 *Contamination:*

6.5.1 Liquid chemicals are provided in containers with tight-fitting tops. To avoid contamination, never interchange the top of one container with another. For this reason, it is common practice for radiographic film processing chemicals manufacturers to color code the container tops, that is, red for developer and blue for fixer.

6.5.2 Clearly label replenisher storage tanks with the solution that they contain and use that container only with that solution. If more than one developer or one fixer formulation are being used, a separate replenisher tank should be dedicated to each chemical. Differences in developer or fixer formulations from one manufacturer to another may contaminate similar solutions.

7. Processing

7.1 *Manual Processing:*

7.1.1 Follow the temperature recommendations from the film or solution manufacturer. Check thermometers and temperature-controlling devices periodically to be sure the process temperatures are correct. Process temperatures should be checked at least once per shift. Keep the temperature of the stop (if used), fixer, and wash water within $\pm 5^\circ\text{F}$ ($\pm 3^\circ\text{C}$) of the developer temperature. An unprotected mercury-filled thermometer should never be used for radiographic film processing applications because accidental breakage could result in serious mercury contamination.

7.1.2 Control of processing solution temperature and immersion time relationships are instrumental considerations when establishing a processing procedure that will consistently produce radiographs of desired density and quality. The actual time and temperature relationships established are governed largely by the industrial radiographic films and chemicals used and should be within the limits of the manufacturer's recommendations for those materials. When determining the immersion time for each solution ensure that the draining time is