



Designation: D5608 – 16

Standard Practices for Decontamination of Sampling and Non Sample Contacting Equipment Used at Low Level Radioactive Waste Sites¹

This standard is issued under the fixed designation D5608; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope*

1.1 These practices cover the decontamination of sampling and non-sample contacting equipment used in the sampling of soils, soil gas, sludges, surface water and groundwater at waste sites known or suspected of containing low level radioactive wastes. It may also have application for decontamination of sampling and heavy construction equipment used during remediation activities.

1.2 This practice is applicable at sites where low level radioactive wastes are known or suspected to exist. This practice may also be applicable for the decontamination of equipment used in known or suspected transuranic, or mixed wastes when used by itself or in conjunction with Practice D5088.

1.3 Procedures are contained in this practice for the decontamination of equipment that comes into contact with the sample matrix (sample contacting equipment), and for ancillary equipment that has not contacted the sample, but may have become contaminated during use (non-contacting equipment). For sample contacting equipment there are four separate procedures (Procedure A through D) in Section 8. For non-contacting equipment, one procedure is presented as covered in Section 9.

1.4 The user is reminded of the importance of proper decontamination planning to minimize the amount of decontamination wastes generated and to reduce or eliminate the use of cleaning agents that are themselves hazardous materials. Quality Assurance/Quality Control (QA/QC) radiological surveys and samples that document decontamination effectiveness can be used to modify or enhance decontamination techniques.

1.5 This practice is applicable to most conventional sampling equipment constructed of metallic and hard, smooth

¹ This practice is under the jurisdiction of ASTM Committee D18 on Soil and Rock and is the direct responsibility of Subcommittee D18.21 on Groundwater and Vadose Zone Investigations.

Current edition approved Feb. 1, 2016. Published February 2016. Originally approved in 2001. Last previous edition approved in 2010 as D5608-10. DOI: 10.1520/D5608-16.

synthetic materials. Materials with rough or porous surfaces, or having a high sorption rate should not be used in radioactive waste sampling due to the difficulties with decontamination.

1.6 In those cases where sampling will be periodically performed, such as sampling of wells, consideration should be given to the use of dedicated sampling equipment if legitimate concerns exist for the production of undesirable or unmanageable waste byproducts, or both, during the decontamination of tools and equipment.

1.7 This practice does not address regulatory requirements for personnel protection or decontamination, or for the handling, labeling, shipping, or storing of wastes or samples. Specific radiological release requirements and limits must be determined by users in accordance with local, state and federal regulations.

1.8 Other jurisdictions may have equivalent requirements. For additional information in the United States, for example, see United States Department of Energy (DOE) 10 CFR Part 835 and U.S. Nuclear Regulatory Commission (NRC) 10 CFR Part 20.

1.9 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.10 *This practice offers an organized collection of information or a series of options and does not recommend a specific course of action. This document cannot replace education or experience and should be used in conjunction with professional judgement. Not all aspects of this practice may be applicable in all circumstances. This ASTM standard is not intended to represent or replace the standard of care by which the adequacy of a given professional service must be judged nor should this document be applied without consideration of a project's many unique aspects. The word "standard" in the title of this document means only that the document has been approved through the ASTM consensus process.*

1.11 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the*

*A Summary of Changes section appears at the end of this standard

responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Specific precautionary statements are given in Section 6.

2. Referenced Documents

2.1 ASTM Standards:²

D653 Terminology Relating to Soil, Rock, and Contained Fluids

D1193 Specification for Reagent Water

D5088 Practice for Decontamination of Field Equipment Used at Waste Sites

2.2 United States Code of Federal Regulations:³

10 CFR Part 20 Standards for Protection Against Radiation 10 CFR 60

10 CFR Part 835 Radiological Protection for Occupational Workers

2.3 Multi-Agency Radiation Survey and Site Investigation Manual (MARSSIM), Nureg-1575, Rev 1, EPA 402-R-97-016, Rev 1, DOE/EH-0624, Rev 1

ANSI/HPS N13.12 Surface and Volume Radioactivity—Standards for Clearance

3. Terminology

3.1 Definitions:

3.1.1 For definitions of general technical terms used within this practice refer to Terminology **D653**.

3.2 General Definitions Used in This Practice

3.2.1 *as low as reasonably achievable (ALARA)*—a process used for radiation protection to manage and control exposures (both individual and collective to the work force and to the general public) and releases of radioactive materials to the environment so that the levels are as low as is reasonable taking into account social, technical, economic, practical, and public policy consideration (from ANSI/HPS N13.12).

3.2.2 *contamination*—either fixed or removable radioactive materials in or on an item where it is not wanted.

3.2.2.1 *Discussion*—Radioactive materials in a glovebox, for example, are not contamination.

3.2.3 *mixed wastes*—wastes containing both radioactivity (as defined by the United States Atomic Energy Act of 1954 as amended) and quantities of United States Environmental Protection Agency Resource Conservation and Recovery Act (RCRA) listed wastes.

3.2.4 *radioactive waste*—waste containing radioactive elements or activation of negligible economic value, considering the cost of recovery or use.

3.3 Definitions of Terms Specific to This Standard:

3.3.1 *controlled area*—an area to which access is physically limited in order to protect individuals from exposure to radiation, contamination, hazardous materials or other hazards.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

³ Available from Superintendent of Documents, U.S. Government Printing Office, Washington, DC 20402.

3.3.1.1 *Discussion*—Controlled areas are intended to prevent the inadvertent access by establishing a boundary (fencing, walls, or other natural features). Exit from a controlled area may be controlled to prevent the spreading of contamination by decontamination processes (known as a decontamination path or zone) prior to personnel or equipment moving to the support zone.

3.3.2 *decontamination*—the process of removing or reducing to a known level undesirable physical, chemical, or radiological constituents from equipment.

3.3.2.1 *Discussion*—Decontamination of sample contacting equipment maximizes the representativeness of the physical, chemical, or radioactive analyses proposed for a given sample.

3.3.3 *non-contacting equipment*—equipment used in and around the sampling that may become contaminated, but that does not contact the sample at anytime.

3.3.3.1 *Discussion*—Examples would include drilling rigs, hand tools, drill rods, excavation equipment, or barrier materials.

3.3.4 *organic desorbing agents*—solvent rinse solutions such as isopropanol, acetone, hexane, or methanol.

3.3.5 *QC water (control rinse water)*—water having a known chemistry, free (below detection levels) of organic or radiological constituents.

3.3.5.1 *Discussion*—Deionized water of reagent grade is normally sufficient, such as ASTM D1193, Type IV.

3.3.6 *rinse water*—water having a known chemistry.

3.3.6.1 *Discussion*—Deionized or distilled water may be used when small quantities are required. When large quantities are required, potable water of a chemistry known to be free (below detection levels) of radioactive or chemical constituents can be used.

3.3.7 *sample contacting equipment*—equipment and tools that physically come in contact with a sample and that could allow cross-contamination from one sample to another.

3.3.7.1 *Discussion*—Examples include drive cylinders, bailers, sample handling, equipment, pumps, and sampling tubes.

3.3.8 *survey*—a radioactivity measurement with instrumentation to evaluate and assess the presence of radioactive materials or other sources of radioactivity under a specific set of conditions.

3.3.8.1 *Discussion*—Also known as frisking.

3.3.9 *wipe test*—a radiation detection test performed to determine the amount of removable radioactive material per 100 cm² surface area by wiping with a dry filter or soft absorbent paper with moderate pressure and then assessing the amount of radioactivity with an instrument of appropriate efficiency.

3.3.9.1 *Discussion*—A radiological survey and a wipe test is generally required for release of equipment from a radiological area to an uncontrolled area or for unrestricted use, (also known as swipe test).

3.3.10 *remediation control survey*—a type of survey that monitors the progress of remedial action by real-time measurement of areas being decontaminated to determine if efforts are effective and to guide further decontamination activities.

4. Summary of Practice

4.1 This practice provides guidance and details for the development of a site and sampling event specific decontamination plan for use in the decontamination of field equipment used during sampling or other activities in areas known, or suspected of containing low-level radioactive wastes. Four techniques or methods are provided, with the selection and use based on the type of contamination and the difficulty of removal.

4.2 Planning should include an evaluation of the costs of the decontamination process, including personnel exposures, waste disposal, personnel time, personal protective equipment (PPE) and other costs versus the use of less hazardous materials for decontamination, or avoidance of decontamination by the use of dedicated equipment, or the use of disposable equipment.

4.3 Approaches and procedures are provided for decontamination of two classifications of equipment, sample-contacting and non-contacting.

4.4 This practice includes the principles of ALARA and waste minimization as well as the protection of sample data quality.

5. Significance and Use

5.1 The primary objectives of work at low-level radioactive waste sites are the protection of personnel, prevention of the spread of contamination, minimization of additional wastes, protection of sample data quality, and the unconditional release of equipment used.

5.2 Preventing the contamination of equipment used at low-level radioactive waste sites and the decontamination of contaminated equipment are key aspects of achieving these goals.

5.3 This practice provides guidance in the planning of work to prevent contamination and when necessary, for the decontamination of equipment that has become contaminated. The benefits include:

5.3.1 Minimizing the spread of contamination within a site and preventing the spread outside of the work area.

5.3.2 Reducing the potential exposure of workers during the work and the subsequent decontamination of equipment.

5.3.3 Minimizing the amounts of additional wastes generated during the work, including liquid, or mixed wastes, including separation of the waste types, such as protective clothing, cleaning equipment, cleaning solutions, and protective wraps and drapes.

5.3.4 Improving the quality of sample data and reliability.

5.3.5 Selecting equipment based on total life-cycle costs counting labor, waste, containment, disposal, treatment, and additional analytical costs, such as using dedicated or disposable equipment rather than decontaminating between uses.

5.4 This practice may not be applicable to all low-level radioactive waste sites, such as sites containing low-level radioactive wastes mixed with chemical or reactive wastes. Field personnel, with assistance from trained radiological control professionals, should have the flexibility to modify the

decontamination procedures with due consideration for the sampling objectives, or if past experience supports alternative procedures for contamination protection or decontamination.

5.5 This practice does not address the monitoring, protection, or decontamination of personnel working with low-level radioactive wastes.

5.6 This practice does not address regulatory requirements that may control or restrict work, the need for permits or regulatory approvals, or the accumulation, handling, or disposal of generated wastes.

5.7 This practice does not set the release levels for equipment that has been decontaminated. Release levels are to be determined in advance in the QA/QC planning process. Guidance for release limits can be found in the reference documents.

5.8 This practice does not address the regulatory requirements for the handling, labeling, shipping, or storage of wastes or samples.

5.9 The decontamination process should be planned to use the least aggressive methods and materials to be used to minimize the generation of additional wastes while resulting in an acceptable decontamination while minimizing the generation of wastes. Studies have found that the use of chemicals can often be avoided, using pressure washes, steam cleaning, or the use of applied heat.

5.10 The practice of performing remediation control surveys can decrease the effort required to achieve decontamination release levels.

6. Hazards

6.1 Equipment decontamination activities involving radioactive constituents provide numerous opportunities for personnel contamination and radiation exposure, the uncontrolled spread of contamination, and the unnecessary generation of additional radioactive or mixed wastes.

6.2 Personnel involved in the decontamination of field equipment used in a known or suspected radiologically contaminated site must be trained and qualified in the work being performed and in emergency procedures.

6.3 Work performed in a known or suspected radiologically contaminated site should be under the continuous control of a trained Radiological Control Technician (also known by other titles including Radiation Safety Technicians, Health Physics Technician, or Radiation Protection Technicians).

6.4 Strict controls around the work area must be maintained at all times to prevent the access or egress of personnel, equipment, or samples to prevent unnecessary exposure, uncontrolled releases of contaminated equipment or personnel, and unnecessary contamination of equipment. The controls will include barriers, such as fences, temporary building, or other enclosures to prevent access or egress without proper monitoring and decontamination.

6.5 Personnel working in a radiologically contaminated area have the potential for receiving radiation exposure as well as internal and external contamination. Personnel should be

trained to a Site Specific Health and Safety Plan, radiation safety and other required training, such as hazardous waste worker training, which specifies the required training, personnel protection, and dosimetry equipment required.

6.6 Some decontamination solutions may be hazardous to humans, or may be incompatible with personal protective clothing normally worn. For example, organic solvents or acids may permeate or degrade protective clothing or equipment. Protective clothing worn during decontamination should be selected for wet work involving the specific chemicals and solutions to be used.

6.7 Chemicals and solutions used during decontamination may be hazardous. Personnel involved should be trained, have the appropriate PPE and respiratory protection, and have the appropriate first aid and response equipment. Personnel should be provided with Safety Data Sheets (SDSs) for the solutions or chemicals to be used. The shipping and handling of these materials may be regulated. Some of these materials are hazardous themselves and when used for decontamination will generate larger amounts of hazardous or mixed wastes that must be collected, containerized, stored, labeled, shipped, and disposed.

6.8 Some equipment will degrade or produce deleterious reactions when in contact with decontamination solutions. Equipment and decontamination solution compatibility and resistance should be considered when selecting equipment and the decontamination procedure.

6.9 Decontamination methods may be incompatible with hazardous substances being removed and cause reactions that produce heat, toxic fumes, or explosions. The potential for incompatible material reactions should be evaluated as a part of the decontamination process selection.

6.10 The use of steam or high pressure washers will expose personnel to the hazards of operation. Manufacturer's operating literature or manuals typically contain safety precautions for the use of the equipment and must be followed.

7. General Procedures

7.1 Adequate planning is required prior to activity in an area known or suspected to contain low-level radioactive or other wastes and contamination. The development of an equipment decontamination plan should be a part of the activity planning. All personnel involved in the work should be familiar with the plan and trained in the specific decontamination procedures. Work and decontamination planning should include the following:

7.1.1 The site location, conditions, known areas of surface and subsurface contamination.

7.1.2 The type, activity level, potential locations of mixed, chemical, or reactive contamination or wastes,

7.1.3 The location of other physical hazards, such as underground utilities, overhead powerlines, and existing waste storage locations.

7.1.4 Emergency responses plans, including emergency decontamination of personnel or equipment, site evacuation and accountability, and response to fire, explosion, or other situations that may occur.

7.1.5 Equipment required to prevent contamination, decontaminate equipment, contain spills, or store contaminated equipment.

7.1.6 Adequacy of monitoring and safety personnel and equipment for the anticipated work, during both normal or emergency conditions,

7.1.7 Assignment of responsibilities, including defining responsibilities for safety, quality, and the work processes being planned.

7.1.8 Establishing the work control area barriers, signage, and controls for personnel, tools, and equipment entering the work area, and the contamination release limits that will be required for equipment, samples, tools, personnel, and wastes to be released from the control area. Personnel and equipment access and release log requirements should be considered, along with requirements for various types of work control permits,

7.1.9 Establishing the decontamination location(s) for the various tools, equipment, samples and personnel equipment, including contamination reduction corridors and decontamination pads for large equipment such as backhoes, drilling rigs, or trucks and vehicles. The benefits of decontaminating equipment near the point of use should be weighed against the risks of transporting equipment to a central decontamination location and potentially spreading contamination.

7.1.10 Establishing a waste disposal plan for how the anticipated wastes will be stored, both temporarily and long-term, the anticipated means of disposal, storage, labeling, or manifesting, and the organizations and individuals who will be responsible. Evaluation of the need for, and benefits of the work or samples should be balanced against the costs and difficulty of handling the wastes that may be generated prior to performing any work.

7.1.11 Providing personnel and equipment resources for environmental monitoring requirements. These may include air monitoring or controls for airborne or windblown contamination, surface runoff controls, or other specific weather work restrictions, such as restricting or stopping work during or before expected windy or wet conditions.

7.1.12 Responsibilities and sequencing for the decontamination and removal of equipment and personnel, removal of barriers, storage of both solid and liquid wastes, and the return of the site to a pre-work condition.

7.1.13 Establishing the contamination levels that are acceptable for free release, or transfer to other contamination areas with controls. Regulations and other guides such as the MARSSIM provide requirements and guidance. Additional decontamination efforts should be employed only as needed to achieve the QA/QC objectives.

7.1.14 Identifying the records that will be required and assigning responsibilities for the completion, review, protection, and retention of records that will be generated during the work, including decontamination. Typical records include (but are not limited to): records of the survey equipment, survey equipment calibration and operational checks, process and effluent monitoring, environmental monitoring, tool and waste monitoring equipment, types and