



SLOVENSKI STANDARD

SIST EN 300 940 V5.16.1:2005

01-februar-2005

8 [[[HJb]`W] b]`h`Y`_ca i b]_UW`g_]`g]ghYa `fZuU&ZL!`Ja Ygb]_`nUa cV]b]`fUX]c`!
GdYWZ]_UW]UfYhY`d`Ugh]f] GA `\$('\$, žfUh`]WU) '%`%ž]nXUU% - * Ł

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile radio interface;
Layer 3 specification (GSM 04.08 version 5.16.1 Release 1996)

iteh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: **EN 300 940 Version 5.16.1**

SIST EN 300 940 V5.16.1:2005
<https://standards.iteh.ai/catalog/standards/sist/465c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005>

ICS:

33.070.01 Mobilni servisi na splošno Mobile services in general

SIST EN 300 940 V5.16.1:2005 en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST EN 300 940 V5.16.1:2005](https://standards.iteh.ai/catalog/standards/sist/463c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005)

<https://standards.iteh.ai/catalog/standards/sist/463c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005>

ETSI EN 300 940 V5.16.1 (2000-10)

European Standard (Telecommunications series)

**Digital cellular telecommunications system (Phase 2+);
Mobile radio interface;
Layer 3 specification
(GSM 04.08 version 5.16.1 Release 1996)**

iTeh STANDARD PREVIEW
(standards.iteh.ai)

GSM®
GLOBAL SYSTEM FOR
MOBILE COMMUNICATIONS

[SIST EN 300 940 V5.16.1:2005](https://standards.iteh.ai/catalog/standards/sist/463c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005)

<https://standards.iteh.ai/catalog/standards/sist/463c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005>



Reference

REN/TSGN-010408QR12

Keywords

Digital cellular telecommunications system,
Global System for Mobile communications (GSM)**ETSI**

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST EN 300 940 V5.16.1:2005<https://standards.iteh.ai/catalog/standards/sist/463c3e19-08a4-4156-8362-928593dd0b74/sist-en-300-940-v5-16-1-2005>

Important notice

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <http://www.etsi.org/tb/status/>

If you find errors in the present document, send your comment to:
editor@etsi.fr

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2000.
All rights reserved.

Contents

Intellectual Property Rights	20
Foreword.....	20
Introduction	21
0 Scope	22
0.1 Scope of the Technical Specification	22
0.2 Application to the interface structures.....	22
0.3 Structure of layer 3 procedures.....	22
0.4 Test procedures	22
0.5 Use of logical channels.....	22
0.6 Overview of control procedures	23
0.6.1 List of procedures	23
0.7 Applicability of implementations	25
1 References	25
2 Definitions and abbreviations.....	29
2.1 Random values	29
2.2 Vocabulary	29
3 Radio Resource management procedures.....	30
3.1 Overview/General	30
3.1.1 General.....	30
3.1.2 Services provided to upper layers.....	30
3.1.2.1 Idle mode	30
3.1.2.2 Dedicated mode.....	30
3.1.2.3 Group receive mode	31
3.1.2.4 Group transmit mode.....	31
3.1.3 Services required from data link and physical layers.....	31
3.1.4 Change of dedicated channels.....	31
3.1.4.1 Change of dedicated channels using SAPI = 0.....	31
3.1.4.2 Change of dedicated channels using other SAPIs than 0	32
3.1.4.3 Sequenced message transfer operation.....	32
3.1.4.3.1 Variables and sequence numbers.....	32
3.1.4.3.2 Procedures for the initiation, transfer execution and termination of the sequenced message transfer operation.....	32
3.1.5 Procedure for Service Request and Contention Resolution	33
3.2 Idle mode procedures	33
3.2.1 Mobile Station side	33
3.2.2 Network side.....	34
3.2.2.1 System information broadcasting	34
3.2.2.2 Paging	35
3.3 RR connection establishment	35
3.3.1 RR connection establishment initiated by the mobile station	35
3.3.1.1 Entering the dedicated mode : immediate assignment procedure	35
3.3.1.1.1 Permission to access the network	35
3.3.1.1.2 Initiation of the immediate assignment procedure.....	35
3.3.1.1.3 Answer from the network	36
3.3.1.1.4 Assignment completion	38
3.3.1.1.5 Abnormal cases	38
3.3.1.2 Entering the group transmit mode: uplink access procedure.....	39
3.3.1.2.1 Mobile station side	39
3.3.1.2.2 Network side.....	40
3.3.1.2.3 Abnormal cases	40
3.3.2 Paging procedure	40
3.3.2.1 Paging initiation by the network	40
3.3.2.2 Paging response.....	41

3.3.2.3	Abnormal cases	41
3.3.3	Notification procedure	42
3.3.3.1	Notification of a call.....	42
3.3.3.2	Joining a VGCS or VBS call.....	42
3.3.3.3	Reduced NCH monitoring mechanism.....	43
3.3.3.4	Notification response procedure.....	44
3.4	Procedures in dedicated mode and in group transmit mode	44
3.4.1	SACCH procedures.....	44
3.4.1.1	General	44
3.4.1.2	Measurement report	45
3.4.1.3	Extended measurement report \$(MAFA)\$.....	45
3.4.2	Transfer of messages and link layer service provision	45
3.4.3	Channel assignment procedure	46
3.4.3.1	Channel assignment initiation	46
3.4.3.2	Assignment completion.....	47
3.4.3.3	Abnormal cases	47
3.4.4	Handover procedure.....	48
3.4.4.1	Handover initiation.....	49
3.4.4.2	Physical channel establishment.....	50
3.4.4.2.1	Finely synchronized cell case	50
3.4.4.2.2	Non synchronized cell case	50
3.4.4.2.3	Pseudo-synchronized cell case	51
3.4.4.2.4	Pre-synchronized cell case.....	51
3.4.4.3	Handover completion	51
3.4.4.4	Abnormal cases	52
3.4.5	Frequency redefinition procedure.....	53
3.4.5.1	Abnormal cases.....	53
3.4.6	Channel mode modify procedure.....	53
3.4.6.1	Normal channel mode modify procedure.....	53
3.4.6.1.1	Initiation of the channel mode modify procedure.....	53
3.4.6.1.2	Completion of channel mode modify procedure.....	54
3.4.6.1.3	Abnormal cases	54
3.4.6.2	Channel mode modify procedure for a voice group call talker.....	54
3.4.6.2.1	Initiation of the channel mode modify procedure.....	54
3.4.6.2.2	Completion of mode change procedure.....	54
3.4.6.2.3	Abnormal cases	54
3.4.7	Ciphering mode setting procedure	54
3.4.7.1	Ciphering mode setting initiation.....	55
3.4.7.2	Ciphering mode setting completion	55
3.4.8	Additional channel assignment procedure	55
3.4.8.1	Additional assignment procedure initiation	56
3.4.8.2	Additional assignment procedure completion	56
3.4.8.3	Abnormal cases	56
3.4.9	Partial channel release procedure.....	56
3.4.9.1	Partial release procedure initiation.....	56
3.4.9.2	Abnormal cases	56
3.4.10	Classmark change procedure	57
3.4.11	Classmark interrogation procedure	57
3.4.11.1	Classmark interrogation initiation.....	57
3.4.11.2	Classmark interrogation completion	57
3.4.12	Indication of notifications and paging informations	57
3.4.13	RR connection release procedure.....	57
3.4.13.1	Normal release procedure	57
3.4.13.1.1	Channel release procedure initiation in dedicated mode and in group transmit mode	58
3.4.13.1.2	Abnormal cases	58
3.4.13.2	Radio link failure in dedicated mode	58
3.4.13.2.1	Mobile side.....	59
3.4.13.2.2	Network side.....	59
3.4.13.3	RR connection abortion in dedicated mode	59
3.4.13.4	Uplink release procedure in group transmit mode	59
3.4.13.5	Radio link failure in group transmit mode	59
3.4.13.5.1	Mobile side.....	60

3.4.13.5.2	Network side.....	60
3.4.14	Receiving a RR STATUS message by a RR entity.....	60
3.4.15	Group receive mode procedures	60
3.4.15.1	Mobile station side	60
3.4.15.1.1	Reception of the VGCS or VBS channel.....	60
3.4.15.1.2	Monitoring of downlink messages and related procedures.....	60
3.4.15.1.3	Uplink reply procedure.....	62
3.4.15.1.4	Leaving the group receive mode	62
3.4.15.2	Network side	63
3.4.15.2.1	Provision of messages on the VGCS or VBS channel downlink.....	63
3.4.15.2.2	Release of the VGCS or VBS Channels	63
3.4.15.3	Failure cases	64
3.4.16	Configuration change procedure.....	64
3.4.16.1	Configuration change initiation.....	64
3.4.16.2	Configuration change completion	64
3.4.16.3	Abnormal cases	64
3.4.17	Mapping of user data substreams onto timeslots in a multislot configuration.....	64
3.4.18	Handling of classmark information at band change.....	65
4	Elementary procedures for Mobility Management.....	65
4.1	General	65
4.1.1	Type of MM procedures	65
4.1.2	MM sublayer states.....	66
4.1.2.1	MM sublayer states in the mobile station.....	66
4.1.2.1.1	Main states.....	66
4.1.2.1.2	Substates of the MM IDLE state	70
4.1.2.2	The update Status	71
4.1.2.3	MM sublayer states on the network side.....	72
4.2	Behaviour in MM IDLE State	73
4.2.1	Primary Service State selection.....	74
4.2.1.1	Selection of the Service State after Power On.....	74
4.2.1.2	Other Cases	74
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.....	74
4.2.2.1	Service State, NORMAL SERVICE.....	75
4.2.2.2	Service State, ATTEMPTING TO UPDATE	75
4.2.2.3	Service State, LIMITED SERVICE.....	76
4.2.2.4	Service State, NO IMSI.....	76
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	76
4.2.2.6	Service State, SEARCH FOR PLMN	77
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	77
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE).....	77
4.2.3	Service state when back to state MM IDLE from another state.....	78
4.3	MM common procedures	78
4.3.1	TMSI reallocation procedure	78
4.3.1.1	TMSI reallocation initiation by the network.....	79
4.3.1.2	TMSI reallocation completion by the mobile station.....	79
4.3.1.3	TMSI reallocation completion in the network.....	79
4.3.1.4	Abnormal cases	79
4.3.2	Authentication procedure.....	80
4.3.2.1	Authentication request by the network.....	80
4.3.2.2	Authentication response by the mobile station.....	80
4.3.2.3	Authentication processing in the network	80
4.3.2.4	Ciphering key sequence number	81
4.3.2.5	Unsuccessful authentication.....	81
4.3.2.6	Abnormal cases	81
4.3.3	Identification procedure	82
4.3.3.1	Identity request by the network.....	82
4.3.3.2	Identification response by the mobile station.....	82
4.3.3.3	Abnormal cases	82
4.3.4	IMSI detach procedure.....	83
4.3.4.1	IMSI detach initiation by the mobile station.....	83
4.3.4.2	IMSI detach procedure in the network	83

4.3.4.3	IMSI detach completion by the mobile station.....	83
4.3.4.4	Abnormal cases	83
4.3.5	Abort procedure	83
4.3.5.1	Abort procedure initiation by the network	84
4.3.5.2	Abort procedure in the mobile station.....	84
4.3.6	MM information procedure.....	84
4.3.6.1	MM information procedure initiation by the network.....	84
4.3.6.2	MM information procedure in the mobile station	84
4.4	MM specific procedures	84
4.4.1	Location updating procedure	85
4.4.2	Periodic updating	85
4.4.3	IMSI attach procedure	86
4.4.4	Generic Location Updating procedure.....	86
4.4.4.1	Location updating initiation by the mobile station.....	86
4.4.4.1a	Network Request for Additional mobile station Capability Information	87
4.4.4.2	Identification request from the network.....	87
4.4.4.3	Authentication by the network	87
4.4.4.4	Ciphering mode setting by the network	87
4.4.4.5	Attempt Counter.....	87
4.4.4.6	Location updating accepted by the network.....	87
4.4.4.7	Location updating not accepted by the network.....	88
4.4.4.8	Release of RR connection after location updating	88
4.4.4.9	Abnormal cases on the mobile station side	89
4.4.4.10	Abnormal cases on the network side.....	90
4.5	Connection management sublayer service provision	90
4.5.1	MM connection establishment.....	91
4.5.1.1	MM connection establishment initiated by the mobile station.....	91
4.5.1.2	Abnormal cases	93
4.5.1.3	MM connection establishment initiated by the network	94
4.5.1.3.1	Mobile Terminating CM Activity.....	94
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$	95
4.5.1.4	Abnormal cases	95
4.5.1.5	MM connection establishment for emergency calls.....	95
4.5.1.6	Call re-establishment.....	96
4.5.1.6.1	Call re-establishment, initiation by the mobile station	96
4.5.1.6.2	Abnormal cases	97
4.5.1.7	Forced release during MO MM connection establishment	98
4.5.2	MM connection information transfer phase.....	99
4.5.2.1	Sending CM messages	99
4.5.2.2	Receiving CM messages	99
4.5.2.3	Abnormal cases	99
4.5.3	MM connection release.....	99
4.5.3.1	Release of associated RR connection.....	99
4.5.3.2	Uplink release in a voice group call.....	100
4.6	Receiving a MM STATUS message by a MM entity.....	100
5	Elementary procedures for circuit-switched Call Control.....	100
5.1	Overview	100
5.1.1	General.....	100
5.1.2	Call Control States.....	106
5.1.2.1	Call states at the mobile station side of the interface	106
5.1.2.1.1	Null (State U0)	106
5.1.2.1.2	MM Connection pending (U0.1)	106
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$	106
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$.....	106
5.1.2.1.2c	CC-Establishmentpresent (U0.4) \$(CCBS)\$.....	106
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$.....	106
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	106
5.1.2.1.3	Call initiated (U1).....	106
5.1.2.1.4	Mobile originating call proceeding (U3)	106
5.1.2.1.5	Call delivered (U4)	107
5.1.2.1.6	Call present (U6)	107

5.1.2.1.7	Call received (U7)	107
5.1.2.1.8	Connect Request (U8)	107
5.1.2.1.9	Mobile terminating call confirmed (U9).....	107
5.1.2.1.10	Active (U10).....	107
5.1.2.1.11	Disconnect request (U11)	107
5.1.2.1.12	Disconnect indication (U12).....	107
5.1.2.1.13	Release request (U19).....	107
5.1.2.1.14	Mobile originating modify (U26)	107
5.1.2.1.15	Mobile terminating modify (U27)	107
5.1.2.2	Network call states	107
5.1.2.2.1	Null (State N0)	108
5.1.2.2.2	MM connection pending (N0.1)	108
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$	108
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$.....	108
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$	108
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$	108
5.1.2.2.2e	Recall present (N0.6) \$(CCBS)\$	108
5.1.2.2.3	Call initiated (N1).....	108
5.1.2.2.4	Mobile originating call proceeding (N3)	108
5.1.2.2.5	Call delivered (N4).....	108
5.1.2.2.6	Call present (N6)	108
5.1.2.2.7	Call received (N7)	108
5.1.2.2.8	Connect request (N8).....	109
5.1.2.2.9	Mobile terminating call confirmed (N9).....	109
5.1.2.2.10	Active (N10).....	109
5.1.2.2.11	{Not used}	109
5.1.2.2.12	Disconnect indication (N12)	109
5.1.2.2.13	Release request (N19).....	109
5.1.2.2.14	Mobile originating modify (N26)	109
5.1.2.2.15	Mobile terminating modify (N27)	109
5.1.2.2.16	Connect Indication (N28)	109
5.2	Call establishment procedures	109
5.2.1	Mobile originating call establishment	110
5.2.1.1	Call initiation.....	110
5.2.1.2	Receipt of a setup message	111
5.2.1.3	Receipt of a CALL PROCEEDING message	112
5.2.1.4	Notification of progressing mobile originated call.....	112
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment.....	112
5.2.1.4.2	Call progress in the PLMN/ISDN environment	113
5.2.1.5	Alerting	113
5.2.1.6	Call connected.....	113
5.2.1.7	Call rejection.....	114
5.2.1.8	Transit network selection	114
5.2.1.9	Traffic channel assignment at mobile originating call establishment	114
5.2.1.10	Call queuing at mobile originating call establishment	114
5.2.2	Mobile terminating call establishment.....	115
5.2.2.1	Call indication	115
5.2.2.2	Compatibility checking	115
5.2.2.3	Call confirmation	115
5.2.2.3.1	Response to SETUP	115
5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	116
5.2.2.3.3	Call failure procedures	116
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	117
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment	117
5.2.2.5	Call accept.....	117
5.2.2.6	Active indication	117
5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	118
5.2.2.8	Call queuing at mobile terminating call establishment	118
5.2.2.9	User connection attachment during a mobile terminating call	118
5.2.3	Network initiated MO call \$(CCBS)\$	118
5.2.3.1	Initiation.....	118
5.2.3.2	CC-Establishment present.....	118

5.2.3.2.1	Recall Alignment Procedure.....	120
5.2.3.3	CC-Establishment confirmation.....	120
5.2.3.4	Recall present.....	121
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment.....	121
5.3	Signalling procedures during the "active" state.....	121
5.3.1	User notification procedure.....	121
5.3.2	Call rearrangements.....	121
5.3.3	Not used.....	122
5.3.4	Support of Dual Services.....	122
5.3.4.1	Service Description.....	122
5.3.4.2	Call establishment.....	122
5.3.4.2.1	Mobile Originating Establishment.....	122
5.3.4.2.2	Mobile Terminating Establishment.....	123
5.3.4.3	Changing the Call Mode.....	123
5.3.4.3.1	Initiation of in-call modification.....	124
5.3.4.3.2	Successful completion of in-call modification.....	124
5.3.4.3.3	Change of the channel configuration.....	124
5.3.4.3.4	Failure of in-call modification.....	124
5.3.4.4	Abnormal procedures.....	125
5.3.5	User initiated service level up- and downgrading.....	125
5.3.5.1	Initiation of service level up- and downgrading.....	125
5.3.5.2	Successful completion of service level up- and downgrading.....	126
5.3.5.3	Rejection of service level up- and downgrading.....	126
5.3.5.4	Time-out recovery.....	126
5.4	Call clearing.....	126
5.4.1	Terminology.....	126
5.4.2	Exception conditions.....	127
5.4.3	Clearing initiated by the mobile station.....	127
5.4.3.1	Initiation of call clearing.....	127
5.4.3.2	Receipt of a DISCONNECT message from the mobile station.....	127
5.4.3.3	Receipt of a RELEASE message from the network.....	128
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station.....	128
5.4.3.5	Abnormal cases.....	128
5.4.4	Clearing initiated by the network.....	128
5.4.4.1	Clearing when tones/announcements provided.....	128
5.4.4.1.1	Receipt of a DISCONNECT message with progress indicator #8 from the network.....	128
5.4.4.1.2	Expiry of timer T306.....	128
5.4.4.2	Clearing when tones/announcements not provided.....	129
5.4.4.2.1	Receipt of a DISCONNECT message without progress indicator or with progress indicator different from #8 from the network.....	129
5.4.4.2.2	Receipt of a RELEASE message from the mobile station.....	129
5.4.4.2.3	Abnormal cases.....	129
5.4.4.3	Completion of clearing.....	129
5.4.4.3.1	Abnormal cases.....	129
5.4.5	Clear collision.....	129
5.5	Miscellaneous procedures.....	130
5.5.1	In-band tones and announcements.....	130
5.5.2	Call collisions.....	130
5.5.3	Status procedures.....	130
5.5.3.1	Status enquiry procedure.....	130
5.5.3.2	Reception of a STATUS message by a CC entity.....	131
5.5.3.2.1	STATUS message with incompatible state.....	131
5.5.3.2.2	STATUS message with compatible state.....	131
5.5.4	Call re-establishment, mobile station side.....	131
5.5.4.1	Indication from the mobility management sublayer.....	131
5.5.4.2	Reaction of call control.....	131
5.5.4.3	Completion of re-establishment.....	131
5.5.4.4	Unsuccessful outcome.....	132
5.5.5	Call re-establishment, network side.....	132
5.5.5.1	State alignment.....	132
5.5.6	Progress.....	132
5.5.7	DTMF protocol control procedure.....	132

5.5.7.1	Start DTMF request by the mobile station	132
5.5.7.2	Start DTMF response by the network	133
5.5.7.3	Stop DTMF request by the mobile station	133
5.5.7.4	Stop DTMF response by the network.....	133
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station.....	133
6	Support of packet services.....	134
7	Examples of structured procedures	134
7.1	General	134
7.1.1	Paging request.....	134
7.1.2	Immediate assignment	135
7.1.3	Service request and contention resolution	135
7.1.4	Authentication.....	136
7.1.5	Ciphering mode setting.....	136
7.1.6	Transaction phase	136
7.1.6.1	Channel mode modify.....	136
7.1.7	Channel release.....	137
7.2	Abnormal cases	137
7.3	Selected examples	137
7.3.1	Location updating	138
7.3.2	Mobile originating call establishment.....	139
7.3.3	Mobile terminating call establishment.....	144
7.3.4	Call clearing.....	147
7.3.5	DTMF protocol control.....	148
7.3.6	Handover	149
7.3.7	In-call modification.....	151
7.3.8	Call re-establishment.....	152
7.3.9	Network initiated mobile originating call \$(CCBS)\$	153
8	Handling of unknown, unforeseen, and erroneous protocol data	158
8.1	General	158
8.2	Message too short.....	158
8.3	Unknown or unforeseen transaction identifier.....	158
8.4	Unknown or unforeseen message type.....	159
8.5	Non-semantic mandatory information element errors	160
8.5.1	Radio resource management	160
8.5.2	Mobility management	160
8.5.3	Call control	160
8.6	Unknown and unforeseen IEs in the non-imperative message part.....	161
8.6.1	IEs unknown in the message	161
8.6.2	Out of sequence IEs	161
8.6.3	Repeated IEs	161
8.7	Non-imperative message part errors.....	161
8.7.1	Syntactically incorrect optional IEs.....	161
8.7.2	Conditional IE errors	161
8.8	Messages with semantically incorrect contents.....	162
9	Message functional definitions and contents.....	162
9.1	Messages for Radio Resources management.....	163
9.1.1	Additional assignment	164
9.1.1.1	Mobile Allocation	165
9.1.1.2	Starting Time.....	165
9.1.2	Assignment command.....	165
9.1.2.1	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8).....	167
9.1.2.2	Description of the Second Channel.....	167
9.1.2.3	Mode of the Second Channel	167
9.1.2.4	Mobile Allocation and Frequency List, after the starting time.....	167
9.1.2.5	Starting Time.....	167
9.1.2.6	Reference cell frequency list	168
9.1.2.7	Cell Channel Description	168
9.1.2.8	Cipher Mode Setting	168
9.1.2.9	VGCS target mode Indication.....	168

9.1.2.10	Description of the multislot allocation	168
9.1.3	Assignment complete.....	169
9.1.4	Assignment failure.....	169
9.1.5	Channel mode modify.....	169
9.1.5.1	Channel Description.....	170
9.1.5.2	VGCS target mode Indication.....	170
9.1.6	Channel mode modify acknowledge.....	170
9.1.7	Channel release.....	171
9.1.7.1	Channel description and mobile allocation	171
9.1.7.2	Group Cipher Key Number	171
9.1.8	Channel request	171
9.1.9	Ciphering mode command.....	173
9.1.10	Ciphering mode complete.....	173
9.1.10.1	Mobile Equipment Identity	174
9.1.11	Classmark change	174
9.1.11.1	Additional Mobile Station Classmark Information	174
9.1.11.2	Mobile Station Classmark	174
9.1.12	Classmark enquiry	174
9.1.12a	[Spare]	175
9.1.12b	Configuration change command.....	175
9.1.12b.1	Description of the multislot allocation	175
9.1.12b.2	Mode of Channel Set "X" ($1 \leq X \leq 8$).....	175
9.1.12c	Configuration change acknowledge.....	176
9.1.12d	Configuration change reject.....	176
9.1.13	Frequency redefinition.....	176
9.1.13.1	Cell Channel Description	177
9.1.14	Handover access.....	177
9.1.15	Handover command.....	177
9.1.15.1	Synchronization Indication.....	179
9.1.15.2	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" ($2 \leq X \leq 8$).....	179
9.1.15.3	Description of the Second Channel.....	179
9.1.15.4	Mode of the Second Channel.....	179
9.1.15.5	Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time.	180
9.1.15.6	Starting Time.....	180
9.1.15.7	Reference cell frequency list.....	181
9.1.15.8	Real Time Difference.....	181
9.1.15.9	Timing Advance.....	181
9.1.15.10	Cipher Mode Setting	181
9.1.15.11	VGCS target mode indication	181
9.1.15.12	Description of the multislot allocation	181
9.1.16	Handover complete	182
9.1.16.1	Mobile Observed Time Difference	182
9.1.17	Handover failure	182
9.1.18	Immediate assignment	182
9.1.18.1	Mobile Allocation	183
9.1.18.2	Starting Time.....	183
9.1.18.3	IA Rest Octets (Frequency parameters, before time)	183
9.1.19	Immediate assignment extended	184
9.1.19.1	Unnecessary IEs	184
9.1.19.2	Mobile Allocation	184
9.1.19.3	Starting Time.....	185
9.1.19.4	Maximum message length.....	185
9.1.19.5	IAX Rest Octets	185
9.1.20	Immediate assignment reject.....	185
9.1.20.1	Use of the indexes	186
9.1.20.2	Filling of the message	186
9.1.20.3	IAR Rest Octets	186
9.1.21	Measurement report.....	186
9.1.21a	Notification/FACCH.....	186
9.1.21a.1	Spare	188
9.1.21a.2	Spare	188

9.1.21a.3	Spare	188
9.1.21a.4	Spare	188
9.1.21b	Notification/NCH	188
9.1.21b.1	Spare	188
9.1.21b.2	Spare	188
9.1.21c	Spare	188
9.1.21d	Notification response	189
9.1.22	Paging request type 1	189
9.1.22.1	Unnecessary IE	190
9.1.22.2	Channels needed for Mobiles 1 and 2	190
9.1.22.3	Mobile Identities	190
9.1.22.4	P1 Rest Octets	190
9.1.23	Paging request type 2	190
9.1.23.1	Channels needed for Mobiles 1 and 2	190
9.1.23.2	Mobile Identity 3	191
9.1.23.3	P2 Rest Octets	191
9.1.24	Paging request type 3	191
9.1.24.1	Channels needed for Mobiles 1 and 2	191
9.1.24.2	P3 Rest Octets	191
9.1.25	Paging response	192
9.1.25.1	Mobile Station Classmark	192
9.1.26	Partial release	192
9.1.26.1	Channel Description	192
9.1.27	Partial release complete	193
9.1.28	Physical information	193
9.1.29	RR Status	193
9.1.30	Synchronization channel information	194
9.1.31	System information Type 1	194
9.1.32	System information type 2	195
9.1.33	System information type 2bis	195
9.1.34	System information type 2ter	196
9.1.35	System information type 3	197
9.1.36	System information type 4	197
9.1.36.1	CBCH Channel description	198
9.1.36.2	CBCH Mobile Allocation	198
9.1.36.3	SI 4 Rest Octets	198
9.1.37	System information type 5	198
9.1.38	System information type 5bis	199
9.1.39	System information type 5ter	199
9.1.40	System information type 6	200
9.1.40.1	Cell Identity	200
9.1.40.2	Location Area Identification	201
9.1.40.3	Cell Options	201
9.1.40.4	NCC permitted	201
9.1.41	System information type 7	201
9.1.42	System information type 8	201
9.1.43	System information Type 9	202
9.1.44	Talker indication	202
9.1.45	Uplink access	203
9.1.46	Uplink busy	203
9.1.47	Uplink free	204
9.1.48	Uplink release	204
9.1.49	VGCS uplink grant	205
9.1.50	System information type 10 \$(ASCII)\$	205
9.1.51	EXTENDED MEASUREMENT ORDER \$(MAFA)\$	206
9.1.52	Extended measurement report \$(MAFA)\$	206
9.2	Messages for mobility management	207
9.2.1	Authentication reject	207
9.2.2	Authentication request	208
9.2.3	Authentication response	208
9.2.4	CM Re-establishment request	209
9.2.4.1	Location area identification	209

9.2.4.2	Mobile Station Classmark	209
9.2.5	CM service accept.....	209
9.2.5a	CM service prompt \$(CCBS)\$.....	210
9.2.6	CM service reject.....	210
9.2.7	CM service abort.....	211
9.2.8	Abort.....	211
9.2.9	CM service request	211
9.2.9.1	Mobile Station Classmark	212
9.2.9.2	Priority	212
9.2.10	Identity request	212
9.2.11	Identity response.....	213
9.2.12	IMSI detach indication.....	213
9.2.12.1	Mobile Station Classmark	213
9.2.13	Location updating accept	213
9.2.13.1	Follow on proceed.....	214
9.2.14	Location updating reject	214
9.2.15	Location updating request.....	214
9.2.15.1	Location area identification.....	215
9.2.15.2	Mobile Station Classmark	215
9.2.15a	MM information	215
9.2.15a.1	Full name for network.....	215
9.2.15a.2	Short name for network.....	216
9.2.15a.3	Network time zone	216
9.2.15a.4	Universal time and time zone.....	216
9.2.16	MM Status	216
9.2.17	TMSI reallocation command	216
9.2.18	TMSI reallocation complete.....	217
9.2.19	MM Null.....	217
9.3	Messages for circuit-switched call control.....	217
9.3.1	Alerting.....	218
9.3.1.1	Alerting (network to mobile station direction).....	218
9.3.1.1.1	Facility.....	219
9.3.1.1.2	Progress indicator.....	219
9.3.1.1.3	User-user	219
9.3.1.2	Alerting (mobile station to network direction).....	219
9.3.1.2.1	Facility.....	220
9.3.1.2.2	User-user	220
9.3.1.2.3	SS version.....	220
9.3.2	Call confirmed	220
9.3.2.1	Repeat indicator	221
9.3.2.2	Bearer capability 1 and bearer capability 2	221
9.3.2.3	Cause.....	221
9.3.2.4	CC Capabilities	221
9.3.3	Call proceeding	221
9.3.3.1	Repeat indicator	222
9.3.3.2	Bearer capability 1 and bearer capability 2	222
9.3.3.3	Facility	222
9.3.3.4	Progress Indicator	222
9.3.3.5	Priority granted	222
9.3.4	Congestion control.....	222
9.3.4.1	Cause.....	223
9.3.5	Connect.....	223
9.3.5.1	Connect (network to mobile station direction).....	223
9.3.5.1.1	Facility.....	224
9.3.5.1.2	Progress indicator.....	224
9.3.5.1.3	User-user	224
9.3.5.2	Connect (mobile station to network direction).....	224
9.3.5.2.1	Facility.....	224
9.3.5.2.2	User-user	224
9.3.5.2.3	SS version.....	224
9.3.6	Connect acknowledge.....	225
9.3.7	Disconnect	225

9.3.7.1	Disconnect (network to mobile station direction)	225
9.3.7.1.1	Facility	225
9.3.7.1.2	Progress indicator	226
9.3.7.1.3	User-user	226
9.3.7.1.4	Allowed actions \$(CCBS)\$	226
9.3.7.2	Disconnect (mobile station to network direction)	226
9.3.7.2.1	Facility	226
9.3.7.2.2	User-user	226
9.3.7.2.3	SS version	226
9.3.8	Emergency setup	227
9.3.8.1	Bearer capability	227
9.3.9	Facility	227
9.3.9.1	Facility (network to mobile station direction)	227
9.3.9.2	Facility (mobile station to network direction)	228
9.3.9.2.1	SS version	228
9.3.10	Hold	228
9.3.11	Hold Acknowledge	229
9.3.12	Hold Reject	229
9.3.13	Modify	229
9.3.13.1	Low layer compatibility	230
9.3.13.2	High layer compatibility	230
9.3.13.3	Reverse call setup direction	230
9.3.14	Modify complete	230
9.3.14.1	Low layer compatibility	231
9.3.14.2	High layer compatibility	231
9.3.14.3	Reverse call setup direction	231
9.3.15	Modify reject	231
9.3.15.1	Low layer compatibility	231
9.3.15.2	High layer compatibility	231
9.3.16	Notify	231
9.3.17	Progress	232
9.3.17.1	User-user	232
9.3.17a	CC-Establishment \$(CCBS)\$	232
9.3.17a.1	Setup container	233
9.3.17b	CC-Establishment confirmed \$(CCBS)\$	233
9.3.17b.1	Repeat indicator	233
9.3.17b.2	Bearer capability 1 and bearer capability 2	234
9.3.17b.3	Cause	234
9.3.18	Release	234
9.3.18.1	Release (network to mobile station direction)	234
9.3.18.1.1	Cause	234
9.3.18.1.2	Second cause	234
9.3.18.1.3	Facility	234
9.3.18.1.4	User-user	235
9.3.18.2	Release (mobile station to network direction)	235
9.3.18.2.1	Cause	235
9.3.18.2.2	Second cause	235
9.3.18.2.3	Facility	235
9.3.18.2.4	User-user	235
9.3.18.2.5	SS version	236
9.3.18a	Recall \$(CCBS)\$	236
9.3.18a.1	Recall Type	236
9.3.18a.2	Facility	236
9.3.19	Release complete	236
9.3.19.1	Release complete (network to mobile station direction)	236
9.3.19.1.1	Cause	237
9.3.19.1.2	Facility	237
9.3.19.1.3	User-user	237
9.3.19.2	Release complete (mobile station to network direction)	237
9.3.19.2.1	Cause	238
9.3.19.2.2	Facility	238
9.3.19.2.3	User-user	238