



SLOVENSKI STANDARD SIST ETS 300 599 E1:2003

01-december-2003

Evropski digitalni celil'ni telekomunikacijski sistem (faza 2) ň Specifikacija dela za mobilne aplikacije (MAP) (GSM 09.02)

European digital cellular telecommunications system (Phase 2); Mobile Application Part (MAP) specification (GSM 09.02)

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: ~~SIST ETS 300 599 E1:2003~~ ETS 300 599 Edition 1
<https://standards.iteh.ai/catalog/standards/sist/904cc74e-9701-490e-8d65-a571b5c025ae/sist-ets-300-599-e1-2003>

ICS:

33.070.50	Globalni sistem za mobilno telekomunikacijo (GSM)	Global System for Mobile Communication (GSM)
-----------	---	--


SIST ETS 300 599 E1:2003

en

iTeh STANDARD PREVIEW **(standards.iteh.ai)**

SIST ETS 300 599 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/904ce74e-9701-490e-8d65-a571b5c025ae/sist-ets-300-599-e1-2003>



EUROPEAN TELECOMMUNICATION STANDARD

ETS 300 599

February 1995

Source: ETSI TC-SMG

Reference: DE/SMG-030902/P

ICS: 33.060.30

Key words: European digital cellular telecommunications, Global System for Mobile communications (GSM)

iTeh STANDARD PREVIEW
European digital cellular telecommunications system (Phase 2);
Mobile Application Part (MAP) specification
(GSM 09.02)

<https://standards.iteh.ai/catalog/standards/sist/ets-300-599-e1-2003>
<https://standards.iteh.ai/catalog/standards/sist/ets-300-599-e1-2003>

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

X.400: c=fr, a=atlas, p=etsi, s=secretariat - **Internet:** secretariat@etsi.fr

Tel.: +33 92 94 42 00 - **Fax:** +33 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1995. All rights reserved.

iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST ETS 300 599 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/904ce74e-9701-490e-8d65-a571b5c025ae/sist-ets-300-599-e1-2003>

Contents

Foreword	19
1 General	21
1.1 Scope	21
1.2 Normative references.	21
1.3 Definitions and abbreviations	27
2 Configuration of the mobile network	29
2.1 The entities of the mobile system	29
2.1.1 The Home Location Register (HLR).	29
2.1.2 The Visitor Location Register (VLR).	29
2.1.3 The Mobile-services Switching Centre (MSC)	30
2.1.4 The Base Station System (BSS).	30
2.1.5 The Gateway MSC (GMSC).	30
2.1.6 The SMS Gateway MSC.	30
2.1.7 The SMS Interworking MSC.	30
2.1.8 The Equipment Identity Register (EIR)	30
2.2 Configuration of a Public Land Mobile Network (PLMN)	31
2.3 Interconnection between PLMNs	31
2.4 The interfaces within the mobile service.	31
2.4.1 Interface between the HLR and the VLR (D-interface)	31
2.4.2 [Spare]	31
2.4.3 Interface between the VLR and its associated MSC(s) (B-interface)	31
2.4.4 Interface between VLRs (G-interface).	31
2.4.5 Interface between the HLR and the MSC (C-interface).	32
2.4.6 Interface between MSCs (E-interface).	32
2.4.7 Interface between the MSC and Base Station Systems (A-interface)	32
2.4.8 Interface between MSC and EIR (F-interface)	32
2.5 Splitting of the data storage	32
3 Overload and compatibility overview.	35
3.1 Overload control	35
3.1.1 Overload control for MSC (outside MAP)	35
3.1.2 Overload control for MAP entities	35
3.1.3 Congestion control for Signalling System No. 7.	38
3.2 Compatibility	38
3.2.1 General	38
3.2.2 Strategy for selecting the Application Context (AC) version	38
3.2.2.1 Proposed method.	38
3.2.2.2 Managing the version look-up table	39
3.2.2.3 Optimizing the method	40
4 Requirements concerning the use of SCCP and TC	41
4.1 Use of SCCP	41
4.1.1 SCCP Class	41
4.1.2 Sub-System Number (SSN)	41
4.1.3 SCCP addressing	41
4.1.3.1 Introduction	41
4.1.3.2 The Mobile-services Switching Centre (MSC).	43
4.1.3.2.1 MSC interaction during handover	43
4.1.3.2.2 MSC for short message routing	43
4.1.3.3 The Home Location Register (HLR)	43
4.1.3.3.1 During call set-up.	43
4.1.3.3.2 Before location updating completion.	44

	4.1.3.3.3	After location updating completion	44
	4.1.3.3.4	VLR restoration	45
	4.1.3.4	The Visitor Location Register (VLR)	45
	4.1.3.4.1	Inter-VLR information retrieval	45
	4.1.3.4.2	HLR request	45
	4.1.3.5	The Interworking MSC (IWMSC) for Short Message Service	45
	4.1.3.6	The Equipment Identity Register (EIR)	45
	4.1.3.7	Summary table.	46
4.2	Use of TC		47
5	General on MAP services		49
5.1	Terminology and definitions.		49
5.2	Modelling principles		49
5.3	Common MAP services		50
	5.3.1	MAP-OPEN service	51
	5.3.2	MAP-CLOSE service	54
	5.3.3	MAP-DELIMITER service.	54
	5.3.4	MAP-U-ABORT service	55
	5.3.5	MAP-P-ABORT service	56
	5.3.6	MAP-NOTICE service.	58
5.4	Sequencing of services		58
5.5	General rules for mapping of services onto TC		60
	5.5.1	Mapping of common services.	60
	5.5.2	Mapping of user specific services.	62
5.6	Definition of parameters.		62
	5.6.1	Common parameters	64
		5.6.1.1	Invoke Id
		5.6.1.2	Linked Id
		5.6.1.3	Provider error
		5.6.1.4	User error
	5.6.2	Numbering and identification parameter	68
		5.6.2.1	MSI
		5.6.2.2	TMSI
		5.6.2.3	IMEI
		5.6.2.4	Previous location area Id
		5.6.2.5	Stored location area Id.
		5.6.2.6	Current location area Id
		5.6.2.7	Target location area Id.
		5.6.2.8	Target cell Id
		5.6.2.9	[Spare]
		5.6.2.10	Originating entity number
		5.6.2.11	MSC number.
		5.6.2.12	Target MSC number.
		5.6.2.13	HLR number
		5.6.2.14	VLR number
		5.6.2.15	HLR Id
		5.6.2.16	LMSI
		5.6.2.17	MS ISDN
		5.6.2.18	OMC Id.
		5.6.2.19	Roaming number.
		5.6.2.20	[Spare]
		5.6.2.21	Handover number
		5.6.2.22	Forwarded-to number
		5.6.2.23	Forwarded-to subaddress
		5.6.2.24	Called number
		5.6.2.25	Calling number.
		5.6.2.26	Originally dialled number
		5.6.2.27	Service centre address
		5.6.2.28	Zone Code

	5.6.2.29	MSIsdn-Alert	70
5.6.3		Subscriber management parameters	70
	5.6.3.1	Category	70
	5.6.3.2	Equipment status	70
	5.6.3.3	Bearer service.	70
	5.6.3.4	Teleservice	70
	5.6.3.5	Basic Service Group	70
	5.6.3.6	GSM bearer capability	70
	5.6.3.7	Subscriber Status.	70
	5.6.3.8	CUG Outgoing Access indicator	71
	5.6.3.9	Operator Determined Barring General Data.	71
	5.6.3.10	ODB HPLMN Specific Data	71
	5.6.3.11	Regional Subscription Data	71
	5.6.3.12	Regional Subscription Response	71
	5.6.3.13	Roaming Restriction Due To Unsupported Feature.	71
5.6.4		Supplementary services parameters	72
	5.6.4.1	SS-Code	72
	5.6.4.2	SS-Status	72
	5.6.4.3	SS-Data.	72
	5.6.4.4	Override Category	72
	5.6.4.5	CLI Restriction Option	73
	5.6.4.6	Forwarding Options.	73
	5.6.4.7	No reply condition timer	73
	5.6.4.8	CUG info	73
	5.6.4.9	CUG subscription.	73
	5.6.4.10	CUG interlock.	73
	5.6.4.11	CUG index	73
	5.6.4.12	CUG feature.	74
	5.6.4.13	Inter CUG options	74
	5.6.4.14	Intra CUG restrictions.	74
	5.6.4.15	Forwarding information.	74
	5.6.4.16	Forwarding feature.	75
	5.6.4.17	Forwarding data.	75
	5.6.4.18	Call barring information.	75
	5.6.4.19	Call barring feature	75
	5.6.4.20	New password	75
	5.6.4.21	Current password.	75
	5.6.4.22	Guidance information.	76
	5.6.4.23	[Spare].	76
	5.6.4.24	SS-Info	76
	5.6.4.25-5.6.4.35	[Spare].	76
	5.6.4.36	USSD Data Coding Scheme	76
	5.6.4.37	USSD String	76
5.6.5		Call parameters.	77
	5.6.5.1	Call reference.	77
5.6.6		Radio parameters	77
	5.6.6.1-5.6.6.6	[Spare]	77
	5.6.6.7	HO-Number Not Required	77
5.6.7		Authentication parameters.	77
	5.6.7.1	Authentication set list.	77
	5.6.7.2	Rand.	77
	5.6.7.3	Sres	77
	5.6.7.4	Kc	77
	5.6.7.5	[Spare].	77
	5.6.7.6	Cksn.	77
	5.6.7.7	Ciphering mode.	77
5.6.8		Short message parameters	78
	5.6.8.1	SM-RP-DA	78
	5.6.8.2	SM-RP-OA	78
	5.6.8.3	MWD status.	78

iTeh STANDARD PREVIEW
(standards.ton.ai)

<https://standards.ton.ai/catalog/standards/sist/5946374e-9701-490e-8d65-9371b5c025ae/sist-ets-300-599-e1-2003>

	5.6.8.4	SM-RP-UI	78
	5.6.8.5	SM-RP-PRI.	78
	5.6.8.6	SM Delivery Outcome	78
	5.6.8.7	More Messages To Send	78
	5.6.8.8	Alert Reason	79
5.6.9		Access and signalling system related parameters.	79
	5.6.9.1	BSS-apdu	79
	5.6.9.2	CM service type	79
	5.6.9.3	Access connection status	79
	5.6.9.4	External Signal Information	79
	5.6.9.5	Access signalling information	79
	5.6.9.6	Location update type.	79
	5.6.9.7	Protocol ID	80
	5.6.9.8	Network signal information	80
5.6.10		System operations parameters	81
	5.6.10.1	Network resources.	81
	5.6.10.2	Trace reference	81
	5.6.10.3	Trace type	81
5.7		Representation of a list of a basic parameter in service-primitives	81
6		Mobility services	83
6.1		Location management services.	83
6.1.1		MAP_UPDATE_LOCATION_AREA service	83
	6.1.1.1	Definition	83
	6.1.1.2	Service primitives	83
	6.1.1.3	parameter definitions and use.	83
6.1.2		MAP_UPDATE_LOCATION service	85
	6.1.2.1	Definition	85
	6.1.2.2	Service primitives	85
	6.1.2.3	Parameter definitions and use.	85
6.1.3		MAP_CANCEL_LOCATION service	87
	6.1.3.1	Definition	87
	6.1.3.2	Service primitives	87
	6.1.3.3	Parameter definitions and use.	87
6.1.4		MAP_SEND_IDENTIFICATION service	88
	6.1.4.1	Definition	88
	6.1.4.2	Service primitives	88
	6.1.4.3	Parameter definitions and use.	88
6.1.5		MAP_DETACH_IMSI service	89
	6.1.5.1	Definition	89
	6.1.5.2	Service primitives	89
	6.1.5.3	Parameter definitions and use.	89
6.1.6		MAP_PURGE_MS service	90
	6.1.6.1	Definition	90
	6.1.6.2	Service primitives	90
	6.1.6.3	Parameter definitions and use.	90
6.2		Paging and search.	91
6.2.1		MAP_PAGE service.	91
	6.2.1.1	Definition	91
	6.2.1.2	Service primitives	91
	6.2.1.3	Parameter definitions and use.	91
6.2.2		MAP_SEARCH_FOR_MS service	93
	6.2.2.1	Definition	93
	6.2.2.2	Service primitives	93
	6.2.2.3	Parameter definitions and use.	93
6.3		Access management services	94
6.3.1		MAP_PROCESS_ACCESS_REQUEST service.	94
	6.3.1.1	Definition	94
	6.3.1.2	Service primitives	94
	6.3.1.3	Parameter definitions and use.	94

6.4	Handover services	96
6.4.1	MAP_PREPARE_HANOVER service	96
6.4.1.1	Definition	96
6.4.1.2	Service primitives	96
6.4.1.3	Parameter use	96
6.4.2	MAP_SEND_END_SIGNAL service.	98
6.4.2.1	Definition	98
6.4.2.2	Service primitives	98
6.4.2.3	Parameter use	98
6.4.3	MAP_PROCESS_ACCESS_SIGNALLING service.	99
6.4.3.1	Definition	99
6.4.3.2	Service primitives	99
6.4.3.3	Parameter use	99
6.4.4	MAP_FORWARD_ACCESS_SIGNALLING service	100
6.4.4.1	Definition	100
6.4.4.2	Service primitives	100
6.4.4.3	Parameter use	100
6.4.5	MAP_PREPARE_SUBSEQUENT_HANOVER service.	101
6.4.5.1	Definition	101
6.4.5.2	Service primitives	101
6.4.5.3	Parameter use	101
6.4.6	MAP_ALLOCATE_HANOVER_NUMBER service	102
6.4.6.1	Definition	102
6.4.6.2	Service primitives	102
6.4.6.3	Parameter use	102
6.4.7	MAP_SEND_HANOVER_REPORT service.	103
6.4.7.1	Definition	103
6.4.7.2	Service primitives	103
6.4.7.3	Parameter use	103
6.5	Authentication management services	104
6.5.1	MAP_AUTHENTICATE service	104
6.5.1.1	Definition	104
6.5.1.2	Service primitives	104
6.5.1.3	Parameter use	104
6.5.2	MAP_SEND_AUTHENTICATION_INFO service	105
6.5.2.1	Definition	105
6.5.2.2	Service primitives	105
6.5.2.3	Parameter use	105
6.6	Security management services	106
6.6.1	MAP_SET_CIPHERING_MODE service	106
6.6.1.1	Definitions	106
6.6.1.2	Service primitives	106
6.6.1.3	Parameter use	106
6.7	International mobile equipment identities management services.	107
6.7.1	MAP_CHECK_IMEI service	107
6.7.1.1	Definition	107
6.7.1.2	Service primitives	107
6.7.1.3	Parameter use	107
6.7.2	MAP_OBTAIN_IMEI service.	109
6.7.2.1	Definition	109
6.7.2.2	Service primitives	109
6.7.2.3	Parameter use	109
6.8	Subscriber management services	110
6.8.1	MAP-INSERT-SUBSCRIBER-DATA service	110
6.8.1.1	Definition	110
6.8.1.2	Service primitives	110
6.8.1.3	Parameter use	111
6.8.1.4	Basic service information related to supplementary services	116
6.8.2	MAP-DELETE-SUBSCRIBER-DATA service.	117

	6.8.2.1	Definition	117
	6.8.2.2	Service primitives	117
	6.8.2.3	Parameter use	117
6.9	Identity management services		119
6.9.1	MAP-PROVIDE-IMSI service		119
	6.9.1.1	Definition	119
	6.9.1.2	Service primitives	119
	6.9.1.3	Parameter use	119
6.9.2	MAP-FORWARD-NEW-TMSI service		120
	6.9.2.1	Definition	120
	6.9.2.2	Service primitives	120
	6.9.2.3	Parameter use	120
6.10	Fault recovery services		121
6.10.1	MAP_RESET service		121
	6.10.1.1	Definition	121
	6.10.1.2	Service primitives	121
	6.10.1.3	Parameter definition and use	121
6.10.2	MAP_FORWARD_CHECK_SS_INDICATION service		122
	6.10.2.1	Definition	122
	6.10.2.2	Service primitives	122
	6.10.2.3	Parameter definition and use	122
6.10.3	MAP_RESTORE_DATA service		123
	6.10.3.1	Definition	123
	6.10.3.2	Service primitives	123
	6.10.3.3	Parameter definitions and use	123
7	Operation and maintenance services		125
7.1	Subscriber tracing services		125
7.1.1	MAP-ACTIVATE-TRACE-MODE service		125
	7.1.1.1	Definition	125
	7.1.1.2	Service primitives	125
	7.1.1.3	Parameter use	125
7.1.2	MAP-DEACTIVATE-TRACE-MODE service		127
	7.1.2.1	Definition	127
	7.1.2.2	Service primitives	127
	7.1.2.3	Parameter use	127
7.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service		128
	7.1.3.1	Definition	128
	7.1.3.2	Service primitives	128
	7.1.3.3	Parameter use	128
7.2	Other operation and maintenance services		129
7.2.1	MAP-SEND-IMSI service		129
	7.2.1.1	Definition	129
	7.2.1.2	Service primitives	129
	7.2.1.3	Parameter use	129
8	Call handling services		131
8.1	MAP_SEND_INFO_FOR_INCOMING_CALL service		131
	8.1.1	Definition	131
	8.1.2	Service primitives	131
	8.1.3	Parameter use	131
8.2	MAP_SEND_INFO_FOR_OUTGOING_CALL service		134
	8.2.1	Definition	134
	8.2.2	Service primitives	134
	8.2.3	Parameter use	134
8.3	MAP_SEND_ROUTING_INFORMATION service		136
	8.3.1	Definition	136
	8.3.2	Service primitives	136
	8.3.3	Parameter use	136
8.4	MAP_PROVIDE_ROAMING_NUMBER service		139

8.4.1	Definition	139
8.4.2	Service primitives.	139
8.4.3	Parameter use	139
8.5	MAP_COMPLETE_CALL service	141
8.5.1	Definition	141
8.5.2	Service primitives.	141
8.5.3	Parameter use	141
8.6	MAP_PROCESS_CALL_WAITING service	143
8.6.1	Definition	143
8.6.2	Service primitives.	143
8.6.3	Parameter use	143
9	Supplementary services related services	145
9.1	MAP_REGISTER_SS service	145
9.1.1	Definition	145
9.1.2	Service primitives.	145
9.1.3	Parameter use	145
9.2	MAP_ERASE_SS service	147
9.2.1	Definition	147
9.2.2	Service primitives.	147
9.2.3	Parameter use	147
9.3	MAP_ACTIVATE_SS service	149
9.3.1	Definition	149
9.3.2	Service primitives.	149
9.3.3	Parameter use	149
9.4	MAP_DEACTIVATE_SS service.	151
9.4.1	Definitions.	151
9.4.2	Service primitives.	151
9.4.3	Parameter use	151
9.5	MAP_INTERROGATE_SS service	153
9.5.1	Definitions.	153
9.5.2	Service primitives.	153
9.5.3	Parameter use	153
9.6	MAP_INVOKE_SS service.	155
9.6.1	Definitions.	155
9.6.2	Service primitives.	155
9.6.3	Parameter use	155
9.7	MAP_REGISTER_PASSWORD service	156
9.7.1	Definitions.	156
9.7.2	Service primitives.	156
9.7.3	Parameter use	156
9.8	MAP_GET_PASSWORD service	157
9.8.1	Definitions.	157
9.8.2	Service primitives.	157
9.8.3	Parameter use	157
9.9	MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service	158
9.9.1	Definitions.	158
9.9.2	Service primitives.	158
9.9.3	Parameter use	158
9.10	MAP_UNSTRUCTURED_SS_REQUEST service	160
9.10.1	Definitions.	160
9.10.2	Service primitives.	160
9.10.3	Parameter use	160
9.11	MAP_UNSTRUCTURED_SS_NOTIFY service.	162
9.11.1	Definitions.	162
9.11.2	Service primitives.	162
9.11.3	Parameter use	162
10	Short message service management services.	165
10.1	MAP-SEND-ROUTING-INFO-FOR-SM service.	165

10.1.1	Definition	165
10.1.2	Service primitives	165
10.1.3	Parameter use	165
10.2	MAP-FORWARD-SHORT-MESSAGE service	167
10.2.1	Definition	167
10.2.2	Service primitives	167
10.2.3	Parameter use	167
10.3	MAP-REPORT-SM-DELIVERY-STATUS service	169
10.3.1	Definition	169
10.3.2	Service primitives	169
10.3.3	Parameter use	169
10.4	MAP-READY-FOR-SM service	171
10.4.1	Definition	171
10.4.2	Service primitives	171
10.4.3	Parameter use	171
10.5	MAP-ALERT-SERVICE-CENTRE service	173
10.5.1	Definition	173
10.5.2	Service primitives	173
10.5.3	Parameter use	173
10.6	MAP-INFORM-SERVICE-CENTRE service	174
10.6.1	Definition	174
10.6.2	Service primitives	174
10.6.3	Parameter use	174
10.7	MAP-SEND-INFO-FOR-MT-SMS service	175
10.7.1	Definition	175
10.7.2	Service primitives	175
10.7.3	Parameter use	175
10.8	MAP-SEND-INFO-FOR-MO-SMS service	176
10.8.1	Definition	176
10.8.2	Service primitives	176
10.8.3	Parameter use	176
11	General	177
11.1	Overview	177
11.2	Underlying services	177
11.3	Model	177
11.4	Conventions	177
12	Elements of procedure	179
12.1	Dialogue establishment	179
12.1.1	Receipt of a MAP-OPEN request primitive	179
12.1.2	Receipt of a TC-BEGIN indication	180
12.1.3	Receipt of a MAP-OPEN response	183
12.1.4	Receipt of the first TC-CONTINUE ind	183
12.1.5	Receipt of a TC-END ind	183
12.1.6	Receipt of a TC-U-ABORT ind	184
12.1.7	Receipt of a TC-P-ABORT ind	184
12.2	Dialogue continuation	184
12.2.1	Sending entity	184
12.2.2	Receiving entity	184
12.3	Dialogue termination	185
12.3.1	Receipt of a MAP-CLOSE request	185
12.3.2	Receipt of a TC-END indication	185
12.4	User Abort	185
12.4.1	MAP-U-ABORT request	185
12.4.2	TC-U-ABORT ind	185
12.5	Provider Abort	186
12.5.1	MAP PM error situation	186
12.5.2	TC-P-ABORT ind	186
12.5.3	TC-U-ABORT ind	186

12.6	Procedures for MAP specific services	186
12.6.1	Service invocation	187
12.6.2	Service invocation receipt	187
12.6.3	Service response	188
12.6.4	Receipt of a response	189
	12.6.4.1 Receipt of a TC-RESULT-NL indication	189
	12.6.4.2 Receipt of a TC-RESULT-L indication	189
	12.6.4.3 Receipt of a TC-U-ERROR indication	190
	12.6.4.4 Receipt of a TC-INVOKE indication	190
	12.6.4.5 Receipt of a TC-U-REJECT indication	191
	12.6.4.6 Receipt of a TC-L-REJECT indication	191
	12.6.4.7 Receipt of a TC-L-CANCEL indication	191
12.6.5	Other events	192
	12.6.5.1 Receipt of a TC-U-REJECT	192
	12.6.5.2 Receipt of a TC-R-REJECT indication	192
	12.6.5.3 Receipt of a TC-L-REJECT indication	192
12.6.6	Parameter checks	192
12.6.7	Returning state machines to idle	193
12.6.8	Load control	193
13	Mapping on to TC services	195
13.1	Dialogue control	195
13.1.1	Directly mapped parameters	195
13.1.2	Use of other parameters of dialogue handling primitives	195
	13.1.2.1 Dialogue Id	195
	13.1.2.2 Application-context-name	195
	13.1.2.3 User information	195
	13.1.2.4 Component present	195
	13.1.2.5 Termination	195
	13.1.2.6 P-Abort-Cause	195
	13.1.2.7 Quality of service	196
13.2	Service specific procedures	196
13.2.1	Directly mapped parameters	196
13.2.2	Use of other parameters of component handling primitives	196
	13.2.2.1 Dialogue Id	196
	13.2.2.2 Class	196
	13.2.2.3 Linked Id	197
	13.2.2.4 Operation	197
	13.2.2.5 Error	199
	13.2.2.6 Parameters	199
	13.2.2.7 Time out	199
	13.2.2.8 Last component	199
	13.2.2.9 Problem code	200
	13.2.2.9.1 Mapping to MAP User Error	200
	13.2.2.9.2 Mapping to MAP Provider Error parameter	200
	13.2.2.9.3 Mapping to diagnostic parameter	201
13.3	SDL descriptions	202
14	Abstract syntax of the MAP protocol	229
14.1	General	229
14.1.1	Encoding rules	229
14.1.2	Use of TC	230
14.1.3	Use of information elements defined outside MAP	230
14.1.4	Compatibility considerations	231
14.1.5	Structure of the Abstract Syntax of MAP	232
14.2	Operation packages	234
14.2.1	General aspects	234
14.2.2	Packages specifications	235
	14.2.2.1 Location updating	235
	14.2.2.2 Location cancellation	235

	14.2.2.3	Roaming number enquiry	235
	14.2.2.4	Information retrieval	236
	14.2.2.5	Inter-VLR information retrieval	236
	14.2.2.6	IMSI retrieval	236
	14.2.2.7 - 14.2.2.9 [spare].		236
	14.2.2.10	Interrogation	236
	14.2.2.11	[spare]	236
	14.2.2.12	Handover Control	237
	14.2.2.13	Subscriber Data management stand alone.	237
	14.2.2.14	Equipment management	237
	14.2.2.15	Subscriber data management.	238
	14.2.2.16	Location register restart	238
	14.2.2.17	Tracing stand-alone	238
	14.2.2.18	Functional SS handling	238
	14.2.2.19	Tracing	239
	14.2.2.20	Binding	239
	14.2.2.21	Unstructured SS handling	239
	14.2.2.22	Short message relay services.	240
	14.2.2.23	Short message gateway services.	240
	14.2.2.24 - 14.2.2.25 [spare]		240
	14.2.2.26	Message waiting data management	240
	14.2.2.27	Alerting	241
	14.2.2.28	Data restoration	241
	14.2.2.29	Purging	241
14.3	Application contexts		242
14.3.1	General aspects.		242
14.3.2	Access context definitions.		243
	14.3.2.1	[spare]	243
	14.3.2.2	Location Updating	243
	14.3.2.3	Location Cancellation	243
	14.3.2.4	Roaming number enquiry	244
	14.3.2.5	[spare]	244
	14.3.2.6	Location Information Retrieval.	244
	14.3.2.7 - 14.3.2.10 [spare]		244
	14.3.2.11	Location registers restart	244
	14.3.2.12	Handover control.	245
	14.3.2.13	IMSI Retrieval	245
	14.3.2.14	Equipment Management	245
	14.3.2.15	Information retrieval	245
	14.3.2.16	Inter-VLR information retrieval	246
	14.3.2.17	Stand Alone Subscriber Data Management	246
	14.3.2.18	Tracing	246
	14.3.2.19	Network functional SS handling.	247
	14.3.2.20	Network unstructured SS handling	247
	14.3.2.21	Short Message Gateway	247
	14.3.2.22	Mobile originating Short Message Relay	248
	14.3.2.23	[spare]	248
	14.3.2.24	Short message alert	248
	14.3.2.25	Short message waiting data management	248
	14.3.2.26	Mobile terminating Short Message Relay.	249
	14.3.2.27	MS purging.	249
	14.3.3	ASN.1 Module for application-context-names	249
14.4	MAP Dialogue Information		252
14.5	MAP operation and error codes.		254
14.6	MAP operation and error types		260
	14.6.1	Mobile Service Operations	260
	14.6.2	Operation and Maintenance Operations	266
	14.6.3	Call Handling Operations	268
	14.6.4	Supplementary service operations	270
	14.6.5	Short message service operations	275

14.6.6	Errors	278
14.7	MAP constants and data types.	282
14.7.1	Mobile Service data types	282
14.7.2	Operation and maintenance data types.	288
14.7.3	Call handling data types	290
14.7.4	Supplementary service data types.	292
14.7.5	Supplementary service codes	297
14.7.6	Short message data types.	300
14.7.7	Error data types.	302
14.7.8	Common data types	304
14.7.9	Teleservice Codes	309
14.7.10	Bearer Service Codes	311
15	General on MAP user procedures	313
15.1	Introduction	313
15.2	Common aspects of user procedure descriptions.	313
15.2.1	General conventions	313
15.2.2	Naming conventions	313
15.2.3	Convention on primitives parameters	315
15.2.3.1	Open service	315
15.2.3.2	Close service	315
15.2.4	Version handling at dialogue establishment.	315
15.2.4.1	Behaviour at the initiating side	315
15.2.4.2	Behaviour at the responding side	315
15.2.5	Abort Handling	316
15.2.6	SDL conventions	316
15.3	Interaction between MAP Provider and MAP Users	316
16	Mobility procedures	317
16.1	Location management Procedures	317
16.1.1	Location updating	322
16.1.1.1	General	322
16.1.1.2	Detailed procedure in the MSC	326
16.1.1.3	Detailed procedure in the VLR	330
16.1.1.4	Detailed procedure in the HLR	343
16.1.1.5	Send Identification	346
16.1.1.5.1	General	346
16.1.1.5.2	Detailed procedure in the VLR	346
16.1.1.5.3	Detailed procedure in the PVLR	346
16.1.1.6	The Process Update Location VLR	348
16.1.1.7	The Process Subscriber Present HLR.	350
16.1.2	Location Cancellation	352
16.1.2.1	General	352
16.1.2.2	Detailed procedure in the HLR.	352
16.1.2.3	Detailed procedure in the VLR	353
16.1.3	Detach IMSI	356
16.1.3.1	General	356
16.1.3.2	Detailed procedure in the MSC	356
16.1.3.3	Detailed procedure in the VLR	357
16.1.4	Purge MS	360
16.1.4.1	General	360
16.1.4.2	Detailed procedure in the VLR	360
16.1.4.3	Detailed procedure in the HLR.	361
16.2	Handover procedure	364
16.2.1	General	364
16.2.2	Handover procedure in MSC-A	368
16.2.2.1	Basic handover	368
16.2.2.2	Handling of access signalling	368
16.2.2.3	Other procedures in stable handover situation	368
16.2.2.4	Subsequent handover	369