



IEC 61970-301

Edition 6.0 2016-12  
REDLINE VERSION

# INTERNATIONAL STANDARD



Energy management system application program interface (EMS-API) –  
Part 301: Common information model (CIM) base

(<https://standards.iteh.ai>)

Document Preview

[IEC 61970-301:2016](#)

<https://standards.iteh.ai/catalog/standards/1c/52f190b2-716e-4d12-9f19-51ad2f046274/iec-61970-301-2016>



## THIS PUBLICATION IS COPYRIGHT PROTECTED

Copyright © 2016 IEC, Geneva, Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester. If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

IEC Central Office  
3, rue de Varembé  
CH-1211 Geneva 20  
Switzerland

Tel.: +41 22 919 02 11  
Fax: +41 22 919 03 00  
[info@iec.ch](mailto:info@iec.ch)  
[www.iec.ch](http://www.iec.ch)

### About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

### About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

#### IEC Catalogue - [webstore.iec.ch/catalogue](http://webstore.iec.ch/catalogue)

The stand-alone application for consulting the entire bibliographical information on IEC International Standards, Technical Specifications, Technical Reports and other documents. Available for PC, Mac OS, Android Tablets and iPad.

#### IEC publications search - [www.iec.ch/searchpub](http://www.iec.ch/searchpub)

The advanced search enables to find IEC publications by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, replaced and withdrawn publications.

#### IEC Just Published - [webstore.iec.ch/justpublished](http://webstore.iec.ch/justpublished)

Stay up to date on all new IEC publications. Just Published details all new publications released. Available online and also once a month by email.

#### Electropedia - [www.electropedia.org](http://www.electropedia.org)

The world's leading online dictionary of electronic and electrical terms containing 20 000 terms and definitions in English and French, with equivalent terms in 15 additional languages. Also known as the International Electrotechnical Vocabulary (IEV) online.

#### IEC Glossary - [std.iec.ch/glossary](http://std.iec.ch/glossary)

65 000 electrotechnical terminology entries in English and French extracted from the Terms and Definitions clause of IEC publications issued since 2002. Some entries have been collected from earlier publications of IEC TC 37, 77, 86 and CISPR.

#### IEC Customer Service Centre - [webstore.iec.ch/csc](http://webstore.iec.ch/csc)

If you wish to give us your feedback on this publication or need further assistance, please contact the Customer Service Centre: [csc@iec.ch](mailto:csc@iec.ch).

<https://standards.iteh.at/catalog/standards/icc/52f190b2-716e-4d12-9f19-51ad2f046274/icc-61970-301-2016>



IEC 61970-301

Edition 6.0 2016-12  
REDLINE VERSION

# INTERNATIONAL STANDARD



Energy management system application program interface (EMS-API) –  
Part 301: Common information model (CIM) base

iTech Standards  
Document Preview

IEC 61970-301:2016

<https://standards.iteh.ai/catalog/standards/iec/52f190b2-716e-4d12-9f19-51ad2f046274/iec-61970-301-2016>

INTERNATIONAL  
ELECTROTECHNICAL  
COMMISSION

ICS 33.200

ISBN 978-2-8322-3763-2

**Warning! Make sure that you obtained this publication from an authorized distributor.**

## CONTENTS

|   |     |
|---|-----|
| FOREWORD .....  | 33  |
| INTRODUCTION .....  | 35  |
| 1 Scope .....   | 37  |
| 2 Normative references .....                                    | 37  |
| 3 Terms and definitions .....                                   | 38  |
| 4 CIM specification .....                                       | 39  |
| 4.1 Overview .....  | 39  |
| 4.2 CIM modeling notation .....                                 | 39  |
| 4.3 CIM packages .....  | 39  |
| 4.4 CIM classes and relationships .....                         | 41  |
| 4.4.1 Classes .....   | 41  |
| 4.4.2 Generalization .....                                      | 42  |
| 4.4.3 Simple association .....                                  | 43  |
| 4.4.4 Aggregation .....   | 44  |
| 4.5 CIM model concepts and examples .....                       | 44  |
| 4.5.1 Concepts .....  | 44  |
| 4.5.2 Containment, equipment hierarchies and naming .....       | 45  |
| 4.5.3 Names model .....   | 46  |
| 4.5.4 Connectivity model .....                                  | 47  |
| 4.5.5 Inheritance hierarchy .....                               | 50  |
| 4.5.6 Transformer model .....                                   | 52  |
| 4.5.7 Transformer tap modeling .....                            | 54  |
| 4.5.8 Phase wire modeling .....                                 | 69  |
| 4.5.9 Grounding devices modeling .....                          | 71  |
| 4.5.10 Cuts, clamps and jumpers model .....                     | 74  |
| 4.5.11 Measurements and controls .....                          | 78  |
| 4.5.12 Regulating control models .....                          | 83  |
| 4.5.13 DC model for CIM .....                                   | 84  |
| 4.5.14 Static Var Compensator voltage regulation .....          | 103 |
| 4.6 Modeling guidelines .....                                   | 105 |
| 4.6.1 Modeling for change .....                                 | 105 |
| 4.6.2 Process for amendments to the CIM .....                   | 105 |
| 4.6.3 Changes to the CIM UML model .....                        | 105 |
| 4.6.4 Changes to the CIM standards documents .....              | 106 |
| 4.6.5 Deprecations .....  | 106 |
| 4.6.6 CIM profiles .....  | 106 |
| 4.7 Modeling tools .....  | 106 |
| 4.8 User implementation conventions .....                       | 107 |
| 4.8.1 Conventions beyond UML .....                              | 107 |
| 4.8.2 Number of terminals for ConductingEquipment objects ..... | 107 |
| 4.9 CIM modeling examples .....                                 | 107 |
| 5 Detailed model .....  | 108 |
| 5.1 Overview .....  | 108 |
| 5.2 Context .....   | 108 |
| 6 Top package IEC61970 Package Base .....                       | 111 |
| 6.1 General .....   | 111 |

|   |       |  |
|---|-------|--|
| <b>6.2 IEC61970CIMVersion root class</b>              | ..... |  |
| <b>6.2 Package Faults</b> .....                       | 112   |  |
| 6.2.1 General .....                                   | 112   |  |
| 6.2.2 EquipmentFault .....                            | 112   |  |
| 6.2.3 Fault.....                                      | 113   |  |
| 6.2.4 FaultCauseType .....                            | 114   |  |
| 6.2.5 FaultImpedance compound .....                   | 114   |  |
| 6.2.6 LineFault .....                                 | 115   |  |
| 6.2.7 PhaseConnectedFaultKind enumeration .....       | 115   |  |
| <b>6.3 Package DocIEC 61970</b> .....                 | 116   |  |
| <b>6.4 Package Domain</b> .....                       | 117   |  |
| <b>6.4.1 General</b> .....                            | 117   |  |
| <b>6.4.2 ActivePower datatype</b> .....               | 123   |  |
| <b>6.4.3 ActivePowerChangeRate datatype</b> .....     | 123   |  |
| <b>6.4.4 ActivePowerPerCurrentFlow datatype</b> ..... | 124   |  |
| <b>6.4.5 ActivePowerPerFrequency datatype</b> .....   | 124   |  |
| <b>6.4.6 Admittance datatype</b> .....                | 124   |  |
| <b>6.4.7 AngleDegrees datatype</b> .....              | 125   |  |
| <b>6.4.8 AngleRadians datatype</b> .....              | 125   |  |
| <b>6.4.9 ApparentPower datatype</b> .....             | 125   |  |
| <b>6.4.10 Area datatype</b> .....                     | 125   |  |
| <b>6.4.11 Boolean primitive</b> .....                 | 126   |  |
| <b>6.4.12 Capacitance datatype</b> .....              | 126   |  |
| <b>6.4.13 CapacitancePerLength datatype</b> .....     | 126   |  |
| <b>6.4.14 Conductance datatype</b> .....              | 126   |  |
| <b>6.4.15 ConductancePerLength datatype</b> .....     | 126   |  |
| <b>6.4.16 CostPerEnergyUnit datatype</b> .....        | 127   |  |
| <b>6.4.17 CostPerVolume datatype</b> .....            | 127   |  |
| <b>6.4.18 CostRate datatype</b> .....                 | 127   |  |
| <b>6.4.19 Currency enumeration</b> .....              | 128   |  |
| <b>6.4.20 CurrentFlow datatype</b> .....              | 128   |  |
| <b>6.4.21 Damping datatype</b> .....                  | 128   |  |
| <b>6.4.22 Date primitive</b> .....                    | 129   |  |
| <b>6.4.23 DateInterval compound</b> .....             | 129   |  |
| <b>6.4.24 DateTime primitive</b> .....                | 129   |  |
| <b>6.4.25 DateTimeInterval compound</b> .....         | 129   |  |
| <b>6.4.26 Decimal primitive</b> .....                 | 129   |  |
| <b>6.4.27 PsrList</b> .....                           |       |  |
| <b>6.4.27 DecimalQuantity compound</b> .....          | 129   |  |
| <b>6.4.28 Displacement datatype</b> .....             | 130   |  |
| <b>6.4.29 Duration primitive</b> .....                | 130   |  |
| <b>6.4.30 Float primitive</b> .....                   | 130   |  |
| <b>6.4.31 ReportingGroup</b> .....                    |       |  |
| <b>6.4.31 FloatQuantity datatype compound</b> .....   | 130   |  |
| <b>6.4.32 Frequency datatype</b> .....                | 130   |  |
| <b>6.4.33 Hours datatype</b> .....                    | 131   |  |
| <b>6.4.34 Impedance datatype</b> .....                | 131   |  |
| <b>6.4.35 Inductance datatype</b> .....               | 131   |  |
| <b>6.4.36 InductancePerLength datatype</b> .....      | 131   |  |

|        |  |     |
|--------|--|-----|
| 6.4.37 | Integer primitive .....                            | 132 |
| 6.4.38 | IntegerQuantity <del>datatype</del> compound ..... | 132 |
| 6.4.39 | KiloActivePower datatype .....                     | 132 |
| 6.4.40 | Length datatype .....                              | 132 |
| 6.4.41 | Minutes datatype .....                             | 133 |
| 6.4.42 | Money datatype .....                               | 133 |
| 6.4.43 | MonthDay primitive .....                           | 133 |
| 6.4.44 | MonthDayInterval compound .....                    | 133 |
| 6.4.45 | PU datatype .....                                  | 133 |
| 6.4.46 | PerCent datatype .....                             | 134 |
| 6.4.47 | Pressure datatype .....                            | 134 |
| 6.4.48 | Reactance datatype .....                           | 134 |
| 6.4.49 | ReactancePerLength datatype .....                  | 134 |
| 6.4.50 | ReactivePower datatype .....                       | 135 |
| 6.4.51 | RealEnergy datatype .....                          | 135 |
| 6.4.52 | Resistance datatype .....                          | 135 |
| 6.4.53 | ResistancePerLength datatype .....                 | 136 |
| 6.4.54 | RotationSpeed datatype .....                       | 136 |
| 6.4.55 | Seconds datatype .....                             | 136 |
| 6.4.56 | Speed datatype .....                               | 136 |
| 6.4.57 | String primitive .....                             | 137 |
| 6.4.58 | StringQuantity <del>datatype</del> compound .....  | 137 |
| 6.4.59 | Susceptance datatype .....                         | 137 |
| 6.4.60 | SusceptancePerLength datatype .....                | 137 |
| 6.4.61 | Temperature datatype .....                         | 138 |
| 6.4.62 | Time primitive .....                               | 138 |
| 6.4.63 | TimeInterval compound .....                        | 138 |
| 6.4.64 | UnitMultiplier enumeration .....                   | 138 |
| 6.4.65 | UnitSymbol enumeration .....                       | 139 |
| 6.4.66 | Voltage datatype .....                             | 140 |
| 6.4.67 | VoltagePerReactivePower datatype .....             | 140 |
| 6.4.68 | Volume datatype .....                              | 140 |
| 6.4.69 | VolumeFlowRate datatype .....                      | 141 |
| 6.4.70 | WaterLevel datatype .....                          | 141 |
| 6.4.71 | Weight datatype .....                              | 141 |
| 6.5    | Package Core .....                                 | 141 |
| 6.5.1  | General .....                                      | 141 |
| 6.5.2  | ACDCTerminal .....                                 | 145 |
| 6.5.3  | BaseFrequency .....                                | 146 |
| 6.5.4  | BasePower .....                                    | 146 |
| 6.5.5  | BaseVoltage .....                                  | 147 |
| 6.5.6  | BasicIntervalSchedule .....                        | 148 |
| 6.5.7  | Bay .....  | 148 |
| 6.5.8  | BreakerConfiguration enumeration .....             | 149 |
| 6.5.9  | BusbarConfiguration enumeration .....              | 149 |
| 6.5.10 | ConductingEquipment .....                          | 150 |
| 6.5.11 | ConnectivityNode .....                             | 151 |
| 6.5.12 | ConnectivityNodeContainer .....                    | 151 |
| 6.5.13 | Curve .....  | 152 |

|        |   |     |
|--------|---|-----|
| 6.5.14 | CurveData root class .....                      | 153 |
| 6.5.15 | CurveStyle enumeration .....                    | 153 |
| 6.5.16 | Equipment .....                                 | 154 |
| 6.5.17 | EquipmentContainer .....                        | 154 |
| 6.5.18 | GeographicalRegion .....                        | 155 |
| 6.5.19 | IdentifiedObject root class .....               | 156 |
| 6.5.20 | IrregularIntervalSchedule .....                 | 156 |
| 6.5.21 | IrregularTimePoint root class .....             | 157 |
| 6.5.22 | Name root class .....                           | 157 |
| 6.5.23 | NameType root class .....                       | 158 |
| 6.5.24 | NameTypeAuthority root class .....              | 158 |
| 6.5.25 | OperatingParticipant .....                      | 159 |
| 6.5.26 | OperatingShare root class .....                 | 159 |
| 6.5.27 | PSRType .....                                   | 160 |
| 6.5.28 | PhaseCode enumeration .....                     | 160 |
| 6.5.29 | PowerSystemResource .....                       | 161 |
| 6.5.30 | RegularIntervalSchedule .....                   | 162 |
| 6.5.31 | RegularTimePoint root class .....               | 163 |
| 6.5.32 | ReportingSuperGroup .....                       | 164 |
| 6.5.33 | SubGeographicalRegion .....                     | 165 |
| 6.5.34 | Substation .....                                | 165 |
| 6.5.35 | Terminal .....                                  | 166 |
| 6.5.36 | VoltageLevel .....                              | 168 |
| 6.6    | Package DiagramLayout .....                     | 169 |
| 6.6.1  | General .....                                   | 169 |
| 6.6.2  | DiagramStyle .....                              | 169 |
| 6.6.3  | Diagram .....                                   | 170 |
| 6.6.4  | DiagramObject .....                             | 171 |
| 6.6.5  | DiagramObjectGluePoint root class .....         | 172 |
| 6.6.6  | DiagramObjectPoint root class .....             | 172 |
| 6.6.7  | DiagramObjectStyle .....                        | 173 |
| 6.6.8  | OrientationKind enumeration .....               | 173 |
| 6.6.9  | TextDiagramObject .....                         | 173 |
| 6.6.10 | VisibilityLayer .....                           | 174 |
| 6.7    | Package OperationalLimits .....                 | 175 |
| 6.7.1  | General .....                                   | 175 |
| 6.7.2  | ActivePowerLimit .....                          | 176 |
| 6.7.3  | ApparentPowerLimit .....                        | 177 |
| 6.7.4  | BranchGroup .....                               | 177 |
| 6.7.5  | BranchGroupTerminal root class .....            | 178 |
| 6.7.6  | CurrentLimit .....                              | 178 |
| 6.7.7  | OperationalLimit .....                          | 179 |
| 6.7.8  | OperationalLimitDirectionKind enumeration ..... | 180 |
| 6.7.9  | OperationalLimitSet .....                       | 180 |
| 6.7.10 | OperationalLimitType .....                      | 181 |
| 6.7.11 | VoltageLimit .....                              | 181 |
| 6.8    | Package Topology .....                          | 182 |
| 6.8.1  | General .....                                   | 182 |
| 6.8.2  | BusNameMarker .....                             | 186 |

|        |   |     |
|--------|---|-----|
| 6.8.3  | DCTopologicalNode .....                           | 187 |
| 6.8.4  | TopologicalIsland .....                           | 187 |
| 6.8.5  | TopologicalNode .....                             | 188 |
| 6.8.9  | CompositeSwitchType datatype .....                |     |
| 6.8.28 | OperatingMode datatype .....                      |     |
| 6.8.35 | PhaseTapChangerAsymetrical .....                  |     |
| 6.8.38 | PhaseTapChangerSymmetrical .....                  |     |
| 6.8.46 | RatioTapChangerTabular .....                      |     |
| 6.8.47 | RatioTapChangerTabularPoint root class .....      |     |
| 6.8.50 | RectifierInverter .....                           |     |
| 6.8.55 | Resistor .....                                    |     |
| 6.8.67 | SynchronousGeneratorType enumeration .....        |     |
| 6.8.70 | SynchronousMachineType enumeration .....          |     |
| 6.8.73 | TapChangerKind enumeration .....                  |     |
| 6.9    | Package Wires .....                               | 189 |
| 6.9.1  | General .....                                     | 189 |
| 6.9.2  | PerLengthSequenceImpedance .....                  | 205 |
| 6.9.3  | PerLengthPhaseImpedance .....                     | 206 |
| 6.9.4  | ShuntCompensatorPhase .....                       | 207 |
| 6.9.5  | RatioTapChanger .....                             | 208 |
| 6.9.6  | BusbarSection .....                               | 209 |
| 6.9.7  | SinglePhaseKind enumeration .....                 | 210 |
| 6.9.8  | TransformerTank .....                             | 210 |
| 6.9.9  | Disconnector .....                                | 211 |
| 6.9.10 | Jumper .....                                      | 212 |
| 6.9.11 | TapSchedule .....                                 | 214 |
| 6.9.12 | TransformerCoreAdmittance .....                   | 215 |
| 6.9.13 | SVCControlMode enumeration .....                  | 215 |
| 6.9.14 | EnergyConsumerPhase .....                         | 215 |
| 6.9.15 | SynchronousMachineOperatingMode enumeration ..... | 216 |
| 6.9.16 | TapChangerControl .....                           | 217 |
| 6.9.17 | PhaseTapChangerTable .....                        | 218 |
| 6.9.18 | TransformerStarImpedance .....                    | 218 |
| 6.9.19 | Breaker .....                                     | 219 |
| 6.9.20 | GroundDisconnector .....                          | 220 |
| 6.9.21 | SwitchSchedule .....                              | 222 |
| 6.9.22 | PowerTransformer .....                            | 222 |
| 6.9.23 | PhaseTapChangerAsymmetrical .....                 | 225 |
| 6.9.24 | Ground .....                                      | 226 |
| 6.9.25 | Line .....  | 227 |
| 6.9.26 | PhaseTapChangerSymmetrical .....                  | 228 |
| 6.9.27 | RegulationSchedule .....                          | 229 |
| 6.9.28 | Fuse .....  | 229 |
| 6.9.29 | TransformerMeshImpedance .....                    | 230 |
| 6.9.30 | SwitchPhase .....                                 | 231 |
| 6.9.31 | PowerTransformerEnd .....                         | 232 |
| 6.9.32 | PetersenCoil .....                                | 234 |
| 6.9.33 | RegulatingCondEq .....                            | 236 |
| 6.9.34 | PhaseTapChangerNonLinear .....                    | 237 |

|        |   |     |
|--------|---|-----|
| 6.9.35 | SeriesCompensator .....                               | 239 |
| 6.9.36 | PhaseShuntConnectionKind enumeration .....            | 240 |
| 6.9.37 | <b>GroundingImpedance</b> .....                       | 240 |
| 6.9.38 | TransformerControlMode enumeration .....              | 241 |
| 6.9.39 | <b>RatioTapChangerTablePoint</b> .....                | 241 |
| 6.9.40 | ACLineSegment .....                                   | 242 |
| 6.9.41 | Recloser .....  | 243 |
| 6.9.42 | CompositeSwitch .....                                 | 244 |
| 6.9.43 | TransformerEnd .....                                  | 245 |
| 6.9.44 | Sectionaliser .....                                   | 247 |
| 6.9.45 | VoltageControlZone .....                              | 248 |
| 6.9.46 | EnergySource .....                                    | 248 |
| 6.9.47 | SynchronousMachine .....                              | 250 |
| 6.9.48 | RegulatingControlModeKind enumeration .....           | 254 |
| 6.9.49 | Clamp .....   | 254 |
| 6.9.50 | TransformerTankEnd .....                              | 255 |
| 6.9.51 | PhaseTapChanger .....                                 | 256 |
| 6.9.52 | ACLineSegmentPhase .....                              | 257 |
| 6.9.53 | <b>RatioTapChangerTable</b> .....                     | 258 |
| 6.9.54 | RotatingMachine .....                                 | 259 |
| 6.9.55 | RegulatingControl .....                               | 261 |
| 6.9.56 | PhaseImpedanceData root class .....                   | 263 |
| 6.9.57 | ShuntCompensator .....                                | 264 |
| 6.9.58 | <b>EarthFaultCompensator</b> .....                    | 265 |
| 6.9.59 | MutualCoupling .....                                  | 266 |
| 6.9.60 | Cut .....   | 267 |
| 6.9.61 | ReactiveCapabilityCurve .....                         | 270 |
| 6.9.62 | Switch .....  | 271 |
| 6.9.63 | StaticVarCompensator .....                            | 272 |
| 6.9.64 | CoolantType enumeration .....                         | 273 |
| 6.9.65 | ProtectedSwitch .....                                 | 274 |
| 6.9.66 | EnergyConsumer .....                                  | 275 |
| 6.9.67 | Junction .....  | 277 |
| 6.9.68 | PhaseTapChangerLinear .....                           | 280 |
| 6.9.69 | Conductor .....                                       | 281 |
| 6.9.70 | PerLengthImpedance .....                              | 282 |
| 6.9.71 | FrequencyConverter .....                              | 283 |
| 6.9.72 | Plant .....   | 284 |
| 6.9.73 | PhaseTapChangerTablePoint <del>root class</del> ..... | 285 |
| 6.9.74 | LoadBreakSwitch .....                                 | 286 |
| 6.9.75 | <b>PetersenCoilModeKind</b> enumeration .....         | 287 |
| 6.9.76 | <b>SynchronousMachineKind</b> enumeration .....       | 287 |
| 6.9.77 | Connector .....                                       | 288 |
| 6.9.78 | AsynchronousMachine .....                             | 289 |
| 6.9.79 | TapChanger .....                                      | 290 |
| 6.9.80 | <b>ShortCircuitRotorKind</b> enumeration .....        | 292 |
| 6.9.81 | WindingConnection enumeration .....                   | 292 |
| 6.9.82 | ExternalNetworkInjection .....                        | 292 |
| 6.9.83 | <b>AsynchronousMachineKind</b> enumeration .....      | 294 |

|         |  |     |
|---------|--|-----|
| 6.9.84  | LinearShuntCompensator .....                         | 295 |
| 6.9.85  | NonlinearShuntCompensator .....                      | 296 |
| 6.9.86  | NonlinearShuntCompensatorPoint root class .....      | 297 |
| 6.9.87  | LinearShuntCompensatorPhase.....                     | 298 |
| 6.9.88  | NonlinearShuntCompensatorPhase .....                 | 298 |
| 6.9.89  | NonlinearShuntCompensatorPhasePoint root class ..... | 299 |
| 6.9.90  | PerLengthLineParameter .....                         | 300 |
| 6.9.91  | TapChangerTablePoint root class .....                | 300 |
| 6.9.92  | PhaseTapChangerTabular .....                         | 301 |
| 6.9.93  | PowerElectronicsConnection .....                     | 302 |
| 6.10    | Package Generation .....                             | 303 |
| 6.10.1  | General .....  | 303 |
| 6.10.2  | Package GenerationDynamicsTrainingSimulation .....   | 304 |
| 6.10.3  | Package Production.....                              | 319 |
| 6.10.16 | SeasonName enumeration.....                          |     |
| 6.11    | Package Outage .....                                 |     |
| 6.11.1  | General 308  |     |
| 6.11.2  | ClearanceTag .....                                   |     |
| 6.11.3  | ClearanceTagType .....                               |     |
| 6.11.4  | OutageSchedule .....                                 |     |
| 6.11.5  | SwitchingOperation.....                              |     |
| 6.11.6  | SwitchState enumeration.....                         |     |
| 6.11    | Package DC .....                                     | 369 |
| 6.11.1  | General .....  | 369 |
| 6.11.2  | ACDCConverter .....                                  | 373 |
| 6.11.3  | ACDCConverterDCTerminal .....                        | 375 |
| 6.11.4  | DCBaseTerminal .....                                 | 376 |
| 6.11.5  | DCConverterUnit .....                                | 377 |
| 6.11.6  | DCLine .....   | 378 |
| 6.11.7  | DCSeriesDevice .....                                 | 378 |
| 6.11.8  | VsQpccControlKind enumeration .....                  | 379 |
| 6.11.9  | CsPpccControlKind enumeration .....                  | 379 |
| 6.11.10 | CsOperatingModeKind enumeration.....                 | 380 |
| 6.11.11 | CsConverter .....                                    | 380 |
| 6.11.12 | DCBreaker.....                                       | 382 |
| 6.11.13 | DCEquipmentContainer .....                           | 382 |
| 6.11.14 | DCBusbar.....  | 383 |
| 6.11.15 | DCConverterOperatingModeKind enumeration.....        | 384 |
| 6.11.16 | DCChopper.....                                       | 384 |
| 6.11.17 | DCDisconnector.....                                  | 385 |
| 6.11.18 | DCGround .....                                       | 386 |
| 6.11.19 | DCLineSegment .....                                  | 386 |
| 6.11.20 | DCShunt.....   | 387 |
| 6.11.21 | DCConductingEquipment .....                          | 388 |
| 6.11.22 | DCSwitch.....  | 389 |
| 6.11.23 | DCNode.....  | 390 |
| 6.11.24 | DCTopologicalIsland.....                             | 390 |
| 6.11.25 | DCPolarityKind enumeration .....                     | 391 |
| 6.11.26 | PerLengthDCLineParameter .....                       | 391 |

|         |  |     |
|---------|--|-----|
| 6.11.27 | DCTerminal .....                           | 392 |
| 6.11.28 | VsPpccControlKind enumeration.....         | 392 |
| 6.11.29 | VsCapabilityCurve .....                    | 393 |
| 6.11.30 | VsConverter .....                          | 393 |
| 6.12    | Package LoadModel .....                    | 395 |
| 6.12.1  | General .....                              | 395 |
| 6.12.2  | ConformLoad.....                           | 397 |
| 6.12.3  | ConformLoadGroup .....                     | 398 |
| 6.12.4  | ConformLoadSchedule .....                  | 399 |
| 6.12.5  | DayType .....                              | 400 |
| 6.12.6  | EnergyArea .....                           | 400 |
| 6.12.7  | LoadArea.....                              | 401 |
| 6.12.8  | LoadGroup .....                            | 401 |
| 6.12.9  | LoadResponseCharacteristic .....           | 402 |
| 6.12.10 | NonConformLoad.....                        | 403 |
| 6.12.11 | NonConformLoadGroup .....                  | 405 |
| 6.12.12 | NonConformLoadSchedule .....               | 405 |
| 6.12.13 | PowerCutZone.....                          | 406 |
| 6.12.14 | Season .....                               | 407 |
| 6.12.15 | SeasonDayTypeSchedule.....                 | 407 |
| 6.12.16 | StationSupply .....                        | 408 |
| 6.12.17 | SubLoadArea.....                           | 409 |
| 6.13    | Package AuxiliaryEquipment.....            | 414 |
| 6.13.1  | General .....                              | 414 |
| 6.13.2  | AuxiliaryEquipment .....                   | 415 |
| 6.13.3  | CurrentTransformer .....                   | 416 |
| 6.13.4  | FaultIndicator .....                       | 417 |
| 6.13.5  | PostLineSensor .....                       | 418 |
| 6.13.6  | PotentialTransformer .....                 | 419 |
| 6.13.7  | PotentialTransformerKind enumeration ..... | 420 |
| 6.13.8  | Sensor.....                                | 420 |
| 6.13.9  | Surge Protector Arrestor .....             | 421 |
| 6.13.10 | WaveTrap .....                             | 422 |
| 6.14    | Package Protection.....                    | 423 |
| 6.14.1  | General .....                              | 423 |
| 6.14.2  | CurrentRelay .....                         | 423 |
| 6.14.3  | ProtectionEquipment .....                  | 424 |
| 6.14.4  | RecloseSequence .....                      | 425 |
| 6.14.5  | SynchrocheckRelay .....                    | 426 |
| 6.15    | Package Equivalents.....                   | 427 |
| 6.15.1  | General .....                              | 427 |
| 6.15.2  | ControlType .....                          | 428 |
| 6.15.2  | EquivalentBranch .....                     | 428 |
| 6.15.3  | EquivalentEquipment .....                  | 431 |
| 6.15.4  | EquivalentInjection .....                  | 432 |
| 6.15.5  | EquivalentNetwork .....                    | 434 |
| 6.15.6  | EquivalentShunt .....                      | 434 |
| 6.16    | Package Meas .....                         | 435 |
| 6.16.1  | General .....                              | 435 |

|         |   |     |
|---------|---|-----|
| 6.16.2  | Accumulator .....                                 | 439 |
| 6.16.3  | AccumulatorLimit .....                            | 439 |
| 6.16.4  | AccumulatorLimitSet .....                         | 440 |
| 6.16.5  | AccumulatorReset .....                            | 440 |
| 6.16.6  | AccumulatorValue .....                            | 441 |
| 6.16.7  | Analog .....                                      | 442 |
| 6.16.8  | AnalogControl .....                               | 443 |
| 6.16.9  | AnalogLimit .....                                 | 444 |
| 6.16.10 | AnalogLimitSet .....                              | 444 |
| 6.16.11 | AnalogValue .....                                 | 445 |
| 6.16.12 | Command .....                                     | 445 |
| 6.16.13 | Control .....                                     | 446 |
| 6.16.14 | Discrete .....                                    | 447 |
| 6.16.15 | DiscreteCommand .....                             | 448 |
| 6.16.16 | DiscreteValue .....                               | 449 |
| 6.16.17 | Limit .....                                       | 450 |
| 6.16.18 | LimitSet .....                                    | 450 |
| 6.16.19 | Measurement .....                                 | 451 |
| 6.16.20 | MeasurementValue .....                            | 452 |
| 6.16.21 | MeasurementValueQuality .....                     | 453 |
| 6.16.22 | MeasurementValueSource .....                      | 453 |
| 6.16.23 | Quality61850 root class .....                     | 454 |
| 6.16.24 | RaiseLowerCommand .....                           | 455 |
| 6.16.25 | SetPoint .....                                    | 456 |
| 6.16.26 | StringMeasurement .....                           | 457 |
| 6.16.27 | StringMeasurementValue .....                      | 457 |
| 6.16.28 | Validity enumeration .....                        | 458 |
| 6.16.29 | ValueAliasSet .....                               | 459 |
| 6.16.30 | ValueToAlias .....                                | 459 |
| 6.17    | Package SCADA .....                               | 460 |
| 6.17.1  | General .....                                     | 460 |
| 6.17.2  | CommunicationLink .....                           | 461 |
| 6.17.3  | RemoteControl .....                               | 462 |
| 6.17.4  | RemotePoint .....                                 | 462 |
| 6.17.5  | RemoteSource .....                                | 463 |
| 6.17.6  | RemoteUnit .....                                  | 464 |
| 6.17.7  | RemoteUnitType enumeration .....                  | 464 |
| 6.17.8  | Source enumeration .....                          | 465 |
| 6.18    | Package ControlArea .....                         | 465 |
| 6.18.1  | General .....                                     | 465 |
| 6.18.2  | AltGeneratingUnitMeas root class .....            | 468 |
| 6.18.3  | AltTieMeas root class .....                       | 468 |
| 6.18.4  | ControlArea .....                                 | 468 |
| 6.18.5  | ControlAreaGeneratingUnit <i>root class</i> ..... | 469 |
| 6.18.6  | ControlAreaTypeKind enumeration .....             | 470 |
| 6.18.7  | TieFlow root class .....                          | 470 |
| 6.19    | Package Contingency .....                         | 471 |
| 6.19.1  | General .....                                     | 471 |
| 6.19.2  | Contingency .....                                 | 472 |

|  |  |     |
|--|--|-----|
| 6.19.3   | ContingencyElement.....                          | 473 |
| 6.19.4   | ContingencyEquipment.....                        | 473 |
| <del>6.19.5</del>  | <del>SvShortCircuit .....</del>                  |     |
| 6.19.5   | ContingencyEquipmentStatusKind enumeration ..... | 474 |
| 6.20   | Package StateVariables .....                     | 474 |
| 6.20.1   | General .....                                    | 474 |
| 6.20.2   | StateVariable root class.....                    | 475 |
| 6.20.3   | SvInjection.....                                 | 475 |
| 6.20.4   | SvPowerFlow.....                                 | 476 |
| 6.20.5   | SvShuntCompensatorSections.....                  | 477 |
| 6.20.6   | SvStatus .....                                   | 477 |
| 6.20.7   | SvTapStep.....                                   | 478 |
| 6.20.8   | SvVoltage.....                                   | 478 |
| <b>Annex A (informative) Custom extensions</b>                           | .....  | 480 |
| A.1  | Overview.....                                    | 480 |
| A.2  | European extensions .....                        | 480 |
| A.2.1  | Overview .....                                   | 480 |
| A.2.2  | OperationalLimitType.....                        | 480 |
| A.2.3  | LimitTypeKind enumeration .....                  | 480 |
| A.2.4  | IdentifiedObject .....                           | 481 |
| A.2.5  | EnergySchedulingType .....                       | 482 |
| A.2.6  | ConnectivityNode .....                           | 482 |
| A.2.7  | TopologicalNode.....                             | 483 |
| <b>Bibliography</b>  | .....  | 485 |
| <b>Figure 1 – Example of working group package dependencies</b>          | .....  | 40  |
| <b>Figure 2 – CIM IEC 61970-301 package diagram</b>                      | .....  | 41  |
| <b>Figure 3 – Example of generalization</b>                              | .....  | 43  |
| <b>Figure 4 – Example of simple association</b>                          | .....  | 44  |
| <b>Figure 5 – Example of aggregation</b>                                 | .....  | 44  |
| <b>Figure 6 – Equipment containers</b>                                   | .....  | 46  |
| <b>Figure 7 – Names</b>  | .....  | 47  |
| <b>Figure 8 – Connectivity model</b>                                     | .....  | 48  |
| <b>Figure 9 – Simple network example</b>                                 | .....  | 49  |
| <b>Figure 10 – Simple network connectivity modeled with CIM Topology</b> | .....  | 50  |
| <b>Figure 11 – Equipment inheritance hierarchy</b>                       | .....  | 51  |
| <b>Figure 12 – Transformer and Tank model</b>                            | .....  | 52  |
| <b>Figure 13 – Transformer model</b>                                     | .....  | 54  |
| <b>Figure 14 – Transformer tap model</b>                                 | .....  | 55  |
| <del><b>Figure 15 – Symmetrical Phase Shifter</b></del>                  | .....  |     |
| <b>Figure 15 – Phasor diagram and equations</b>                          | .....  | 59  |
| <del><b>Figure 16 – Asymmetrical Phase Shifter</b></del>                 | .....  |     |
| <b>Figure 16 – Symmetrical phase shifter impedance variation</b>         | .....  | 60  |
| <b>Figure 17 – Core organization</b>                                     | .....  | 61  |
| <b>Figure 18 – Phasor diagram and equations</b>                          | .....  | 61  |
| <b>Figure 19 – Core organization</b>                                     | .....  | 62  |

|  |     |
|--|-----|
| Figure 20 – Phasor diagram and equations .....   | 64  |
| Figure 21 – Core organization.....   | 65  |
| Figure 22 – Phasor diagram and equations .....   | 65  |
| Figure 23 – Phasor diagrams and equations .....  | 67  |
| Figure 24 – Core organization.....   | 68  |
| Figure 25 – Phase wire data model.....   | 70  |
| <b>Figure 26 – Class diagram IEC61970::IEC61970Dependencies</b>  |     |
| Figure 26 – Phase connectivity .....   | 71  |
| Figure 27 – Station including Petersen coils drawing example .....   | 72  |
| Figure 28 – Grounding device data model .....  | 73  |
| <b>Figure 29 – Instance diagram objects with one terminal coil.....</b>  |     |
| Figure 30 – Cuts, clamps, and jumpers UML model .....  | 75  |
| Figure 31 – Example before cuts and jumpers <b>are</b> applied .....   | 76  |
| Figure 32 – Example after cuts and jumpers <b>are</b> applied .....  | 77  |
| Figure 33 – Example of jumper without cut or clamp .....   | 78  |
| Figure 34 – Navigating from PSR to MeasurementValue .....  | 80  |
| Figure 35 – Measurement placement .....  | 83  |
| Figure 36 – Regulating control models.....   | 84  |
| Figure 37 – HVDC bipolar link from IEC 60633 .....   | 85  |
| Figure 38 – A point-to-point VSC transmission scheme .....   | 86  |
| Figure 39 – HVDC power flow model.....   | 86  |
| Figure 40 – Current Source Converter power flow .....  | 87  |
| Figure 41 – Voltage Source Converter power flow .....  | 88  |
| <b>Figure 42 – Class diagram Topology::TopologicalNodeTerminal</b>   |     |
| Figure 42 – Power flow cases .....   | 89  |
| <b>Figure 43 – Class Diagram Topology::TopologyMeasRelations.....</b>  |     |
| Figure 43 – VSC transmission with a symmetrical monopole illustrated with capacitive earthing on the DC side (IEC 62747) ..... | 90  |
| Figure 44 – VSC P-Q capability curve .....   | 90  |
| Figure 45 – Bipolar VSC transmission with earth return (IEC 62747) .....   | 91  |
| Figure 46 – Object instances for a bipolar current source HVDC line .....  | 92  |
| Figure 47 – Object instances for symmetric monopole VSC HVDC data model.....   | 93  |
| Figure 48 – Containment structure for a bipolar HVDC line .....  | 94  |
| Figure 49 – Containment structure for a bipolar back-to-back HVDC station .....  | 95  |
| Figure 50 – The Basic topology in package Core .....   | 96  |
| Figure 51 – DC and AC topology.....  | 97  |
| Figure 52 – HVDC Containment .....   | 98  |
| Figure 53 – Equipment model .....  | 99  |
| Figure 54 – HVDC line model.....   | 100 |
| Figure 55 – Key for Figure 56, Figure 57 and Figure 58 .....   | 101 |
| Figure 56 – Simple monopole with measurements .....  | 101 |
| Figure 57 – Simple bipolar .....   | 102 |
| Figure 58 – Monopole one side with detailed model .....  | 102 |