



SLOVENSKI STANDARD SIST ETS 300 940 E1:2005

01-februar-2005

8 [[[HJb]`W] b]`hY`ca i b]_UW`g_]`g]ghYa `fZhU&ZL!`GdYWZ]_UW]`UfYhY`d`Ugh`nU
j a Ygb]_`a cV]`bY[UfUX]Uf] GA `\$('\$, žfUh`]]WU) `("%

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile radio interface;
Layer 3 specification (GSM 04.08 version 5.4.1)

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: **ETS 300 940 Edition 1**
<https://standards.iteh.ai/catalog/standards/sist/d6357150-d661-4016-94bb-79c8191f3051/sist-ets-300-940-e1-2005>

ICS:


33.070.01 Mobilni servisi na splošno Mobile services in general

SIST ETS 300 940 E1:2005 en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 940 E1:2005

<https://standards.iteh.ai/catalog/standards/sist/d6357f30-f961-40f6-94bb-79c8191f3051/sist-ets-300-940-e1-2005>



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 940

April 1997

Source: ETSI TC-SMG

Reference: DE/SMG-030408QR3

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile radio interface layer 3 specification
(GSM 04.08 version 5.4.1)**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

X.400: c=fr, a=atlas, p=etsi, s=secretariat - **Internet:** secretariat@etsi.fr

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1997. All rights reserved.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST ETS 300 940 E1:2005](https://standards.iteh.ai/catalog/standards/sist/d6357f30-f961-40f6-94bb-79c8191f3051/sist-ets-300-940-e1-2005)

<https://standards.iteh.ai/catalog/standards/sist/d6357f30-f961-40f6-94bb-79c8191f3051/sist-ets-300-940-e1-2005>

Contents

Foreword	21
0 Scope	23
0.1 Scope of the Technical Specification	23
0.2 Application to the interface structures.....	23
0.3 Structure of layer 3 procedures	23
0.4 Test procedures.....	23
0.5 Use of logical channels.....	23
0.6 Overview of control procedures	24
0.6.1 List of procedures.....	24
0.7 Applicability of implementations	25
1 Normative references	27
2 Definitions and abbreviations	31
2.1 Random values.....	31
2.2 Vocabulary.....	31
3 Radio Resource management procedures	33
3.1 Overview/General.....	33
3.1.1 General	33
3.1.2 Services provided to upper layers	33
3.1.2.1 Idle mode	33
3.1.2.2 Dedicated mode	33
3.1.2.3 Group receive mode.....	34
3.1.2.4 Group transmit mode.....	34
3.1.3 Services required from data link and physical layers	34
3.1.4 Change of dedicated channels	34
3.1.4.1 Change of dedicated channels using SAPI = 0.....	34
3.1.4.2 Change of dedicated channels using other SAPIs than 0	35
3.1.4.3 Sequenced message transfer operation.....	35
3.1.4.3.1 Variables and sequence numbers.....	35
3.1.4.3.1.2 Send sequence number N(SD).....	35
3.1.4.3.2 Procedures for the initiation, transfer execution and termination of the sequenced message transfer operation	35
3.1.4.3.2.2 Transfer Execution.....	35
3.1.5 Procedure for Service Request and Contention Resolution	36
3.2 Idle mode procedures.....	37
3.2.1 Mobile Station side	37
3.2.2 Network side.....	37
3.2.2.1 System information broadcasting.....	37
3.2.2.2 Paging	38
3.3 RR connection establishment.....	38
3.3.1 RR connection establishment initiated by the MS.....	38
3.3.1.1 Entering the dedicated mode : immediate assignment procedure.....	38
3.3.1.1.1 Permission to access the network.....	38
3.3.1.1.2 Initiation of the immediate assignment procedure	39
3.3.1.1.3 Answer from the network	40
3.3.1.1.3.1 On receipt of a CHANNEL REQUEST message.....	40

	3.3.1.1.3.2	Assignment rejection	41
	3.3.1.1.4	Assignment completion.....	41
	3.3.1.1.5	Abnormal cases.....	42
	3.3.1.2	Entering the group transmit mode: uplink access procedure.....	42
	3.3.1.2.1	MS side	42
	3.3.1.2.1.1	Uplink investigation procedure	42
	3.3.1.2.1.2	Uplink access procedure	43
	3.3.1.2.2	Network side	43
	3.3.1.2.3	Abnormal cases.....	43
3.3.2		Paging procedure	43
	3.3.2.1	Paging initiation by the network	43
	3.3.2.2	Paging response	45
	3.3.2.3	Abnormal cases	45
3.3.3		Notification procedure	46
	3.3.3.1	Notification of a call	46
	3.3.3.2	Joining a VGCS or VBS call	46
	3.3.3.2	"Reduced NCH monitoring" mechanism	47
3.4		Procedures in dedicated mode and in group transmit mode.....	48
3.4.1		SACCH procedures.....	48
	3.4.1.1	General.....	48
	3.4.1.2	Measurement report.....	48
3.4.2		Transfer of messages and link layer service provision.....	49
3.4.3		Channel assignment procedure	49
	3.4.3.1	Channel assignment initiation.....	50
	3.4.3.2	Assignment completion	51
	3.4.3.3	Abnormal cases	51
3.4.4		Handover procedure.....	52
	3.4.4.1	Handover initiation	52
	3.4.4.2	Physical channel establishment.....	54
	3.4.4.2.1	Finely synchronized cell case	54
	3.4.4.2.2	Non-synchronized cell case	54
	3.4.4.2.3	Pseudo-synchronized cell case	55
	3.4.4.2.4	Pre-synchronized cell case	55
	3.4.4.3	Handover completion	55
	3.4.4.4	Abnormal cases	56
3.4.5		Frequency redefinition procedure	57
	3.4.5.1	Abnormal cases	57
3.4.6		Channel mode modify procedure.....	57
	3.4.6.1	Normal channel mode modify procedure.....	58
	3.4.6.1.1	Initiation of the channel mode modify procedure	58
	3.4.6.1.2	Completion of channel mode modify procedure	58
	3.4.6.1.3	Abnormal cases.....	58
	3.4.6.2	Channel mode modify procedure for a voice group call talker	58
	3.4.6.2.1	Initiation of the channel mode modify procedure	58
	3.4.6.2.2	Completion of mode change procedure.....	58
	3.4.6.2.3	Abnormal cases.....	59
3.4.7		Ciphering mode setting procedure.....	59
	3.4.7.1	Ciphering mode setting initiation	59
	3.4.7.2	Ciphering mode setting completion	59
3.4.8		Additional channel assignment procedure.....	60
	3.4.8.1	Additional assignment procedure initiation	60
	3.4.8.2	Additional assignment procedure completion	60
	3.4.8.3	Abnormal cases	60
3.4.9		Partial channel release procedure	61
	3.4.9.1	Partial release procedure initiation.....	61

	3.4.9.2	Abnormal cases.....	61	
3.4.10		Classmark change procedure	61	
3.4.11		Classmark interrogation procedure.....	61	
	3.4.11.1	Classmark interrogation initiation	62	
	3.4.11.2	Classmark interrogation completion	62	
3.4.12		Indication of notifications and paging informations.....	62	
3.4.13		RR connection release procedure	63	
	3.4.13.1	Normal release procedure	63	
		3.4.13.1.1 Channel release procedure initiation in dedicated mode and in group transmit mode.....	63	
		3.4.13.1.2 Abnormal cases.....	64	
	3.4.13.2	Radio link failure in dedicated mode.....	64	
		3.4.13.2.1 Mobile side	64	
		3.4.13.2.2 Network side	64	
	3.4.13.3	RR connection abortion in dedicated mode.....	65	
	3.4.13.4	Uplink release procedure in group transmit mode.....	65	
3.4.14		Receiving a RR STATUS message by a RR entity.....	65	
3.4.15		Group receive mode procedures.....	65	
	3.4.15.1	MS side	65	
		3.4.15.1.1 Reception of the VGCS or VBS channel.....	65	
		3.4.15.1.2 Monitoring of downlink messages and related procedures	65	
		3.4.15.1.2.1 Channel assignment procedure	65	
		3.4.15.1.2.2 Frequency redefinition procedure	66	
		3.4.15.1.2.3 Channel mode modify procedure.....	66	
		3.4.15.1.2.4 Notification and paging information	66	
		3.4.15.1.2.5 Uplink status messages.....	66	
		3.4.15.1.2.6 Channel release message	66	
		3.4.15.1.3 Uplink reply procedure	66	
		3.4.15.1.4 Leaving the group receive mode	67	
		3.4.15.1.4.1 Returning to idle mode	67	
		3.4.15.1.4.2 Going to group transmit mode	67	
	3.4.15.2	Network side	67	
		3.4.15.2.1 Provision of messages on the VGCS or VBS channel downlink	67	
		3.4.15.2.1.1 General	67	
		3.4.15.2.1.2 Provision of general information messages	67	
		3.4.15.2.1.3 Provision of messages related to the voice group call uplink channel	68	
		3.4.15.2.2 Release of the VGCS or VBS Channels.....	68	
	3.4.15.3	Failure cases.....	69	
4		Elementary procedures for Mobility Management.....	69	
	4.1	General	69	
		4.1.1 Type of MM procedures.....	69	
		4.1.2 MM sublayer states	70	
		4.1.2.1 MM sublayer states in the MS.....	70	
			4.1.2.1.1 Main states	70
			4.1.2.1.2 Substates of the MM IDLE state.....	73
		4.1.2.2 The update Status.....	74	
		4.1.2.3 MM sublayer states on the network side.....	75	
	4.2	Behaviour in MM IDLE State	76	
		4.2.1 Primary Service State selection	76	
			4.2.1.1 Selection of the Service State after Power On.	76
			4.2.1.2 Other Cases.....	77
		4.2.2 Detailed Description of the MS behaviour in MM IDLE State.	77	

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 940 E1:2005

<https://standards.iteh.ai/catalog/standards/sist/d6357f30-b61-408-94b7-79c8191f051/sist-ets-300-940-e1-2005>

79c8191f051/sist-ets-300-940-e1-2005

	4.2.2.1	Service State, NORMAL SERVICE.....	77
	4.2.2.2	Service State, ATTEMPTING TO UPDATE	78
	4.2.2.3	Service State, LIMITED SERVICE	78
	4.2.2.4	Service State, NO IMSI	78
	4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE	79
	4.2.2.6	Service State, SEARCH FOR PLMN.....	79
	4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	79
	4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE)	80
	4.2.3	Service state when back to state MM IDLE from another state	80
4.3		MM common procedures.....	81
	4.3.1	TMSI reallocation procedure.....	81
	4.3.1.1	TMSI reallocation initiation by the network.....	81
	4.3.1.2	TMSI reallocation completion by the MS	81
	4.3.1.3	TMSI reallocation completion in the network.....	82
	4.3.1.4	Abnormal cases	82
	4.3.2	Authentication procedure	83
	4.3.2.1	Authentication request by the network.....	83
	4.3.2.2	Authentication response by the MS.....	83
	4.3.2.3	Authentication processing in the network.....	83
	4.3.2.4	Ciphering key sequence number	83
	4.3.2.5	Unsuccessful authentication.....	84
	4.3.2.6	Abnormal cases	84
	4.3.3	Identification procedure	85
	4.3.3.1	Identity request by the network	85
	4.3.3.2	Identification response by the MS	85
	4.3.3.3	Abnormal cases	85
	4.3.4	IMSI detach procedure	86
	4.3.4.1	IMSI detach initiation by the MS	86
	4.3.4.2	IMSI detach procedure in the network	86
	4.3.4.3	IMSI detach completion by the MS	86
	4.3.4.4	Abnormal cases	86
	4.3.5	Abort procedure	87
	4.3.5.1	Abort procedure initiation by the network	87
	4.3.5.2	Abort procedure in the MS.....	87
	4.3.6	MM information procedure.....	87
	4.3.6.1	MM information procedure initiation by the network.....	87
	4.3.6.2	MM information procedure in the MS	87
4.4		MM specific procedures.....	88
	4.4.1	Location updating procedure.....	88
	4.4.2	Periodic updating	89
	4.4.3	IMSI attach procedure	90
	4.4.4	Generic Location Updating procedure.....	90
	4.4.4.1	Location updating initiation by the MS	90
	4.4.4.1a	Network Request for Additional MS Capability Information	90
	4.4.4.2	Identification request from the network	90
	4.4.4.3	Authentication by the network.....	90
	4.4.4.4	Ciphering mode setting by the network	90
	4.4.4.5	Attempt Counter.....	90
	4.4.4.6	Location updating accepted by the network.....	91
	4.4.4.7	Location updating not accepted by the network	91
	4.4.4.8	Release of RR connection after location updating	92
	4.4.4.9	Abnormal cases on the MS side	92
	4.4.4.10	Abnormal cases on the network side	93
4.5		Connection management sublayer service provision.....	94
	4.5.1	MM connection establishment.....	94
	4.5.1.1	MM connection establishment initiated by the MS	94
	4.5.1.2	Abnormal cases	97
	4.5.1.3	MM connection establishment initiated by the network.....	98

	4.5.1.4	Abnormal cases.....	98
	4.5.1.5	MM connection establishment for emergency calls.....	99
	4.5.1.6	Call re-establishment.....	99
	4.5.1.6.1	Call re-establishment, initiation by the MS.....	100
	4.5.1.6.2	Abnormal cases.....	101
	4.5.1.7	Forced release during MO MM connection establishment.....	102
4.5.2		MM connection information transfer phase.....	102
	4.5.2.1	Sending CM messages.....	103
	4.5.2.2	Receiving CM messages.....	103
	4.5.2.3	Abnormal cases.....	103
4.5.3		MM connection release.....	103
	4.5.3.1	Release of associated RR connection.....	103
	4.5.3.2	Uplink release in a voice group call.....	104
4.6		Receiving a MM STATUS message by a MM entity.....	104
5		Elementary procedures for circuit-switched Call Control.....	105
5.1		Overview.....	105
	5.1.1	General.....	105
	5.1.2	Call Control States.....	108
	5.1.2.1	Call states at the MS side of the interface.....	108
	5.1.2.1.1	Null (State U0).....	108
	5.1.2.1.2	MM Connection pending (U0.1).....	108
	5.1.2.1.3	Call initiated (U1).....	108
	5.1.2.1.4	Mobile originating call proceeding (U3).....	108
	5.1.2.1.5	Call delivered (U4).....	108
	5.1.2.1.6	Call present (U6).....	108
	5.1.2.1.7	Call received (U7).....	108
	5.1.2.1.8	Connect Request (U8).....	108
	5.1.2.1.9	Mobile terminating call confirmed (U9).....	108
	5.1.2.1.10	Active (U10).....	108
	5.1.2.1.11	Disconnect request (U11).....	108
	5.1.2.1.12	Disconnect indication (U12).....	109
	5.1.2.1.13	Release request (U19).....	109
	5.1.2.1.14	Mobile originating modify (U26).....	109
	5.1.2.1.15	Mobile terminating modify (U27).....	109
	5.1.2.2	Network call states.....	109
	5.1.2.2.1	Null (State N0).....	109
	5.1.2.2.2	MM connection pending (N0.1).....	109
	5.1.2.2.3	Call initiated (N1).....	109
	5.1.2.2.4	Mobile originating call proceeding (N3).....	109
	5.1.2.2.5	Call delivered (N4).....	109
	5.1.2.2.6	Call present (N6).....	109
	5.1.2.2.7	Call received (N7).....	109
	5.1.2.2.8	Connect request (N8).....	110
	5.1.2.2.9	Mobile terminating call confirmed (N9).....	110
	5.1.2.2.10	Active (N10).....	110
	5.1.2.2.11	{Not used}.....	110
	5.1.2.2.12	Disconnect indication (N12).....	110
	5.1.2.2.13	Release request (N19).....	110
	5.1.2.2.14	Mobile originating modify (N26).....	110
	5.1.2.2.15	Mobile terminating modify (N27).....	110
	5.1.2.2.16	Connect Indication (N28).....	110
5.2		Call establishment procedures.....	110
	5.2.1	Mobile originating call establishment.....	111
	5.2.1.1	Call initiation.....	111
	5.2.1.2	Receipt of a setup message.....	112
	5.2.1.3	Receipt of a CALL PROCEEDING message.....	113
	5.2.1.4	Notification of progressing mobile originated call.....	113

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 940 E1:2005
<https://standards.iteh.ai/catalog/standards/sist/d6357f30-061-40f6-945b-79c8191f051/sist-ets-300-940-e1-2005>

	5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment	113
	5.2.1.4.2	Call progress in the PLMN/ISDN environment.....	114
	5.2.1.5	Alerting.....	114
	5.2.1.6	Call connected	115
	5.2.1.7	Call rejection.....	115
	5.2.1.8	Transit network selection	115
	5.2.1.9	Traffic channel assignment at mobile originating call establishment.....	116
	5.2.1.10	Call queuing at mobile originating call establishment.....	116
5.2.2		Mobile terminating call establishment.....	116
	5.2.2.1	Call indication.....	116
	5.2.2.2	Compatibility checking	117
	5.2.2.3	Call confirmation	117
	5.2.2.3.1	Response to SETUP	117
	5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	117
	5.2.2.3.3	Call failure procedures	118
	5.2.2.3.4	Called MS clearing during mobile terminating call establishment	118
	5.2.2.4	Notification of interworking in connection with mobile terminating call establishment.....	118
	5.2.2.5	Call accept	119
	5.2.2.6	Active indication	119
	5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	119
	5.2.2.8	Call queuing at mobile terminating call establishment.....	119
	5.2.2.9	User connection attachment during a mobile terminating call.....	119
5.3		Signalling procedures during the "active" state	120
	5.3.1	User notification procedure	120
	5.3.2	Call rearrangements.....	120
	5.3.3	Not used	120
	5.3.4	Support of Dual Services.....	120
	5.3.4.1	Service Description	120
	5.3.4.2	Call establishment.....	121
	5.3.4.2.1	Mobile Originating Establishment.....	121
	5.3.4.2.2	Mobile Terminating Establishment	121
	5.3.4.3	Changing the Call Mode.....	122
	5.3.4.3.1	Initiation of in-call modification.....	122
	5.3.4.3.2	Successful completion of in-call modification	122
	5.3.4.3.3	Change of the channel configuration ...	123
	5.3.4.3.4	Failure of in-call modification	123
	5.3.4.4	Abnormal procedures	123
5.4		Call clearing	125
	5.4.1	Terminology	125
	5.4.2	Exception conditions.....	125
	5.4.3	Clearing initiated by the MS.....	125
	5.4.3.1	Initiation of call clearing.....	125
	5.4.3.2	Receipt of a DISCONNECT message from the MS.....	126
	5.4.3.3	Receipt of a RELEASE message from the network.....	126
	5.4.3.4	Receipt of a RELEASE COMPLETE message from the MS.....	126
	5.4.3.5	Abnormal cases	126
5.4.4		Clearing initiated by the network	126
	5.4.4.1	Clearing when tones/announcements provided.....	126

	5.4.4.1.1	Receipt of a DISCONNECT message with progress indicator #8 from the network	127
	5.4.4.1.2	Expiry of timer T306	127
	5.4.4.2	Clearing when tones/announcements not provided	127
	5.4.4.2.1	Receipt of a DISCONNECT message without progress indicator or with progress indicator different from #8 from the network	127
	5.4.4.2.2	Receipt of a RELEASE message from the MS.....	127
	5.4.4.2.3	Abnormal cases.....	127
	5.4.4.3	Completion of clearing.....	127
	5.4.4.3.1	Abnormal cases.....	128
	5.4.5	Clear collision.....	128
5.5		Miscellaneous procedures.....	128
	5.5.1	In-band tones and announcements	128
	5.5.2	Call collisions.....	128
	5.5.3	Status procedures	128
	5.5.3.1	Status enquiry procedure.....	128
	5.5.3.2	Reception of a STATUS message by a CC entity	129
	5.5.3.2.1	STATUS message with incompatible state.....	129
	5.5.3.2.2	STATUS message with compatible state.....	129
	5.5.4	Call re-establishment, MS side	129
	5.5.4.1	Indication from the mobility management sublayer	129
	5.5.4.2	Reaction of call control.....	130
	5.5.4.3	Completion of re-establishment	130
	5.5.4.4	Unsuccessful outcome.....	130
	5.5.5	Call re-establishment, network side.....	130
	5.5.5.1	State alignment.....	130
	5.5.6	Progress.....	130
	5.5.7	DTMF protocol control procedure	131
	5.5.7.1	Start DTMF request by the MS	131
	5.5.7.2	Start DTMF response by the network.....	131
	5.5.7.3	Stop DTMF request by the MS	131
	5.5.7.4	Stop DTMF response by the network	131
	5.5.7.5	Sequencing of subsequent start DTMF requests by the MS	131
6		Support of packet services.....	133
7		Examples of structured procedures.....	134
	7.1	General	134
	7.1.1	Paging request.....	135
	7.1.2	Immediate assignment	135
	7.1.3	Service request and contention resolution	136
	7.1.4	Authentication.....	136
	7.1.5	Ciphering mode setting.....	137
	7.1.6	Transaction phase	137
	7.1.6.1	Channel mode modify.....	137
	7.1.7	Channel release.....	138
	7.2	Abnormal cases	139
	7.3	Selected examples	139
	7.3.1	Location updating	140
	7.3.2	Mobile originating call establishment.....	142
	7.3.3	Mobile terminating call establishment.....	146
	7.3.4	Call clearing	149
	7.3.5	DTMF protocol control	150

	7.3.6	Handover	151
	7.3.7	In-call modification	153
	7.3.8	Call re-establishment.....	154
8		Handling of unknown, unforeseen, and erroneous protocol data.....	155
	8.1	General	155
	8.2	Message too short.....	155
	8.3	Unknown or unforeseen transaction identifier	155
	8.4	Unknown or unforeseen message type	156
	8.5	Non-semantic mandatory information element errors.....	156
	8.5.1	Radio resource management	157
	8.5.2	Mobility management	157
	8.5.3	Call control.....	157
	8.6	Unknown and unforeseen IEs in the non-imperative message part	157
	8.6.1	IEs unknown in the message.....	157
	8.6.2	Out of sequence IEs	157
	8.6.3	Repeated IEs	158
	8.7	Non-imperative message part errors	158
	8.7.1	Syntactically incorrect optional IEs	158
	8.7.2	Conditional IE errors	158
	8.8	Messages with semantically incorrect contents	158
9		Message functional definitions and contents.....	159
	9.1	Messages for Radio Resources management.....	160
	9.1.1	Additional assignment.....	162
	9.1.1.1	Mobile Allocation.....	162
	9.1.1.2	Starting Time	162
	9.1.2	Assignment command	163
	9.1.2.1	Mode of the First Channel.....	164
	9.1.2.2	Description of the Second Channel	164
	9.1.2.3	Mode of the Second Channel	164
	9.1.2.4	Mobile Allocation and Frequency List, after the starting time	164
	9.1.2.5	Starting Time	164
	9.1.2.6	Reference cell frequency list	165
	9.1.2.7	Cell Channel Description	165
	9.1.2.8	Cipher Mode Setting.....	165
	9.1.2.9	VGCS target mode Indication.....	166
	9.1.3	Assignment complete	166
	9.1.4	Assignment failure.....	167
	9.1.5	Channel mode modify.....	167
	9.1.5.1	Channel Description.....	167
	9.1.5.2	VGCS target mode Indication.....	167
	9.1.6	Channel mode modify acknowledge.....	168
	9.1.7	Channel release.....	169
	9.1.7.1	Channel description and mobile allocation.....	169
	9.1.7.2	Group Cipher Key Number.....	169
	9.1.8	Channel request.....	170
	9.1.9	Ciphering mode command	172
	9.1.10	Ciphering mode complete	173
	9.1.10.1	Mobile Equipment Identity.....	173
	9.1.11	Classmark change	173
	9.1.11.1	Additional MS Classmark Information.....	173
	9.1.11.2	MS Classmark	173
	9.1.12	Classmark enquiry	174
	9.1.13	Frequency redefinition	175
	9.1.13.1	Cell Channel Description	175
	9.1.14	Handover access	175
	9.1.15	Handover command	176
	9.1.15.1	Synchronization Indication	177

9.1.15.2	Mode of the First Channel.....	177
9.1.15.3	Description of the Second Channel	177
9.1.15.4	Mode of the Second Channel	177
9.1.15.5	Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time	178
9.1.15.6	Starting Time.....	178
9.1.15.7	Reference cell frequency list	179
9.1.15.8	Real Time Difference.....	179
9.1.15.9	Timing Advance	179
9.1.15.10	Cipher Mode Setting	179
9.1.15.11	VGCS target mode indication.....	179
9.1.16	Handover complete.....	180
9.1.16.1	Mobile Observed Time Difference	180
9.1.17	Handover failure	180
9.1.18	Immediate assignment	181
9.1.18.1	Mobile Allocation.....	181
9.1.18.2	Starting Time.....	181
9.1.18.3	IA Rest Octets (Frequency parameters, before time)	181
9.1.19	Immediate assignment extended.....	182
9.1.19.1	Unnecessary IEs.....	182
9.1.19.2	Mobile Allocation.....	183
9.1.19.3	Starting Time.....	183
9.1.19.4	Maximum message length.....	183
9.1.19.5	IAX Rest Octets	183
9.1.20	Immediate assignment reject	184
9.1.20.1	Use of the indexes	184
9.1.20.2	Filling of the message	184
9.1.21	Measurement report	185
9.1.22	Paging request type 1.....	186
9.1.22.1	Unnecessary IE	186
9.1.22.2	Channels needed for Mobiles 1 and 2	186
9.1.22.3	Mobile Identities.....	186
9.1.22.4	P1 Rest Octets.....	186
9.1.23	Paging request type 2.....	187
9.1.23.1	Channels needed for Mobiles 1 and 2	187
9.1.23.2	Mobile Identity 3	187
9.1.23.3	P2 Rest Octets.....	187
9.1.24	Paging request type 3.....	188
9.1.24.1	Channels needed for Mobiles 1 and 2	188
9.1.24.2	P3 Rest Octets.....	188
9.1.25	Paging response.....	189
9.1.25.1	MS Classmark.....	189
9.1.26	Partial release.....	190
9.1.26.1	Channel Description	190
9.1.27	Partial release complete.....	190
9.1.28	Physical information	191
9.1.29	RR Status	191
9.1.30	Synchronization channel information	192
9.1.31	System information Type 1	193
9.1.32	System information type 2.....	193
9.1.33	System information type 2bis.....	194
9.1.34	System information type 2ter.....	195
9.1.35	System information type 3.....	196
9.1.36	System information type 4.....	197
9.1.36.1	CBCH Channel description.....	198
9.1.36.2	CBCH Mobile Allocation.....	198
9.1.36.3	SI 4 Rest Octets.....	198
9.1.37	System information type 5.....	198
9.1.38	System information type 5bis.....	199
9.1.39	System information type 5ter.....	199

9.1.40	System information type 6	200
9.1.40.1	Cell Identity	201
9.1.40.2	Location Area Identification	201
9.1.40.3	Cell Options	201
9.1.40.4	NCC permitted	201
9.1.40.5	Group or broadcast call reference	201
9.1.40.6	PCH information	201
9.1.40.7	Composition if the optional information elements on the SACCH of a VGCS or VBS downlink	201
9.1.41	System information type 7	202
9.1.42	System information type 8	202
9.1.43	System information Type 9	203
9.1.44	System information type 10	204
9.1.44.1	Representation of the information on the BCCHs	204
9.1.44.2	Group or broadcast call reference	204
9.1.44.3	PCH information	205
9.1.44.4	Composition of the optional information elements	205
9.1.45	System information type 10bis	206
9.1.46	System information type 11	207
9.1.46.1	VBS/VGCS Channel description and NCH position	208
9.1.46.2	Frequency list	208
9.1.46.3	Starting Time	208
9.1.46.4	Group or broadcast call reference	208
9.1.46.5	PCH information	209
9.1.46.6	Composition of the optional information elements	209
9.1.47	System information type 12	210
9.1.47.1	Cell description and cell reselection parameters	210
9.1.A1	Notification/NCH Type 1	211
9.1.A1.1	Group Channel Description	211
9.1.A1.2	NT/N1 Rest Octets	211
9.1.A2	Notification/NCH Type 2	212
9.1.A2.1	Cell Description	212
9.1.A2.2	NT/N2 Rest Octets	212
9.1.A3	Notification/FACCH	213
9.1.A3.1	VBS/VGCS Channel description	214
9.1.A3.2	PCH information	214
9.1.A3.3	Paging Information	214
9.1.A3.4	Composition of the optional information elements	214
9.1.A4	Notification/SACCH	215
9.1.A4.1	PCH information	215
9.1.A4.2	Paging Information	215
9.1.A4.3	Composition of the optional information elements	216
9.1.A5	Uplink busy	216
9.1.A6	Uplink free	217
9.1.A6.1	UIC	217
9.1.A6.2	Uplink access request indication	217
9.1.A6.3	Group or broadcast call reference	217
9.1.A6.4	PCH information	218
9.1.A6.5	Paging Information	218
9.1.A6.6	Composition of the optional information elements	218
9.1.A7	Uplink release	218
9.1.A8	Uplink access	219
9.1.A9	VGCS uplink grant	220
9.1.A10	Talker indication	220
9.1.A11	Notification response	221
9.2	Messages for mobility management	222
9.2.1	Authentication reject	223
9.2.2	Authentication request	223
9.2.3	Authentication response	224
9.2.4	CM Re-establishment request	224

	9.2.4.1	Location area identification	224
	9.2.4.2	MS Classmark.....	224
9.2.5		CM service accept.....	225
9.2.6		CM service reject	225
9.2.7		CM service abort.....	226
9.2.8		Abort.....	226
9.2.9		CM service request.....	227
	9.2.9.1	MS Classmark.....	227
	9.2.9.2	Priority	227
9.2.10		Identity request	227
9.2.11		Identity response.....	229
9.2.12		IMSI detach indication.....	229
	9.2.12.1	MS Classmark.....	229
9.2.13		Location updating accept.....	230
	9.2.13.1	Follow on proceed	230
9.2.14		Location updating reject	230
9.2.15		Location updating request	231
	9.2.15.1	Location area identification	231
	9.2.15.2	MS Classmark.....	231
9.2.15a		MM information	232
	9.2.15a.1	Full name for network.....	232
	9.2.15a.2	Short name for network.....	232
	9.2.15a.3	Network time zone	232
	9.2.15a.4	Network time zone and time.....	232
9.2.16		MM Status	233
9.2.17		TMSI reallocation command	234
9.2.18		TMSI reallocation complete.....	234
9.2.19		MM Null	235
9.3		Messages for circuit-switched call control.....	236
	9.3.1	Alerting.....	237
	9.3.1.1	Alerting (network to MS direction)	237
		9.3.1.1.1 Facility.....	237
		9.3.1.1.2 Progress indicator	237
		9.3.1.1.3 User-user.....	237
	9.3.1.2	Alerting (MS to network direction)	238
		9.3.1.2.1 Facility.....	238
		9.3.1.2.2 User-user.....	238
		9.3.1.2.3 SS version	238
9.3.2		Call confirmed	239
	9.3.2.1	Repeat indicator	240
	9.3.2.2	Bearer capability 1 and bearer capability 2	240
	9.3.2.3	Cause	240
	9.3.2.4	CC Capabilities.....	240
9.3.3		Call proceeding	241
	9.3.3.1	Repeat indicator	242
	9.3.3.2	Bearer capability 1 and bearer capability 2	242
	9.3.3.3	Facility	242
	9.3.3.4	Progress Indicator	242
	9.3.3.5	Priority granted.....	242
9.3.4		Congestion control.....	243
	9.3.4.1	Cause	243
9.3.5		Connect.....	244
	9.3.5.1	Connect (network to MS direction)	244
		9.3.5.1.1 Facility.....	245
		9.3.5.1.2 Progress indicator	245
		9.3.5.1.3 User-user.....	245
	9.3.5.2	Connect (MS to network direction)	245
		9.3.5.2.1 Facility.....	246
		9.3.5.2.2 User-user.....	246
		9.3.5.2.3 SS version	246