



**Universal Mobile Telecommunications System (UMTS);
LTE;
Non-Access-Stratum (NAS)
protocol for Evolved Packet System (EPS);
Stage 3
(3GPP TS 24.301 version 13.9.0 Release 13)**



ReferenceRTS/TSGC-0124301vd90

Keywords

LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2017.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.
GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	18
1 Scope	19
2 References	19
3 Definitions and abbreviations.....	22
3.1 Definitions	22
3.2 Abbreviations	27
4 General	29
4.1 Overview	29
4.2 Linkage between the protocols for EPS mobility management and EPS session management	29
4.2.A Handling of NAS signalling low priority indication	30
4.3 UE mode of operation	30
4.3.1 General.....	30
4.3.2 Change of UE mode of operation	31
4.3.2.1 General.....	31
4.3.2.2 Change of UE's usage setting.....	33
4.3.2.3 Change of voice domain preference for E-UTRAN.....	34
4.3.2.4 Change or determination of IMS registration status.....	35
4.3.2.5 Change of configuration regarding the use of SMS.....	36
4.4 NAS security	37
4.4.1 General.....	37
4.4.2 Handling of EPS security contexts	37
4.4.2.1 General.....	37
4.4.2.2 Establishment of a mapped EPS security context during intersystem handover	38
4.4.2.3 Establishment of secure exchange of NAS messages	39
4.4.2.4 Change of security keys	40
4.4.2.5 Derivation of keys at CS to PS SRVCC handover from A/Gb mode to S1 mode or from Iu mode to S1 mode	40
4.4.3 Handling of NAS COUNT and NAS sequence number	41
4.4.3.1 General.....	41
4.4.3.2 Replay protection.....	42
4.4.3.3 Integrity protection and verification.....	42
4.4.3.4 Ciphering and deciphering.....	43
4.4.3.5 NAS COUNT wrap around.....	43
4.4.4 Integrity protection of NAS signalling messages.....	43
4.4.4.1 General.....	43
4.4.4.2 Integrity checking of NAS signalling messages in the UE	44
4.4.4.3 Integrity checking of NAS signalling messages in the MME	44
4.4.5 Ciphering of NAS signalling messages	46
4.5 Disabling and re-enabling of UE's E-UTRA capability	46
4.6 Applicability of procedures	48
4.6.1 Relay nodes.....	48
4.7 EPS mobility management and EPS session management in NB-S1 mode.....	48
4.8 EPS mobility management and EPS session management in WB-S1 mode for IoT.....	49
5 Elementary procedures for EPS mobility management.....	49
5.1 Overview	49
5.1.1 General.....	49
5.1.2 Types of EMM procedures	49
5.1.3 EMM sublayer states	50
5.1.3.1 General.....	50
5.1.3.2 EMM sublayer states in the UE.....	51

5.1.3.2.1	General	51
5.1.3.2.2	Main states.....	51
5.1.3.2.2.1	EMM-NULL	51
5.1.3.2.2.2	EMM-DEREGISTERED	51
5.1.3.2.2.3	EMM-REGISTERED-INITIATED	51
5.1.3.2.2.4	EMM-REGISTERED	51
5.1.3.2.2.5	EMM-DEREGISTERED-INITIATED	51
5.1.3.2.2.6	EMM-TRACKING-AREA-UPDATING-INITIATED	51
5.1.3.2.2.7	EMM-SERVICE-REQUEST-INITIATED	51
5.1.3.2.3	Substates of state EMM-DEREGISTERED	52
5.1.3.2.3.1	General.....	52
5.1.3.2.3.2	EMM-DEREGISTERED.NORMAL-SERVICE	52
5.1.3.2.3.3	EMM-DEREGISTERED.LIMITED-SERVICE	52
5.1.3.2.3.4	EMM-DEREGISTERED.ATTEMPTING-TO-ATTACH	53
5.1.3.2.3.5	EMM-DEREGISTERED.PLMN-SEARCH	53
5.1.3.2.3.6	EMM-DEREGISTERED.NO-IMSI	53
5.1.3.2.3.7	EMM-DEREGISTERED.ATTACH-NEEDED	53
5.1.3.2.3.8	EMM-DEREGISTERED.NO-CELL-AVAILABLE	53
5.1.3.2.4	Substates of state EMM-REGISTERED	53
5.1.3.2.4.1	General.....	53
5.1.3.2.4.2	EMM-REGISTERED.NORMAL-SERVICE	53
5.1.3.2.4.3	EMM-REGISTERED.ATTEMPTING-TO-UPDATE	53
5.1.3.2.4.4	EMM-REGISTERED.LIMITED-SERVICE	53
5.1.3.2.4.5	EMM-REGISTERED.PLMN-SEARCH	53
5.1.3.2.4.6	EMM-REGISTERED.UPDATE-NEEDED	53
5.1.3.2.4.7	EMM-REGISTERED.NO-CELL-AVAILABLE	54
5.1.3.2.4.8	EMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM	54
5.1.3.2.4.9	EMM-REGISTERED.IMSI-DETACH-INITIATED	54
5.1.3.3	EPS update status	54
5.1.3.4	EMM sublayer states in the MME	54
5.1.3.4.1	EMM-DEREGISTERED	54
5.1.3.4.2	EMM-COMMON-PROCEDURE-INITIATED	54
5.1.3.4.3	EMM-REGISTERED	55
5.1.3.4.4	EMM-DEREGISTERED-INITIATED	55
5.1.4	Coordination between EMM and GMM	55
5.1.5	Coordination between EMM and MM	56
5.2	Behaviour of the UE in state EMM-DEREGISTERED and state EMM-REGISTERED	56
5.2.1	General.....	56
5.2.2	UE behaviour in state EMM-DEREGISTERED	56
5.2.2.1	General	56
5.2.2.2	Primary substate selection	57
5.2.2.2.1	Selection of the substate after power on	57
5.2.2.3	Detailed description of UE behaviour in state EMM-DEREGISTERED	57
5.2.2.3.1	NORMAL-SERVICE	57
5.2.2.3.2	LIMITED-SERVICE	57
5.2.2.3.3	ATTEMPTING-TO-ATTACH	57
5.2.2.3.4	PLMN-SEARCH	58
5.2.2.3.5	NO-IMSI	58
5.2.2.3.6	ATTACH-NEEDED	58
5.2.2.3.7	NO-CELL-AVAILABLE	58
5.2.2.4	Substate when back to state EMM-DEREGISTERED from another EMM state	58
5.2.3	UE behaviour in state EMM-REGISTERED	59
5.2.3.1	General	59
5.2.3.2	Detailed description of UE behaviour in state EMM-REGISTERED	59
5.2.3.2.1	NORMAL-SERVICE	59
5.2.3.2.2	ATTEMPTING-TO-UPDATE	59
5.2.3.2.3	LIMITED-SERVICE	59
5.2.3.2.4	PLMN-SEARCH	60
5.2.3.2.5	UPDATE-NEEDED	60
5.2.3.2.6	NO-CELL-AVAILABLE	60
5.2.3.2.7	ATTEMPTING-TO-UPDATE-MM	60
5.2.3.2.8	IMSI-DETACH-INITIATED	60

5.3	General on elementary EMM procedures.....	61
5.3.1	EMM modes and NAS signalling connection.....	61
5.3.1.1	Establishment of the NAS signalling connection.....	61
5.3.1.2	Release of the NAS signalling connection.....	62
5.3.1.2.1	General	62
5.3.1.2.2	UE is using EPS services with control plane CIoT EPS optimization.....	63
5.3.1.3	Suspend and resume of the NAS signalling connection.....	63
5.3.2	Lists of forbidden tracking areas.....	64
5.3.3	List of forbidden PLMNs for attach in S101 mode.....	65
5.3.3a	Forbidden PLMNs for EPS services	65
5.3.4	Equivalent PLMNs list.....	65
5.3.5	Handling of the periodic tracking area update timer and mobile reachable timer (S1 mode only).....	65
5.3.6	Handling of timer T3402	67
5.3.7	Handling of the Local Emergency Numbers List	67
5.3.7a	Specific requirements for UE configured to use timer T3245	67
5.3.7b	Specific requirements for UE when receiving non-integrity protected reject messages.....	68
5.3.8	Abnormal cases in the UE	70
5.3.9	Handling of NAS level mobility management congestion control	70
5.3.10	Access class control.....	71
5.3.11	Power saving mode.....	71
5.3.12	Extended idle-mode DRX cycle	72
5.3.13	Interaction between power saving mode and extended idle mode DRX cycle	73
5.3.14	Dedicated core network	73
5.3.15	CIoT EPS optimizations	73
5.4	EMM common procedures	75
5.4.1	GUTI reallocation procedure.....	75
5.4.1.1	General	75
5.4.1.2	GUTI reallocation initiation by the network.....	75
5.4.1.3	GUTI reallocation completion by the UE	75
5.4.1.4	GUTI reallocation completion by the network.....	75
5.4.1.5	Abnormal cases in the UE.....	75
5.4.1.6	Abnormal cases on the network side	76
5.4.2	Authentication procedure.....	77
5.4.2.1	General	77
5.4.2.2	Authentication initiation by the network.....	77
5.4.2.3	Authentication response by the UE.....	78
5.4.2.4	Authentication completion by the network	79
5.4.2.5	Authentication not accepted by the network	79
5.4.2.6	Authentication not accepted by the UE.....	80
5.4.2.7	Abnormal cases	80
5.4.3	Security mode control procedure	85
5.4.3.1	General	85
5.4.3.2	NAS security mode control initiation by the network.....	85
5.4.3.3	NAS security mode command accepted by the UE.....	87
5.4.3.4	NAS security mode control completion by the network	88
5.4.3.5	NAS security mode command not accepted by the UE.....	88
5.4.3.6	Abnormal cases in the UE.....	88
5.4.3.7	Abnormal cases on the network side	89
5.4.4	Identification procedure.....	89
5.4.4.1	General	89
5.4.4.2	Identification initiation by the network.....	90
5.4.4.3	Identification response by the UE	90
5.4.4.4	Identification completion by the network	90
5.4.4.5	Abnormal cases in the UE.....	90
5.4.4.6	Abnormal cases on the network side.....	90
5.4.5	EMM information procedure	91
5.4.5.1	General	91
5.4.5.2	EMM information procedure initiation by the network	91
5.4.5.3	EMM information procedure in the UE	92
5.4.5.4	Abnormal cases on the network side.....	92
5.5	EMM specific procedures	92
5.5.1	Attach procedure.....	92

5.5.1.1	General	92
5.5.1.2	Attach procedure for EPS services.....	93
5.5.1.2.1	General	93
5.5.1.2.2	Attach procedure initiation	94
5.5.1.2.3	EMM common procedure initiation	96
5.5.1.2.4	Attach accepted by the network.....	96
5.5.1.2.4A	Attach successful for EPS services and not accepted for SMS services	99
5.5.1.2.5	Attach not accepted by the network.....	100
5.5.1.2.5A	Attach for emergency bearer services not accepted by the network.....	104
5.5.1.2.5B	Attach for initiating a PDN connection for emergency bearer services not accepted by the network.....	105
5.5.1.2.6	Abnormal cases in the UE	106
5.5.1.2.6A	Abnormal cases in the UE, SMS services not accepted.....	109
5.5.1.2.7	Abnormal cases on the network side	109
5.5.1.3	Combined attach procedure for EPS services and non-EPS services (S1 mode only)	111
5.5.1.3.1	General	111
5.5.1.3.2	Combined attach procedure initiation.....	111
5.5.1.3.3	EMM common procedure initiation	111
5.5.1.3.4	Combined attach accepted by the network	111
5.5.1.3.4.1	General.....	111
5.5.1.3.4.2	Combined attach successful	111
5.5.1.3.4.3	Combined attach successful for EPS services only.....	112
5.5.1.3.5	Combined attach not accepted by the network	113
5.5.1.3.6	Abnormal cases in the UE	117
5.5.1.3.7	Abnormal cases on the network side	118
5.5.2	Detach procedure	118
5.5.2.1	General	118
5.5.2.2	UE initiated detach procedure	119
5.5.2.2.1	UE initiated detach procedure initiation	119
5.5.2.2.2	UE initiated detach procedure completion for EPS services only	120
5.5.2.2.3	UE initiated combined detach procedure completion	120
5.5.2.2.4	Abnormal cases in the UE	121
5.5.2.2.5	Abnormal cases on the network side	122
5.5.2.3	Network initiated detach procedure	123
5.5.2.3.1	Network initiated detach procedure initiation	123
5.5.2.3.2	Network initiated detach procedure completion by the UE	123
5.5.2.3.3	Network initiated detach procedure completion by the network	127
5.5.2.3.4	Abnormal cases in the UE	127
5.5.2.3.5	Abnormal cases on the network side	127
5.5.3	Tracking area updating procedure (S1 mode only).....	129
5.5.3.1	General	129
5.5.3.2	Normal and periodic tracking area updating procedure	130
5.5.3.2.1	General	130
5.5.3.2.2	Normal and periodic tracking area updating procedure initiation	130
5.5.3.2.3	EMM common procedure initiation	134
5.5.3.2.4	Normal and periodic tracking area updating procedure accepted by the network	134
5.5.3.2.4A	Tracking area updating successful for EPS services and not accepted for SMS services.....	141
5.5.3.2.5	Normal and periodic tracking area updating procedure not accepted by the network	142
5.5.3.2.5A	Tracking area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network	146
5.5.3.2.6	Abnormal cases in the UE	147
5.5.3.2.6A	Abnormal cases in the UE, SMS services not accepted.....	151
5.5.3.2.7	Abnormal cases on the network side	151
5.5.3.3	Combined tracking area updating procedure.....	153
5.5.3.3.1	General	153
5.5.3.3.2	Combined tracking area updating procedure initiation.....	153
5.5.3.3.3	EMM common procedure initiation	155
5.5.3.3.4	Combined tracking area updating procedure accepted by the network	155
5.5.3.3.4.1	General.....	155
5.5.3.3.4.2	Combined tracking area updating successful	155
5.5.3.3.4.3	Combined tracking area updating successful for EPS services only.....	156
5.5.3.3.5	Combined tracking area updating procedure not accepted by the network	157

5.5.3.3.6	Abnormal cases in the UE	163
5.5.3.3.7	Abnormal cases on the network side	164
5.6	EMM connection management procedures (S1 mode only)	164
5.6.1	Service request procedure	164
5.6.1.1	General	164
5.6.1.2	Service request procedure initiation	168
5.6.1.2.1	UE is not using EPS services with control plane CIoT EPS optimization	168
5.6.1.2.2	UE is using EPS services with control plane CIoT EPS optimization	168
5.6.1.3	EMM common procedure initiation	169
5.6.1.4	Service request procedure accepted by the network	169
5.6.1.4.1	UE is not using EPS services with control plane CIoT EPS optimization	169
5.6.1.4.2	UE is using EPS services with control plane CIoT EPS optimization	171
5.6.1.5	Service request procedure not accepted by the network	174
5.6.1.5A	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network	180
5.6.1.6	Abnormal cases in the UE	180
5.6.1.7	Abnormal cases on the network side	186
5.6.2	Paging procedure	187
5.6.2.1	General	187
5.6.2.2	Paging for EPS services	187
5.6.2.2.1	Paging for EPS services through E-UTRAN using S-TMSI	187
5.6.2.2.1.1	General	187
5.6.2.2.1.2	Abnormal cases on the network side	189
5.6.2.2.2	Paging for EPS services through E-UTRAN using IMSI	189
5.6.2.3	Paging for CS fallback to A/Gb or Iu mode	190
5.6.2.3.1	General	190
5.6.2.3.2	Abnormal cases in the UE	191
5.6.2.3.3	Abnormal cases on the network side	191
5.6.2.4	Paging for SMS	191
5.6.3	Transport of NAS messages procedure	191
5.6.3.1	General	191
5.6.3.2	UE initiated transport of NAS messages	192
5.6.3.3	Network initiated transport of NAS messages	192
5.6.3.4	Abnormal cases in the UE	192
5.6.3.5	Abnormal cases on the network side	192
5.6.4	Generic transport of NAS messages procedure	192
5.6.4.1	General	192
5.6.4.2	UE initiated generic transport of NAS messages	193
5.6.4.3	Network initiated transport of NAS messages	193
5.6.4.4	Abnormal cases in the UE	193
5.6.4.5	Abnormal cases on the network side	193
5.7	Reception of an EMM STATUS message by an EMM entity	193
6	Elementary procedures for EPS session management	194
6.1	Overview	194
6.1.1	General	194
6.1.2	Types of ESM procedures	195
6.1.3	ESM sublayer states	196
6.1.3.1	General	196
6.1.3.2	ESM sublayer states in the UE	196
6.1.3.2.1	BEARER CONTEXT INACTIVE	196
6.1.3.2.2	BEARER CONTEXT ACTIVE	196
6.1.3.2.3	PROCEDURE TRANSACTION INACTIVE	196
6.1.3.2.4	PROCEDURE TRANSACTION PENDING	196
6.1.3.3	ESM sublayer states in the MME	197
6.1.3.3.1	BEARER CONTEXT INACTIVE	197
6.1.3.3.2	BEARER CONTEXT ACTIVE PENDING	197
6.1.3.3.3	BEARER CONTEXT ACTIVE	197
6.1.3.3.4	BEARER CONTEXT INACTIVE PENDING	197
6.1.3.3.5	BEARER CONTEXT MODIFY PENDING	197
6.1.3.3.6	PROCEDURE TRANSACTION INACTIVE	198
6.1.3.3.7	PROCEDURE TRANSACTION PENDING	198

6.1.4	Coordination between ESM and SM	198
6.1.5	Coordination between ESM and EMM for supporting ISR	199
6.2	IP address allocation	199
6.2.1	General	199
6.2.2	IP address allocation via NAS signalling	200
6.2A	IP header compression	201
6.3	General on elementary ESM procedures	201
6.3.1	Services provided by lower layers	201
6.3.2	Principles of address handling for ESM procedures	202
6.3.3	Abnormal cases in the UE	204
6.3.4	Abnormal cases in the network	205
6.3.5	Handling of APN based congestion control	205
6.3.5A	Handling of group specific session management congestion control	205
6.3.6	Handling of network rejection not due to APN based congestion control	206
6.3.7	Handling of WLAN offload control	206
6.3.8	Handling of serving PLMN rate control	206
6.3.9	Handling of APN rate control	207
6.4	Network initiated ESM procedures	207
6.4.1	Default EPS bearer context activation procedure	207
6.4.1.1	General	207
6.4.1.2	Default EPS bearer context activation initiated by the network	207
6.4.1.3	Default EPS bearer context activation accepted by the UE	208
6.4.1.4	Default EPS bearer context activation not accepted by the UE	209
6.4.1.5	Abnormal cases in the UE	209
6.4.1.6	Abnormal cases on the network side	209
6.4.2	Dedicated EPS bearer context activation procedure	210
6.4.2.1	General	210
6.4.2.2	Dedicated EPS bearer context activation initiated by the network	210
6.4.2.3	Dedicated EPS bearer context activation accepted by the UE	210
6.4.2.4	Dedicated EPS bearer context activation not accepted by the UE	211
6.4.2.5	Abnormal cases in the UE	212
6.4.2.6	Abnormal cases on the network side	213
6.4.3	EPS bearer context modification procedure	213
6.4.3.1	General	213
6.4.3.2	EPS bearer context modification initiated by the network	213
6.4.3.3	EPS bearer context modification accepted by the UE	214
6.4.3.4	EPS bearer context modification not accepted by the UE	215
6.4.3.5	Abnormal cases in the UE	217
6.4.3.6	Abnormal cases on the network side	217
6.4.4	EPS bearer context deactivation procedure	217
6.4.4.1	General	217
6.4.4.2	EPS bearer context deactivation initiated by the network	217
6.4.4.3	EPS bearer context deactivation accepted by the UE	218
6.4.4.4	Abnormal cases in the UE	220
6.4.4.5	Abnormal cases on the network side	220
6.4.4.6	Local EPS bearer context deactivation without NAS signalling	221
6.5	UE requested ESM procedures	222
6.5.0	General	222
6.5.1	UE requested PDN connectivity procedure	222
6.5.1.1	General	222
6.5.1.2	UE requested PDN connectivity procedure initiation	223
6.5.1.3	UE requested PDN connectivity procedure accepted by the network	224
6.5.1.4	UE requested PDN connectivity procedure not accepted by the network	225
6.5.1.4.1	General	225
6.5.1.4.2	Handling of network rejection due to ESM cause #26	227
6.5.1.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	229
6.5.1.4A	Handling the maximum number of active EPS bearer contexts	234
6.5.1.4B	Void	234
6.5.1.5	Abnormal cases in the UE	234
6.5.1.6	Abnormal cases on the network side	234
6.5.1.7	Handling PDN connectivity request for UE configured for dual priority	235
6.5.2	UE requested PDN disconnect procedure	235

6.5.2.1	General	235
6.5.2.2	UE requested PDN disconnection procedure initiation	236
6.5.2.3	UE requested PDN disconnection procedure accepted by the network	236
6.5.2.4	UE requested PDN disconnection procedure not accepted by the network	236
6.5.2.5	Abnormal cases in the UE	237
6.5.2.6	Abnormal cases on the network side	237
6.5.3	UE requested bearer resource allocation procedure	237
6.5.3.1	General	237
6.5.3.2	UE requested bearer resource allocation procedure initiation	238
6.5.3.3	UE requested bearer resource allocation procedure accepted by the network	238
6.5.3.4	UE requested bearer resource allocation procedure not accepted by the network	239
6.5.3.4.1	General	239
6.5.3.4.2	Handling of network rejection due to ESM cause #26	240
6.5.3.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	242
6.5.3.4A	Handling the maximum number of active EPS bearer contexts	244
6.5.3.5	Abnormal cases in the UE	244
6.5.3.6	Abnormal cases on the network side	244
6.5.4	UE requested bearer resource modification procedure	245
6.5.4.1	General	245
6.5.4.2	UE requested bearer resource modification procedure initiation	245
6.5.4.3	UE requested bearer resource modification procedure accepted by the network	246
6.5.4.4	UE requested bearer resource modification procedure not accepted by the network	247
6.5.4.4.1	General	247
6.5.4.4.2	Handling of network rejection due to ESM cause #26	249
6.5.4.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	251
6.5.4.5	Abnormal cases in the UE	252
6.5.4.6	Abnormal cases on the network side	253
6.5.5	Handling session management request for UE configured for dual priority	253
6.6	Miscellaneous procedures	254
6.6.1	Exchange of protocol configuration options	254
6.6.1.1	General	254
6.6.1.2	ESM information request procedure	254
6.6.1.2.1	General	254
6.6.1.2.2	ESM information request initiated by the network	254
6.6.1.2.3	ESM information request completion by the UE	255
6.6.1.2.4	ESM information request completion by the network	255
6.6.1.2.5	Abnormal cases in the UE	255
6.6.1.2.6	Abnormal cases on the network side	255
6.6.1.3	Exchange of protocol configuration options in other messages	255
6.6.2	Notification procedure	255
6.6.2.1	General	255
6.6.2.2	Notification procedure initiation by the network	256
6.6.2.3	Notification procedure in the UE	256
6.6.2.4	Abnormal cases on the network side	256
6.6.3	Remote UE Report procedure	256
6.6.3.1	General	256
6.6.3.2	Remote UE Report initiated by the UE	256
6.6.3.3	Remote UE Report completion by the network	257
6.6.3.4	Remote UE Report completion by the UE	257
6.6.3.5	Abnormal cases in the UE	257
6.6.3.6	Abnormal cases on the network side	257
6.6.4	Transport of user data via the control plane procedure	257
6.6.4.1	General	257
6.6.4.2	UE initiated transport of user data via the control plane	257
6.6.4.3	Network initiated transport of user data via the control plane	258
6.7	Reception of an ESM STATUS message by an ESM entity	259
7	Handling of unknown, unforeseen, and erroneous protocol data	260
7.1	General	260
7.2	Message too short	260
7.3	Unknown or unforeseen procedure transaction identity or EPS bearer identity	260
7.3.1	Procedure transaction identity	260

7.3.2	EPS bearer identity	262
7.4	Unknown or unforeseen message type	263
7.5	Non-semantical mandatory information element errors	263
7.5.1	Common procedures	263
7.5.2	EPS mobility management.....	264
7.5.3	EPS session management.....	264
7.6	Unknown and unforeseen IEs in the non-imperative message part.....	265
7.6.1	IEs unknown in the message	265
7.6.2	Out of sequence IEs	265
7.6.3	Repeated IEs	265
7.7	Non-imperative message part errors.....	265
7.7.1	Syntactically incorrect optional IEs	265
7.7.2	Conditional IE errors	265
7.8	Messages with semantically incorrect contents	266
8	Message functional definitions and contents.....	266
8.1	Overview	266
8.2	EPS mobility management messages	267
8.2.1	Attach accept	267
8.2.1.1	Message definition	267
8.2.1.2	GUTI.....	268
8.2.1.3	Location area identification.....	268
8.2.1.4	MS identity.....	268
8.2.1.5	EMM cause	269
8.2.1.6	T3402 value.....	269
8.2.1.7	T3423 value.....	269
8.2.1.8	Equivalent PLMNs.....	269
8.2.1.9	Emergency number list	269
8.2.1.10	EPS network feature support.....	269
8.2.1.11	Additional update result	269
8.2.1.12	T3412 extended value	269
8.2.1.13	T3324 value.....	269
8.2.1.14	Extended DRX parameters.....	269
8.2.1.15	SMS services status.....	270
8.2.2	Attach complete	270
8.2.3	Attach reject.....	270
8.2.3.1	Message definition	270
8.2.3.2	ESM message container	271
8.2.3.3	T3346 value.....	271
8.2.3.4	T3402 value.....	271
8.2.3.5	Extended EMM cause	271
8.2.4	Attach request	271
8.2.4.1	Message definition	271
8.2.4.2	Old P-TMSI signature	272
8.2.4.3	Additional GUTI	273
8.2.4.4	Last visited registered TAI.....	273
8.2.4.5	DRX parameter	273
8.2.4.6	MS network capability	273
8.2.4.7	Old location area identification.....	273
8.2.4.8	TMSI status	273
8.2.4.9	Mobile station classmark 2.....	273
8.2.4.10	Mobile station classmark 3.....	273
8.2.4.11	Supported Codecs	273
8.2.4.12	Additional update type	273
8.2.4.13	Voice domain preference and UE's usage setting.....	273
8.2.4.14	Device properties	273
8.2.4.15	Old GUTI type	274
8.2.4.16	MS network feature support.....	274
8.2.4.17	TMSI based NRI container	274
8.2.4.18	T3324 value.....	274
8.2.4.19	T3412 extended value	274
8.2.4.20	Extended DRX parameters.....	274

8.2.5	Authentication failure	274
8.2.5.1	Message definition	274
8.2.5.2	Authentication failure parameter.....	274
8.2.6	Authentication reject.....	275
8.2.7	Authentication request	275
8.2.8	Authentication response.....	275
8.2.9	CS service notification.....	276
8.2.9.1	Message definition	276
8.2.9.2	CLI	276
8.2.9.3	SS Code.....	276
8.2.9.4	LCS indicator	276
8.2.9.5	LCS client identity	277
8.2.10	Detach accept.....	277
8.2.10.1	Detach accept (UE originating detach)	277
8.2.10.2	Detach accept (UE terminated detach).....	277
8.2.11	Detach request	277
8.2.11.1	Detach request (UE originating detach)	277
8.2.11.2	Detach request (UE terminated detach).....	278
8.2.11.2.1	Message definition.....	278
8.2.11.2.2	EMM cause.....	278
8.2.12	Downlink NAS Transport.....	278
8.2.13	EMM information.....	279
8.2.13.1	Message definition	279
8.2.13.2	Full name for network.....	279
8.2.13.3	Short name for network.....	279
8.2.13.4	Local time zone	280
8.2.13.5	Universal time and local time zone	280
8.2.13.6	Network daylight saving time	280
8.2.14	EMM status.....	280
8.2.15	Extended service request	280
8.2.15.1	Message definition	280
8.2.15.2	CSFB response	281
8.2.15.3	EPS bearer context status	281
8.2.15.4	Device properties	281
8.2.16	GUTI reallocation command	281
8.2.16.1	Message definition	281
8.2.16.2	TAI list	282
8.2.17	GUTI reallocation complete	282
8.2.18	Identity request	282
8.2.19	Identity response	283
8.2.20	Security mode command	283
8.2.20.1	Message definition	283
8.2.20.2	IMEISV request	284
8.2.20.3	Replayed nonce _{UE}	284
8.2.20.4	Nonce _{MME}	284
8.2.21	Security mode complete.....	284
8.2.21.1	Message definition	284
8.2.21.2	IMEISV	285
8.2.22	Security mode reject	285
8.2.23	Security protected NAS message.....	285
8.2.24	Service reject	285
8.2.24.1	Message definition	285
8.2.24.2	T3442 value.....	286
8.2.24.3	T3346 value.....	286
8.2.25	Service request.....	286
8.2.26	Tracking area update accept.....	286
8.2.26.1	Message definition	286
8.2.26.2	T3412 value.....	287
8.2.26.3	GUTI.....	287
8.2.26.4	TAI list	288
8.2.26.5	EPS bearer context status	288
8.2.26.6	Location area identification.....	288

8.2.26.7	MS identity.....	288
8.2.26.8	EMM cause	288
8.2.26.9	T3402 value.....	288
8.2.26.10	T3423 value.....	288
8.2.26.11	Equivalent PLMNs.....	288
8.2.26.12	Emergency number list	288
8.2.26.13	EPS network feature support.....	288
8.2.26.14	Additional update result	288
8.2.26.15	T3412 extended value	288
8.2.26.16	T3324 value.....	288
8.2.26.17	Extended DRX parameters.....	289
8.2.26.18	SMS services status.....	289
8.2.27	Tracking area update complete	289
8.2.28	Tracking area update reject.....	289
8.2.28.1	Message definition	289
8.2.28.2	T3346 value.....	290
8.2.28.3	Extended EMM cause	290
8.2.29	Tracking area update request	290
8.2.29.1	Message definition	290
8.2.29.2	Non-current native NAS key set identifier.....	293
8.2.29.3	GPRS ciphering key sequence number	293
8.2.29.4	Old P-TMSI signature.....	293
8.2.29.5	Additional GUTI	293
8.2.29.6	Nonce _{UE}	293
8.2.29.7	UE network capability.....	293
8.2.29.8	Last visited registered TAI.....	293
8.2.29.9	DRX parameter	293
8.2.29.10	UE radio capability information update needed.....	293
8.2.29.11	EPS bearer context status	293
8.2.29.12	MS network capability	293
8.2.29.13	Old location area identification.....	293
8.2.29.14	TMSI status	294
8.2.29.15	Mobile station classmark 2.....	294
8.2.29.16	Mobile station classmark 3.....	294
8.2.29.17	Supported Codecs	294
8.2.29.18	Additional update type	294
8.2.29.19	Voice domain preference and UE's usage setting.....	294
8.2.29.20	Old GUTI type	294
8.2.29.21	Device properties	294
8.2.29.22	MS network feature support.....	294
8.2.29.23	TMSI based NRI container	294
8.2.29.24	T3324 value.....	294
8.2.29.25	T3412 extended value	294
8.2.29.26	Extended DRX parameters.....	294
8.2.30	Uplink NAS Transport.....	295
8.2.31	Downlink generic NAS transport.....	295
8.2.31.1	Message definition	295
8.2.31.2	Additional information.....	295
8.2.32	Uplink generic NAS transport	296
8.2.32.1	Message definition	296
8.2.32.2	Additional information.....	296
8.2.33	CONTROL PLANE SERVICE REQUEST	296
8.2.33.1	Message definition	296
8.2.33.2	ESM message container	297
8.2.33.3	NAS message container	297
8.2.33.4	EPS bearer context status	297
8.2.33.5	Device properties	297
8.2.34	Service Accept.....	297
8.2.34.1	Message definition	297
8.2.34.2	EPS bearer context status.....	298
8.3	EPS session management messages	298
8.3.1	Activate dedicated EPS bearer context accept.....	298