

ETSI TS 124 008 V8.20.0 (2018-01)



**Digital cellular telecommunications system (Phase 2+) (GSM);
Universal Mobile Telecommunications System (UMTS);
LTE;
Mobile radio interface Layer 3 specification;
Core network protocols;
Stage 3
(3GPP TS 24.008 version 8.20.0 Release 8)**



ReferenceRTS/TSGC-0124008v8k0

KeywordsGSM,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at
<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:
<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2018.
All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M logo is protected for the benefit of its Members.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	24
Introduction	24
1 Scope	25
1.1 Scope of the Technical Specification	25
1.2 Application to the interface structures.....	25
1.3 Structure of layer 3 procedures.....	25
1.4 Test procedures	25
1.5 Use of logical channels in A/Gb mode.....	26
1.6 Overview of control procedures	26
1.6.1 List of procedures	26
1.7 Applicability of implementations	28
1.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS).....	28
1.7.2 General Packet Radio Service (GPRS)	28
1.7.2.1 Packet services in GSM (A/Gb mode only)	28
1.7.2.2 Packet services in Iu mode (Iu mode only)	29
2 References	29
2.1 Definitions and abbreviations.....	35
2.1.1 Random values.....	35
2.1.2 Vocabulary.....	35
3 Radio Resource management procedures.....	38
4 Elementary procedures for Mobility Management.....	38
4.1 General	38
4.1.1 MM and GMM procedures	38
4.1.1.1 Types of MM and GMM procedures	38
4.1.1.1.1 Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	40
4.1.1.1.1a Integrity protection for emergency call (Iu mode only).....	41
4.1.1.2 MM-GMM co-ordination for GPRS MS's	41
4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I	41
4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II or III.....	42
4.1.1.2A Coordination between GMM and EMM	43
4.1.1.3 Core Network System Information for MM (Iu mode only).....	43
4.1.1.4 Core Network System Information for GMM (Iu mode only).....	43
4.1.1.5 Access class control	43
4.1.2 MM sublayer states.....	44
4.1.2.1 MM sublayer states in the mobile station.....	44
4.1.2.1.1 Main states.....	44
4.1.2.1.2 Substates of the MM IDLE state	48
4.1.2.2 The update Status	50
4.1.2.3 MM sublayer states on the network side.....	50
4.1.3 GPRS mobility management (GMM) sublayer states.....	52
4.1.3.1 GMM states in the MS	52
4.1.3.1.1 Main states.....	52
4.1.3.1.2 Substates of state GMM-DEREGISTERED.....	52
4.1.3.1.3 Substates of state GMM-REGISTERED.....	53
4.1.3.2 GPRS update status	55
4.1.3.3 GMM mobility management states on the network side.....	55
4.1.3.3.1 Main States	56
4.1.3.3.2 Substates of state GMM-REGISTERED.....	56
4.2 Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state	57
4.2.1 Primary Service State selection	57

4.2.1.1	Selection of the Service State after Power On.....	57
4.2.1.2	Other Cases	58
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.	58
4.2.2.1	Service State, NORMAL SERVICE	58
4.2.2.2	Service State, ATTEMPTING TO UPDATE	59
4.2.2.3	Service State, LIMITED SERVICE.....	59
4.2.2.4	Service State, NO IMSI.....	60
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	60
4.2.2.6	Service State, SEARCH FOR PLMN	61
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE).....	61
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE).....	61
4.2.2.9	Service State, eCALL INACTIVE.....	62
4.2.3	Service state when back to state MM IDLE from another state.....	62
4.2.4	Behaviour in state GMM-DEREGISTERED.....	63
4.2.4.1	Primary substate selection.....	63
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability.....	63
4.2.4.1.2	Other Cases.....	64
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED.....	64
4.2.4.2.1	Substate, NORMAL-SERVICE	64
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH	64
4.2.4.2.3	Substate, LIMITED-SERVICE	64
4.2.4.2.4	Substate, NO-IMSI	64
4.2.4.2.5	Substate, NO-CELL	65
4.2.4.2.6	Substate, PLMN-SEARCH	65
4.2.4.2.7	Substate, ATTACH-NEEDED	65
4.2.4.2.8	Substate, SUSPENDED (A/Gb mode only).....	65
4.2.4.3	Substate when back to state GMM-DEREGISTERED from another GMM state	65
4.2.5	Behaviour in state GMM-REGISTERED	65
4.2.5.1	Detailed description of the MS behaviour in state GMM-REGISTERED.....	66
4.2.5.1.1	Substate, NORMAL-SERVICE	66
4.2.5.1.2	Substate, SUSPENDED (A/Gb mode only).....	66
4.2.5.1.3	Substate, UPDATE-NEEDED.....	66
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE	66
4.2.5.1.5	Substate, NO-CELL-AVAILABLE	67
4.2.5.1.6	Substate, LIMITED-SERVICE	67
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM	67
4.2.5.1.8	Substate, PLMN-SEARCH	67
4.3	MM common procedures	67
4.3.1	TMSI reallocation procedure	67
4.3.1.1	TMSI reallocation initiation by the network	68
4.3.1.2	TMSI reallocation completion by the mobile station	68
4.3.1.3	TMSI reallocation completion in the network.....	68
4.3.1.4	Abnormal cases	68
4.3.2	Authentication procedure.....	69
4.3.2a	Authentication procedure used for a UMTS authentication challenge.....	69
4.3.2b	Authentication Procedure used for a GSM authentication challenge.....	69
4.3.2.1	Authentication request by the network.....	70
4.3.2.2	Authentication response by the mobile station.....	70
4.3.2.3	Authentication processing in the network	71
4.3.2.4	Ciphering key sequence number	71
4.3.2.5	Authentication not accepted by the network	71
4.3.2.5.1	Authentication not accepted by the MS.....	72
4.3.2.6	Abnormal cases	72
4.3.2.6.1	MS behaviour towards a network that has failed the authentication procedure.....	75
4.3.2.7	Handling of keys at intersystem change from Iu mode to A/Gb mode	75
4.3.2.7a	Use of established security contexts.....	75
4.3.2.8	Handling of keys at intersystem change from A/Gb mode to Iu mode	76
4.3.2.9	Void.....	77
4.3.2.10	Derivation of keys at SRVCC handover from S1 mode.....	77
4.3.2.11	Derivation of keys at SRVCC handover from Iu mode to Iu mode	77
4.3.2.12	Derivation of keys at SRVCC handover from Iu mode to A/Gb mode.....	78
4.3.3	Identification procedure	79

4.3.3.1	Identity request by the network	79
4.3.3.2	Identification response by the mobile station	79
4.3.3.3	Abnormal cases	80
4.3.4	IMSI detach procedure.....	80
4.3.4.1	IMSI detach initiation by the mobile station	80
4.3.4.2	IMSI detach procedure in the network	81
4.3.4.3	IMSI detach completion by the mobile station.....	81
4.3.4.4	Abnormal cases	81
4.3.5	Abort procedure	81
4.3.5.1	Abort procedure initiation by the network	81
4.3.5.2	Abort procedure in the mobile station.....	82
4.3.6	MM information procedure.....	82
4.3.6.1	MM information procedure initiation by the network.....	82
4.3.6.2	MM information procedure in the mobile station	82
4.4	MM specific procedures	82
4.4.1	Location updating procedure	82
4.4.2	Periodic updating	84
4.4.3	IMSI attach procedure	85
4.4.4	Generic Location Updating procedure.....	85
4.4.4.1	Location updating initiation by the mobile station.....	85
4.4.4.1a	Network Request for Additional mobile station Capability Information	86
4.4.4.2	Identification request from the network	86
4.4.4.3	Authentication by the network	86
4.4.4.4	Security mode setting by the network	86
4.4.4.5	Attempt Counter.....	86
4.4.4.6	Location updating accepted by the network.....	86
4.4.4.7	Location updating not accepted by the network.....	88
4.4.4.8	Release of RR connection after location updating	89
4.4.4.9	Abnormal cases on the mobile station side	89
4.4.4.10	Abnormal cases on the network side.....	91
4.4.5	Void.....	91
4.4.6	Void.....	91
4.4.7	eCall inactivity procedure.....	91
4.5	Connection management sublayer service provision	92
4.5.1	MM connection establishment.....	92
4.5.1.1	MM connection establishment initiated by the mobile station.....	92
4.5.1.2	Abnormal cases	95
4.5.1.3	MM connection establishment initiated by the network	97
4.5.1.3.1	Mobile Terminating CM Activity.....	97
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$	97
4.5.1.3.3	Paging response in Iu mode (Iu mode only)	98
4.5.1.3.4	Paging response for CS fallback.....	99
4.5.1.4	Abnormal cases	99
4.5.1.5	MM connection establishment for emergency calls.....	99
4.5.1.5a	MM connection establishment for emergency calls for CS fallback.....	100
4.5.1.6	Call re-establishment.....	100
4.5.1.6.1	Call re-establishment, initiation by the mobile station	100
4.5.1.6.2	Abnormal cases	102
4.5.1.7	Forced release during MO MM connection establishment	103
4.5.1.8	MM connection establishment due to SRVCC handover.....	103
4.5.2	MM connection information transfer phase.....	103
4.5.2.1	Sending CM messages	103
4.5.2.2	Receiving CM messages	103
4.5.2.3	Abnormal cases	104
4.5.3	MM connection release.....	104
4.5.3.1	Release of associated RR connection	104
4.5.3.2	Uplink release in a voice group call	105
4.6	Receiving a MM STATUS message by a MM entity.....	105
4.7	Elementary mobility management procedures for GPRS services	105
4.7.1	General.....	105
4.7.1.1	Lower layer failure.....	105
4.7.1.2	Ciphering of messages (A/Gb mode only)	105

4.7.1.3	P-TMSI signature	106
4.7.1.4	Radio resource sublayer address handling	106
4.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only)	106
4.7.1.5	P-TMSI handling	107
4.7.1.5.1	P-TMSI handling in A/Gb mode	107
4.7.1.5.2	P-TMSI handling in Iu mode	107
4.7.1.5.3	Void	108
4.7.1.5.4	Void	108
4.7.1.6	Change of network mode of operation	108
4.7.1.6.1	Change of network mode of operation in A/Gb mode (A/Gb mode only)	108
4.7.1.6.2	Change of network mode of operation in Iu mode (Iu mode only)	109
4.7.1.6.3	Change of network mode of operation at Iu mode to A/Gb mode inter-system change	109
4.7.1.6.4	Change of network mode of operation at A/Gb mode to Iu mode inter-system change	110
4.7.1.7	Intersystem change between A/Gb mode and Iu mode	111
4.7.1.8	List of forbidden PLMNs for GPRS service	112
4.7.1.8a	Establishment of the PS signalling connection (Iu mode only)	112
4.7.1.9	Release of the PS signalling connection (Iu mode only)	113
4.7.2	GPRS Mobility management timers and UMTS PS signalling connection control	113
4.7.2.1	READY timer behaviour	113
4.7.2.1.1	READY timer behaviour (A/Gb mode only)	113
4.7.2.1.2	Handling of READY timer in Iu mode (Iu mode only)	114
4.7.2.2	Periodic routing area updating	114
4.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	116
4.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only)	116
4.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only)	116
4.7.2.6	Cell Update triggered by low layers	116
4.7.3	GPRS attach procedure	117
4.7.3.1	GPRS attach procedure for GPRS services	118
4.7.3.1.1	GPRS attach procedure initiation	118
4.7.3.1.2	GMM common procedure initiation	119
4.7.3.1.3	GPRS attach accepted by the network	119
4.7.3.1.4	GPRS attach not accepted by the network	120
4.7.3.1.5	Abnormal cases in the MS	124
4.7.3.1.6	Abnormal cases on the network side	125
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services	127
4.7.3.2.1	Combined GPRS attach procedure initiation	127
4.7.3.2.2	GMM Common procedure initiation	127
4.7.3.2.3	Combined GPRS attach accepted by the network	128
4.7.3.2.4	Combined GPRS attach not accepted by the network	129
4.7.3.2.5	Abnormal cases in the MS	132
4.7.3.2.6	Abnormal cases on the network side	133
4.7.4	GPRS detach procedure	133
4.7.4.1	MS initiated GPRS detach procedure	133
4.7.4.1.1	MS initiated GPRS detach procedure initiation	133
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only	134
4.7.4.1.3	MS initiated combined GPRS detach procedure completion	134
4.7.4.1.4	Abnormal cases in the MS	134
4.7.4.1.5	Abnormal cases on the network side	136
4.7.4.2	Network initiated GPRS detach procedure	136
4.7.4.2.1	Network initiated GPRS detach procedure initiation	136
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS	136
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network	141
4.7.4.2.4	Abnormal cases on the network side	141
4.7.5	Routing area updating procedure	142
4.7.5.1	Normal and periodic routing area updating procedure	144
4.7.5.1.1	Normal and periodic routing area updating procedure initiation	144
4.7.5.1.2	GMM Common procedure initiation	145
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network	145
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network	148
4.7.5.1.5	Abnormal cases in the MS	152
4.7.5.1.6	Abnormal cases on the network side	153
4.7.5.2	Combined routing area updating procedure	155

4.7.5.2.1	Combined routing area updating procedure initiation	155
4.7.5.2.2	GMM Common procedure initiation	156
4.7.5.2.3	Combined routing area updating procedure accepted by the network.....	156
4.7.5.2.4	Combined routing area updating not accepted by the network.....	158
4.7.5.2.5	Abnormal cases in the MS.....	162
4.7.5.2.6	Abnormal cases on the network side	162
4.7.6	P-TMSI reallocation procedure.....	163
4.7.6.1	P-TMSI reallocation initiation by the network.....	163
4.7.6.2	P-TMSI reallocation completion by the MS	163
4.7.6.3	P-TMSI reallocation completion by the network.....	163
4.7.6.4	Abnormal cases on the network side.....	163
4.7.7	Authentication and ciphering procedure.....	165
4.7.7a	Authentication and ciphering procedure used for UMTS authentication challenge.....	165
4.7.7b	Authentication and ciphering procedure used for GSM authentication challenge	165
4.7.7c	Change of the ciphering algorithm at PS Handover.....	166
4.7.7.1	Authentication and ciphering initiation by the network	166
4.7.7.2	Authentication and ciphering response by the MS.....	167
4.7.7.3	Authentication and ciphering completion by the network.....	168
4.7.7.4	GPRS ciphering key sequence number	168
4.7.7.5	Authentication not accepted by the network.....	169
4.7.7.5.1	Authentication not accepted by the MS	169
4.7.7.6	Abnormal cases	170
4.7.7.6.1	MS behaviour towards a network that has failed the authentication procedure.....	173
4.7.7.7	Use of established security contexts.....	173
4.7.7.8	Handling of keys at intersystem change from Iu mode to A/Gb mode.....	174
4.7.7.9	Handling of keys at intersystem change from A/Gb mode to Iu mode	174
4.7.7.10	Handling of keys at intersystem change from SI mode to Iu mode or A/Gb mode	175
4.7.8	Identification procedure.....	176
4.7.8.1	Identification initiation by the network.....	176
4.7.8.2	Identification response by the MS.....	177
4.7.8.3	Identification completion by the network	177
4.7.8.3a	Abnormal cases in the MS	177
4.7.8.4	Abnormal cases on the network side	177
4.7.9	Paging procedure	178
4.7.9.1	Paging for GPRS services	178
4.7.9.1.1	Paging for GPRS services using P-TMSI.....	178
4.7.9.1.2	Paging for GPRS services using IMSI.....	179
4.7.9.2	Paging for non-GPRS services.....	179
4.7.10	Receiving a GMM STATUS message by a GMM entity	179
4.7.11	Void.....	180
4.7.12	GMM Information procedure	180
4.7.12.1	GMM information procedure initiation by the network.....	180
4.7.12.2	GMM information procedure in the mobile station	180
4.7.13	Service Request procedure (Iu mode only).....	180
4.7.13.1	Service Request procedure initiation.....	182
4.7.13.2	GMM common procedure initiation	182
4.7.13.3	Service request procedure accepted by the network.....	182
4.7.13.4	Service request procedure not accepted by the network.....	183
4.7.13.5	Abnormal cases in the MS	186
4.7.13.6	Abnormal cases on the network side.....	187
4.7.14	Void.....	188
5	Elementary procedures for circuit-switched Call Control.....	188
5.1	Overview	188
5.1.1	General.....	188
5.1.2	Call Control States	193
5.1.2.1	Call states at the mobile station side of the interface	193
5.1.2.1.1	Null (State U0)	193
5.1.2.1.2	MM Connection pending (U0.1)	193
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$	194
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$.....	194
5.1.2.1.2c	CC-Establishment present (U0.4) \$(CCBS)\$	194

5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$	194
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	194
5.1.2.1.3	Call initiated (U1)	194
5.1.2.1.4	Mobile originating call proceeding (U3)	194
5.1.2.1.5	Call delivered (U4)	194
5.1.2.1.6	Call present (U6)	194
5.1.2.1.7	Call received (U7)	194
5.1.2.1.8	Connect Request (U8)	194
5.1.2.1.9	Mobile terminating call confirmed (U9)	195
5.1.2.1.10	Active (U10)	195
5.1.2.1.11	Disconnect request (U11)	195
5.1.2.1.12	Disconnect indication (U12)	195
5.1.2.1.13	Release request (U19)	195
5.1.2.1.14	Mobile originating modify (U26)	195
5.1.2.1.15	Mobile terminating modify (U27)	195
5.1.2.2	Network call states	195
5.1.2.2.1	Null (State N0)	195
5.1.2.2.2	MM connection pending (N0.1)	195
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$	195
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$	195
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$	196
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$	196
5.1.2.2.3	Call initiated (N1)	196
5.1.2.2.4	Mobile originating call proceeding (N3)	196
5.1.2.2.5	Call delivered (N4)	196
5.1.2.2.6	Call present (N6)	196
5.1.2.2.7	Call received (N7)	196
5.1.2.2.8	Connect request (N8)	196
5.1.2.2.9	Mobile terminating call confirmed (N9)	196
5.1.2.2.10	Active (N10)	196
5.1.2.2.11	Not used	196
5.1.2.2.12	Disconnect indication (N12)	196
5.1.2.2.13	Release request (N19)	197
5.1.2.2.14	Mobile originating modify (N26)	197
5.1.2.2.15	Mobile terminating modify (N27)	197
5.1.2.2.16	Connect Indication (N28)	197
5.2	Call establishment procedures	197
5.2.1	Mobile originating call establishment	197
5.2.1.1	Call initiation	198
5.2.1.2	Receipt of a setup message	199
5.2.1.3	Receipt of a CALL PROCEEDING message	200
5.2.1.4	Notification of progressing mobile originated call	201
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment	201
5.2.1.4.2	Call progress in the PLMN/ISDN environment	201
5.2.1.5	Alerting	201
5.2.1.6	Call connected	202
5.2.1.7	Call rejection	203
5.2.1.8	Transit network selection	203
5.2.1.9	Traffic channel assignment at mobile originating call establishment	203
5.2.1.10	Call queuing at mobile originating call establishment	203
5.2.1.11	Speech Codec Selection	203
5.2.1.12	Cellular Text telephone Modem (CTM) selection	204
5.2.2	Mobile terminating call establishment	205
5.2.2.1	Call indication	205
5.2.2.2	Compatibility checking	205
5.2.2.3	Call confirmation	205
5.2.2.3.1	Response to SETUP	205
5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	206
5.2.2.3.3	Call failure procedures	207
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	207
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment	207
5.2.2.5	Call accept	208

5.2.2.6	Active indication	208
5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	208
5.2.2.8	Call queuing at mobile terminating call establishment	209
5.2.2.9	User connection attachment during a mobile terminating call	209
5.2.2.10	Speech Codec Selection	209
5.2.2.11	Cellular Text telephone Modem (CTM) selection	209
5.2.3	Network initiated MO call \$(CCBS)\$	209
5.2.3.1	Initiation	209
5.2.3.2	CC-Establishment present	210
5.2.3.2.1	Recall Alignment Procedure.....	211
5.2.3.3	CC-Establishment confirmation.....	212
5.2.3.4	Recall present.....	212
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment	213
5.2.4	Call establishment for SRVCC	213
5.2.4.1	General	213
5.2.4.2	Call activation	213
5.2.4.3	Traffic channel assignment and user connection attachment	213
5.3	Signalling procedures during the "active" state	214
5.3.1	User notification procedure.....	214
5.3.2	Call rearrangements	214
5.3.3	Codec Change Procedure	214
5.3.4	Support of Dual Services	214
5.3.4.1	Service Description	214
5.3.4.2	Call establishment	215
5.3.4.2.1	Mobile Originating Establishment.....	215
5.3.4.2.2	Mobile Terminating Establishment	215
5.3.4.3	Changing the Call Mode	216
5.3.4.3.1	Initiation of in-call modification	216
5.3.4.3.2	Successful completion of in-call modification	216
5.3.4.3.3	Change of the channel configuration.....	217
5.3.4.3.4	Failure of in-call modification.....	218
5.3.4.4	Abnormal procedures	218
5.3.5	User initiated service level up- and downgrading (A/Gb mode and GERAN Iu mode only).....	219
5.3.5.1	Initiation of service level up- and downgrading.....	219
5.3.5.2	Successful completion of service level up- and downgrading	219
5.3.5.3	Rejection of service level up- and downgrading	219
5.3.5.4	Time-out recovery	220
5.3.6	Support of multimedia calls	220
5.3.6.1	Service description	220
5.3.6.2	Call establishment	220
5.3.6.2.1	Mobile originated multimedia call establishment.....	220
5.3.6.2.2	Mobile terminating multimedia call	221
5.3.6.2.2.1	Fallback to speech.....	222
5.3.6.3	In-call modification in the "active" state	222
5.3.6.3.1	Void	223
5.3.6.3.2	Void	223
5.3.6.3.3	Void	223
5.3.6.4	Multimedia CAT during the alerting phase of a mobile originated call.....	223
5.3.6.5	DTMF transmission during a multimedia call	223
5.4	Call clearing	224
5.4.1	Terminology	224
5.4.2	Exception conditions.....	224
5.4.3	Clearing initiated by the mobile station	224
5.4.3.1	Initiation of call clearing	224
5.4.3.2	Receipt of a DISCONNECT message from the mobile station.....	225
5.4.3.3	Receipt of a RELEASE message from the network.....	225
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	225
5.4.3.5	Abnormal cases	225
5.4.4	Clearing initiated by the network.....	225
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"	225
5.4.4.1.1	Clearing when tones/announcements provided.....	226
5.4.4.1.2	Clearing when tones/announcements not provided	226

5.4.4.1.3	Completion of clearing	227
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"	227
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible"	227
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible"	228
5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible"	229
5.4.4.2.4	Receipt of a RELEASE message from the mobile station	229
5.4.4.2.5	Completion of clearing	230
5.5	Miscellaneous procedures	230
5.5.1	In-band tones and announcements	230
5.5.2	Call collisions	231
5.5.3	Status procedures	231
5.5.3.1	Status enquiry procedure	231
5.5.3.2	Reception of a STATUS message by a CC entity	231
5.5.3.2.1	STATUS message with incompatible state	231
5.5.3.2.2	STATUS message with compatible state	231
5.5.4	Call re-establishment, mobile station side	232
5.5.4.1	Indication from the mobility management sublayer	232
5.5.4.2	Reaction of call control	232
5.5.4.3	Completion of re-establishment	232
5.5.4.4	Unsuccessful outcome	232
5.5.5	Call re-establishment, network side	232
5.5.5.1	State alignment	232
5.5.6	Progress	233
5.5.7	DTMF protocol control procedure	233
5.5.7.1	Start DTMF request by the mobile station	233
5.5.7.2	Start DTMF response by the network	233
5.5.7.3	Stop DTMF request by the mobile station	234
5.5.7.4	Stop DTMF response by the network	234
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station	234
6	Support for packet services	235
6.1	GPRS Session management	235
6.1.1	General	235
6.1.2	Session management states	235
6.1.2.1	Session management states in the MS	236
6.1.2.1.1	PDP-INACTIVE	236
6.1.2.1.2	PDP-ACTIVE-PENDING	236
6.1.2.1.3	PDP-INACTIVE-PENDING	236
6.1.2.1.4	PDP-ACTIVE	236
6.1.2.1.5	PDP-MODIFY_PENDING	236
6.1.2.1.6	MBMS-ACTIVE-PENDING	236
6.1.2.1.7	MBMS-ACTIVE	236
6.1.2.2	Session management states on the network side	238
6.1.2.2.1	PDP-INACTIVE	238
6.1.2.2.2	PDP-ACTIVE-PENDING	238
6.1.2.2.3	PDP-INACTIVE-PENDING	238
6.1.2.2.4	PDP-ACTIVE	238
6.1.2.2.5	PDP-MODIFY_PENDING	238
6.1.2.2.6	MBMS-ACTIVE-PENDING	239
6.1.2.2.7	MBMS-INACTIVE-PENDING	239
6.1.2.2.8	MBMS-ACTIVE	239
6.1.2A	PDP address allocation	240
6.1.2A.1	General	240
6.1.2A.1.1	Interworking with PDN based on IP	240
6.1.2A.1.2	Interworking with PDN based on PPP	240
6.1.2A.2	IP address allocation via NAS signalling	241
6.1.3	Session Management procedures	241
6.1.3.1	PDP context activation	241
6.1.3.1.1	Successful PDP context activation initiated by the mobile station	242
6.1.3.1.2	Successful PDP context activation requested by the network	243

6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS.....	243
6.1.3.1.4	Unsuccessful PDP context activation requested by the network.....	244
6.1.3.1.5	Abnormal cases.....	244
6.1.3.2	Secondary PDP Context Activation Procedure.....	246
6.1.3.2.1	Successful Secondary PDP Context Activation Procedure Initiated by the MS.....	247
6.1.3.2.1a	Successful Secondary PDP Context Activation Procedure Requested by the network.....	247
6.1.3.2.2	Unsuccessful Secondary PDP Context Activation Procedure initiated by the MS.....	248
6.1.3.2.2a	Unsuccessful secondary PDP context activation requested by the network.....	248
6.1.3.2.3	Abnormal cases.....	249
6.1.3.3	PDP context modification procedure.....	251
6.1.3.3.1	Network initiated PDP Context Modification.....	252
6.1.3.3.2	MS initiated PDP Context Modification accepted by the network.....	252
6.1.3.3.3	MS initiated PDP Context Modification not accepted by the network.....	253
6.1.3.3.3a	Network initiated PDP Context Modification not accepted by the MS.....	255
6.1.3.3.4	Abnormal cases.....	255
6.1.3.4	PDP context deactivation procedure.....	257
6.1.3.4.1	PDP context deactivation initiated by the MS.....	257
6.1.3.4.2	PDP context deactivation initiated by the network.....	258
6.1.3.4.3	Abnormal cases.....	258
6.1.3.4a	Void.....	259
6.1.3.5	Void.....	259
6.1.3.6	Receiving a SM STATUS message by a SM entity.....	259
6.1.3.7	Protocol configuration options.....	260
6.1.3.8	MBMS context activation.....	260
6.1.3.8.1	Successful MBMS context activation.....	260
6.1.3.8.2	Unsuccessful MBMS context activation requested by the MS.....	260
6.1.3.8.3	Unsuccessful MBMS context activation requested by the network.....	261
6.1.3.8.4	Abnormal cases.....	261
6.1.3.9	MBMS context deactivation.....	262
6.1.3.9.1	MBMS context deactivation initiated by the network.....	262
6.1.3.9.2	Abnormal cases.....	263
6.1.3.10	MBMS protocol configuration options.....	263
6.2	void.....	263
6.3	Coordination between SM and GMM for supporting ISR.....	263
6.4	MSISDN notification procedure.....	263
7	Examples of structured procedures.....	264
8	Handling of unknown, unforeseen, and erroneous protocol data.....	264
8.1	General.....	264
8.2	Message too short.....	264
8.3	Unknown or unforeseen transaction identifier.....	265
8.3.1	Call Control.....	265
8.3.2	Session Management.....	266
8.4	Unknown or unforeseen message type.....	267
8.5	Non-semantic mandatory information element errors.....	267
8.5.1	Radio resource management.....	268
8.5.2	Mobility management.....	268
8.5.3	Call control.....	268
8.5.4	GMM mobility management.....	268
8.5.5	Session management.....	268
8.6	Unknown and unforeseen IEs in the non-imperative message part.....	269
8.6.1	IEs unknown in the message.....	269
8.6.2	Out of sequence IEs.....	269
8.6.3	Repeated IEs.....	269
8.7	Non-imperative message part errors.....	269
8.7.1	Syntactically incorrect optional IEs.....	269
8.7.2	Conditional IE errors.....	269
8.8	Messages with semantically incorrect contents.....	270
9	Message functional definitions and contents.....	270
9.1	Messages for Radio Resources management.....	271
9.2	Messages for mobility management.....	271

9.2.1	Authentication reject.....	272
9.2.2	Authentication request.....	272
9.2.2.1	Authentication Parameter AUTN.....	272
9.2.3	Authentication response.....	273
9.2.3.1	Authentication Response Parameter.....	273
9.2.3.2	Authentication Response Parameter (extension).....	273
9.2.3a	Authentication Failure.....	273
9.2.3a.1	Authentication Failure parameter.....	274
9.2.4	CM Re-establishment request.....	274
9.2.4.1	Location area identification.....	274
9.2.4.2	Mobile Station Classmark.....	274
9.2.5	CM service accept.....	274
9.2.5a	CM service prompt \$(CCBS)\$.....	275
9.2.6	CM service reject.....	275
9.2.7	CM service abort.....	276
9.2.8	Abort.....	276
9.2.9	CM service request.....	277
9.2.9.1	Mobile Station Classmark.....	277
9.2.9.2	Priority.....	277
9.2.10	Identity request.....	277
9.2.11	Identity response.....	278
9.2.12	IMSI detach indication.....	278
9.2.12.1	Mobile Station Classmark.....	279
9.2.13	Location updating accept.....	279
9.2.13.1	Follow on proceed.....	279
9.2.13.2	CTS permission.....	280
9.2.13.3	Equivalent PLMNs.....	280
9.2.13.4	Emergency Number List.....	280
9.2.14	Location updating reject.....	280
9.2.15	Location updating request.....	280
9.2.15.1	Location area identification.....	281
9.2.15.2	Mobile Station Classmark.....	281
9.2.15.3	Mobile Station Classmark for Iu mode.....	281
9.2.15a	MM information.....	281
9.2.15a.1	Full name for network.....	282
9.2.15a.2	Short name for network.....	282
9.2.15a.3	Local time zone.....	282
9.2.15a.4	Universal time and local time zone.....	282
9.2.15a.5	LSA Identity.....	282
9.2.15a.6	Network Daylight Saving Time.....	283
9.2.16	MM Status.....	283
9.2.17	TMSI reallocation command.....	283
9.2.18	TMSI reallocation complete.....	284
9.2.19	MM Null.....	284
9.3	Messages for circuit-switched call control.....	285
9.3.1	Alerting.....	285
9.3.1.1	Alerting (network to mobile station direction).....	285
9.3.1.1.1	Facility.....	286
9.3.1.1.2	Progress indicator.....	286
9.3.1.1.3	User-user.....	286
9.3.1.2	Alerting (mobile station to network direction).....	286
9.3.1.2.1	Facility.....	287
9.3.1.2.2	User-user.....	287
9.3.1.2.3	SS version.....	287
9.3.2	Call confirmed.....	287
9.3.2.1	Repeat indicator.....	288
9.3.2.2	Bearer capability 1 and bearer capability 2.....	288
9.3.2.3	Cause.....	289
9.3.2.4	CC Capabilities.....	289
9.3.2.5	Stream Identifier.....	289
9.3.2.6	Supported Codecs.....	289
9.3.3	Call proceeding.....	289