

# ETSI TS 124 008 V10.16.0 (2018-01)



**Digital cellular telecommunications system (Phase 2+) (GSM);  
Universal Mobile Telecommunications System (UMTS);  
LTE;  
Mobile radio interface Layer 3 specification;  
Core network protocols;  
Stage 3  
(3GPP TS 24.008 version 10.16.0 Release 10)**



---

**Reference**RTS/TSGC-0124008vag0

---

---

**Keywords**GSM,LTE,UMTS

---

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

**Important notice**

---

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

---

**Copyright Notification**

---

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2018.

All rights reserved.

**DECT™**, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

**3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

**oneM2M** logo is protected for the benefit of its Members.

**GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

---

# Intellectual Property Rights

## Essential patents

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

## Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

---

# Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

---

# Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

# Contents

Intellectual Property Rights .....	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	26
Introduction .....	26
1 Scope .....	27
1.1 Scope of the Technical Specification .....	27
1.2 Application to the interface structures.....	27
1.3 Structure of layer 3 procedures.....	27
1.4 Test procedures .....	27
1.5 Use of logical channels in A/Gb mode.....	28
1.6 Overview of control procedures .....	28
1.6.1 List of procedures .....	28
1.7 Applicability of implementations .....	30
1.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS).....	30
1.7.2 General Packet Radio Service (GPRS) .....	30
1.7.2.1 Packet services in GSM (A/Gb mode only) .....	30
1.7.2.2 Packet services in Iu mode (Iu mode only) .....	31
1.8 Handling of NAS signalling low priority indication.....	31
2 References .....	31
2.1 Definitions and abbreviations.....	37
2.1.1 Random values.....	37
2.1.2 Vocabulary.....	38
3 Radio Resource management procedures.....	41
4 Elementary procedures for Mobility Management.....	41
4.1 General .....	41
4.1.1 MM and GMM procedures .....	42
4.1.1.1 Types of MM and GMM procedures .....	42
4.1.1.1.1 Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	43
4.1.1.1.1a Integrity protection for emergency call (Iu mode only).....	45
4.1.1.2 MM-GMM co-ordination for GPRS MS's .....	46
4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I .....	46
4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II or III.....	47
4.1.1.2A Coordination between GMM and EMM .....	47
4.1.1.3 Core Network System Information for MM (Iu mode only) .....	47
4.1.1.4 Core Network System Information for GMM (Iu mode only).....	47
4.1.1.4.1 General .....	47
4.1.1.4.2 Control of Network Mode of Operation I.....	48
4.1.1.5 Access class control .....	48
4.1.1.6 Specific requirements for MS configured to use timer T3245 .....	49
4.1.1.7 Handling of NAS level mobility management congestion control.....	49
4.1.2 MM sublayer states.....	50
4.1.2.1 MM sublayer states in the mobile station.....	50
4.1.2.1.1 Main states.....	50
4.1.2.1.2 Substates of the MM IDLE state .....	53
4.1.2.2 The update Status .....	55
4.1.2.3 MM sublayer states on the network side.....	55
4.1.3 GPRS mobility management (GMM) sublayer states.....	57
4.1.3.1 GMM states in the MS .....	57
4.1.3.1.1 Main states.....	57
4.1.3.1.2 Substates of state GMM-DEREGISTERED.....	58
4.1.3.1.3 Substates of state GMM-REGISTERED.....	58
4.1.3.2 GPRS update status .....	61

4.1.3.3	GMM mobility management states on the network side.....	61
4.1.3.3.1	Main States.....	61
4.1.3.3.2	Substates of state GMM-REGISTERED.....	62
4.2	Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state .....	63
4.2.1	Primary Service State selection .....	63
4.2.1.1	Selection of the Service State after Power On.....	63
4.2.1.2	Other Cases .....	64
4.2.2	Detailed Description of the MS behaviour in MM IDLE State. ....	64
4.2.2.1	Service State, NORMAL SERVICE.....	64
4.2.2.2	Service State, ATTEMPTING TO UPDATE .....	65
4.2.2.3	Service State, LIMITED SERVICE.....	65
4.2.2.4	Service State, NO IMSI.....	66
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	66
4.2.2.6	Service State, SEARCH FOR PLMN .....	66
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE) .....	67
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE).....	67
4.2.2.9	Service State, eCALL INACTIVE.....	67
4.2.3	Service state when back to state MM IDLE from another state.....	68
4.2.4	Behaviour in state GMM-DEREGISTERED.....	68
4.2.4.1	Primary substate selection.....	69
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability.....	69
4.2.4.1.2	Other Cases.....	69
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED.....	70
4.2.4.2.1	Substate, NORMAL-SERVICE .....	70
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH.....	70
4.2.4.2.3	Substate, LIMITED-SERVICE .....	70
4.2.4.2.4	Substate, NO-IMSI .....	70
4.2.4.2.5	Substate, NO-CELL .....	71
4.2.4.2.6	Substate, PLMN-SEARCH .....	71
4.2.4.2.7	Substate, ATTACH-NEEDED .....	71
4.2.4.2.8	Substate, SUSPENDED (A/Gb mode only).....	71
4.2.4.3	Substate when back to state GMM-DEREGISTERED from another GMM state .....	71
4.2.5	Behaviour in state GMM-REGISTERED.....	71
4.2.5.1	Detailed description of the MS behaviour in state GMM-REGISTERED.....	72
4.2.5.1.1	Substate, NORMAL-SERVICE .....	72
4.2.5.1.2	Substate, SUSPENDED (A/Gb mode only) .....	72
4.2.5.1.3	Substate, UPDATE-NEEDED .....	72
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE .....	72
4.2.5.1.5	Substate, NO-CELL-AVAILABLE .....	73
4.2.5.1.6	Substate, LIMITED-SERVICE .....	73
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM .....	73
4.2.5.1.8	Substate, PLMN-SEARCH .....	73
4.3	MM common procedures .....	73
4.3.1	TMSI reallocation procedure .....	74
4.3.1.1	TMSI reallocation initiation by the network .....	74
4.3.1.2	TMSI reallocation completion by the mobile station .....	74
4.3.1.3	TMSI reallocation completion in the network.....	74
4.3.1.4	Abnormal cases .....	75
4.3.2	Authentication procedure.....	75
4.3.2a	Authentication procedure used for a UMTS authentication challenge.....	75
4.3.2b	Authentication Procedure used for a GSM authentication challenge.....	76
4.3.2.1	Authentication request by the network.....	76
4.3.2.2	Authentication response by the mobile station.....	76
4.3.2.3	Authentication processing in the network .....	77
4.3.2.3a	128-bit circuit-switched GSM ciphering key .....	77
4.3.2.4	Ciphering key sequence number .....	77
4.3.2.5	Authentication not accepted by the network .....	78
4.3.2.5.1	Authentication not accepted by the MS .....	79
4.3.2.6	Abnormal cases .....	79
4.3.2.6.1	MS behaviour towards a network that has failed the authentication procedure.....	82
4.3.2.7	Handling of keys at intersystem change from Iu mode to A/Gb mode .....	82
4.3.2.7a	Use of established security contexts.....	83

4.3.2.8	Handling of keys at intersystem change from A/Gb mode to Iu mode .....	84
4.3.2.9	Void.....	84
4.3.2.10	Derivation of keys at SRVCC handover from S1 mode.....	84
4.3.2.10.1	PDN connection with integrity protection.....	84
4.3.2.10.2	PDN connection without integrity protection.....	85
4.3.2.11	Derivation of keys at SRVCC handover from Iu mode to Iu mode .....	85
4.3.2.11.1	PDN connection with integrity protection.....	85
4.3.2.11.2	PDN connection without integrity protection.....	86
4.3.2.12	Derivation of keys at SRVCC handover from Iu mode to A/Gb mode.....	86
4.3.2.12.1	PDN connection with integrity protection.....	86
4.3.2.12.2	PDN connection without integrity protection.....	87
4.3.3	Identification procedure.....	87
4.3.3.1	Identity request by the network.....	88
4.3.3.2	Identification response by the mobile station.....	88
4.3.3.3	Abnormal cases.....	88
4.3.4	IMSI detach procedure.....	88
4.3.4.0	General.....	88
4.3.4.1	IMSI detach initiation by the mobile station.....	89
4.3.4.2	IMSI detach procedure in the network.....	89
4.3.4.3	IMSI detach completion by the mobile station.....	89
4.3.4.4	Abnormal cases.....	89
4.3.5	Abort procedure.....	90
4.3.5.1	Abort procedure initiation by the network.....	90
4.3.5.2	Abort procedure in the mobile station.....	90
4.3.6	MM information procedure.....	90
4.3.6.1	MM information procedure initiation by the network.....	90
4.3.6.2	MM information procedure in the mobile station.....	91
4.4	MM specific procedures.....	91
4.4.1	Location updating procedure.....	91
4.4.2	Periodic updating.....	93
4.4.3	IMSI attach procedure.....	94
4.4.4	Generic Location Updating procedure.....	94
4.4.4.1	Location updating initiation by the mobile station.....	94
4.4.4.1a	Network Request for Additional mobile station Capability Information.....	94
4.4.4.2	Identification request from the network.....	94
4.4.4.3	Authentication by the network.....	95
4.4.4.4	Security mode setting by the network.....	95
4.4.4.5	Attempt Counter.....	95
4.4.4.6	Location updating accepted by the network.....	95
4.4.4.7	Location updating not accepted by the network.....	97
4.4.4.8	Release of RR connection after location updating.....	98
4.4.4.9	Abnormal cases on the mobile station side.....	99
4.4.4.10	Abnormal cases on the network side.....	101
4.4.5	Void.....	101
4.4.6	Void.....	101
4.4.7	eCall inactivity procedure.....	101
4.5	Connection management sublayer service provision.....	102
4.5.1	MM connection establishment.....	102
4.5.1.1	MM connection establishment initiated by the mobile station.....	102
4.5.1.2	Abnormal cases.....	106
4.5.1.3	MM connection establishment initiated by the network.....	107
4.5.1.3.1	Mobile Terminating CM Activity.....	107
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$.....	108
4.5.1.3.3	Paging response in Iu mode (Iu mode only).....	109
4.5.1.3.4	Paging response for CS fallback.....	109
4.5.1.4	Abnormal cases.....	110
4.5.1.5	MM connection establishment for emergency calls.....	110
4.5.1.5a	MM connection establishment for emergency calls for CS fallback.....	111
4.5.1.6	Call re-establishment.....	111
4.5.1.6.1	Call re-establishment, initiation by the mobile station.....	111
4.5.1.6.2	Abnormal cases.....	113
4.5.1.7	Forced release during MO MM connection establishment.....	114

4.5.1.8	MM connection establishment due to SRVCC handover.....	114
4.5.2	MM connection information transfer phase.....	114
4.5.2.1	Sending CM messages .....	114
4.5.2.2	Receiving CM messages .....	114
4.5.2.3	Abnormal cases .....	115
4.5.3	MM connection release.....	115
4.5.3.1	Release of associated RR connection.....	115
4.5.3.2	Uplink release in a voice group call.....	116
4.6	Receiving a MM STATUS message by a MM entity.....	116
4.7	Elementary mobility management procedures for GPRS services .....	116
4.7.1	General.....	116
4.7.1.1	Lower layer failure.....	116
4.7.1.2	Ciphering of messages (A/Gb mode only).....	116
4.7.1.3	P-TMSI signature.....	117
4.7.1.4	Radio resource sublayer address handling .....	117
4.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only) .....	117
4.7.1.5	P-TMSI handling.....	118
4.7.1.5.1	P-TMSI handling in A/Gb mode .....	118
4.7.1.5.2	P-TMSI handling in Iu mode.....	119
4.7.1.5.3	Void.....	119
4.7.1.5.4	Void.....	119
4.7.1.6	Change of network mode of operation.....	119
4.7.1.6.1	Change of network mode of operation in A/Gb mode (A/Gb mode only) .....	119
4.7.1.6.2	Change of network mode of operation in Iu mode (Iu mode only) .....	120
4.7.1.6.3	Change of network mode of operation at Iu mode to A/Gb mode inter-system change .....	120
4.7.1.6.4	Change of network mode of operation at A/Gb mode to Iu mode inter-system change .....	121
4.7.1.7	Intersystem change between A/Gb mode and Iu mode .....	122
4.7.1.7a	Intersystem change from S1 mode to A/Gb mode or S1 mode to Iu mode with ISR activated .....	123
4.7.1.8	List of forbidden PLMNs for GPRS service .....	124
4.7.1.8a	Establishment of the PS signalling connection (Iu mode only).....	124
4.7.1.9	Release of the PS signalling connection (Iu mode only).....	125
4.7.2	GPRS Mobility management timers and UMTS PS signalling connection control.....	125
4.7.2.1	READY timer behaviour.....	125
4.7.2.1.1	READY timer behaviour (A/Gb mode only).....	125
4.7.2.1.2	Handling of READY timer in the MS in Iu mode and S1 mode .....	126
4.7.2.1.2a	Handling of READY timer in the network in Iu mode and S1 mode .....	127
4.7.2.2	Periodic routing area updating .....	127
4.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only) .....	129
4.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only).....	129
4.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only) .....	129
4.7.2.6	Cell Update triggered by low layers.....	129
4.7.3	GPRS attach procedure.....	129
4.7.3.1	GPRS attach procedure for GPRS services .....	131
4.7.3.1.1	GPRS attach procedure initiation .....	131
4.7.3.1.2	GMM common procedure initiation.....	132
4.7.3.1.3	GPRS attach accepted by the network.....	132
4.7.3.1.4	GPRS attach not accepted by the network.....	134
4.7.3.1.4a	GPRS attach for emergency bearer services not accepted by the network (UTRAN Iu mode only) .....	138
4.7.3.1.4b	Attach for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only) .....	139
4.7.3.1.5	Abnormal cases in the MS.....	139
4.7.3.1.6	Abnormal cases on the network side .....	141
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services .....	142
4.7.3.2.1	Combined GPRS attach procedure initiation.....	143
4.7.3.2.2	GMM Common procedure initiation .....	143
4.7.3.2.3	Combined GPRS attach accepted by the network .....	143
4.7.3.2.4	Combined GPRS attach not accepted by the network .....	144
4.7.3.2.5	Abnormal cases in the MS.....	148
4.7.3.2.6	Abnormal cases on the network side .....	148
4.7.4	GPRS detach procedure .....	148
4.7.4.0	General .....	148

4.7.4.1	MS initiated GPRS detach procedure.....	149
4.7.4.1.1	MS initiated GPRS detach procedure initiation.....	149
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only.....	150
4.7.4.1.3	MS initiated combined GPRS detach procedure completion.....	150
4.7.4.1.4	Abnormal cases in the MS.....	150
4.7.4.1.5	Abnormal cases on the network side.....	152
4.7.4.2	Network initiated GPRS detach procedure.....	152
4.7.4.2.1	Network initiated GPRS detach procedure initiation.....	152
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS.....	153
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network.....	157
4.7.4.2.4	Abnormal cases on the network side.....	157
4.7.5	Routing area updating procedure.....	158
4.7.5.1	Normal and periodic routing area updating procedure.....	160
4.7.5.1.1	Normal and periodic routing area updating procedure initiation.....	161
4.7.5.1.2	GMM Common procedure initiation.....	162
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network.....	162
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network.....	165
4.7.5.1.4a	Routing area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only).....	170
4.7.5.1.5	Abnormal cases in the MS.....	170
4.7.5.1.6	Abnormal cases on the network side.....	173
4.7.5.2	Combined routing area updating procedure.....	174
4.7.5.2.0	General.....	174
4.7.5.2.1	Combined routing area updating procedure initiation.....	174
4.7.5.2.2	GMM Common procedure initiation.....	176
4.7.5.2.3	Combined routing area updating procedure accepted by the network.....	176
4.7.5.2.4	Combined routing area updating not accepted by the network.....	178
4.7.5.2.5	Abnormal cases in the MS.....	182
4.7.5.2.6	Abnormal cases on the network side.....	182
4.7.6	P-TMSI reallocation procedure.....	183
4.7.6.1	P-TMSI reallocation initiation by the network.....	183
4.7.6.2	P-TMSI reallocation completion by the MS.....	183
4.7.6.3	P-TMSI reallocation completion by the network.....	183
4.7.6.4	Abnormal cases on the network side.....	183
4.7.7	Authentication and ciphering procedure.....	185
4.7.7a	Authentication and ciphering procedure used for UMTS authentication challenge.....	185
4.7.7b	Authentication and ciphering procedure used for GSM authentication challenge.....	185
4.7.7c	Change of the ciphering algorithm at PS Handover.....	186
4.7.7.1	Authentication and ciphering initiation by the network.....	186
4.7.7.2	Authentication and ciphering response by the MS.....	187
4.7.7.3	Authentication and ciphering completion by the network.....	188
4.7.7.3a	128-bit packet-switched GSM ciphering key.....	188
4.7.7.4	GPRS ciphering key sequence number.....	188
4.7.7.5	Authentication not accepted by the network.....	190
4.7.7.5.1	Authentication not accepted by the MS.....	190
4.7.7.6	Abnormal cases.....	191
4.7.7.6.1	MS behaviour towards a network that has failed the authentication procedure.....	194
4.7.7.7	Use of established security contexts.....	194
4.7.7.8	Handling of keys at intersystem change from Iu mode to A/Gb mode.....	195
4.7.7.9	Handling of keys at intersystem change from A/Gb mode to Iu mode.....	196
4.7.7.10	Handling of keys at intersystem change from S1 mode to Iu mode or A/Gb mode.....	197
4.7.8	Identification procedure.....	199
4.7.8.1	Identification initiation by the network.....	199
4.7.8.2	Identification response by the MS.....	199
4.7.8.3	Identification completion by the network.....	199
4.7.8.3a	Abnormal cases in the MS.....	199
4.7.8.4	Abnormal cases on the network side.....	199
4.7.9	Paging procedure.....	200
4.7.9.1	Paging for GPRS services.....	200
4.7.9.1.1	Paging for GPRS services using P-TMSI.....	200
4.7.9.1.2	Paging for GPRS services using IMSI.....	201
4.7.9.2	Paging for non-GPRS services.....	202

4.7.10	Receiving a GMM STATUS message by a GMM entity .....	202
4.7.11	Void .....	202
4.7.12	GMM Information procedure .....	202
4.7.12.1	GMM information procedure initiation by the network .....	202
4.7.12.2	GMM information procedure in the mobile station .....	202
4.7.13	Service Request procedure (Iu mode only) .....	202
4.7.13.1	Service Request procedure initiation .....	204
4.7.13.2	GMM common procedure initiation .....	204
4.7.13.3	Service request procedure accepted by the network .....	205
4.7.13.4	Service request procedure not accepted by the network .....	205
4.7.13.4a	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network .....	209
4.7.13.5	Abnormal cases in the MS .....	209
4.7.13.6	Abnormal cases on the network side .....	211
4.7.14	Void .....	212
5	Elementary procedures for circuit-switched Call Control .....	212
5.1	Overview .....	212
5.1.1	General .....	212
5.1.2	Call Control States .....	219
5.1.2.1	Call states at the mobile station side of the interface .....	219
5.1.2.1.1	Null (State U0) .....	219
5.1.2.1.2	MM Connection pending (U0.1) .....	219
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$ .....	219
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$ .....	219
5.1.2.1.2c	CC-Establishment present (U0.4) \$(CCBS)\$ .....	219
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$ .....	219
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$ .....	219
5.1.2.1.3	Call initiated (U1) .....	219
5.1.2.1.4	Mobile originating call proceeding (U3) .....	219
5.1.2.1.5	Call delivered (U4) .....	220
5.1.2.1.6	Call present (U6) .....	220
5.1.2.1.7	Call received (U7) .....	220
5.1.2.1.8	Connect Request (U8) .....	220
5.1.2.1.9	Mobile terminating call confirmed (U9) .....	220
5.1.2.1.10	Active (U10) .....	220
5.1.2.1.11	Disconnect request (U11) .....	220
5.1.2.1.12	Disconnect indication (U12) .....	220
5.1.2.1.13	Release request (U19) .....	220
5.1.2.1.14	Mobile originating modify (U26) .....	220
5.1.2.1.15	Mobile terminating modify (U27) .....	220
5.1.2.2	Network call states .....	220
5.1.2.2.1	Null (State N0) .....	221
5.1.2.2.2	MM connection pending (N0.1) .....	221
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$ .....	221
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$ .....	221
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$ .....	221
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$ .....	221
5.1.2.2.3	Call initiated (N1) .....	221
5.1.2.2.4	Mobile originating call proceeding (N3) .....	221
5.1.2.2.5	Call delivered (N4) .....	221
5.1.2.2.6	Call present (N6) .....	221
5.1.2.2.7	Call received (N7) .....	221
5.1.2.2.8	Connect request (N8) .....	221
5.1.2.2.9	Mobile terminating call confirmed (N9) .....	222
5.1.2.2.10	Active (N10) .....	222
5.1.2.2.11	Not used .....	222
5.1.2.2.12	Disconnect indication (N12) .....	222
5.1.2.2.13	Release request (N19) .....	222
5.1.2.2.14	Mobile originating modify (N26) .....	222
5.1.2.2.15	Mobile terminating modify (N27) .....	222
5.1.2.2.16	Connect Indication (N28) .....	222

5.2	Call establishment procedures.....	222
5.2.1	Mobile originating call establishment.....	223
5.2.1.1	Call initiation.....	224
5.2.1.2	Receipt of a setup message.....	224
5.2.1.3	Receipt of a CALL PROCEEDING message.....	225
5.2.1.4	Notification of progressing mobile originated call.....	226
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment.....	226
5.2.1.4.2	Call progress in the PLMN/ISDN environment.....	226
5.2.1.5	Alerting.....	226
5.2.1.6	Call connected.....	227
5.2.1.7	Call rejection.....	228
5.2.1.8	Transit network selection.....	228
5.2.1.9	Traffic channel assignment at mobile originating call establishment.....	228
5.2.1.10	Call queuing at mobile originating call establishment.....	228
5.2.1.11	Speech Codec Selection.....	229
5.2.1.12	Cellular Text telephone Modem (CTM) selection.....	230
5.2.2	Mobile terminating call establishment.....	230
5.2.2.1	Call indication.....	230
5.2.2.2	Compatibility checking.....	231
5.2.2.3	Call confirmation.....	231
5.2.2.3.1	Response to SETUP.....	231
5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network.....	231
5.2.2.3.3	Call failure procedures.....	232
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment.....	233
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment.....	233
5.2.2.5	Call accept.....	233
5.2.2.6	Active indication.....	233
5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	234
5.2.2.8	Call queuing at mobile terminating call establishment.....	234
5.2.2.9	User connection attachment during a mobile terminating call.....	234
5.2.2.10	Speech Codec Selection.....	234
5.2.2.11	Cellular Text telephone Modem (CTM) selection.....	234
5.2.3	Network initiated MO call \$(CCBS)\$.....	235
5.2.3.1	Initiation.....	235
5.2.3.2	CC-Establishment present.....	235
5.2.3.2.1	Recall Alignment Procedure.....	236
5.2.3.3	CC-Establishment confirmation.....	237
5.2.3.4	Recall present.....	238
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment.....	238
5.2.4	Call establishment for SRVCC.....	239
5.2.4.1	General.....	239
5.2.4.2	Call activation.....	239
5.2.4.3	Traffic channel assignment and user connection attachment.....	239
5.2.4.4	State verification.....	240
5.3	Signalling procedures during the "active" state.....	240
5.3.1	User notification procedure.....	240
5.3.2	Call rearrangements.....	240
5.3.3	Codec Change Procedure.....	240
5.3.4	Support of Dual Services.....	240
5.3.4.1	Service Description.....	240
5.3.4.2	Call establishment.....	241
5.3.4.2.1	Mobile Originating Establishment.....	241
5.3.4.2.2	Mobile Terminating Establishment.....	242
5.3.4.3	Changing the Call Mode.....	242
5.3.4.3.1	Initiation of in-call modification.....	242
5.3.4.3.2	Successful completion of in-call modification.....	242
5.3.4.3.3	Change of the channel configuration.....	244
5.3.4.3.4	Failure of in-call modification.....	244
5.3.4.4	Abnormal procedures.....	244
5.3.5	User initiated service level up- and downgrading (A/Gb mode and GERAN Iu mode only).....	245
5.3.5.1	Initiation of service level up- and downgrading.....	245
5.3.5.2	Successful completion of service level up- and downgrading.....	245

5.3.5.3	Rejection of service level up- and downgrading .....	246
5.3.5.4	Time-out recovery .....	246
5.3.6	Support of multimedia calls .....	246
5.3.6.1	Service description .....	246
5.3.6.2	Call establishment .....	246
5.3.6.2.1	Mobile originated multimedia call establishment .....	246
5.3.6.2.2	Mobile terminating multimedia call .....	247
5.3.6.2.2.1	Fallback to speech .....	248
5.3.6.3	In-call modification in the "active" state .....	248
5.3.6.3.1	Void .....	249
5.3.6.3.2	Void .....	249
5.3.6.3.3	Void .....	249
5.3.6.4	Multimedia CAT during the alerting phase of a mobile originated call .....	249
5.3.6.5	DTMF transmission during a multimedia call .....	250
5.4	Call clearing .....	250
5.4.1	Terminology .....	250
5.4.2	Exception conditions .....	250
5.4.3	Clearing initiated by the mobile station .....	251
5.4.3.1	Initiation of call clearing .....	251
5.4.3.2	Receipt of a DISCONNECT message from the mobile station .....	251
5.4.3.3	Receipt of a RELEASE message from the network .....	251
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station .....	251
5.4.3.5	Abnormal cases .....	251
5.4.4	Clearing initiated by the network .....	251
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure" .....	252
5.4.4.1.1	Clearing when tones/announcements provided .....	252
5.4.4.1.2	Clearing when tones/announcements not provided .....	252
5.4.4.1.3	Completion of clearing .....	253
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure" .....	253
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible" .....	253
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible" .....	254
5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible" .....	255
5.4.4.2.4	Receipt of a RELEASE message from the mobile station .....	255
5.4.4.2.5	Completion of clearing .....	256
5.5	Miscellaneous procedures .....	256
5.5.1	In-band tones and announcements .....	256
5.5.2	Call collisions .....	257
5.5.3	Status procedures .....	257
5.5.3.1	Status enquiry procedure .....	257
5.5.3.2	Reception of a STATUS message by a CC entity .....	257
5.5.3.2.1	STATUS message with incompatible state .....	257
5.5.3.2.2	STATUS message with compatible state .....	257
5.5.4	Call re-establishment, mobile station side .....	258
5.5.4.1	Indication from the mobility management sublayer .....	258
5.5.4.2	Reaction of call control .....	258
5.5.4.3	Completion of re-establishment .....	258
5.5.4.4	Unsuccessful outcome .....	258
5.5.5	Call re-establishment, network side .....	259
5.5.5.1	State alignment .....	259
5.5.6	Progress .....	259
5.5.7	DTMF protocol control procedure .....	259
5.5.7.1	Start DTMF request by the mobile station .....	259
5.5.7.2	Start DTMF response by the network .....	260
5.5.7.3	Stop DTMF request by the mobile station .....	260
5.5.7.4	Stop DTMF response by the network .....	260
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station .....	260
6	Support for packet services .....	261
6.1	GPRS Session management .....	261
6.1.1	General .....	261

6.1.2	Session management states .....	262
6.1.2.1	Session management states in the MS.....	262
6.1.2.1.1	PDP-INACTIVE.....	262
6.1.2.1.2	PDP-ACTIVE-PENDING .....	262
6.1.2.1.3	PDP-INACTIVE-PENDING.....	262
6.1.2.1.4	PDP-ACTIVE.....	262
6.1.2.1.5	PDP-MODIFY_PENDING .....	262
6.1.2.1.6	MBMS-ACTIVE-PENDING .....	262
6.1.2.1.7	MBMS-ACTIVE .....	262
6.1.2.2	Session management states on the network side .....	264
6.1.2.2.1	PDP-INACTIVE.....	264
6.1.2.2.2	PDP-ACTIVE-PENDING .....	264
6.1.2.2.3	PDP-INACTIVE-PENDING .....	264
6.1.2.2.4	PDP-ACTIVE.....	264
6.1.2.2.5	PDP-MODIFY_PENDING .....	264
6.1.2.2.6	MBMS-ACTIVE-PENDING .....	265
6.1.2.2.7	MBMS-INACTIVE-PENDING .....	265
6.1.2.2.8	MBMS-ACTIVE .....	265
6.1.2A	PDP address allocation .....	266
6.1.2A.1	General .....	266
6.1.2A.1.1	Interworking with PDN based on IP.....	266
6.1.2A.1.2	Interworking with PDN based on PPP.....	266
6.1.2A.2	IP address allocation via NAS signalling .....	267
6.1.3	Session Management procedures .....	267
6.1.3.1	PDP context activation .....	267
6.1.3.1.1	Successful PDP context activation initiated by the mobile station .....	268
6.1.3.1.2	Successful PDP context activation requested by the network .....	269
6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS.....	270
6.1.3.1.4	Unsuccessful PDP context activation requested by the network .....	272
6.1.3.1.5	Abnormal cases .....	272
6.1.3.2	Secondary PDP Context Activation Procedure.....	274
6.1.3.2.1	Successful Secondary PDP Context Activation Procedure Initiated by the MS.....	275
6.1.3.2.1a	Successful Secondary PDP Context Activation Procedure Requested by the network .....	275
6.1.3.2.2	Unsuccessful Secondary PDP Context Activation Procedure initiated by the MS.....	276
6.1.3.2.2a	Unsuccessful secondary PDP context activation requested by the network .....	277
6.1.3.2.3	Abnormal cases .....	277
6.1.3.3	PDP context modification procedure .....	280
6.1.3.3.1	Network initiated PDP Context Modification .....	281
6.1.3.3.2	MS initiated PDP Context Modification accepted by the network.....	281
6.1.3.3.3	MS initiated PDP Context Modification not accepted by the network.....	282
6.1.3.3.3a	Network initiated PDP Context Modification not accepted by the MS .....	285
6.1.3.3.4	Abnormal cases .....	285
6.1.3.4	PDP context deactivation procedure .....	286
6.1.3.4.1	PDP context deactivation initiated by the MS .....	287
6.1.3.4.2	PDP context deactivation initiated by the network.....	287
6.1.3.4.3	Abnormal cases .....	288
6.1.3.4a	Void.....	289
6.1.3.5	Void.....	289
6.1.3.5a	Notification procedure .....	289
6.1.3.5a.1	General .....	289
6.1.3.5a.2	Notification procedure initiation by the network.....	289
6.1.3.5a.3	Notification procedure in the MS .....	290
6.1.3.6	Receiving a SM STATUS message by a SM entity .....	290
6.1.3.7	Protocol configuration options .....	291
6.1.3.8	MBMS context activation .....	291
6.1.3.8.1	Successful MBMS context activation.....	291
6.1.3.8.2	Unsuccessful MBMS context activation requested by the MS.....	291
6.1.3.8.3	Unsuccessful MBMS context activation requested by the network.....	293
6.1.3.8.4	Abnormal cases .....	293
6.1.3.9	MBMS context deactivation.....	294
6.1.3.9.1	MBMS context deactivation initiated by the network .....	294
6.1.3.9.2	Abnormal cases .....	294

6.1.3.10	MBMS protocol configuration options .....	295
6.1.3.11	Handling of APN based congestion control .....	295
6.2	void.....	295
6.3	Coordination between SM and GMM for supporting ISR .....	295
6.4	MSISDN notification procedure.....	295
7	Examples of structured procedures .....	296
8	Handling of unknown, unforeseen, and erroneous protocol data .....	296
8.1	General .....	296
8.2	Message too short.....	296
8.3	Unknown or unforeseen transaction identifier .....	297
8.3.1	Call Control .....	297
8.3.2	Session Management .....	298
8.4	Unknown or unforeseen message type .....	299
8.5	Non-semantic mandatory information element errors .....	299
8.5.1	Radio resource management .....	300
8.5.2	Mobility management .....	300
8.5.3	Call control .....	300
8.5.4	GMM mobility management.....	300
8.5.5	Session management.....	300
8.6	Unknown and unforeseen IEs in the non-imperative message part.....	301
8.6.1	IEs unknown in the message .....	301
8.6.2	Out of sequence IEs .....	301
8.6.3	Repeated IEs .....	301
8.7	Non-imperative message part errors.....	301
8.7.1	Syntactically incorrect optional IEs .....	301
8.7.2	Conditional IE errors .....	301
8.8	Messages with semantically incorrect contents .....	302
9	Message functional definitions and contents.....	302
9.1	Messages for Radio Resources management.....	303
9.2	Messages for mobility management .....	303
9.2.1	Authentication reject.....	304
9.2.2	Authentication request .....	304
9.2.2.1	Authentication Parameter AUTN.....	304
9.2.3	Authentication response.....	305
9.2.3.1	Authentication Response Parameter.....	305
9.2.3.2	Authentication Response Parameter (extension).....	305
9.2.3a	Authentication Failure .....	305
9.2.3a.1	Authentication Failure parameter.....	306
9.2.4	CM Re-establishment request .....	306
9.2.4.1	Location area identification.....	306
9.2.4.2	Mobile Station Classmark .....	306
9.2.4.3	Device properties .....	306
9.2.5	CM service accept.....	306
9.2.5a	CM service prompt \$(CCBS)\$.....	307
9.2.6	CM service reject.....	307
9.2.6.1	T3246 value.....	308
9.2.7	CM service abort.....	308
9.2.8	Abort.....	308
9.2.9	CM service request .....	309
9.2.9.1	Mobile Station Classmark .....	309
9.2.9.2	Priority .....	309
9.2.9.3	Additional update parameters.....	309
9.2.9.4	Device properties .....	309
9.2.10	Identity request .....	310
9.2.11	Identity response .....	310
9.2.12	IMSI detach indication.....	310
9.2.12.1	Mobile Station Classmark .....	311
9.2.13	Location updating accept .....	311
9.2.13.1	Follow on proceed.....	311
9.2.13.2	CTS permission.....	312