

SLOVENSKI STANDARD

SIST ETS 300 940 E2:2005

01-februar-2005

8][JhUb]WW] b]hYY_ca i b]_UWg]g]ghYa 'fUhU&žl! Ja Ygb]_nUa cV]b]fUX]c'!
GdYwZ_UWYUfYhY'd`Ugh]f] GA '\$('\$, žfUh]]WU) ** " Ł

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile radio interface;
Layer 3 specification (GSM 04.08 version 5.6.3)

iTeh STANDARD PREVIEW (standards.iteh.ai)

Ta slovenski standard je istoveten z: [SIST ETS 300 940 E2:2005](https://standards.iteh.ai/catalog/standards/sist/0a61beb0-02b3-4821-9c2c-fab4b8fb2d6/sist-ets-300-940-e2-2005)
<https://standards.iteh.ai/catalog/standards/sist/0a61beb0-02b3-4821-9c2c-fab4b8fb2d6/sist-ets-300-940-e2-2005>

ICS:

33.070.01 Mobilni servisi na splošno Mobile services in general

SIST ETS 300 940 E2:2005 en

**iTeh STANDARD PREVIEW
(standards.iteh.ai)**

SIST ETS 300 940 E2:2005
<https://standards.iteh.ai/catalog/standards/sist/0a61beb0-02b3-4821-9c2c-fab4b8f3b2d6/sist-ets-300-940-e2-2005>



EUROPEAN TELECOMMUNICATION STANDARD

ETS 300 940

February 1998

Second Edition

Source: SMG

Reference: RE/SMG-030408QR4

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile radio interface;
Layer 3 specification
(GSM 04.08 version 5.6.3)**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

X.400: c=fr, a=atlas, p=etsi, s=secretariat - **Internet:** secretariat@etsi.fr

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1998. All rights reserved.

Page 2

ETS 300 940 (GSM 04.08 version 5.6.3): February 1998

iTeh STANDARD PREVIEW (standards.iteh.ai)

[SIST ETS 300 940 E2:2005](#)

<https://standards.iteh.ai/catalog/standards/sist/0a61beb0-02b3-4821-9c2c-fab4b8f3b2d6/sist-ets-300-940-e2-2005>

Contents

	3.3.1.1.3.2	Assignment rejection	39
	3.3.1.1.4	Assignment completion	39
	3.3.1.1.5	Abnormal cases	40
3.3.1.2	Entering the group transmit mode: uplink access procedure	40	
	3.3.1.2.1	Mobile station side	40
	3.3.1.2.1.1	Uplink investigation procedure	40
	3.3.1.2.1.2	Uplink access procedure	41
	3.3.1.2.2	Network side	41
	3.3.1.2.3	Abnormal cases	41
3.3.2	Paging procedure	42	
	3.3.2.1	Paging initiation by the network	42
	3.3.2.2	Paging response	43
	3.3.2.3	Abnormal cases	43
3.3.3	Notification procedure	44	
	3.3.3.1	Notification of a call	44
	3.3.3.2	Joining a VGCS or VBS call	44
	3.3.3.3	Reduced NCH monitoring mechanism	45
3.4	Procedures in dedicated mode and in group transmit mode	46	
3.4.1	SACCH procedures	46	
	3.4.1.1	General	46
	3.4.1.2	Measurement report	46
3.4.2	Transfer of messages and link layer service provision	47	
3.4.3	Channel assignment procedure	47	
	3.4.3.1	Channel assignment initiation	47
	3.4.3.2	Assignment completion	49
	3.4.3.3	Abnormal cases	49
3.4.4	Handover procedure	50	
	3.4.4.1	Handover initiation	50
	3.4.4.2	Physical channel establishment	52
	3.4.4.2.1	Finely synchronized cell case	52
	3.4.4.2.2	Non synchronized cell case	52
	3.4.4.2.3	Pseudo-synchronized cell case	53
	3.4.4.2.4	Pre-synchronized cell case	53
	3.4.4.3	Handover completion	53
	3.4.4.4	Abnormal cases	54
3.4.5	Frequency redefinition procedure	55	
	3.4.5.1	Abnormal cases	55
3.4.6	Channel mode modify procedure	55	
	3.4.6.1	Normal channel mode modify procedure	56
	3.4.6.1.1	Initiation of the channel mode modify procedure	56
	3.4.6.1.2	Completion of channel mode modify procedure	56
	3.4.6.1.3	Abnormal cases	56
	3.4.6.2	Channel mode modify procedure for a voice group call talker	56
	3.4.6.2.1	Initiation of the channel mode modify procedure	56
	3.4.6.2.2	Completion of mode change procedure	57
	3.4.6.2.3	Abnormal cases	57
3.4.7	Ciphering mode setting procedure	57	
	3.4.7.1	Ciphering mode setting initiation	57
	3.4.7.2	Ciphering mode setting completion	57
3.4.8	Additional channel assignment procedure	58	
	3.4.8.1	Additional assignment procedure initiation	58
	3.4.8.2	Additional assignment procedure completion	58
	3.4.8.3	Abnormal cases	58
3.4.9	Partial channel release procedure	59	
	3.4.9.1	Partial release procedure initiation	59

3.4.9.2	Abnormal cases.....	59
3.4.10	Classmark change procedure	59
3.4.11	Classmark interrogation procedure.....	59
3.4.11.1	Classmark interrogation initiation	59
3.4.11.2	Classmark interrogation completion	60
3.4.12	Indication of notifications and paging informations.....	60
3.4.13	RR connection release procedure	61
3.4.13.1	Normal release procedure	61
3.4.13.1.1	Channel release procedure initiation in dedicated mode and in group transmit mode	61
3.4.13.1.2	Abnormal cases.....	62
3.4.13.2	Radio link failure in dedicated mode.....	62
3.4.13.2.1	Mobile side	62
3.4.13.2.2	Network side	62
3.4.13.3	RR connection abortion in dedicated mode.....	62
3.4.13.4	Uplink release procedure in group transmit mode.....	63
3.4.14	Receiving a RR STATUS message by a RR entity.....	63
3.4.15	Group receive mode procedures.....	63
3.4.15.1	Mobile station side	63
3.4.15.1.1	Reception of the VGCS or VBS channel	63
3.4.15.1.2	Monitoring of downlink messages and related procedures	63
3.4.15.1.2.1	Channel assignment procedure	63
3.4.15.1.2.2	Frequency redefinition procedure	63
3.4.15.1.2.3	Channel mode modify procedure	64
3.4.15.1.2.4	Notification and paging information	64
3.4.15.1.2.4.1	Use of Reduced NCH monitoring	64
3.4.15.1.2.5	Uplink status messages.....	64
3.4.15.1.2.6	Channel release message	64
3.4.15.1.2.7	Information on paging channel restructuring	65
3.4.15.1.3	Uplink reply procedure	65
3.4.15.1.4	Leaving the group receive mode	65
3.4.15.1.4.1	Returning to idle mode	65
3.4.15.1.4.2	Going to group transmit mode	65
3.4.15.2	Network side	66
3.4.15.2.1	Provision of messages on the VGCS or VBS channel downlink	66
3.4.15.2.1.1	General	66
3.4.15.2.1.2	Provision of general information messages	66
3.4.15.2.1.3	Provision of messages related to the voice group call uplink channel	66
3.4.15.2.2	Release of the VGCS or VBS Channels.....	67
3.4.15.3	Failure cases.....	67
3.4.16	Configuration change procedure.....	67
3.4.16.1	Configuration change initiation	67
3.4.16.2	Configuration change completion	67
3.4.16.3	Abnormal cases	68
3.4.17	Mapping of user data substreams onto timeslots in a multislot configuration.....	68
3.4.18	Handling of classmark information at band change.....	68
4	Elementary procedures for Mobility Management.....	69
4.1	General	69
4.1.1	Type of MM procedures.....	69
4.1.2	MM sublayer states	69

4.1.2.1	MM sublayer states in the mobile station.....	70
4.1.2.1.1	Main states	70
4.1.2.1.2	Substates of the MM IDLE state	73
4.1.2.2	The update Status.....	74
4.1.2.3	MM sublayer states on the network side.....	75
4.2	Behaviour in MM IDLE State.....	76
4.2.1	Primary Service State selection	76
4.2.1.1	Selection of the Service State after Power On.....	76
4.2.1.2	Other Cases.....	77
4.2.2	Detailed Description of the MS behaviour in MM IDLE State	77
4.2.2.1	Service State, NORMAL SERVICE.....	77
4.2.2.2	Service State, ATTEMPTING TO UPDATE	77
4.2.2.3	Service State, LIMITED SERVICE	78
4.2.2.4	Service State, NO IMSI	78
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE	79
4.2.2.6	Service State, SEARCH FOR PLMN.....	79
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	79
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE)	79
4.2.3	Service state when back to state MM IDLE from another state	80
4.3	MM common procedures.....	80
4.3.1	TMSI reallocation procedure.....	81
4.3.1.1	TMSI reallocation initiation by the network.....	81
4.3.1.2	TMSI reallocation completion by the mobile station.....	81
4.3.1.3	TMSI reallocation completion in the network.....	81
4.3.1.4	Abnormal cases	81
4.3.2	Authentication procedure	83
4.3.2.1	Authentication request by the network.....	83
4.3.2.2	Authentication response by the mobile station.....	83
4.3.2.3	Authentication processing in the network.....	83
4.3.2.4	Ciphering key sequence number.....	83
4.3.2.5	Unsuccessful authentication.....	84
4.3.2.6	Abnormal cases	84
4.3.3	Identification procedure	85
4.3.3.1	Identity request by the network	85
4.3.3.2	Identification response by the mobile station.....	85
4.3.3.3	Abnormal cases	85
4.3.4	IMSI detach procedure.....	85
4.3.4.1	IMSI detach initiation by the mobile station	85
4.3.4.2	IMSI detach procedure in the network	86
4.3.4.3	IMSI detach completion by the mobile station	86
4.3.4.4	Abnormal cases	86
4.3.5	Abort procedure	86
4.3.5.1	Abort procedure initiation by the network	86
4.3.5.2	Abort procedure in the mobile station.....	87
4.3.6	MM information procedure.....	87
4.3.6.1	MM information procedure initiation by the network.....	87
4.3.6.2	MM information procedure in the mobile station	87
4.4	MM specific procedures.....	88
4.4.1	Location updating procedure.....	88
4.4.2	Periodic updating	89
4.4.3	IMSI attach procedure	89
4.4.4	Generic Location Updating procedure	90
4.4.4.1	Location updating initiation by the mobile station	90
4.4.4.1a	Network Request for Additional mobile station Capability Information	90
4.4.4.2	Identification request from the network	90
4.4.4.3	Authentication by the network.....	90
4.4.4.4	Ciphering mode setting by the network	90

4.4.4.5	Attempt Counter	90
4.4.4.6	Location updating accepted by the network.....	91
4.4.4.7	Location updating not accepted by the network	91
4.4.4.8	Release of RR connection after location updating	92
4.4.4.9	Abnormal cases on the mobile station side.....	92
4.4.4.10	Abnormal cases on the network side	93
4.5	Connection management sublayer service provision	94
4.5.1	MM connection establishment.....	94
4.5.1.1	MM connection establishment initiated by the mobile station.....	94
4.5.1.2	Abnormal cases.....	97
4.5.1.3	MM connection establishment initiated by the network	98
4.5.1.4	Abnormal cases.....	98
4.5.1.5	MM connection establishment for emergency calls.....	98
4.5.1.6	Call re-establishment.....	99
	4.5.1.6.1 Call re-establishment, initiation by the mobile station.....	100
	4.5.1.6.2 Abnormal cases.....	101
4.5.1.7	Forced release during MO MM connection establishment.	102
4.5.2	MM connection information transfer phase.....	102
4.5.2.1	Sending CM messages.....	102
4.5.2.2	Receiving CM messages	103
4.5.2.3	Abnormal cases.....	103
4.5.3	MM connection release	103
4.5.3.1	Release of associated RR connection.....	103
4.5.3.2	Uplink release in a voice group call	103
4.6	Receiving a MM STATUS message by a MM entity.....	103
5	Elementary procedures for circuit-switched Call Control.....	104
5.1	Overview	104
5.1.1	General	104
5.1.2	Call Control States.....	107
	https://standards.itec.ai/catalog/standards/ist/0a61fc50-03b1-4824-9e2c-fab4b8f3b2d6/sist-ets-300-940-e2-2005	
	5.1.2.1 Call states at the mobile station side of the interface	107
	5.1.2.1.1 Null (State U0).....	107
	5.1.2.1.2 MM Connection pending (U0.1).....	107
	5.1.2.1.3 Call initiated (U1).....	107
	5.1.2.1.4 Mobile originating call proceeding (U3)107	107
	5.1.2.1.5 Call delivered (U4).....	107
	5.1.2.1.6 Call present (U6)	107
	5.1.2.1.7 Call received (U7)	107
	5.1.2.1.8 Connect Request (U8).....	107
	5.1.2.1.9 Mobile terminating call confirmed (U9) 107	107
	5.1.2.1.10 Active (U10)	107
	5.1.2.1.11 Disconnect request (U11).....	107
	5.1.2.1.12 Disconnect indication (U12)	108
	5.1.2.1.13 Release request (U19).....	108
	5.1.2.1.14 Mobile originating modify (U26).....	108
	5.1.2.1.15 Mobile terminating modify (U27).....	108
	5.1.2.2 Network call states	108
	5.1.2.2.1 Null (State N0).....	108
	5.1.2.2.2 MM connection pending (N0.1)	108
	5.1.2.2.3 Call initiated (N1)	108
	5.1.2.2.4 Mobile originating call proceeding (N3)108	108
	5.1.2.2.5 Call delivered (N4)	108
	5.1.2.2.6 Call present (N6)	108
	5.1.2.2.7 Call received (N7)	108
	5.1.2.2.8 Connect request (N8).....	109
	5.1.2.2.9 Mobile terminating call confirmed (N9) 109	109
	5.1.2.2.10 Active (N10)	109
	5.1.2.2.11 {Not used}.....	109

	5.1.2.2.12	Disconnect indication (N12).....	109
	5.1.2.2.13	Release request (N19)	109
	5.1.2.2.14	Mobile originating modify (N26).....	109
	5.1.2.2.15	Mobile terminating modify (N27).....	109
	5.1.2.2.16	Connect Indication (N28)	109
5.2	Call establishment procedures		109
5.2.1	Mobile originating call establishment.....		110
5.2.1.1	Call initiation		110
5.2.1.2	Receipt of a setup message		111
5.2.1.3	Receipt of a CALL PROCEEDING message		112
5.2.1.4	Notification of progressing mobile originated call.....		112
	5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment	112
	5.2.1.4.2	Call progress in the PLMN/ISDN environment.....	113
	5.2.1.5	Alerting.....	113
	5.2.1.6	Call connected	114
	5.2.1.7	Call rejection.....	114
	5.2.1.8	Transit network selection	114
	5.2.1.9	Traffic channel assignment at mobile originating call establishment.....	114
	5.2.1.10	Call queuing at mobile originating call establishment.....	115
5.2.2	Mobile terminating call establishment.....		115
5.2.2.1	Call indication.....		115
5.2.2.2	Compatibility checking		116
5.2.2.3	Call confirmation		116
	5.2.2.3.1	Response to SETUP	116
	5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	116
	5.2.2.3.3	Call failure procedures	117
	5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment..	117
	5.2.2.4	Notification of interworking in connection with mobile terminating call establishment.....	117
	5.2.2.5	Call accept	117
	5.2.2.6	Active indication	117
	5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	118
	5.2.2.8	Call queuing at mobile terminating call establishment.....	118
	5.2.2.9	User connection attachment during a mobile terminating call.....	118
5.3	Signalling procedures during the "active" state		118
5.3.1	User notification procedure		118
5.3.2	Call rearrangements.....		119
5.3.3	Not used		119
5.3.4	Support of Dual Services		119
	5.3.4.1	Service Description	119
	5.3.4.2	Call establishment	119
	5.3.4.2.1	Mobile Originating Establishment.....	119
	5.3.4.2.2	Mobile Terminating Establishment	120
	5.3.4.3	Changing the Call Mode.....	120
	5.3.4.3.1	Initiation of in-call modification.....	121
	5.3.4.3.2	Successful completion of in-call modification.....	121
	5.3.4.3.3	Change of the channel configuration ...	121
	5.3.4.3.4	Failure of in-call modification.....	121
	5.3.4.3.4.1	Network rejection of in-call modification.....	121

	5.3.4.3.4.2	Mobile station rejection of in-call modification.....	122
	5.3.4.3.4.3	Time-out recovery.....	122
5.3.5	5.3.4.4	Abnormal procedures	122
	5.3.5.1	User initiated service level up- and downgrading.....	123
	5.3.5.2	Initiation of service level up- and downgrading	123
	5.3.5.3	Successful completion of service level up- and downgrading.....	123
	5.3.5.4	Rejection of service level up- and downgrading.....	123
	5.3.5.4	Time-out recovery.....	123
5.4	Call clearing		124
	5.4.1	Terminology	124
	5.4.2	Exception conditions	124
	5.4.3	Clearing initiated by the mobile station.....	124
	5.4.3.1	Initiation of call clearing	124
	5.4.3.2	Receipt of a DISCONNECT message from the mobile station.....	125
	5.4.3.3	Receipt of a RELEASE message from the network	125
	5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	125
	5.4.3.5	Abnormal cases.....	125
5.4.4	Clearing initiated by the network		125
	5.4.4.1	Clearing when tones/announcements provided.....	125
	5.4.4.1.1	Receipt of a DISCONNECT message with progress indicator #8 from the network	126
	5.4.4.1.2	Expiry of timer T306	126
	5.4.4.2	Clearing when tones/announcements not provided	126
	5.4.4.2.1	Receipt of a DISCONNECT message without progress indicator or with progress indicator different from #8 from the network	126
	5.4.4.2.2	Receipt of a RELEASE message from the mobile station	126
	5.4.4.2.3	Abnormal cases.....	126
	5.4.4.3	Completion of clearing.....	126
	5.4.4.3.1	Abnormal cases.....	127
5.5	5.4.5	Clear collision.....	127
	Miscellaneous procedures		127
	5.5.1	In-band tones and announcements	127
	5.5.2	Call collisions.....	127
	5.5.3	Status procedures	127
	5.5.3.1	Status enquiry procedure.....	127
	5.5.3.2	Reception of a STATUS message by a CC entity	128
	5.5.3.2.1	STATUS message with incompatible state.....	128
	5.5.3.2.2	STATUS message with compatible state.....	128
	5.5.4	Call re-establishment, mobile station side	128
	5.5.4.1	Indication from the mobility management sublayer	128
	5.5.4.2	Reaction of call control	128
	5.5.4.3	Completion of re-establishment	129
	5.5.4.4	Unsuccessful outcome	129
	5.5.5	Call re-establishment, network side	129
	5.5.5.1	State alignment.....	129
	5.5.6	Progress.....	129
	5.5.7	DTMF protocol control procedure	129
	5.5.7.1	Start DTMF request by the mobile station.....	130
	5.5.7.2	Start DTMF response by the network.....	130
	5.5.7.3	Stop DTMF request by the mobile station	130

iTeh STANDARD PREVIEW

(standards.iteh.ai)

SIST ETS 300 940 E2:2005

<https://standards.iteh.ai/catalog/standards/jt/0a61beb0-02b2-4821-9e20-fab4b8f3b2d6/sist-ets-300-940-e2-2005>

5.5.7.4	Stop DTMF response by the network	130
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station	130
6	Support of packet services	131
7	Examples of structured procedures	132
7.1	General	132
7.1.1	Paging request	132
7.1.2	Immediate assignment	132
7.1.3	Service request and contention resolution	133
7.1.4	Authentication.....	133
7.1.5	Ciphering mode setting.....	134
7.1.6	Transaction phase	134
7.1.6.1	Channel mode modify	134
7.1.7	Channel release.....	135
7.2	Abnormal cases.....	135
7.3	Selected examples	135
7.3.1	Location updating.....	136
7.3.2	Mobile originating call establishment.....	137
7.3.3	Mobile terminating call establishment.....	141
7.3.4	Call clearing	144
7.3.5	DTMF protocol control	146
7.3.6	Handover	147
7.3.7	In-call modification	149
7.3.8	Call re-establishment.....	149
8	Handling of unknown, unforeseen, and erroneous protocol data.....	150
8.1	General	150
8.2	Message too short.....	150
8.3	Unknown or unforeseen transaction identifier	150
8.4	Unknown or unforeseen message type	151
8.5	Non-semantical mandatory information element errors	151
8.5.1	Radio resource management	152
8.5.2	Mobility management	152
8.5.3	Call control.....	152
8.6	Unknown and unforeseen IEs in the non-imperative message part	152
8.6.1	IEIs unknown in the message.....	152
8.6.2	Out of sequence IEs	152
8.6.3	Repeated IEs	153
8.7	Non-imperative message part errors	153
8.7.1	Syntactically incorrect optional IEs	153
8.7.2	Conditional IE errors	153
8.8	Messages with semantically incorrect contents	153
9	Message functional definitions and contents	154
9.1	Messages for Radio Resources management.....	155
9.1.1	Additional assignment.....	157
9.1.1.1	Mobile Allocation.....	157
9.1.1.2	Starting Time	157
9.1.2	Assignment command	158
9.1.2.1	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8)	159
9.1.2.2	Description of the Second Channel	159
9.1.2.3	Mode of the Second Channel	159
9.1.2.4	Mobile Allocation and Frequency List, after the starting time	159
9.1.2.5	Starting Time	160
9.1.2.6	Reference cell frequency list	160
9.1.2.7	Cell Channel Description	160

9.1.2.8	Cipher Mode Setting	160
9.1.2.9	VGCS target mode Indication	161
9.1.2.10	Description of the multislot allocation	161
9.1.3	Assignment complete	161
9.1.4	Assignment failure	162
9.1.5	Channel mode modify.....	162
9.1.5.1	Channel Description	162
9.1.5.2	VGCS target mode Indication	162
9.1.6	Channel mode modify acknowledge	163
9.1.7	Channel release.....	163
9.1.7.1	Channel description and mobile allocation	163
9.1.7.2	Group Cipher Key Number.....	164
9.1.8	Channel request	164
9.1.9	Ciphering mode command	166
9.1.10	Ciphering mode complete	167
9.1.10.1	Mobile Equipment Identity.....	167
9.1.11	Classmark change	167
9.1.11.1	Additional Mobile Station Classmark Information.....	167
9.1.11.2	Mobile Station Classmark	167
9.1.12	Classmark enquiry.....	168
9.1.12a	[Spare]	169
9.1.12b	Configuration change command	169
9.1.12b.1	Description of the multislot allocation	169
9.1.12b.2	Mode of Channel Set "X" (1=<X=<8).....	169
9.1.12c	Configuration change acknowledge	170
9.1.12d	Configuration change reject	170
9.1.13	Frequency redefinition	171
9.1.13.1	Cell Channel Description.....	171
9.1.14	Handover access	171
9.1.15	Handover command	172
9.1.15.1	Synchronization Indication.....	173
9.1.15.2	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8).....	173
9.1.15.3	Description of the Second Channel	173
9.1.15.4	Mode of the Second Channel	174
9.1.15.5	Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time	174
9.1.15.6	Starting Time	174
9.1.15.7	Reference cell frequency list	175
9.1.15.8	Real Time Difference.....	175
9.1.15.9	Timing Advance	175
9.1.15.10	Cipher Mode Setting	175
9.1.15.11	VGCS target mode indication.....	175
9.1.15.12	Description of the multislot allocation	176
9.1.16	Handover complete	177
9.1.16.1	Mobile Observed Time Difference	177
9.1.17	Handover failure	177
9.1.18	Immediate assignment	178
9.1.18.1	Mobile Allocation.....	178
9.1.18.2	Starting Time	178
9.1.18.3	IA Rest Octets (Frequency parameters, before time)	178
9.1.19	Immediate assignment extended	179
9.1.19.1	Unnecessary IEs.....	179
9.1.19.2	Mobile Allocation.....	180
9.1.19.3	Starting Time	180
9.1.19.4	Maximum message length.....	180
9.1.19.5	IAX Rest Octets	180
9.1.20	Immediate assignment reject	181
9.1.20.1	Use of the indexes	181
9.1.20.2	Filling of the message.....	181

	9.1.20.3	IAR Rest Octets	181
9.1.21		Measurement report	182
9.1.21a		Notification/FACCH	183
	9.1.21a.1	VBS/VGCS Channel description	183
	9.1.21a.2	PCH information	184
	9.1.21a.3	Paging Information	184
	9.1.21a.4	Composition of the optional information elements.....	184
9.1.21b		Notification/NCH.....	184
	9.1.21b.1	Group Channel Description	185
	9.1.21b.2	NT/N Rest Octets.....	185
9.1.21c		Notification/SACCH	185
	9.1.21c.1	PCH information.....	186
	9.1.21c.2	Paging Information	186
	9.1.21c.3	Composition of the optional information elements.....	186
9.1.21d		Notification response.....	186
9.1.22		Paging request type 1	187
	9.1.22.1	Unnecessary IE.....	187
	9.1.22.2	Channels needed for Mobiles 1 and 2	187
	9.1.22.3	Mobile Identities.....	187
	9.1.22.4	P1 Rest Octets.....	187
9.1.23		Paging request type 2	188
	9.1.23.1	Channels needed for Mobiles 1 and 2	188
	9.1.23.2	Mobile Identity 3	188
	9.1.23.3	P2 Rest Octets.....	188
9.1.24		Paging request type 3	189
	9.1.24.1	Channels needed for Mobiles 1 and 2	189
	9.1.24.2	P3 Rest Octets.....	189
9.1.25		Paging response.....	190
	9.1.25.1	Mobile Station Classmark.....	190
9.1.26		Partial release	191
	9.1.26.1	Channel Description.....	191
9.1.27		Partial release complete.....	191
9.1.28		Physical information	192
9.1.29		RR Status	192
9.1.30		Synchronization channel information.....	193
9.1.31		System information Type 1	194
9.1.32		System information type 2	194
9.1.33		System information type 2bis	195
9.1.34		System information type 2ter	196
9.1.35		System information type 3	197
9.1.36		System information type 4	198
	9.1.36.1	CBCH Channel description	198
	9.1.36.2	CBCH Mobile Allocation.....	198
	9.1.36.3	SI 4 Rest Octets.....	198
9.1.37		System information type 5	199
9.1.38		System information type 5bis	200
9.1.39		System information type 5ter	200
9.1.40		System information type 6	201
	9.1.40.1	Cell Identity	201
	9.1.40.2	Location Area Identification.....	201
	9.1.40.3	Cell Options.....	201
	9.1.40.4	NCC permitted	201
9.1.41		System information type 7	202
9.1.42		System information type 8	202
9.1.43		System information Type 9	203
9.1.44		Talker indication.....	203
9.1.45		Uplink access	204
9.1.46		Uplink busy.....	205
9.1.47		Uplink free.....	206
	9.1.47.1	UIC	206

9.1.47.2	Uplink access request indication	206
9.1.47.3	Group or broadcast call reference	206
9.1.47.4	PCH information	206
9.1.47.5	Paging Information	206
9.1.47.6	Composition of the optional information elements	207
9.1.48	Uplink release	207
9.1.49	VGCS uplink grant	208
9.2	Messages for mobility management	209
9.2.1	Authentication reject	210
9.2.2	Authentication request	210
9.2.3	Authentication response	211
9.2.4	CM Re-establishment request	211
9.2.4.1	Location area identification	211
9.2.4.2	Mobile Station Classmark	211
9.2.5	CM service accept	212
9.2.6	CM service reject	212
9.2.7	CM service abort	213
9.2.8	Abort	213
9.2.9	CM service request	214
9.2.9.1	Mobile Station Classmark	214
9.2.9.2	Priority	214
9.2.10	Identity request	215
9.2.11	Identity response	215
9.2.12	IMSI detach indication	216
9.2.12.1	Mobile Station Classmark	216
9.2.13	Location updating accept	217
9.2.13.1	Follow on proceed	217
9.2.14	Location updating reject	217
9.2.15	Location updating request	218
9.2.15.1	Location area identification	218
9.2.15.2	Mobile Station Classmark	218
9.2.15a	MM information	219
9.2.15a.1	SIST ETS 300 940 E2:2005 https://standards.itehsolution.com/161.html/02b3-4821-9c2c-0ab5b2d6/sites/300-940-e2-2005	219
9.2.15a.2	Short name for network	219
9.2.15a.3	Network time zone	219
9.2.15a.4	Network time zone and time	219
9.2.16	MM Status	220
9.2.17	TMSI reallocation command	220
9.2.18	TMSI reallocation complete	220
9.2.19	MM Null	221
9.3	Messages for circuit-switched call control	222
9.3.1	Alerting	223
9.3.1.1	Alerting (network to mobile station direction)	223
9.3.1.1.1	Facility	223
9.3.1.1.2	Progress indicator	223
9.3.1.1.3	User-user	223
9.3.1.2	Alerting (mobile station to network direction)	224
9.3.1.2.1	Facility	224
9.3.1.2.2	User-user	224
9.3.1.2.3	SS version	224
9.3.2	Call confirmed	225
9.3.2.1	Repeat indicator	226
9.3.2.2	Bearer capability 1 and bearer capability 2	226
9.3.2.3	Cause	226
9.3.2.4	CC Capabilities	226
9.3.3	Call proceeding	227
9.3.3.1	Repeat indicator	227
9.3.3.2	Bearer capability 1 and bearer capability 2	227
9.3.3.3	Facility	227
9.3.3.4	Progress Indicator	227