



LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 36.331 version 15.6.0 Release 15)



ReferenceRTS/TSGR-0236331vf60

Keywords

LTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2019.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	22
1 Scope	23
2 References	23
3 Definitions, symbols and abbreviations	27
3.1 Definitions	27
3.2 Abbreviations	29
4 General	33
4.1 Introduction	33
4.2 Architecture	34
4.2.1 UE states and state transitions including inter RAT	34
4.2.2 Signalling radio bearers	38
4.3 Services	39
4.3.1 Services provided to upper layers	39
4.3.2 Services expected from lower layers	40
4.4 Functions	40
4.5 Data available for transmission for NB-IoT	41
5 Procedures	41
5.1 General	41
5.1.1 Introduction.....	41
5.1.2 General requirements.....	42
5.2 System information	43
5.2.1 Introduction.....	43
5.2.1.1 General	43
5.2.1.2 Scheduling.....	44
5.2.1.2a Scheduling for NB-IoT	45
5.2.1.3 System information validity and notification of changes	46
5.2.1.4 Indication of ETWS notification	47
5.2.1.5 Indication of CMAS notification.....	48
5.2.1.6 Notification of EAB parameters change	48
5.2.1.7 Access Barring parameters change in NB-IoT	48
5.2.2 System information acquisition	49
5.2.2.1 General	49
5.2.2.2 Initiation.....	49
5.2.2.3 System information required by the UE.....	49
5.2.2.4 System information acquisition by the UE.....	50
5.2.2.5 Essential system information missing	54
5.2.2.6 Actions upon reception of the <i>MasterInformationBlock</i> message.....	55
5.2.2.7 Actions upon reception of the <i>SystemInformationBlockType1</i> message	55
5.2.2.8 Actions upon reception of <i>SystemInformation</i> messages	57
5.2.2.9 Actions upon reception of <i>SystemInformationBlockType2</i>	57
5.2.2.10 Actions upon reception of <i>SystemInformationBlockType3</i>	58
5.2.2.11 Actions upon reception of <i>SystemInformationBlockType4</i>	59
5.2.2.12 Actions upon reception of <i>SystemInformationBlockType5</i>	59
5.2.2.13 Actions upon reception of <i>SystemInformationBlockType6</i>	60
5.2.2.14 Actions upon reception of <i>SystemInformationBlockType7</i>	60
5.2.2.15 Actions upon reception of <i>SystemInformationBlockType8</i>	61
5.2.2.16 Actions upon reception of <i>SystemInformationBlockType9</i>	61
5.2.2.17 Actions upon reception of <i>SystemInformationBlockType10</i>	62
5.2.2.18 Actions upon reception of <i>SystemInformationBlockType11</i>	62
5.2.2.19 Actions upon reception of <i>SystemInformationBlockType12</i>	62

5.2.2.20	Actions upon reception of <i>SystemInformationBlockType13</i>	63
5.2.2.21	Actions upon reception of <i>SystemInformationBlockType14</i>	63
5.2.2.22	Actions upon reception of <i>SystemInformationBlockType15</i>	64
5.2.2.23	Actions upon reception of <i>SystemInformationBlockType16</i>	64
5.2.2.24	Actions upon reception of <i>SystemInformationBlockType17</i>	64
5.2.2.25	Actions upon reception of <i>SystemInformationBlockType18</i>	64
5.2.2.26	Actions upon reception of <i>SystemInformationBlockType19</i>	64
5.2.2.27	Actions upon reception of <i>SystemInformationBlockType20</i>	65
5.2.2.28	Actions upon reception of <i>SystemInformationBlockType21</i>	65
5.2.2.29	Actions upon reception of <i>SystemInformationBlockType22-NB</i>	65
5.2.2.30	Actions upon reception of <i>SystemInformationBlockType23-NB</i>	65
5.2.2.31	Actions upon reception of <i>SystemInformationBlockType24</i>	65
5.2.2.32	Actions upon reception of <i>SystemInformationBlockType25</i>	65
5.2.2.33	Actions upon reception of <i>SystemInformationBlockType26</i>	65
5.2.2.34	Actions upon reception of <i>SystemInformationBlockPos</i>	66
5.2.3	Acquisition of an SI message	66
5.2.3a	Acquisition of an SI message by BL UE or UE in CE or a NB-IoT UE	66
5.2.3b	Acquisition of an SI message from MBMS-dedicated cell	67
5.3	Connection control	68
5.3.1	Introduction	68
5.3.1.1	RRC connection control	68
5.3.1.2	Security	70
5.3.1.2a	RN security	71
5.3.1.3	Connected mode mobility	72
5.3.1.4	Connection control in NB-IoT	73
5.3.2	Paging	74
5.3.2.1	General	74
5.3.2.2	Initiation	75
5.3.2.3	Reception of the <i>Paging</i> message by the UE	75
5.3.3	RRC connection establishment	76
5.3.3.1	General	76
5.3.3.1a	Conditions for establishing RRC Connection for sidelink communication/ discovery/ V2X sidelink communication	79
5.3.3.1b	Conditions for initiating EDT	80
5.3.3.2	Initiation	81
5.3.3.3	Actions related to transmission of <i>RRCConnectionRequest</i> message	87
5.3.3.3a	Actions related to transmission of <i>RRCConnectionResumeRequest</i> message	88
5.3.3.3b	Actions related to transmission of <i>RRCEarlyDataRequest</i> message	90
5.3.3.3c	UE actions upon receiving EDT fallback indication from lower layers	91
5.3.3.4	Reception of the <i>RRCConnectionSetup</i> by the UE	91
5.3.3.4a	Reception of the <i>RRCConnectionResume</i> by the UE	94
5.3.3.4b	Reception of the <i>RRCEarlyDataComplete</i> by the UE	98
5.3.3.5	Cell re-selection or cell selection while T300, T302, T303, T305, T306, T308 or T309 is running	99
5.3.3.6	T300 expiry	100
5.3.3.7	T302, T303, T305, T306, or T308 expiry or stop	102
5.3.3.8	Reception of the <i>RRCConnectionReject</i> by the UE	102
5.3.3.9	Abortion of RRC connection establishment	104
5.3.3.9a	Abortion of UP-EDT	104
5.3.3.10	Handling of SSAC related parameters	104
5.3.3.11	Access barring check	105
5.3.3.12	EAB check	106
5.3.3.13	Access barring check for ACDC	107
5.3.3.14	Access Barring check for NB-IoT	107
5.3.3.15	Failure to deliver NAS information in <i>RRCConnectionSetupComplete</i> message	109
5.3.3.16	Integrity check failure from lower layers while T300 is running for UP-EDT or <i>RRC_INACTIVE</i>	109
5.3.3.17	Inability to comply with <i>RRCConnectionResume</i>	110
5.3.4	Initial security activation	110
5.3.4.1	General	110
5.3.4.2	Initiation	110
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	110
5.3.5	RRC connection reconfiguration	112

5.3.5.1	General	112
5.3.5.2	Initiation	112
5.3.5.3	Reception of an <i>RRCCConnectionReconfiguration</i> not including the <i>mobilityControlInfo</i> by the UE	112
5.3.5.4	Reception of an <i>RRCCConnectionReconfiguration</i> including the <i>mobilityControlInfo</i> by the UE (handover)	115
5.3.5.5	Reconfiguration failure	121
5.3.5.6	T304 expiry (handover failure)	121
5.3.5.7	Void	123
5.3.5.7a	T307 expiry (SCG change failure)	123
5.3.5.8	Radio Configuration involving full configuration option	123
5.3.6	Counter check	125
5.3.6.1	General	125
5.3.6.2	Initiation	125
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	125
5.3.7	RRC connection re-establishment	126
5.3.7.1	General	126
5.3.7.2	Initiation	127
5.3.7.3	Actions following cell selection while T311 is running	128
5.3.7.4	Actions related to transmission of <i>RRCCConnectionReestablishmentRequest</i> message	129
5.3.7.5	Reception of the <i>RRCCConnectionReestablishment</i> by the UE	130
5.3.7.6	T311 expiry	133
5.3.7.7	T301 expiry or selected cell no longer suitable	133
5.3.7.8	Reception of <i>RRCCConnectionReestablishmentReject</i> by the UE	133
5.3.8	RRC connection release	134
5.3.8.1	General	134
5.3.8.2	Initiation	134
5.3.8.3	Reception of the <i>RRCCConnectionRelease</i> by the UE	134
5.3.8.4	T320 expiry	136
5.3.8.5	T322 expiry	137
5.3.8.6	UE actions upon receiving the expiry of <i>DataInactivityTimer</i>	137
5.3.8.7	UE actions upon entering RRC_INACTIVE	137
5.3.9	RRC connection release requested by upper layers	138
5.3.9.1	General	138
5.3.9.2	Initiation	138
5.3.10	Radio resource configuration	138
5.3.10.0	General	138
5.3.10.1	SRB addition/ modification	139
5.3.10.1a	SCG RLC bearer addition or reconfiguration for SRBs	140
5.3.10.2	DRB release	141
5.3.10.3	DRB addition/ modification	141
5.3.10.3a1	DC specific DRB addition or reconfiguration	143
5.3.10.3a2	LWA specific DRB addition or reconfiguration	146
5.3.10.3a3	LWIP specific DRB addition or reconfiguration	147
5.3.10.3a4	SCG RLC bearer addition or reconfiguration for DRBs in NE-DC	147
5.3.10.3a	SCell release	148
5.3.10.3b	SCell addition/ modification	148
5.3.10.3c	PSCell addition or modification	149
5.3.10.3d	SCell group release	149
5.3.10.3e	SCell group addition/ modification	149
5.3.10.4	MAC main reconfiguration	150
5.3.10.5	Semi-persistent scheduling reconfiguration	150
5.3.10.6	Physical channel reconfiguration	150
5.3.10.7	Radio Link Failure Timers and Constants reconfiguration	151
5.3.10.8	Time domain measurement resource restriction for serving cell	152
5.3.10.9	Other configuration	152
5.3.10.10	SCG reconfiguration	155
5.3.10.11	SCG dedicated resource configuration	157
5.3.10.12	Reconfiguration SCG or split DRB by <i>drb-ToAddModList</i>	157
5.3.10.13	Neighbour cell information reconfiguration	157
5.3.10.14	Void	158
5.3.10.15	Sidelink dedicated configuration	158

5.3.10.15a	V2X sidelink Communication dedicated configuration	159
5.3.10.16	T370 expiry	160
5.3.10.17	SRB release	160
5.3.10.18	Scheduling Request Configuration for NB-IoT	160
5.3.10.19	NE-DC release	160
5.3.11	Radio link failure related actions	161
5.3.11.1	Detection of physical layer problems in RRC_CONNECTED	161
5.3.11.1a	Early detection of physical layer problems in RRC_CONNECTED	161
5.3.11.1b	Detection of physical layer improvements in RRC_CONNECTED	161
5.3.11.2	Recovery of physical layer problems	161
5.3.11.2a	Recovery of early detection of physical layer problems	162
5.3.11.2b	Cancellation of physical layer improvements in RRC_CONNECTED	162
5.3.11.3	Detection of radio link failure	162
5.3.11.3a	Detection of early-out-of-sync event	164
5.3.11.3b	Detection of early-in-sync event	164
5.3.12	UE actions upon leaving RRC_CONNECTED or RRC_INACTIVE	164
5.3.13	UE actions upon PUCCH/ SPUCCH/ SRS release request	166
5.3.13a	UE actions upon SR release request for NB-IoT	166
5.3.14	Proximity indication	167
5.3.14.1	General	167
5.3.14.2	Initiation	167
5.3.14.3	Actions related to transmission of <i>ProximityIndication</i> message	167
5.3.15	Void	168
5.3.16	Unified Access Control	168
5.3.16.1	General	168
5.3.16.2	Initiation	168
5.3.16.3	Void	170
5.3.16.4	T302, T309 expiry or stop (Barring alleviation)	170
5.3.16.5	Access barring check	170
5.3.17	RAN notification area update	171
5.3.17.1	General	171
5.3.17.2	Initiation	171
5.3.17.3	Inter RAT cell reselection or CN type change	171
5.4	Inter-RAT mobility	171
5.4.1	Introduction	171
5.4.2	Handover to E-UTRA	172
5.4.2.1	General	172
5.4.2.2	Initiation	172
5.4.2.3	Reception of the <i>RRConnectionReconfiguration</i> by the UE	172
5.4.2.4	Reconfiguration failure	175
5.4.2.5	T304 expiry (handover to E-UTRA failure)	175
5.4.3	Mobility from E-UTRA	176
5.4.3.1	General	176
5.4.3.2	Initiation	176
5.4.3.3	Reception of the <i>MobilityFromEUTRACommand</i> by the UE	177
5.4.3.4	Successful completion of the mobility from E-UTRA	178
5.4.3.5	Mobility from E-UTRA failure	179
5.4.4	Handover from E-UTRA preparation request (CDMA2000)	179
5.4.4.1	General	179
5.4.4.2	Initiation	180
5.4.4.3	Reception of the <i>HandoverFromEUTRAPreparationRequest</i> by the UE	180
5.4.5	UL handover preparation transfer (CDMA2000)	180
5.4.5.1	General	180
5.4.5.2	Initiation	180
5.4.5.3	Actions related to transmission of the <i>ULHandoverPreparationTransfer</i> message	181
5.4.5.4	Failure to deliver the <i>ULHandoverPreparationTransfer</i> message	181
5.4.6	Inter-RAT cell change order to E-UTRAN	181
5.4.6.1	General	181
5.4.6.2	Initiation	181
5.4.6.3	UE fails to complete an inter-RAT cell change order	181
5.5	Measurements	182
5.5.1	Introduction	182

5.5.2	Measurement configuration	184
5.5.2.1	General	184
5.5.2.2	Measurement identity removal	185
5.5.2.2a	Measurement identity autonomous removal	185
5.5.2.3	Measurement identity addition/ modification	185
5.5.2.4	Measurement object removal	186
5.5.2.5	Measurement object addition/ modification	187
5.5.2.6	Reporting configuration removal	189
5.5.2.7	Reporting configuration addition/ modification	190
5.5.2.8	Quantity configuration	190
5.5.2.9	Measurement gap configuration	190
5.5.2.9a	Measurement gap configuration for RSTD measurements with dense PRS configuration	192
5.5.2.10	Discovery signals measurement timing configuration	192
5.5.2.11	RSSI measurement timing configuration	192
5.5.2.12	Measurement gap sharing configuration	193
5.5.2.13	NR measurement timing configuration	193
5.5.3	Performing measurements	193
5.5.3.1	General	193
5.5.3.2	Layer 3 filtering	197
5.5.3.3	Derivation of NR cell quality	198
5.5.3.4	Derivation of NR beam quality	198
5.5.4	Measurement report triggering	199
5.5.4.1	General	199
5.5.4.2	Event A1 (Serving becomes better than threshold)	205
5.5.4.3	Event A2 (Serving becomes worse than threshold)	205
5.5.4.4	Event A3 (Neighbour becomes offset better than PCell/ PSCell)	206
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	207
5.5.4.6	Event A5 (PCell/ PSCell becomes worse than threshold1 and neighbour becomes better than threshold2)	207
5.5.4.6a	Event A6 (Neighbour becomes offset better than SCell)	208
5.5.4.7	Event B1 (Inter RAT neighbour becomes better than threshold)	209
5.5.4.8	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	209
5.5.4.9	Event C1 (CSI-RS resource becomes better than threshold)	210
5.5.4.10	Event C2 (CSI-RS resource becomes offset better than reference CSI-RS resource)	211
5.5.4.11	Event W1 (WLAN becomes better than a threshold)	211
5.5.4.12	Event W2 (All WLAN inside WLAN mobility set becomes worse than threshold1 and a WLAN outside WLAN mobility set becomes better than threshold2)	212
5.5.4.13	Event W3 (All WLAN inside WLAN mobility set becomes worse than a threshold)	213
5.5.4.14	Event V1 (The channel busy ratio is above a threshold)	213
5.5.4.15	Event V2 (The channel busy ratio is below a threshold)	214
5.5.4.16	Event H1 (The Aerial UE height is above a threshold)	214
5.5.4.17	Event H2 (The Aerial UE height is below a threshold)	214
5.5.5	Measurement reporting	215
5.5.5.1	General	215
5.5.5.2	Determination of available NR measurement results	222
5.5.5.3	Selection of NR sorting quality	222
5.5.6	Measurement related actions	223
5.5.6.1	Actions upon handover and re-establishment	223
5.5.6.2	Speed dependant scaling of measurement related parameters	224
5.5.7	Inter-frequency RSTD measurement indication	224
5.5.7.1	General	224
5.5.7.2	Initiation	224
5.5.7.3	Actions related to transmission of <i>InterFreqRSTDMeasurementIndication</i> message	225
5.6	Other	225
5.6.0	General	225
5.6.1	DL information transfer	226
5.6.1.1	General	226
5.6.1.2	Initiation	226
5.6.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	226
5.6.2	UL information transfer	227
5.6.2.1	General	227

5.6.2.2	Initiation.....	227
5.6.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	227
5.6.2.4	Failure to deliver <i>ULInformationTransfer</i> message.....	227
5.6.2a	UL information transfer for MR-DC	228
5.6.2a.1	General.....	228
5.6.2a.2	Initiation.....	228
5.6.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	228
5.6.2a.4	Void.....	229
5.6.3	UE capability transfer	229
5.6.3.1	General.....	229
5.6.3.2	Initiation.....	229
5.6.3.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	229
5.6.4	CSFB to 1x Parameter transfer	233
5.6.4.1	General.....	233
5.6.4.2	Initiation.....	234
5.6.4.3	Actions related to transmission of <i>CSFBParametersRequestCDMA2000</i> message.....	234
5.6.4.4	Reception of the <i>CSFBParametersResponseCDMA2000</i> message.....	234
5.6.5	UE Information.....	234
5.6.5.1	General.....	234
5.6.5.2	Initiation.....	234
5.6.5.3	Reception of the <i>UEInformationRequest</i> message	234
5.6.6	Logged Measurement Configuration	236
5.6.6.1	General.....	236
5.6.6.2	Initiation.....	237
5.6.6.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE.....	237
5.6.6.4	T330 expiry	237
5.6.7	Release of Logged Measurement Configuration.....	237
5.6.7.1	General.....	237
5.6.7.2	Initiation.....	237
5.6.8	Measurements logging.....	238
5.6.8.1	General.....	238
5.6.8.2	Initiation.....	238
5.6.9	In-device coexistence indication.....	241
5.6.9.1	General.....	241
5.6.9.2	Initiation.....	241
5.6.9.3	Actions related to transmission of <i>InDeviceCoexIndication</i> message.....	242
5.6.10	UE Assistance Information.....	243
5.6.10.1	General.....	243
5.6.10.2	Initiation.....	244
5.6.10.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	245
5.6.11	Mobility history information.....	246
5.6.11.1	General.....	246
5.6.11.2	Initiation.....	246
5.6.12	RAN-assisted WLAN interworking.....	247
5.6.12.1	General.....	247
5.6.12.2	Dedicated WLAN offload configuration.....	247
5.6.12.3	WLAN offload RAN evaluation	247
5.6.12.4	T350 expiry or stop	248
5.6.12.5	Cell selection/ re-selection while T350 is running	248
5.6.13	SCG failure information	248
5.6.13.1	General.....	248
5.6.13.2	Initiation.....	248
5.6.13.3	Actions related to transmission of <i>SCGFailureInformation</i> message	249
5.6.13.4	Failure type determination in NE-DC	249
5.6.13.5	Setting the contents of <i>MeasResultSCG-FailureMRDC</i>	250
5.6.13a	NR SCG failure information.....	250
5.6.13a.1	General.....	250
5.6.13a.2	Initiation.....	251
5.6.13a.3	Actions related to transmission of <i>SCGFailureInformationNR</i> message	251
5.6.14	LTE-WLAN Aggregation.....	251
5.6.14.1	Introduction.....	251
5.6.14.2	Reception of LWA configuration.....	251

5.6.14.3	Release of LWA configuration	252
5.6.15	WLAN connection management.....	252
5.6.15.1	Introduction.....	252
5.6.15.2	WLAN connection status reporting.....	253
5.6.15.2.1	General	253
5.6.15.2.2	Initiation	253
5.6.15.2.3	Actions related to transmission of <i>WLANConnectionStatusReport</i> message	253
5.6.15.3	T351 Expiry (WLAN connection attempt timeout)	253
5.6.15.4	WLAN status monitoring.....	253
5.6.16	RAN controlled LTE-WLAN interworking.....	254
5.6.16.1	General	254
5.6.16.2	WLAN traffic steering command.....	255
5.6.17	LTE-WLAN aggregation with IPsec tunnel	255
5.6.17.1	General.....	255
5.6.17.2	LWIP reconfiguration	255
5.6.17.3	LWIP release.....	256
5.6.18	Void.....	256
5.6.19	Application layer measurement reporting.....	256
5.6.19.1	General	256
5.6.19.2	Initiation.....	257
5.6.20	IDLE Mode Measurements.....	257
5.6.20.1	General	257
5.6.20.2	Initiation.....	257
5.6.20.3	T331 expiry or stop	258
5.6.21	Failure information	258
5.6.21.1	General	258
5.6.21.2	Initiation.....	258
5.6.21.3	Actions related to transmission of <i>FailureInformation</i> message.....	258
5.7	Generic error handling.....	259
5.7.1	General.....	259
5.7.2	ASN.1 violation or encoding error.....	259
5.7.3	Field set to a not comprehended value.....	259
5.7.4	Mandatory field missing.....	259
5.7.5	Not comprehended field.....	261
5.8	MBMS.....	261
5.8.1	Introduction.....	261
5.8.1.1	General	261
5.8.1.2	Scheduling.....	261
5.8.1.3	MCCH information validity and notification of changes.....	261
5.8.2	MCCH information acquisition	263
5.8.2.1	General	263
5.8.2.2	Initiation.....	263
5.8.2.3	MCCH information acquisition by the UE.....	263
5.8.2.4	Actions upon reception of the <i>MBSFNAreaConfiguration</i> message.....	263
5.8.2.5	Actions upon reception of the <i>MBMScountingRequest</i> message.....	264
5.8.3	MBMS PTM radio bearer configuration.....	264
5.8.3.1	General	264
5.8.3.2	Initiation.....	264
5.8.3.3	MRB establishment	264
5.8.3.4	MRB release.....	264
5.8.4	MBMS Counting Procedure	264
5.8.4.1	General	264
5.8.4.2	Initiation.....	265
5.8.4.3	Reception of the <i>MBMScountingRequest</i> message by the UE	265
5.8.5	MBMS interest indication.....	266
5.8.5.1	General	266
5.8.5.2	Initiation.....	266
5.8.5.3	Determine MBMS frequencies of interest.....	267
5.8.5.4	Actions related to transmission of <i>MBMSInterestIndication</i> message	268
5.8a	SC-PTM	269
5.8a.1	Introduction.....	269
5.8a.1.1	General	269

5.8a.1.2	SC-MCCH scheduling	269
5.8a.1.3	SC-MCCH information validity and notification of changes.....	269
5.8a.1.4	Procedures.....	270
5.8a.2	SC-MCCH information acquisition	270
5.8a.2.1	General.....	270
5.8a.2.2	Initiation.....	270
5.8a.2.3	SC-MCCH information acquisition by the UE	270
5.8a.2.4	Actions upon reception of the <i>SCPTMConfiguration</i> message.....	271
5.8a.3	SC-PTM radio bearer configuration	271
5.8a.3.1	General.....	271
5.8a.3.2	Initiation.....	271
5.8a.3.3	SC-MRB establishment.....	271
5.8a.3.4	SC-MRB release	272
5.9	RN procedures.....	272
5.9.1	RN reconfiguration	272
5.9.1.1	General.....	272
5.9.1.2	Initiation.....	272
5.9.1.3	Reception of the <i>RNReconfiguration</i> by the RN	272
5.10	Sidelink	273
5.10.1	Introduction.....	273
5.10.1a	Conditions for sidelink communication operation.....	273
5.10.1d	Conditions for V2X sidelink communication operation	274
5.10.2	Sidelink UE information.....	274
5.10.2.1	General.....	274
5.10.2.2	Initiation.....	275
5.10.2.3	Actions related to transmission of <i>SidelinkUEInformation</i> message	280
5.10.3	Sidelink communication monitoring.....	282
5.10.4	Sidelink communication transmission	284
5.10.5	Sidelink discovery monitoring.....	285
5.10.6	Sidelink discovery announcement	286
5.10.6a	Sidelink discovery announcement pool selection	289
5.10.6b	Sidelink discovery announcement reference carrier selection	289
5.10.7	Sidelink synchronisation information transmission	290
5.10.7.1	General.....	290
5.10.7.2	Initiation.....	291
5.10.7.3	Transmission of SLSS.....	293
5.10.7.4	Transmission of <i>MasterInformationBlock-SL</i> or <i>MasterInformationBlock-SL-V2X</i> message	295
5.10.7.5	Void.....	296
5.10.8	Sidelink synchronisation reference	296
5.10.8.1	General.....	296
5.10.8.2	Selection and reselection of synchronisation reference.....	296
5.10.8a	Selection and reselection of synchronisation carrier frequency	299
5.10.9	Sidelink common control information	302
5.10.9.1	General.....	302
5.10.9.2	Actions related to reception of <i>MasterInformationBlock-SL/ MasterInformationBlock-SL-V2X</i> message	302
5.10.10	Sidelink relay UE operation.....	302
5.10.10.1	General.....	302
5.10.10.2	AS-conditions for relay related sidelink communication transmission by sidelink relay UE	303
5.10.10.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink relay UE	303
5.10.10.4	Sidelink relay UE threshold conditions.....	303
5.10.11	Sidelink remote UE operation.....	303
5.10.11.1	General.....	303
5.10.11.2	AS-conditions for relay related sidelink communication transmission by sidelink remote UE	304
5.10.11.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink remote UE	304
5.10.11.4	Selection and reselection of sidelink relay UE.....	304
5.10.11.5	Sidelink remote UE threshold conditions.....	305
5.10.12	V2X sidelink communication monitoring.....	305
5.10.13	V2X sidelink communication transmission	306
5.10.13.1	Transmission of V2X sidelink communication.....	306
5.10.13.1a	Transmission of P2X related V2X sidelink communication	308
5.10.13.2	V2X sidelink communication transmission pool selection	309

5.10.13.3	V2X sidelink communication transmission reference cell selection	310
5.10.14	DFN derivation from GNSS	311
6	Protocol data units, formats and parameters (tabular & ASN.1)	311
6.1	General	311
6.2	RRC messages	313
6.2.1	General message structure	313
–	EUTRA-RRC-Definitions	313
–	BCCH-BCH-Message	313
–	BCCH-BCH-Message-MBMS	313
–	BCCH-DL-SCH-Message	314
–	BCCH-DL-SCH-Message-BR	314
–	BCCH-DL-SCH-Message-MBMS	314
–	MCCH-Message	315
–	PCCH-Message	315
–	DL-CCCH-Message	315
–	DL-DCCH-Message	316
–	UL-CCCH-Message	316
–	UL-DCCH-Message	317
–	SC-MCCH-Message	317
6.2.2	Message definitions	318
–	CounterCheck	318
–	CounterCheckResponse	319
–	CSFBParametersRequestCDMA2000	320
–	CSFBParametersResponseCDMA2000	320
–	DLInformationTransfer	321
–	FailureInformation	322
–	HandoverFromEUTRAPreparationRequest (CDMA2000)	322
–	InDeviceCoexIndication	324
–	InterFreqRSTDMeasurementIndication	326
–	LoggedMeasurementConfiguration	328
–	MasterInformationBlock	330
–	MasterInformationBlock-MBMS	331
–	MBMSCountingRequest	331
–	MBMSCountingResponse	332
–	MBMSInterestIndication	333
–	MBSFNAreaConfiguration	334
–	MeasReportAppLayer	335
–	MeasurementReport	335
–	MobilityFromEUTRACommand	336
–	Paging	339
–	ProximityIndication	340
–	RNReconfiguration	341
–	RNReconfigurationComplete	342
–	RRCCConnectionReconfiguration	342
–	RRCCConnectionReconfigurationComplete	351
–	RRCCConnectionReestablishment	352
–	RRCCConnectionReestablishmentComplete	353
–	RRCCConnectionReestablishmentReject	354
–	RRCCConnectionReestablishmentRequest	355
–	RRCCConnectionReject	355
–	RRCCConnectionRelease	356
–	RRCCConnectionRequest	362
–	RRCCConnectionResume	363
–	RRCCConnectionResumeComplete	364
–	RRCCConnectionResumeRequest	365
–	RRCCConnectionSetup	366
–	RRCCConnectionSetupComplete	366
–	RRCEarlyDataComplete	369
–	RRCEarlyDataRequest	370
–	SCGFailureInformation	371
–	SCGFailureInformationNR	372

–	SCPTMConfiguration	373
–	SCPTMConfiguration-BR	373
–	SecurityModeCommand	374
–	SecurityModeComplete	374
–	SecurityModeFailure.....	375
–	SidelinkUEInformation	375
–	SystemInformation	379
–	SystemInformationBlockType1	380
–	SystemInformationBlockType1-MBMS	388
–	UEAssistanceInformation	390
–	UECapabilityEnquiry.....	394
–	UECapabilityInformation	395
–	UEInformationRequest.....	396
–	UEInformationResponse	397
–	ULHandoverPreparationTransfer (CDMA2000).....	403
–	ULInformationTransfer	404
–	ULInformationTransferMRDC.....	405
–	WLANConnectionStatusReport	405
6.3	RRC information elements	406
6.3.1	System information blocks	406
–	SystemInformationBlockPos.....	406
–	SystemInformationBlockType2	406
–	SystemInformationBlockType3	412
–	SystemInformationBlockType4	415
–	SystemInformationBlockType5	416
–	SystemInformationBlockType6	421
–	SystemInformationBlockType7	424
–	SystemInformationBlockType8	425
–	SystemInformationBlockType9	429
–	SystemInformationBlockType10	430
–	SystemInformationBlockType11	430
–	SystemInformationBlockType12	431
–	SystemInformationBlockType13	432
–	SystemInformationBlockType14	432
–	SystemInformationBlockType15	433
–	SystemInformationBlockType16	434
–	SystemInformationBlockType17	435
–	SystemInformationBlockType18	436
–	SystemInformationBlockType19	437
–	SystemInformationBlockType20	439
–	SystemInformationBlockType21	442
–	SystemInformationBlockType24	443
–	SystemInformationBlockType25	446
–	SystemInformationBlockType26	447
6.3.2	Radio resource control information elements	448
–	AntennaInfo	448
–	AntennaInfoUL	451
–	AUL-Config	451
–	CQI-ReportAperiodic	452
–	CQI-ReportBoth	456
–	CQI-ReportConfig	457
–	CQI-ReportPeriodic	460
–	CQI-ReportPeriodicProcExtId	464
–	CrossCarrierSchedulingConfig	464
–	CSI-IM-Config	465
–	CSI-IM-ConfigId	466
–	CSI-Process	466
–	CSI-ProcessId	467
–	CSI-RS-Config	468
–	CSI-RS-ConfigBeamformed	469
–	CSI-RS-ConfigEMIMO	470
–	CSI-RS-ConfigNonPrecoded	471