

ETSI TS 136 300 V13.14.0 (2020-04)



LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA)
and Evolved Universal Terrestrial
Radio Access Network (E-UTRAN);
Overall description;
Stage 2
(3GPP TS 36.300 version 13.14.0 Release 13)



ReferenceRTS/TSGR-0236300vde0

KeywordsLTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2020.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	15
1 Scope	16
2 References	16
3 Definitions, symbols and abbreviations	18
3.1 Definitions	18
3.2 Abbreviations	21
4 Overall architecture	25
4.1 Functional Split	26
4.2 Void.....	28
4.2.1 Void	28
4.2.2 Void	28
4.3 Radio Protocol architecture	28
4.3.1 User plane	29
4.3.2 Control plane	29
4.4 Synchronization.....	30
4.5 IP fragmentation.....	30
4.6 Support of HeNBs	30
4.6.1 Architecture	30
4.6.2 Functional Split.....	32
4.6.3 Interfaces.....	34
4.6.3.1 Protocol Stack for S1 User Plane	34
4.6.3.2 Protocol Stacks for S1 Control Plane	35
4.6.3.3 Protocol Stack for S5 interface.....	36
4.6.3.4 Protocol Stack for SGi interface.....	36
4.6.3.5 Protocol Stack for X2 User Plane and X2 Control Plane	36
4.6.4 Void	36
4.6.5 Support of LIPA with HeNB	36
4.6.6 Support of X2 GW	38
4.6.6.1 Enhanced TNL Address Discovery	39
4.6.6.2 Routing of X2AP messages	39
4.6.6.3 (H)eNB unavailability	39
4.6.6.4 (H)eNB registration.....	39
4.7 Support for relaying.....	39
4.7.1 General.....	39
4.7.2 Architecture	40
4.7.3 S1 and X2 user plane aspects.....	40
4.7.4 S1 and X2 control plane aspects	41
4.7.5 Radio protocol aspects	42
4.7.6 Signalling procedures	43
4.7.6.1 RN attach procedure.....	43
4.7.6.2 E-RAB activation/modification.....	44
4.7.6.3 RN startup procedure	44
4.7.6.4 RN detach procedure.....	45
4.7.6.5 Neighbouring Information Transfer	46
4.7.6.6 Mobility to or from RN	46
4.7.7 Relay Node OAM Aspects	46
4.7.7.1 Architecture.....	46
4.7.7.2 OAM Traffic QoS Requirements	47
4.7.7.3 Security Aspects.....	47
4.7.7.4 Void.....	47
4.7.7.5 OAM Requirements for Configuration Parameters.....	47

4.7.7.5.1	Parameters Associated with Relay Bearer Mapping.....	47
4.8	Support of SIPTO at the Local Network	47
4.8.1	General.....	47
4.8.2	SIPTO at the Local Network with collocated L-GW.....	48
4.8.3	Support for SIPTO@LN with Stand-Alone Gateway.....	49
4.9	Support for Dual Connectivity	49
4.9.1	General.....	49
4.9.2	Radio Protocol Architecture	49
4.9.3	Network Interfaces.....	50
4.9.3.1	E-UTRAN Control Plane for Dual Connectivity	50
4.9.3.2	E-UTRAN User Plane for Dual Connectivity.....	50
4.9.3.3	Support of HeNBs for Dual Connectivity.....	51
4.9.3.4	Support of SIPTO@LN and LIPA for Dual Connectivity	51
4.10	NB-IoT	53
5	Physical Layer for E-UTRA.....	53
5.1	Downlink Transmission Scheme.....	56
5.1.1	Basic transmission scheme based on OFDM.....	56
5.1.1a	Basic transmission scheme based on OFDM for NB-IoT.....	56
5.1.2	Physical-layer processing	56
5.1.3	Physical downlink control channels.....	57
5.1.4	Downlink Reference signal and synchronization signals.....	58
5.1.4a	Downlink Reference signal and synchronization signals for NB-IoT	58
5.1.5	Downlink multi-antenna transmission	58
5.1.5a	Downlink multi-antenna transmission for NB-IoT.....	59
5.1.6	MBSFN transmission.....	59
5.1.7	Physical layer procedure.....	59
5.1.7.1	Link adaptation	59
5.1.7.2	Power Control	59
5.1.7.3	Cell search.....	59
5.1.7.3a	Cell search for NB-IoT.....	59
5.1.8	Physical layer measurements definition.....	59
5.1.9	Coordinated Multi-Point transmission.....	60
5.2	Uplink Transmission Scheme.....	60
5.2.1	Basic transmission scheme	60
5.2.1a	Basic transmission scheme for NB-IoT.....	60
5.2.2	Physical-layer processing	61
5.2.3	Physical uplink control channel.....	61
5.2.3a	Uplink control information for NB-IoT.....	62
5.2.4	Uplink Reference signal.....	62
5.2.4a	Uplink Reference signal for NB-IoT	62
5.2.5	Random access preamble.....	62
5.2.5a	Random access preamble for NB-IoT.....	63
5.2.6	Uplink multi-antenna transmission	63
5.2.7	Physical channel procedure.....	63
5.2.7.1	Link adaptation	63
5.2.7.2	Uplink Power control	63
5.2.7.3	Uplink timing control.....	63
5.2.8	Coordinated Multi-Point reception	63
5.3	Transport Channels.....	64
5.3.1	Mapping between transport channels and physical channels.....	65
5.3.1a	Mapping between transport channels and narrowband physical channels.....	66
5.4	E-UTRA physical layer model	67
5.4.1	Void.....	67
5.4.2	Void.....	67
5.5	Carrier Aggregation.....	67
5.5a	Multi-carrier operation for NB-IoT.....	68
5.6	Sidelink	68
5.6.1	Basic transmission scheme	68
5.6.2	Physical-layer processing	68
5.6.3	Physical Sidelink control channel.....	69
5.6.4	Sidelink reference signals	69

5.6.5	Physical channel procedure.....	69
5.6.5.1	Sidelink power control	69
5.6.6	Physical layer measurements definition.....	69
5.7	Licensed-Assisted Access	69
5.7.1	Channel Access Priority Classes.....	69
5.7.2	Multiplexing of data.....	70
6	Layer 2.....	70
6.1	MAC Sublayer.....	72
6.1.1	Services and Functions	72
6.1.2	Logical Channels	73
6.1.2.1	Control Channels.....	73
6.1.2.2	Traffic Channels.....	73
6.1.3	Mapping between logical channels and transport channels	74
6.1.3.1	Mapping in Uplink	74
6.1.3.2	Mapping in Downlink	74
6.1.3.3	Mapping in Sidelink.....	75
6.2	RLC Sublayer.....	76
6.2.1	Services and Functions	76
6.2.2	PDU Structure.....	76
6.3	PDCP Sublayer.....	77
6.3.1	Services and Functions	77
6.3.2	PDU Structure.....	78
6.4	Carrier Aggregation.....	78
6.5	Dual Connectivity.....	79
7	RRC.....	80
7.1	Services and Functions	80
7.2	RRC protocol states & state transitions	81
7.3	Transport of NAS messages	82
7.3a	CIoT signalling reduction optimizations	82
7.3a.1	General.....	82
7.3a.2	Control Plane CIoT EPS optimizations	82
7.3a.3	User Plane CIoT EPS optimizations	83
7.4	System Information	86
7.5	Carrier Aggregation.....	87
7.6	Dual Connectivity.....	88
8	E-UTRAN identities.....	89
8.1	E-UTRAN related UE identities.....	89
8.2	Network entity related Identities	89
8.3	Sidelink communication related identities	90
8.4	MBMS related identities	90
9	ARQ and HARQ	91
9.1	HARQ principles.....	91
9.2	ARQ principles.....	92
9.3	Void.....	92
10	Mobility.....	92
10.1	Intra E-UTRAN.....	93
10.1.1	Mobility Management in ECM-IDLE	93
10.1.1.1	Cell selection.....	93
10.1.1.2	Cell reselection.....	94
10.1.1.3	Void.....	95
10.1.1.4	Void.....	95
10.1.1.5	Void.....	95
10.1.2	Mobility Management in ECM-CONNECTED.....	95
10.1.2.1	Handover.....	95
10.1.2.1.1	C-plane handling	96
10.1.2.1.2	U-plane handling	99
10.1.2.2	Path Switch	100
10.1.2.2.1	Path Switch upon handover	100
10.1.2.2.2	Path Update upon Dual Connectivity specific activities.....	100

10.1.2.2.3	Path Switch upon UE context resume	101
10.1.2.3	Data forwarding	101
10.1.2.3.1	For RLC-AM DRBs	101
10.1.2.3.2	For RLC-UM DRBs	101
10.1.2.3.3	SRB handling	102
10.1.2.3.4	User data forwarding for Dual Connectivity	102
10.1.2.4	Void.....	102
10.1.2.5	Void.....	102
10.1.2.6	Void.....	102
10.1.2.7	Timing Advance.....	102
10.1.2.8	Dual Connectivity operation	103
10.1.2.8.1	SeNB Addition	103
10.1.2.8.2	SeNB Modification.....	104
10.1.2.8.2.1	Intra-MeNB handover involving SCG change.....	107
10.1.2.8.3	SeNB Release	108
10.1.2.8.4	Change of SeNB	109
10.1.2.8.5	MeNB to eNB Change.....	110
10.1.2.8.6	SCG change	111
10.1.2.8.7	eNB to MeNB change	112
10.1.2.8.8	Inter-MeNB handover without SeNB change.....	113
10.1.2.8.9	Addition of a hybrid HeNB as the SeNB.....	115
10.1.3	Measurements	116
10.1.3.1	Intra-frequency neighbour (cell) measurements.....	118
10.1.3.2	Inter-frequency neighbour (cell) measurements.....	118
10.1.4	Paging and C-plane establishment	118
10.1.5	Random Access Procedure	119
10.1.5.1	Contention based random access procedure.....	120
10.1.5.2	Non-contention based random access procedure	122
10.1.5.3	Interaction model between L1 and L2/3 for Random Access Procedure	123
10.1.6	Radio Link Failure	123
10.1.7	Radio Access Network Sharing	124
10.1.8	Handling of Roaming and Area Restrictions for UEs in ECM-CONNECTED.....	125
10.1.8a	Handling of Roaming and Access Restrictions for UEs in ECM-CONNECTED	125
10.2	Inter RAT	125
10.2.1	Cell reselection	125
10.2.2	Handover	126
10.2.2a	Inter-RAT cell change order to GERAN with NACC	126
10.2.2b	Inter-RAT handovers from E-UTRAN	127
10.2.2b.1	Data forwarding	127
10.2.2b.1.1	For RLC-AM bearers	127
10.2.2b.1.2	For RLC-UM bearers	127
10.2.3	Measurements	127
10.2.3.1	Inter-RAT handovers from E-UTRAN	127
10.2.3.2	Inter-RAT handovers to E-UTRAN	128
10.2.3.3	Inter-RAT cell reselection from E-UTRAN.....	128
10.2.3.4	Limiting measurement load at UE	128
10.2.4	Network Aspects.....	128
10.2.5	CS fallback.....	128
10.3	Mobility between E-UTRAN and Non-3GPP radio technologies.....	129
10.3.1	UE Capability Configuration	129
10.3.2	Mobility between E-UTRAN and cdma2000 network	129
10.3.2.1	Tunnelling of cdma2000 Messages over E-UTRAN between UE and cdma2000 Access Nodes	130
10.3.2.2	Mobility between E-UTRAN and HRPD.....	131
10.3.2.2.1	Mobility from E-UTRAN to HRPD	131
10.3.2.2.1.1	HRPD System Information Transmission in E-UTRAN	131
10.3.2.2.1.2	Measuring HRPD from E-UTRAN.....	131
10.3.2.2.1.2.1	Idle Mode Measurement Control	131
10.3.2.2.1.2.2	Active Mode Measurement Control	131
10.3.2.2.1.2.3	Active Mode Measurement	131
10.3.2.2.1.3	Pre-registration to HRPD Procedure.....	131
10.3.2.2.1.4	E-UTRAN to HRPD Cell Re-selection.....	132
10.3.2.2.1.5	E-UTRAN to HRPD Handover.....	132

10.3.2.2.2	Mobility from HRPD to E-UTRAN	132
10.3.2.3	Mobility between E-UTRAN and cdma2000 1xRTT	132
10.3.2.3.1	Mobility from E-UTRAN to cdma2000 1xRTT	132
10.3.2.3.1.1	cdma2000 1xRTT System Information Transmission in E-UTRAN	132
10.3.2.3.1.2	Measuring cdma2000 1xRTT from E-UTRAN	132
10.3.2.3.1.2.1	Idle Mode Measurement Control	133
10.3.2.3.1.2.2	Active Mode Measurement Control	133
10.3.2.3.1.2.3	Active Mode Measurement	133
10.3.2.3.1.3	E-UTRAN to cdma2000 1xRTT Cell Re-selection	133
10.3.2.3.1.4	E-UTRAN to cdma2000 1xRTT Handover	133
10.3.2.3.2	Mobility from cdma2000 1xRTT to E-UTRAN	133
10.3.2.3.3	1xRTT CS Fallback	134
10.3.3	CDMA2000 interworking in LTE shared networks	135
10.4	Area Restrictions	135
10.4a	Roaming and Access Restrictions	136
10.5	Mobility to and from CSG and Hybrid cells	136
10.5.0	Principles for idle-mode mobility with CSG cells	136
10.5.0.1	Intra-frequency mobility	136
10.5.0.2	Inter-frequency mobility	136
10.5.0.3	Inter-RAT Mobility	136
10.5.1	Inbound mobility to CSG cells	136
10.5.1.1	RRC_IDLE	136
10.5.1.2	RRC_CONNECTED	137
10.5.2	Outbound mobility from CSG cells	139
10.5.2.1	RRC_IDLE	139
10.5.2.2	RRC_CONNECTED	139
10.6	Measurement Model	140
10.7	Hybrid Cells	140
10.7.1	RRC_IDLE	140
10.7.2	RRC_CONNECTED	141
10.7.2.1	Inbound Mobility	141
10.7.2.2	Outbound Mobility	141
11	Scheduling and Rate Control	141
11.1	Basic Scheduler Operation	141
11.1.1	Downlink Scheduling	142
11.1.2	Uplink Scheduling	142
11.2	Activation/Deactivation Mechanism	143
11.3	Measurements to Support Scheduler Operation	144
11.4	Rate Control of GBR, MBR and UE-AMBR	144
11.4.1	Downlink	144
11.4.2	Uplink	144
11.4.3	UE-AMBR for Dual Connectivity	144
11.5	CQI reporting for Scheduling	145
11.6	Explicit Congestion Notification	145
12	DRX in RRC_CONNECTED	145
13	QoS	147
13.1	Bearer service architecture	147
13.2	QoS parameters	148
13.3	QoS support in Hybrid Cells	148
14	Security	149
14.1	Overview and Principles	149
14.2	Security termination points	152
14.3	State Transitions and Mobility	153
14.3.1	RRC_IDLE to RRC_CONNECTED	153
14.3.2	RRC_CONNECTED to RRC_IDLE	153
14.3.3	Intra E-UTRAN Mobility	153
14.3.4	SeNB Removal	153
14.4	AS Key Change in RRC_CONNECTED	153
14.5	Security Interworking	154

14.6	RN integrity protection for DRB(s).....	154
15	MBMS.....	154
15.1	General.....	155
15.1.1	E-MBMS Logical Architecture.....	155
15.1.2	E-MBMS User Plane Protocol Architecture.....	157
15.1.3	E-MBMS Control Plane Protocol Architecture.....	157
15.2	MBMS Cells.....	158
15.2.1	MBMS-dedicated cell.....	158
15.2.2	MBMS/Unicast-mixed cell.....	158
15.3	MBMS Transmission.....	158
15.3.1	General.....	158
15.3.2	Single-cell transmission.....	158
15.3.3	Multi-cell transmission.....	159
15.3.4	MBMS Reception States.....	161
15.3.5	MCCH Structure.....	161
15.3.5a	SC-MCCH structure.....	161
15.3.6	MBMS signalling on BCCH.....	162
15.3.7	MBMS User Data flow synchronisation.....	162
15.3.8	Synchronisation of MCCH Update Signalling via M2.....	163
15.3.9	IP Multicast Distribution.....	163
15.4	Service Continuity.....	164
15.5	Network sharing.....	166
15.6	Network Functions for Support of Multiplexing.....	166
15.7	Procedures.....	166
15.7.1	Procedures for Broadcast mode.....	166
15.7.1.1	Session Start procedure.....	166
15.7.1.2	Session Stop procedure.....	168
15.7a	M1 Interface.....	169
15.7a.1	M1 User Plane.....	169
15.8	M2 Interface.....	169
15.8.1	M2 Control Plane.....	169
15.8.2	M2 Interface Functions.....	170
15.8.2.1	General.....	170
15.8.2.2	MBMS Session Handling Function.....	170
15.8.2.3	MBMS Scheduling Information Provision Function.....	170
15.8.2.4	M2 Interface Management Function.....	171
15.8.2.5	M2 Configuration Function.....	171
15.8.2.6	MBMS Service Counting Function.....	171
15.8.2.7	MBMS Service Suspension and Resumption Function.....	171
15.8.2.8	MBMS Overload Notification Function.....	171
15.8.3	M2 Interface Signalling Procedures.....	171
15.8.3.1	General.....	171
15.8.3.2	MBMS Session signalling procedure.....	171
15.8.3.3	MBMS Scheduling Information procedure.....	171
15.8.3.4	M2 Interface Management procedures.....	172
15.8.3.4.1	Reset procedure.....	172
15.8.3.4.2	Error Indication procedure.....	172
15.8.3.5	M2 Configuration procedures.....	172
15.8.3.5.1	M2 Setup procedure.....	172
15.8.3.5.2	eNB Configuration Update procedure.....	172
15.8.3.5.3	MCE Configuration Update procedure.....	172
15.8.3.6	MBMS Service Counting procedures.....	172
15.8.3.6.1	MBMS Service Counting procedure.....	172
15.8.3.6.2	MBMS Service Counting Results Report procedure.....	172
15.8.3.7	MBMS Overload Notification procedure.....	172
15.9	M3 Interface.....	172
15.9.1	M3 Control Plane.....	172
15.9.2	M3 Interface Functions.....	173
15.9.2.1	General.....	173
15.9.2.2	MBMS Session Handling Function.....	173
15.9.2.3	M3 Interface Management Function.....	173

15.9.2.4	M3 Configuration Function.....	174
15.9.3	M3 Interface Signalling Procedures.....	174
15.9.3.1	General.....	174
15.9.3.2	MBMS Session signalling procedure.....	174
15.9.3.3	M3 Interface Management procedures.....	174
15.9.3.3.1	Reset procedure.....	174
15.9.3.3.2	Error Indication procedure.....	174
15.9.3.4	M3 Configuration procedures.....	174
15.9.3.4.1	M3 Setup procedure.....	174
15.9.3.4.2	MCE Configuration Update procedure.....	174
15.10	MBMS Counting.....	175
15.10.1	General.....	175
15.10.2	Counting Procedure.....	175
16	Radio Resource Management aspects.....	175
16.1	RRM functions.....	175
16.1.1	Radio Bearer Control (RBC).....	175
16.1.2	Radio Admission Control (RAC).....	176
16.1.3	Connection Mobility Control (CMC).....	176
16.1.4	Dynamic Resource Allocation (DRA) - Packet Scheduling (PS).....	176
16.1.5	Inter-cell Interference Coordination (ICIC).....	176
16.1.5.1	UE configurations for time domain ICIC.....	177
16.1.5.2	OAM requirements for time domain ICIC.....	177
16.1.5.2.1	Configuration for CSG cell.....	177
16.1.5.2.2	Configuration for interfering non-CSG cell.....	177
16.1.6	Load Balancing (LB).....	178
16.1.7	Inter-RAT Radio Resource Management.....	178
16.1.8	Subscriber Profile ID for RAT/Frequency Priority.....	178
16.1.9	Inter-eNB CoMP.....	178
16.1.10	Cell on/off and cell discovery.....	178
16.2	RRM architecture.....	179
16.2.1	Centralised Handling of certain RRM Functions.....	179
16.2.2	De-Centralised RRM.....	179
16.2.2.1	UE History Information.....	179
16.2.3	Void.....	179
16.3	UE assistance information for RRM and UE power optimisations.....	179
17	Void.....	180
17.1	Void.....	180
18	UE capabilities.....	180
19	S1 Interface.....	181
19.1	S1 User plane.....	181
19.2	S1 Control Plane.....	182
19.2.1	S1 Interface Functions.....	183
19.2.1.1	S1 Paging function.....	184
19.2.1.2	S1 UE Context Management function.....	184
19.2.1.3	Initial Context Setup Function.....	184
19.2.1.3a	UE Context Modification Function.....	184
19.2.1.3b	UE Context Resume Function.....	184
19.2.1.4	Mobility Functions for UEs in ECM-CONNECTED.....	184
19.2.1.4.1	Intra-LTE Handover.....	184
19.2.1.4.2	Inter-3GPP-RAT Handover.....	184
19.2.1.5	E-RAB Service Management function.....	185
19.2.1.6	NAS Signalling Transport function.....	185
19.2.1.7	NAS Node Selection Function (NNSF).....	185
19.2.1.8	S1-interface management functions.....	185
19.2.1.9	MME Load balancing Function.....	185
19.2.1.10	Location Reporting Function.....	186
19.2.1.11	Warning Message Transmission function.....	186
19.2.1.12	Overload Function.....	186
19.2.1.13	RAN Information Management Function.....	186

19.2.1.14	S1 CDMA2000 Tunnelling function.....	186
19.2.1.15	Configuration Transfer Function.....	186
19.2.1.16	LPPa Signalling Transport function.....	186
19.2.1.17	Trace Function.....	186
19.2.1.18	UE Radio Capability Match.....	186
19.2.2	S1 Interface Signalling Procedures.....	186
19.2.2.1	Paging procedure.....	187
19.2.2.2	S1 UE Context Release procedure.....	187
19.2.2.2.1	S1 UE Context Release (EPC triggered).....	187
19.2.2.2.2	S1 UE Context Release Request (eNB triggered).....	187
19.2.2.3	Initial Context Setup procedure.....	188
19.2.2.3a	UE Context Modification procedure.....	189
19.2.2.4	E-RAB signalling procedures.....	190
19.2.2.4.1	E-RAB Setup procedure.....	190
19.2.2.4.2	E-RAB Modification procedure.....	191
19.2.2.4.3	E-RAB Release procedure.....	192
19.2.2.4.4	E-RAB Release Indication procedure.....	192
19.2.2.4.5	E-RAB Modification Indication procedure.....	193
19.2.2.5	Handover signalling procedures.....	193
19.2.2.5.1	Handover Preparation procedure.....	193
19.2.2.5.2	Handover Resource Allocation procedure.....	194
19.2.2.5.3	Handover Notification procedure.....	195
19.2.2.5.4	Handover Cancellation.....	195
19.2.2.5.5	Path Switch procedure.....	195
19.2.2.5.6	Message sequence diagrams.....	196
19.2.2.5.7	eNB Status Transfer procedure.....	204
19.2.2.5.8	MME Status Transfer procedure.....	205
19.2.2.6	NAS transport procedures.....	205
19.2.2.7	S1 interface Management procedures.....	208
19.2.2.7.1	Reset procedure.....	208
19.2.2.7.1a	eNB initiated Reset procedure.....	208
19.2.2.7.1b	MME initiated Reset procedure.....	208
19.2.2.7.2	Error Indication functions and procedures.....	208
19.2.2.7.2a	eNB initiated error indication.....	209
19.2.2.7.2b	MME initiated error indication.....	209
19.2.2.8	S1 Setup procedure.....	209
19.2.2.9	eNB Configuration Update procedure.....	210
19.2.2.9a	eNB Configuration Transfer procedure.....	210
19.2.2.10	MME Configuration Update procedure.....	211
19.2.2.10a	MME Configuration Transfer procedure.....	211
19.2.2.11	Location Reporting procedures.....	212
19.2.2.11.1	Location Reporting Control procedure.....	212
19.2.2.11.2	Location Report procedure.....	213
19.2.2.11.3	Location Report Failure Indication procedure.....	213
19.2.2.12	Overload procedure.....	213
19.2.2.12.1	Overload Start procedure.....	213
19.2.2.12.2	Overload Stop procedure.....	214
19.2.2.13	Write-Replace Warning procedure.....	214
19.2.2.14	eNB Direct Information Transfer procedure.....	215
19.2.2.15	MME Direct Information Transfer procedure.....	215
19.2.2.16	S1 CDMA2000 Tunnelling procedures.....	215
19.2.2.16.1	Downlink S1 CDMA2000 Tunnelling procedure.....	216
19.2.2.16.2	Uplink S1 CDMA2000 Tunnelling procedure.....	216
19.2.2.17	Kill procedure.....	216
19.2.2.18	LPPa Transport procedures.....	217
19.2.2.18.1	Downlink UE Associated LPPa Transport procedure.....	217
19.2.2.18.2	Uplink UE Associated LPPa Transport procedure.....	217
19.2.2.18.3	Downlink Non UE Associated LPPa Transport procedure.....	218
19.2.2.18.4	Uplink Non UE Associated LPPa Transport procedure.....	218
19.2.2.19	Trace procedures.....	218
19.2.2.19.1	Trace Start procedure.....	219
19.2.2.19.2	Trace Failure Indication procedure.....	219

19.2.2.19.3	Deactivate Trace procedure	219
19.2.2.19.4	Cell Traffic Trace procedure	220
19.2.2.20	UE Capability Info Indication procedure	220
19.2.2.21	UE Radio Capability Match procedure	220
19.2.2.22	PWS Restart Indication procedure	221
19.2.2.23	PWS Failure Indication procedure	221
19.2.2.24	UE Context Modification Indication procedure	222
19.2.2.25	Connection Establishment Indication procedure	222
19.2.2.26	UE Context Suspend procedure	223
19.2.2.27	UE Context Resume procedure	223
20	X2 Interface	224
20.1	User Plane	224
20.1.1	Flow Control Functions	224
20.2	Control Plane	224
20.2.1	X2-CP Functions	225
20.2.2	X2-CP Procedures	226
20.2.2.1	Handover Preparation procedure	226
20.2.2.2	Handover Cancel procedure	226
20.2.2.2a	SeNB Addition Preparation procedure	227
20.2.2.2b	SeNB Reconfiguration Completion procedure	227
20.2.2.2c	MeNB initiated SeNB Modification Preparation procedure	228
20.2.2.2d	SeNB initiated SeNB Modification procedure	228
20.2.2.2e	MeNB initiated SeNB Release procedure	229
20.2.2.2f	SeNB initiated SeNB Release procedure	229
20.2.2.2g	SeNB Counter Check procedure	229
20.2.2.3	UE Context Release procedure	229
20.2.2.4	SN Status Transfer procedure	230
20.2.2.5	Error Indication procedure	230
20.2.2.6	Load Indication procedure	231
20.2.2.7	X2 Setup procedure	231
20.2.2.8	eNB Configuration Update procedure	231
20.2.2.9	Reset procedure	232
20.2.2.10	Resource Status Reporting Initiation procedure	232
20.2.2.11	Resource Status Reporting procedure	233
20.2.2.12	Radio Link Failure Indication procedure	233
20.2.2.13	Handover Report procedure	233
20.2.2.14	Mobility Settings Change procedure	234
20.2.2.15	Cell Activation procedure	234
20.2.2.16	X2 Release procedure	235
20.2.2.17	X2AP Message Transfer procedure	235
20.2.2.18	X2 Removal procedure	235
20.2.2.19	Retrieve UE Context	236
20.2.3	Void	237
21	Void	237
21.1	Void	237
21.2	Void	237
21.3	Void	237
22	Support for self-configuration and self-optimisation	237
22.1	Definitions	237
22.2	UE Support for self-configuration and self-optimisation	238
22.3	Self-configuration	238
22.3.1	Dynamic configuration of the S1-MME interface	238
22.3.1.1	Prerequisites	238
22.3.1.2	SCTP initialization	239
22.3.1.3	Application layer initialization	239
22.3.2	Dynamic Configuration of the X2 interface	239
22.3.2.1	Prerequisites	239
22.3.2.2	SCTP initialization	239
22.3.2.3	Application layer initialization	239
22.3.2a	Automatic Neighbour Relation Function	239

22.3.3	Intra-LTE/frequency Automatic Neighbour Relation Function	241
22.3.4	Inter-RAT/Inter-frequency Automatic Neighbour Relation Function	242
22.3.5	Framework for PCI Selection	243
22.3.6	TNL address discovery	243
22.3.6.1	TNL address discovery of candidate eNB via S1 interface	243
22.3.7	Dynamic configuration of the Xw-C interface.....	244
22.3.7.1	Prerequisites	244
22.3.7.2	SCTP initialization	244
22.3.7.3	Application layer initialization.....	244
22.4	Self-optimisation	244
22.4.1	Support for Mobility Load Balancing.....	244
22.4.1.1	General	244
22.4.1.2.1	Load reporting for intra-LTE scenario	245
22.4.1.2.2	Load reporting for inter-RAT scenario	246
22.4.2	Support for Mobility Robustness Optimisation	246
22.4.2.1	General	246
22.4.2.2	Connection failure due to intra-LTE mobility.....	246
22.4.2.2a	Connection failure due to inter-RAT mobility	249
22.4.2.3	Unnecessary HO to another RAT.....	250
22.4.2.4	O&M Requirements	251
22.4.2.5	Inter-RAT ping-pong	251
22.4.2.6	Dynamic coverage configuration changes	252
22.4.3	Support for RACH Optimisation	252
22.4.4	Support for Energy Saving	252
22.4.4.1	General	252
22.4.4.2	Solution description	252
22.4.4.3	O&M requirements	253
22.4.5	Radio Link Failure report	253
22.5	Void.....	254
22.6	Void.....	254
22A	LTE-WLAN Aggregation and RAN Controlled LTE-WLAN Interworking.....	254
22A.1	LTE-WLAN Aggregation	254
22A.1.1	General.....	254
22A.1.2	Radio Protocol Architecture	254
22A.1.3	Network Interfaces.....	255
22A.1.3.1	General	255
22A.1.3.2	User Plane	256
22A.1.3.3	Control Plane.....	256
22A.1.4	Mobility	257
22A.1.5	WLAN Measurements	257
22A.1.6	Procedure for WLAN Connection Status Reporting.....	257
22A.1.7	LTE-WLAN Aggregation Operation	258
22A.1.7.1	WT Addition	258
22A.1.7.2	WT Modification.....	259
22A.1.7.3	WT Release	260
22A.1.7.4	Change of WT	262
22A.1.8	WLAN Authentication.....	262
22A.2	RAN Controlled LTE WLAN Interworking.....	262
22A.2.1	General.....	262
22A.2.2	Network Interfaces.....	263
22A.2.2.1	General	263
22A.2.2.2	User Plane Plane	263
22A.2.2.3	Control Plane.....	263
22A.2.3	Mobility	263
22A.2.4	WLAN Measurements	263
22A.2.5	Procedure for WLAN Connection Status Reporting.....	263
22A.2.6	Traffic Steering Operation	263
22A.2.6.1	Traffic Steering from E-UTRAN to WLAN	263
22A.2.6.2	Traffic Steering from WLAN to E-UTRAN	264
22A.3	LTE/WLAN Radio Level Integration with IPsec Tunnel.....	264
22A.3.1	LWIP Operation.....	267