



SLOVENSKI STANDARD

SIST ETS 300 940 E3:2005

01-februar-2005

8][JhUb]WW] b]hYY_ca i b]_UWg]g]ghYa 'fUhU&žl! Ja Ygb]_nUa cV]b]fUX]c'!
GdYwZ_UWYUfYhY'd`Ugh]f] GA '\$('\$, žfUh]]WU) "- "%L

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile radio interface;
Layer 3 specification (GSM 04.08 version 5.9.1)

iTeh STANDARD PREVIEW (standards.iteh.ai)

Ta slovenski standard je istoveten z: [SIST ETS 300 940 E3:2005](https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4e19-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005)
[ETS 300 940 Edition 3](https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4e19-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005)
<https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4e19-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005>

ICS:

33.070.01 Mobilni servisi na splošno Mobile services in general

SIST ETS 300 940 E3:2005

en

**iTeh STANDARD PREVIEW
(standards.iteh.ai)**

SIST ETS 300 940 E3:2005
<https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4ef9-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005>



EUROPEAN TELECOMMUNICATION STANDARD

ETS 300 940

October 1998

Third Edition

Source: SMG

Reference: RE/SMG-030408QR5

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile radio interface;
Layer 3 specification
(GSM 04.08 version 5.9.1)**

<https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4ef9-a119-3b10e0f31999>

3rd edition (1998)

Layer 3 specification

(GSM 04.08 version 5.9.1)

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1998. All rights reserved.

Page 2

ETS 300 940 (GSM 04.08 version 5.9.1): October 1998

iTeh STANDARD PREVIEW (standards.iteh.ai)

[SIST ETS 300 940 E3:2005](#)

<https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4ef9-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005>

Contents

Foreword	21
Introduction.....	21
0 Scope	23
0.1 Scope of the Technical Specification.....	23
0.2 Application to the interface structures.....	23
0.3 Structure of layer 3 procedures.....	23
0.4 Test procedures	23
0.5 Use of logical channels.....	23
0.6 Overview of control procedures	24
0.6.1 List of procedures.....	24
0.7 Applicability of implementations.....	25
1 Normative references.....	26
2 Definitions and abbreviations	30
2.1 Random values	30
2.2 Vocabulary	30
3 Radio Resource management procedures	32
3.1 Overview/General	32
3.1.1 General.....	32
3.1.2 Services provided to upper layers.....	32
3.1.2.1 Idle mode	32
3.1.2.2 Dedicated mode	32
3.1.2.3 Group receive mode	33
3.1.2.4 Group transmit mode	33
3.1.3 Services required from data link and physical layers	33
3.1.4 Change of dedicated channels.....	33
3.1.4.1 Change of dedicated channels using SAPI = 0	33
3.1.4.2 Change of dedicated channels using other SAPIs than 0	34
3.1.4.3 Sequenced message transfer operation.....	34
3.1.4.3.1 Variables and sequence numbers	34
3.1.4.3.1.2 Send sequence number N(SD).....	34
3.1.4.3.2 Procedures for the initiation, transfer execution and termination of the sequenced message transfer operation.....	35
3.1.4.3.2.2 Transfer Execution.....	35
3.1.4.5 Procedure for Service Request and Contention Resolution	35
3.2 Idle mode procedures	36
3.2.1 Mobile Station side	36
3.2.2 Network side.....	36
3.2.2.1 System information broadcasting	36
3.2.2.2 Paging.....	37
3.3 RR connection establishment	37
3.3.1 RR connection establishment initiated by the mobile station	37
3.3.1.1 Entering the dedicated mode : immediate assignment procedure.....	37
3.3.1.1.1 Permission to access the network	37
3.3.1.1.2 Initiation of the immediate assignment procedure.....	38
3.3.1.1.3 Answer from the network	39
3.3.1.1.3.1 On receipt of a CHANNEL REQUEST message	39
3.3.1.1.3.2 Assignment rejection	40

	3.3.1.1.4	Assignment completion	40	
	3.3.1.1.5	Abnormal cases	41	
3.3.1.2	Entering the group transmit mode: uplink access procedure	41		
	3.3.1.2.1	Mobile station side.....	41	
	3.3.1.2.1.1	Uplink investigation procedure	41	
	3.3.1.2.1.2	Uplink access procedure.....	42	
	3.3.1.2.2	Network side	42	
	3.3.1.2.3	Abnormal cases	43	
3.3.2	Paging procedure	43		
	3.3.2.1	Paging initiation by the network.....	43	
	3.3.2.2	Paging response	44	
	3.3.2.3	Abnormal cases	44	
3.3.3	Notification procedure.....	45		
	3.3.3.1	Notification of a call	45	
	3.3.3.2	Joining a VGCS or VBS call.....	45	
	3.3.3.3	Reduced NCH monitoring mechanism	46	
3.4	Procedures in dedicated mode and in group transmit mode	47		
3.4.1	SACCH procedures	47		
	3.4.1.1	General	47	
	3.4.1.2	Measurement report.....	48	
	3.4.1.3	Extended measurement report \$(MAFA)\$	48	
3.4.2	Transfer of messages and link layer service provision.....	48		
3.4.3	Channel assignment procedure.....	48		
	3.4.3.1	Channel assignment initiation	49	
	3.4.3.2	Assignment completion.....	51	
	3.4.3.3	Abnormal cases	51	
3.4.4	Handover procedure	52		
	3.4.4.1	Handover initiation	52	
	3.4.4.2	Physical channel establishment	54	
		3.4.4.2.1	Finely synchronized cell case	54
		3.4.4.2.2	Non synchronized cell case.....	54
		3.4.4.2.3	Pseudo-synchronized cell case	55
		3.4.4.2.4	Pre-synchronized cell case	55
	3.4.4.3	Handover completion.....	55	
	3.4.4.4	Abnormal cases	56	
3.4.5	Frequency redefinition procedure	57		
	3.4.5.1	Abnormal cases	57	
3.4.6	Channel mode modify procedure.....	57		
	3.4.6.1	Normal channel mode modify procedure	58	
		3.4.6.1.1	Initiation of the channel mode modify procedure	58
		3.4.6.1.2	Completion of channel mode modify procedure	58
		3.4.6.1.3	Abnormal cases	58
	3.4.6.2	Channel mode modify procedure for a voice group call talker	58	
		3.4.6.2.1	Initiation of the channel mode modify procedure	58
		3.4.6.2.2	Completion of mode change procedure	59
		3.4.6.2.3	Abnormal cases	59
3.4.7	Ciphering mode setting procedure.....	59		
	3.4.7.1	Ciphering mode setting initiation	59	
	3.4.7.2	Ciphering mode setting completion.....	59	
3.4.8	Additional channel assignment procedure	60		
	3.4.8.1	Additional assignment procedure initiation	60	
	3.4.8.2	Additional assignment procedure completion	60	
	3.4.8.3	Abnormal cases	60	
3.4.9	Partial channel release procedure	61		
	3.4.9.1	Partial release procedure initiation	61	
	3.4.9.2	Abnormal cases	61	
3.4.10	Classmark change procedure.....	61		

3.4.11	Classmark interrogation procedure	61
3.4.11.1	Classmark interrogation initiation	61
3.4.11.2	Classmark interrogation completion	62
3.4.12	Indication of notifications and paging informations	62
3.4.13	RR connection release procedure.....	63
3.4.13.1	Normal release procedure	63
3.4.13.1.1	Channel release procedure initiation in dedicated mode and in group transmit mode	63
3.4.13.1.2	Abnormal cases	64
3.4.13.2	Radio link failure in dedicated mode.....	64
3.4.13.2.1	Mobile side.....	64
3.4.13.2.2	Network side	64
3.4.13.3	RR connection abortion in dedicated mode.....	64
3.4.13.4	Uplink release procedure in group transmit mode.....	65
3.4.14	Receiving a RR STATUS message by a RR entity	65
3.4.15	Group receive mode procedures.....	65
3.4.15.1	Mobile station side	65
3.4.15.1.1	Reception of the VGCS or VBS channel	65
3.4.15.1.2	Monitoring of downlink messages and related procedures.....	65
3.4.15.1.2.1	Channel assignment procedure	65
3.4.15.1.2.2	Frequency redefinition procedure	65
3.4.15.1.2.3	Channel mode modify procedure.....	66
3.4.15.1.2.4	Notification and paging information	66
3.4.15.1.2.4.1	Use of Reduced NCH monitoring	66
3.4.15.1.2.5	Uplink status messages.....	66
3.4.15.1.2.6	Channel release message	66
3.4.15.1.2.7	Information on paging channel restructuring	67
3.4.15.1.3	Uplink reply procedure	67
3.4.15.1.4	Leaving the group receive mode	67
3.4.15.1.4.1	Returning to idle mode	67
3.4.15.1.4.2	Going to group transmit mode	67
3.4.15.2	Network side.....	68
3.4.15.2.1	Provision of messages on the VGCS or VBS channel downlink	68
3.4.15.2.1.1	General	68
3.4.15.2.1.2	Provision of general information messages	68
3.4.15.2.1.3	Provision of messages related to the voice group call uplink channel.....	68
3.4.15.2.2	Release of the VGCS or VBS Channels.....	69
3.4.15.3	Failure cases	69
3.4.16	Configuration change procedure	69
3.4.16.1	Configuration change initiation	69
3.4.16.2	Configuration change completion	69
3.4.16.3	Abnormal cases.....	69
3.4.17	Mapping of user data substreams onto timeslots in a multislots configuration	70
3.4.18	Handling of classmark information at band change	70
4	Elementary procedures for Mobility Management	71
4.1	General	71
4.1.1	Type of MM procedures	71
4.1.2	MM sublayer states	71
4.1.2.1	MM sublayer states in the mobile station.....	72
4.1.2.1.1	Main states.....	72
4.1.2.1.2	Substates of the MM IDLE state	75
4.1.2.2	The update Status	76
4.1.2.3	MM sublayer states on the network side	77

4.2	Behaviour in MM IDLE State	78
4.2.1	Primary Service State selection	78
4.2.1.1	Selection of the Service State after Power On.....	78
4.2.1.2	Other Cases.....	79
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.	79
4.2.2.1	Service State, NORMAL SERVICE.....	79
4.2.2.2	Service State, ATTEMPTING TO UPDATE.....	79
4.2.2.3	Service State, LIMITED SERVICE.....	80
4.2.2.4	Service State, NO IMSI.....	80
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE	81
4.2.2.6	Service State, SEARCH FOR PLMN	81
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	81
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE)	81
4.2.3	Service state when back to state MM IDLE from another state.....	82
4.3	MM common procedures	82
4.3.1	TMSI reallocation procedure.....	82
4.3.1.1	TMSI reallocation initiation by the network.....	83
4.3.1.2	TMSI reallocation completion by the mobile station.....	83
4.3.1.3	TMSI reallocation completion in the network.....	83
4.3.1.4	Abnormal cases	83
4.3.2	Authentication procedure.....	85
4.3.2.1	Authentication request by the network.....	85
4.3.2.2	Authentication response by the mobile station.....	85
4.3.2.3	Authentication processing in the network	85
4.3.2.4	Ciphering key sequence number	85
4.3.2.5	Unsuccessful authentication	86
4.3.2.6	Abnormal cases	86
4.3.3	Identification procedure	87
4.3.3.1	Identity request by the network	87
4.3.3.2	Identification response by the mobile station	87
4.3.3.3	Abnormal cases	87
4.3.4	IMSI detach procedure	87
4.3.4.1	https://standards.ieee.org/standard/sist/0aca874a-42ba-4c19-a119-3b0eh/BSI.html SIST ETS 300 940 E3:2005 IMSI detach initiation by the mobile station	87
4.3.4.2	IMSI detach procedure in the network	88
4.3.4.3	IMSI detach completion by the mobile station.....	88
4.3.4.4	Abnormal cases	88
4.3.5	Abort procedure	88
4.3.5.1	Abort procedure initiation by the network.....	88
4.3.5.2	Abort procedure in the mobile station	89
4.3.6	MM information procedure.....	89
4.3.6.1	MM information procedure initiation by the network.....	89
4.3.6.2	MM information procedure in the mobile station	89
4.4	MM specific procedures	90
4.4.1	Location updating procedure	90
4.4.2	Periodic updating	91
4.4.3	IMSI attach procedure	91
4.4.4	Generic Location Updating procedure	92
4.4.4.1	Location updating initiation by the mobile station.....	92
4.4.4.1a	Network Request for Additional mobile station Capability Information	92
4.4.4.2	Identification request from the network.....	92
4.4.4.3	Authentication by the network	92
4.4.4.4	Ciphering mode setting by the network.....	92
4.4.4.5	Attempt Counter	92
4.4.4.6	Location updating accepted by the network.....	93
4.4.4.7	Location updating not accepted by the network.....	93
4.4.4.8	Release of RR connection after location updating.....	94
4.4.4.9	Abnormal cases on the mobile station side	94
4.4.4.10	Abnormal cases on the network side	95
4.5	Connection management sublayer service provision.....	96
4.5.1	MM connection establishment	96

4.5.1.1	MM connection establishment initiated by the mobile station	96
4.5.1.2	Abnormal cases.....	99
4.5.1.3	MM connection establishment initiated by the network	100
4.5.1.3.1	Mobile Terminating CM Activity	100
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$.....	100
4.5.1.4	Abnormal cases.....	101
4.5.1.5	MM connection establishment for emergency calls.....	101
4.5.1.6	Call re-establishment.....	102
4.5.1.6.1	Call re-establishment, initiation by the mobile station.....	103
4.5.1.6.2	Abnormal cases	104
4.5.1.7	Forced release during MO MM connection establishment	105
4.5.2	MM connection information transfer phase	105
4.5.2.1	Sending CM messages	105
4.5.2.2	Receiving CM messages.....	106
4.5.2.3	Abnormal cases.....	106
4.5.3	MM connection release	106
4.5.3.1	Release of associated RR connection.....	106
4.5.3.2	Uplink release in a voice group call	107
4.6	Receiving a MM STATUS message by a MM entity.....	107
5	Elementary procedures for circuit-switched Call Control	108
5.1	Overview	108
5.1.1	General.....	108
5.1.2	Call Control States	113
5.1.2.1	Call states at the mobile station side of the interface	113
5.1.2.1.1	Null (State U0)	113
5.1.2.1.2	MM Connection pending (U0.1).....	113
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$.....	113
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$.....	113
5.1.2.1.2c	CC-Establishmentpresent (U0.4) \$(CCBS)\$.....	113
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$.....	113
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	113
5.1.2.1.3	Call initiated (U1)	113
5.1.2.1.4	Mobile originating call proceeding (U3)113	
5.1.2.1.5	Call delivered (U4)	114
5.1.2.1.6	Call present (U6).....	114
5.1.2.1.7	Call received (U7)	114
5.1.2.1.8	Connect Request (U8)	114
5.1.2.1.9	Mobile terminating call confirmed (U9)114	
5.1.2.1.10	Active (U10)	114
5.1.2.1.11	Disconnect request (U11)	114
5.1.2.1.12	Disconnect indication (U12).....	114
5.1.2.1.13	Release request (U19).....	114
5.1.2.1.14	Mobile originating modify (U26)	114
5.1.2.1.15	Mobile terminating modify (U27).....	114
5.1.2.2	Network call states	114
5.1.2.2.1	Null (State N0)	115
5.1.2.2.2	MM connection pending (N0.1).....	115
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$.....	115
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$.....	115
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$.....	115
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$.....	115

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST ETS 300 940 E3:2005](https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4e99-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005)

<https://standards.iteh.ai/catalog/standards/sist/6aca874a-42ba-4e99-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005>

	This	state exists for a mobile originating call when the network has received acknowledgement that the mobile station has received all call information necessary to effect call establishment.5.1.2.2.2e Recall present (N0.6) \$(CCBS)\$.....	115
	5.1.2.2.3	Call initiated (N1).....	115
	5.1.2.2.4	Mobile originating call proceeding (N3)115	
	5.1.2.2.5	Call delivered (N4).....	115
	5.1.2.2.6	Call present (N6)	115
	5.1.2.2.7	Call received (N7).....	115
	5.1.2.2.8	Connect request (N8)	116
	5.1.2.2.9	Mobile terminating call confirmed (N9)116	
	5.1.2.2.10	Active (N10).....	116
	5.1.2.2.11	{Not used}	116
	5.1.2.2.12	Disconnect indication (N12)	116
	5.1.2.2.13	Release request (N19)	116
	5.1.2.2.14	Mobile originating modify (N26).....	116
	5.1.2.2.15	Mobile terminating modify (N27)	116
	5.1.2.2.16	Connect Indication (N28)	116
5.2	Call establishment procedures.....		116
5.2.1	Mobile originating call establishment.....		117
	5.2.1.1	Call initiation.....	117
	5.2.1.2	Receipt of a setup message	118
	5.2.1.3	Receipt of a CALL PROCEEDING message.....	119
	5.2.1.4	Notification of progressing mobile originated call.....	119
	5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment	119
	5.2.1.4.2	Call progress in the PLMN/ISDN environment	120
	5.2.1.5	Alerting	120
	5.2.1.6	Call connected	121
	5.2.1.7	Call rejection	121
	5.2.1.8	Transit network selection	121
	5.2.1.9	Traffic channel assignment at mobile originating call establishment.....	121
	5.2.1.10	Call queuing at mobile originating call establishment	122
5.2.2	Mobile terminating call establishment.....		122
	5.2.2.1	Call indication.....	122
	5.2.2.2	Compatibility checking	123
	5.2.2.3	Call confirmation	123
	5.2.2.3.1	Response to SETUP	123
	5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	123
	5.2.2.3.3	Call failure procedures	124
	5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	124
	5.2.2.4	Notification of interworking in connection with mobile terminating call establishment.....	124
	5.2.2.5	Call accept	124
	5.2.2.6	Active indication	124
	5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	125
	5.2.2.8	Call queuing at mobile terminating call establishment	125
	5.2.2.9	User connection attachment during a mobile terminating call.....	125
	5.2.3	Network initiated MO call \$(CCBS)\$.....	125
	5.2.3.1	Initiation	125
	5.2.3.2	CC-Establishment present	126
	5.2.3.2.1	Recall Alignment Procedure.....	127

iTeh STANDARD PREVIEW (standards.iteh.ai)

<https://standards.iteh.ai/catalog/standards/sist/0aca874a-42ba-4cf9-a119-3b0eb7f5fb9/sist-ets-300-940-e3-2005>

	Further	details on Facility handling are given in GSM 04.105.2.3.3 CC-Establishment confirmation	128
	5.2.3.4	Recall present.....	128
	5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment.....	129
5.3	Signalling procedures during the "active" state.....		129
5.3.1	User notification procedure		129
5.3.2	Call rearrangements.....		129
5.3.3	Not used.....		130
5.3.4	Support of Dual Services.....		130
	5.3.4.1	Service Description.....	130
	5.3.4.2	Call establishment	130
	5.3.4.2.1	Mobile Originating Establishment	130
	5.3.4.2.2	Mobile Terminating Establishment.....	131
	5.3.4.3	Changing the Call Mode	131
	5.3.4.3.1	Initiation of in-call modification.....	132
	5.3.4.3.2	Successful completion of in-call modification.....	132
	5.3.4.3.3	Change of the channel configuration..	132
	5.3.4.3.4	Failure of in-call modification	132
	5.3.4.3.4.1	Network rejection of in-call modification.....	132
	5.3.4.3.4.2	Mobile station rejection of in-call modification.....	133
	5.3.4.3.4.3	Time-out recovery	133
	5.3.4.4	Abnormal procedures.....	133
5.3.5	User initiated service level up- and downgrading		134
	5.3.5.1	Initiation of service level up- and downgrading.....	134
	5.3.5.2	Successful completion of service level up- and downgrading	134
	5.3.5.3	Rejection of service level up- and downgrading	134
	5.3.5.4	Time-out recovery.....	134
5.4	https://standards.iten.ai/catalog/standards/sist/6aca8744-42ba-4cf9-a119-3b0eb7d5ffbd/sist-ets-300-940-e3-2005		135
5.4.1	Call clearing		135
5.4.2	Terminology.....		135
5.4.3	Exception conditions		135
	5.4.3.1	Clearing initiated by the mobile station.....	135
	5.4.3.2	Initiation of call clearing	135
	5.4.3.2	Receipt of a DISCONNECT message from the mobile station.	136
	5.4.3.3	Receipt of a RELEASE message from the network	136
	5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station.....	136
	5.4.3.5	Abnormal cases.....	136
5.4.4	Clearing initiated by the network		136
	5.4.4.1	Clearing when tones/announcements provided	136
	5.4.4.1.1	Receipt of a DISCONNECT message with progress indicator #8 from the network	137
	5.4.4.1.2	Expiry of timer T306.....	137
	5.4.4.2	Clearing when tones/announcements not provided	137
	5.4.4.2.1	Receipt of a DISCONNECT message without progress indicator or with progress indicator different from #8 from the network	137
	5.4.4.2.2	Receipt of a RELEASE message from the mobile station.....	137
	5.4.4.2.3	Abnormal cases	137
	5.4.4.3	Completion of clearing.....	137
	5.4.4.3.1	Abnormal cases	138
5.4.5	Clear collision		138
5.5	Miscellaneous procedures		138

5.5.1	In-band tones and announcements	138
5.5.2	Call collisions	138
5.5.3	Status procedures.....	138
5.5.3.1	Status enquiry procedure	138
5.5.3.2	Reception of a STATUS message by a CC entity	139
5.5.3.2.1	STATUS message with incompatible state.....	139
5.5.3.2.2	STATUS message with compatible state.....	139
5.5.4	Call re-establishment, mobile station side	139
5.5.4.1	Indication from the mobility management sublayer.....	139
5.5.4.2	Reaction of call control.....	139
5.5.4.3	Completion of re-establishment	140
5.5.4.4	Unsuccessful outcome.....	140
5.5.5	Call re-establishment, network side.....	140
5.5.5.1	State alignment	140
5.5.6	Progress	140
5.5.7	DTMF protocol control procedure	140
5.5.7.1	Start DTMF request by the mobile station	141
5.5.7.2	Start DTMF response by the network	141
5.5.7.3	Stop DTMF request by the mobile station	141
5.5.7.4	Stop DTMF response by the network	141
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station.....	141
6	Support of packet services.	142
7	Examples of structured procedures.....	143
7.1	General.....	143
7.1.1	Paging request.....	144
7.1.2	Immediate assignment	144
7.1.3	Service request and contention resolution.....	145
7.1.4	Authentication	145
7.1.5	Ciphering mode setting.....	146
7.1.6	Transaction phase.....	146
7.1.6.1	Channel mode modify	146
7.1.7	Channel release.....	147
7.2	Abnormal cases	147
7.3	Selected examples.....	147
7.3.1	Location updating	148
7.3.2	Mobile originating call establishment.....	149
7.3.3	Mobile terminating call establishment.....	153
7.3.4	Call clearing	156
7.3.5	DTMF protocol control	157
7.3.6	Handover	158
7.3.7	In-call modification.....	160
7.3.8	Call re-establishment.....	161
7.3.9	Network initiated mobile originating call \$(CCBS)\$	162
8	Handling of unknown, unforeseen, and erroneous protocol data	166
8.1	General.....	166
8.2	Message too short.....	167
8.3	Unknown or unforeseen transaction identifier.....	167
8.4	Unknown or unforeseen message type.....	168
8.5	Non-semantical mandatory information element errors	169
8.5.1	Radio resource management	170
8.5.2	Mobility management.....	170
8.5.3	Call control.....	170
8.6	Unknown and unforeseen IEs in the non-imperative message part	170
8.6.1	IEIs unknown in the message.....	170
8.6.2	Out of sequence IEs	170
8.6.3	Repeated IEs	171
8.7	Non-imperative message part errors	171

8.7.1	Syntactically incorrect optional IEs	171
8.7.2	Conditional IE errors.....	171
8.8	Messages with semantically incorrect contents	171
9	Message functional definitions and contents	172
9.1	Messages for Radio Resources management	173
9.1.1	Additional assignment	175
9.1.1.1	Mobile Allocation.....	175
9.1.1.2	Starting Time	175
9.1.2	Assignment command.....	176
9.1.2.1	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8).....	177
9.1.2.2	Description of the Second Channel	177
9.1.2.3	Mode of the Second Channel.....	177
9.1.2.4	Mobile Allocation and Frequency List, after the starting time	177
9.1.2.5	Starting Time	178
9.1.2.6	Reference cell frequency list.....	178
9.1.2.7	Cell Channel Description	178
9.1.2.8	Cipher Mode Setting	178
9.1.2.9	VGCS target mode Indication	179
9.1.2.10	Description of the multislot allocation	179
9.1.3	Assignment complete	179
9.1.4	Assignment failure.....	180
9.1.5	Channel mode modify	180
9.1.5.1	Channel Description	180
9.1.5.2	VGCS target mode Indication	180
9.1.6	Channel mode modify acknowledge	181
9.1.7	Channel release	182
9.1.7.1	Channel description and mobile allocation	182
9.1.7.2	Group Cipher Key Number	182
9.1.8	Channel request	183
9.1.9	Ciphering mode command	185
9.1.10	https://standards.ieee.org/catalog/standards/sist/0aca874a-42ba-4cf9-a119-3b1e6b7d5ffbd/sist-ets-300-940-e3-2005	186
9.1.11	Ciassmark change	186
9.1.11.1	Additional Mobile Station Classmark Information	186
9.1.11.2	Mobile Station Classmark.....	186
9.1.12	Classmark enquiry.....	187
9.1.12a	[Spare].....	188
9.1.12b	Configuration change command	188
9.1.12b.1	Description of the multislot allocation	188
9.1.12b.2	Mode of Channel Set "X" (1=<X<=8).....	188
9.1.12c	Configuration change acknowledge	189
9.1.12d	Configuration change reject	189
9.1.13	Frequency redefinition	190
9.1.13.1	Cell Channel Description	190
9.1.14	Handover access.....	190
9.1.15	Handover command	191
9.1.15.1	Synchronization Indication	192
9.1.15.2	Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8).....	192
9.1.15.3	Description of the Second Channel	192
9.1.15.4	Mode of the Second Channel	193
9.1.15.5	Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time.	193
9.1.15.6	Starting Time	193
9.1.15.7	Reference cell frequency list.....	194
9.1.15.8	Real Time Difference.....	194
9.1.15.9	Timing Advance.....	194
9.1.15.10	Cipher Mode Setting	194
9.1.15.11	VGCS target mode indication	194
9.1.15.12	Description of the multislot allocation	195

9.1.16	Handover complete.....	196
9.1.16.1	Mobile Observed Time Difference	196
9.1.17	Handover failure	196
9.1.18	Immediate assignment	197
9.1.18.1	Mobile Allocation	197
9.1.18.2	Starting Time.....	197
9.1.18.3	IA Rest Octets (Frequency parameters, before time)	197
9.1.19	Immediate assignment extended.....	198
9.1.19.1	Unnecessary IEs	198
9.1.19.2	Mobile Allocation	199
9.1.19.3	Starting Time.....	199
9.1.19.4	Maximum message length.....	199
9.1.19.5	IAX Rest Octets	199
9.1.20	Immediate assignment reject.....	200
9.1.20.1	Use of the indexes	200
9.1.20.2	Filling of the message	200
9.1.20.3	IAR Rest Octets	200
9.1.21	Measurement report	201
9.1.21a	Notification/FACCH.....	202
9.1.21a.1	VBS/VGCS Channel description	202
9.1.21a.2	PCH information.....	203
9.1.21a.3	Paging Information.....	203
9.1.21a.4	Composition of the optional information elements	203
9.1.21b	Notification/NCH	203
9.1.21b.1	Group Channel Description.....	204
9.1.21b.2	NT/N Rest Octets.....	204
9.1.21d	Notification response	204
9.1.22	Paging request type 1.....	205
9.1.22.1	Unnecessary IE	205
9.1.22.2	Channels needed for Mobiles 1 and 2	205
9.1.22.3	Mobile Identities	205
9.1.22.4	P1 Rest Octets	205
9.1.23	Paging request type 2.....	206
9.1.23.1	Channels needed for Mobiles 1 and 2	206
9.1.23.2	Mobile Identity 3	206
9.1.23.3	3b0eh/15ffbd/sist-ets-300-940-e3-2005 P2 Rest Octets	206
9.1.24	Paging request type 3	207
9.1.24.1	Channels needed for Mobiles 1 and 2	207
9.1.24.2	P3 Rest Octets	207
9.1.25	Paging response.....	208
9.1.25.1	Mobile Station Classmark	208
9.1.26	Partial release	209
9.1.26.1	Channel Description.....	209
9.1.27	Partial release complete	209
9.1.28	Physical information.....	210
9.1.29	RR Status	210
9.1.30	Synchronization channel information	211
9.1.31	System information Type 1	212
9.1.32	System information type 2	212
9.1.33	System information type 2bis.....	213
9.1.34	System information type 2ter	214
9.1.35	System information type 3	215
9.1.36	System information type 4	216
9.1.36.1	CBCH Channel description	216
9.1.36.2	CBCH Mobile Allocation	216
9.1.36.3	SI 4 Rest Octets	216
9.1.37	System information type 5	217
9.1.38	System information type 5bis.....	218
9.1.39	System information type 5ter	218
9.1.40	System information type 6	219
9.1.40.1	Cell Identity.....	219
9.1.40.2	Location Area Identification.....	219
9.1.40.3	Cell Options.....	219

9.1.41	NCC permitted.....	219
9.1.42	System information type 7	220
9.1.43	System information type 8	220
9.1.43	System information Type 9.....	221
9.1.44	Talker indication	222
9.1.45	Uplink access	223
9.1.46	Uplink busy	224
9.1.47	Uplink free	225
9.1.48	Uplink release.....	225
9.1.49	VGCS uplink grant.....	227
9.1.50	System information type 10 \$(ASCI)\$.....	228
9.1.51	EXTENDED MEASUREMENT ORDER \$(MAFA)\$	228
9.1.52	Extended measurement report \$(MAFA)\$	228
9.2	Messages for mobility management.....	229
9.2.1	Authentication reject.....	230
9.2.2	Authentication request.....	230
9.2.3	Authentication response.....	231
9.2.4	CM Re-establishment request.....	231
9.2.4.1	Location area identification	231
9.2.4.2	Mobile Station Classmark.....	231
9.2.5	CM service accept	232
9.2.5a	CM service prompt \$(CCBS)\$.....	232
9.2.6	CM service reject.....	233
9.2.7	CM service abort	234
9.2.8	Abort.....	234
9.2.9	CM service request	235
9.2.9.1	Mobile Station Classmark.....	235
9.2.9.2	Priority.....	235
9.2.10	Identity request	236
9.2.11	Identity response	236
9.2.12	IMSI detach indication.....	237
9.2.12.1	Mobile Station Classmark.....	237
9.2.13	Location updating accept	238
9.2.13.1	Follow on proceed	238
9.2.14	Location updating reject	238
9.2.15	Location updating request	239
9.2.15.1	Location area identification	239
9.2.15.2	Mobile Station Classmark.....	239
9.2.15a	MM information.....	240
9.2.15a.1	Full name for network	240
9.2.15a.2	Short name for network	240
9.2.15a.3	Network time zone	240
9.2.15a.4	Network time zone and time	240
9.2.16	MM Status	241
9.2.17	TMSI reallocation command	241
9.2.18	TMSI reallocation complete	241
9.2.19	MM Null	242
9.3	Messages for circuit-switched call control	243
9.3.1	Alerting	244
9.3.1.1	Alerting (network to mobile station direction).....	244
9.3.1.1.1	Facility	244
9.3.1.1.2	Progress indicator	244
9.3.1.1.3	User-user	244
9.3.1.2	Alerting (mobile station to network direction).....	245
9.3.1.2.1	Facility	245
9.3.1.2.2	User-user	245
9.3.1.2.3	SS version	245
9.3.2	Call confirmed	246
9.3.2.1	Repeat indicator.....	247
9.3.2.2	Bearer capability 1 and bearer capability 2	247
9.3.2.3	Cause	247
9.3.2.4	CC Capabilities	247
9.3.3	Call proceeding	248