

ETSI TS 138 331 V16.6.0 (2021-10)



**5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 16.6.0 Release 16)**



ReferenceRTS/TSGR-0238331v60

Keywords

5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Important notice

<https://standards.iteh.ai/catalog/standards/sist/07acf3d2-1e79-4e7d-8e6d-870a187c497c/etsi-ts-138-331-v16-6-0-2021-10>
The present document can be downloaded from:
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:
<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2021.
All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

<https://standards.iteh.ai/catalog/standards/sist/07acf3d2-1e79-4e7d-8e6d-8704087c44f7/etsi-ts-138-331-v16-6-0-2021-10>

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	20
1 Scope	21
2 References	21
3 Definitions, symbols and abbreviations	23
3.1 Definitions	23
3.2 Abbreviations	25
4 General	27
4.1 Introduction	27
4.2 Architecture	27
4.2.1 UE states and state transitions including inter RAT	27
4.2.2 Signalling radio bearers	29
4.3 Services	30
4.3.1 Services provided to upper layers.....	30
4.3.2 Services expected from lower layers	30
4.4 Functions	30
5 Procedures	32
5.1 General	32
5.1.1 Introduction.....	32
5.1.2 General requirements.....	32
5.1.3 Requirements for UE in MR-DC.....	32
5.2 System information.....	33
5.2.1 Introduction.....	33
5.2.2 System information acquisition	34
5.2.2.1 General UE requirements.....	34
5.2.2.2 SIB validity and need to (re)-acquire SIB	34
5.2.2.2.1 SIB validity.....	34
5.2.2.2.2 SI change indication and PWS notification	36
5.2.2.3 Acquisition of System Information	36
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	36
5.2.2.3.2 Acquisition of an SI message	37
5.2.2.3.3 Request for on demand system information	39
5.2.2.3.3a Request for on demand positioning system information	40
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	40
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	41
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	42
5.2.2.4 Actions upon receipt of System Information	42
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	42
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	42
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	45
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	46
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	46
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	47
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	47
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	47
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	48
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	49
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	49
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	49
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	49
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	50

iTeh STANDARD PREVIEW
(standards.iteh.ai)

ETSI TS 138 331 V16.6.0 (2021-10)
<https://standards.iteh.ai/catalog/standards/sist/07ac3d2-1e79-4e7d-8e6d-87b4087c44f7/etsi-ts-138-331-v16-6-0-2021-10>

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	50
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	50
5.2.2.5	Essential system information missing	50
5.3	Connection control	51
5.3.1	Introduction.....	51
5.3.1.1	RRC connection control	51
5.3.1.2	AS Security	51
5.3.2	Paging	53
5.3.2.1	General	53
5.3.2.2	Initiation.....	53
5.3.2.3	Reception of the <i>Paging message</i> by the UE	53
5.3.3	RRC connection establishment	54
5.3.3.1	General	54
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/V2X sidelink communication.....	54
5.3.3.2	Initiation.....	55
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message.....	55
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	55
5.3.3.5	Reception of the <i>RRCReject</i> by the UE.....	58
5.3.3.6	Cell re-selection or cell selection while T390, T300 or T302 is running (UE in RRC_IDLE)	58
5.3.3.7	T300 expiry	59
5.3.3.8	Abortion of RRC connection establishment.....	60
5.3.4	Initial AS security activation	60
5.3.4.1	General	60
5.3.4.2	Initiation.....	60
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE.....	61
5.3.5	RRC reconfiguration.....	61
5.3.5.1	General	61
5.3.5.2	Initiation.....	62
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	63
5.3.5.4	Secondary cell group release	70
5.3.5.5	Cell Group configuration	70
5.3.5.5.1	General	70
5.3.5.5.2	Reconfiguration with sync	71
5.3.5.5.3	RLC bearer release	73
5.3.5.5.4	RLC bearer addition/modification.....	73
5.3.5.5.5	MAC entity configuration	74
5.3.5.5.6	RLF Timers & Constants configuration	74
5.3.5.5.7	SpCell Configuration.....	75
5.3.5.5.8	SCell Release.....	75
5.3.5.5.9	SCell Addition/Modification	75
5.3.5.5.10	BH RLC channel release	76
5.3.5.5.11	BH RLC channel addition/modification.....	76
5.3.5.6	Radio Bearer configuration	77
5.3.5.6.1	General	77
5.3.5.6.2	SRB release	77
5.3.5.6.3	SRB addition/modification	77
5.3.5.6.4	DRB release.....	79
5.3.5.6.5	DRB addition/modification	79
5.3.5.7	AS Security key update.....	82
5.3.5.8	Reconfiguration failure	83
5.3.5.8.1	Void	83
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	83
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure)	85
5.3.5.9	Other configuration	87
5.3.5.10	MR-DC release	89
5.3.5.11	Full configuration.....	89
5.3.5.12	BAP configuration	91
5.3.5.12a	IAB Other Configuration	91
5.3.5.12a.1	IP address management	91
5.3.5.12a.1.1	IP Address Release	91
5.3.5.12a.1.2	IP Address Addition/Modification.....	91

5.3.5.13	Conditional Reconfiguration	93
5.3.5.13.1	General	93
5.3.5.13.2	Conditional reconfiguration removal	93
5.3.5.13.3	Conditional reconfiguration addition/modification	93
5.3.5.13.4	Conditional reconfiguration evaluation	93
5.3.5.13.5	Conditional reconfiguration execution	94
5.3.5.14	Sidelink dedicated configuration	94
5.3.6	Counter check	96
5.3.6.1	General	96
5.3.6.2	Initiation	96
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	96
5.3.7	RRC connection re-establishment	97
5.3.7.1	General	97
5.3.7.2	Initiation	97
5.3.7.3	Actions following cell selection while T311 is running	99
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	101
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	102
5.3.7.6	T311 expiry	103
5.3.7.7	T301 expiry or selected cell no longer suitable	103
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	103
5.3.8	RRC connection release	104
5.3.8.1	General	104
5.3.8.2	Initiation	104
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	104
5.3.8.4	T320 expiry	107
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	107
5.3.9	RRC connection release requested by upper layers	107
5.3.9.1	General	107
5.3.9.2	Initiation	107
5.3.10	Radio link failure related actions	107
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	107
5.3.10.2	Recovery of physical layer problems	108
5.3.10.3	Detection of radio link failure	108
5.3.10.4	RLF cause determination	110
5.3.10.5	RLF report content determination	110
5.3.11	UE actions upon going to RRC_IDLE	112
5.3.12	UE actions upon PUCCH/SRS release request	113
5.3.13	RRC connection resume	114
5.3.13.1	General	114
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/V2X sidelink communication	115
5.3.13.2	Initiation	115
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	117
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	118
5.3.13.5	T319 expiry or Integrity check failure from lower layers while T319 is running	121
5.3.13.6	Cell re-selection or cell selection while T390, T319 or T302 is running (UE in RRC_INACTIVE)	122
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE	123
5.3.13.8	RNA update	123
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	123
5.3.13.10	Reception of the <i>RRCReject</i> by the UE	123
5.3.13.11	Inability to comply with <i>RRCResume</i>	123
5.3.13.12	Inter RAT cell reselection	123
5.3.14	Unified Access Control	124
5.3.14.1	General	124
5.3.14.2	Initiation	124
5.3.14.3	Void	126
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	126
5.3.14.5	Access barring check	126
5.3.15	RRC connection reject	127
5.3.15.1	Initiation	127
5.3.15.2	Reception of the <i>RRCReject</i> by the UE	127

5.4	Inter-RAT mobility.....	128
5.4.1	Introduction.....	128
5.4.2	Handover to NR.....	128
5.4.2.1	General.....	128
5.4.2.2	Initiation.....	128
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE.....	128
5.4.3	Mobility from NR.....	129
5.4.3.1	General.....	129
5.4.3.2	Initiation.....	129
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	129
5.4.3.4	Successful completion of the mobility from NR.....	130
5.4.3.5	Mobility from NR failure.....	130
5.5	Measurements.....	131
5.5.1	Introduction.....	131
5.5.2	Measurement configuration.....	133
5.5.2.1	General.....	133
5.5.2.2	Measurement identity removal.....	135
5.5.2.3	Measurement identity addition/modification.....	135
5.5.2.4	Measurement object removal.....	136
5.5.2.5	Measurement object addition/modification.....	136
5.5.2.6	Reporting configuration removal.....	138
5.5.2.7	Reporting configuration addition/modification.....	139
5.5.2.8	Quantity configuration.....	139
5.5.2.9	Measurement gap configuration.....	139
5.5.2.10	Reference signal measurement timing configuration.....	140
5.5.2.10a	RSSI measurement timing configuration.....	141
5.5.2.11	Measurement gap sharing configuration.....	141
5.5.3	Performing measurements.....	142
5.5.3.1	General.....	142
5.5.3.2	Layer 3 filtering.....	146
5.5.3.3	Derivation of cell measurement results.....	147
5.5.3.3a	Derivation of layer 3 beam filtered measurement results.....	147
5.5.4	Measurement reporting triggering.....	148
5.5.4.1	General.....	148
5.5.4.2	Event A1 (Serving becomes better than threshold).....	153
5.5.4.3	Event A2 (Serving becomes worse than threshold).....	153
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell).....	154
5.5.4.5	Event A4 (Neighbour becomes better than threshold).....	155
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2).....	155
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell).....	156
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold).....	157
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2).....	157
5.5.4.10	Event I1 (Interference becomes higher than threshold).....	158
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold).....	159
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold).....	159
5.5.4.13	Void.....	160
5.5.4.14	Void.....	160
5.5.5	Measurement reporting.....	160
5.5.5.1	General.....	160
5.5.5.2	Reporting of beam measurement information.....	167
5.5.5.3	Sorting of cell measurement results.....	168
5.5.6	Location measurement indication.....	169
5.5.6.1	General.....	169
5.5.6.2	Initiation.....	169
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message.....	169
5.5a	Logged Measurements.....	170
5.5a.1	Logged Measurement Configuration.....	170
5.5a.1.1	General.....	170
5.5a.1.2	Initiation.....	170
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE.....	170

5.5a.1.4	T330 expiry	171
5.5a.2	Release of Logged Measurement Configuration.....	171
5.5a.2.1	General	171
5.5a.2.2	Initiation.....	171
5.5a.3	Measurements logging.....	171
5.5a.3.1	General	171
5.5a.3.2	Initiation.....	171
5.6	UE capabilities	173
5.6.1	UE capability transfer	173
5.6.1.1	General	173
5.6.1.2	Initiation.....	174
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	174
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	174
5.6.1.5	Void.....	177
5.7	Other.....	177
5.7.1	DL information transfer	177
5.7.1.1	General	177
5.7.1.2	Initiation.....	177
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	177
5.7.1a	DL information transfer for MR-DC	178
5.7.1a.1	General	178
5.7.1a.2	Initiation.....	178
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message.....	178
5.7.2	UL information transfer	179
5.7.2.1	General	179
5.7.2.2	Initiation.....	179
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	179
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message.....	179
5.7.2a	UL information transfer for MR-DC	179
5.7.2a.1	General	179
5.7.2a.2	Initiation.....	180
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	180
5.7.2b	UL transfer of IRAT information.....	180
5.7.2b.1	General	180
5.7.2b.2	Initiation.....	180
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	181
5.7.3	SCG failure information	181
5.7.3.1	General	181
5.7.3.2	Initiation.....	181
5.7.3.3	Failure type determination for (NG)EN-DC	182
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	182
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	183
5.7.3a	EUTRA SCG failure information	185
5.7.3a.1	General	185
5.7.3a.2	Initiation.....	185
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message.....	185
5.7.3b	MCG failure information	186
5.7.3b.1	General	186
5.7.3b.2	Initiation.....	186
5.7.3b.3	Failure type determination	186
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message.....	187
5.7.3b.5	T316 expiry	188
5.7.4	UE Assistance Information	189
5.7.4.1	General	189
5.7.4.2	Initiation.....	189
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	193
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE.....	198
5.7.4a	Void	199
5.7.5	Failure information	199
5.7.5.1	General	199
5.7.5.2	Initiation.....	199
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message.....	199

5.7.6	DL message segment transfer	200
5.7.6.1	General	200
5.7.6.2	Initiation	200
5.7.6.3	Reception of <i>DL DedicatedMessageSegment</i> by the UE	200
5.7.7	UL message segment transfer	200
5.7.7.1	General	200
5.7.7.2	Initiation	201
5.7.7.3	Actions related to transmission of <i>UL DedicatedMessageSegment</i> message	201
5.7.8	Idle/inactive Measurements	201
5.7.8.1	General	201
5.7.8.1a	Measurement configuration	201
5.7.8.2	Void	202
5.7.8.2a	Performing measurements	202
5.7.8.3	T331 expiry or stop	205
5.7.8.4	Cell re-selection or cell selection while T331 is running	205
5.7.9	Mobility history information	206
5.7.9.1	General	206
5.7.9.2	Initiation	206
5.7.10	UE Information	206
5.7.10.1	General	206
5.7.10.2	Initiation	207
5.7.10.3	Reception of the <i>UE InformationRequest</i> message	207
5.7.10.4	Actions upon successful completion of random-access procedure	209
5.7.10.5	RA information determination for RA report and RLF report	209
5.7.12	IAB Other Information	210
5.7.12.1	General	210
5.7.12.2	Initiation	211
5.7.12.3	Actions related to transmission of <i>IAB OtherInformation</i> message	211
5.8	Sidelink	212
5.8.1	General	212
5.8.2	Conditions for NR sidelink communication operation	213
5.8.3	Sidelink UE information for NR sidelink communication	213
5.8.3.1	General	213
5.8.3.2	Initiation	214
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	215
5.8.4	Void	216
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication	216
5.8.5.1	General	216
5.8.5.2	Initiation	216
5.8.5.3	Transmission of SLSS	217
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	218
5.8.5a.1	General	218
5.8.5a.2	Initiation	219
5.8.6	Sidelink synchronisation reference	219
5.8.6.1	General	219
5.8.6.2	Selection and reselection of synchronisation reference	219
5.8.6.3	Sidelink communication transmission reference cell selection	222
5.8.7	Sidelink communication reception	222
5.8.8	Sidelink communication transmission	222
5.8.9	Sidelink RRC procedure	224
5.8.9.1	Sidelink RRC reconfiguration	224
5.8.9.1.1	General	224
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	225
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	226
5.8.9.1.4	Void	227
5.8.9.1.5	Void	227
5.8.9.1.6	Void	227
5.8.9.1.7	Void	227
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	227
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	227
5.8.9.1a	Sidelink radio bearer management	227
5.8.9.1a.1	Sidelink DRB release	227

5.8.9.1a.2	Sidelink DRB addition/modification	229
5.8.9.1a.3	Sidelink SRB release	230
5.8.9.1a.4	Sidelink SRB addition	230
5.8.9.2	Sidelink UE capability transfer	231
5.8.9.2.1	General	231
5.8.9.2.2	Initiation	231
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	231
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	231
5.8.9.3	Sidelink radio link failure related actions	232
5.8.9.4	Sidelink common control information	232
5.8.9.4.1	General	232
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	232
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	232
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	234
5.8.10	Sidelink measurement	234
5.8.10.1	Introduction	234
5.8.10.2	Sidelink measurement configuration	235
5.8.10.2.1	General	235
5.8.10.2.2	Sidelink measurement identity removal	235
5.8.10.2.3	Sidelink measurement identity addition/modification	235
5.8.10.2.4	Sidelink measurement object removal	236
5.8.10.2.5	Sidelink measurement object addition/modification	236
5.8.10.2.6	Sidelink reporting configuration removal	236
5.8.10.2.7	Sidelink reporting configuration addition/modification	237
5.8.10.2.8	Sidelink quantity configuration	237
5.8.10.3	Performing NR sidelink measurements	237
5.8.10.3.1	General	237
5.8.10.3.2	Derivation of NR sidelink measurement results	238
5.8.10.4	Sidelink measurement report triggering	238
5.8.10.4.1	General	238
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	239
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	239
5.8.10.5	Sidelink measurement reporting	240
5.8.10.5.1	General	240
5.8.11	Zone identity calculation	241
5.8.12	DFN derivation from GNSS	241
6	Protocol data units, formats and parameters (ASN.1)	242
6.1	General	242
6.1.1	Introduction	242
6.1.2	Need codes and conditions for optional downlink fields	242
6.1.3	General rules	245
6.2	RRC messages	245
6.2.1	General message structure	245
–	<i>NR-RRC-Definitions</i>	245
–	<i>BCCH-BCH-Message</i>	245
–	<i>BCCH-DL-SCH-Message</i>	246
–	<i>DL-CCCH-Message</i>	246
–	<i>DL-DCCH-Message</i>	247
–	<i>PCCH-Message</i>	247
–	<i>UL-CCCH-Message</i>	248
–	<i>UL-CCCH1-Message</i>	248
–	<i>UL-DCCH-Message</i>	249
6.2.2	Message definitions	251
–	<i>CounterCheck</i>	251
–	<i>CounterCheckResponse</i>	252
–	<i>DedicatedSIBRequest</i>	253
–	<i>DLDedicatedMessageSegment</i>	254
–	<i>DLInformationTransfer</i>	255
–	<i>DLInformationTransferMRDC</i>	256
–	<i>FailureInformation</i>	257
–	<i>IABOtherInformation</i>	258

–	LocationMeasurementIndication	261
–	LoggedMeasurementConfiguration	262
–	MCGFailureInformation	263
–	MeasurementReport	265
–	MIB	266
–	MobilityFromNRCommand	267
–	Paging	269
–	RRCReestablishment	270
–	RRCReestablishmentComplete	270
–	RRCReestablishmentRequest	271
–	RRCReconfiguration	272
–	RRCReconfigurationComplete	277
–	RRCReject	279
–	RRCRelease	280
–	RRCResume	284
–	RRCResumeComplete	286
–	RRCResumeRequest	288
–	RRCResumeRequest1	289
–	RRCSetup	290
–	RRCSetupComplete	291
–	RRCSetupRequest	292
–	RRCSystemInfoRequest	293
–	SCGFailureInformation	294
–	SCGFailureInformationEUTRA	296
–	SecurityModeCommand	297
–	SecurityModeComplete	298
–	SecurityModeFailure	298
–	SIB1	299
–	SidelinkUEInformationNR	302
–	SystemInformation	304
–	UEAssistanceInformation	305
–	UECapabilityEnquiry	312
–	UECapabilityInformation	313
–	UEInformationRequest	314
–	UEInformationResponse	315
–	ULDedicatedMessageSegment	325
–	ULInformationTransfer	326
–	ULInformationTransferIRAT	326
–	ULInformationTransferMRDC	327
6.3	RRC information elements	328
6.3.0	Parameterized types	328
–	SetupRelease	328
6.3.1	System information blocks	329
–	SIB2	329
–	SIB3	333
–	SIB4	334
–	SIB5	338
–	SIB6	341
–	SIB7	341
–	SIB8	342
–	SIB9	343
–	SIB10	344
–	SIB11	345
–	SIB12	345
–	SIB13	347
–	SIB14	348
6.3.1a	Positioning System information blocks	348
–	PosSystemInformation-r16-IEs	348
–	PosSI-SchedulingInfo	349
–	SIBpos	351
6.3.2	Radio resource control information elements	352
–	AdditionalSpectrumEmission	352

Alpha	352
AMF-Identifier	353
ARFCN-ValueEUTRA	353
ARFCN-ValueNR	353
ARFCN-ValueUTRA-FDD	354
AvailabilityCombinationsPerCell	354
AvailabilityIndicator	355
BAP-RoutingID	356
BeamFailureRecoveryConfig	356
BeamFailureRecoverySCellConfig	359
BetaOffsets	360
BH-LogicalChannelIdentity	361
BH-LogicalChannelIdentity-Ext	361
BH-RLC-ChannelConfig	362
BH-RLC-ChannelID	363
BSR-Config	363
BWP	364
BWP-Downlink	364
BWP-DownlinkCommon	365
BWP-DownlinkDedicated	366
BWP-Id	367
BWP-Uplink	368
BWP-UplinkCommon	368
BWP-UplinkDedicated	369
CellAccessRelatedInfo	372
CellAccessRelatedInfo-EUTRA-5GC	373
CellAccessRelatedInfo-EUTRA-EPC	374
CellGroupConfig	374
CellGroupId	379
CellIdentity	380
CellReselectionPriority	380
CellReselectionSubPriority	380
CGI-InfoEUTRA	381
CGI-InfoEUTRALogging	381
CGI-InfoNR	382
CGI-Info-Logging	383
CLI-RSSI-Range	383
CodebookConfig	384
CommonLocationInfo	387
CondReconfigId	388
CondReconfigToAddModList	389
ConditionalReconfiguration	389
ConfiguredGrantConfig	390
ConfiguredGrantConfigIndex	396
ConfiguredGrantConfigIndexMAC	396
ConnEstFailureControl	397
ControlResourceSet	397
ControlResourceSetId	400
ControlResourceSetZero	400
CrossCarrierSchedulingConfig	400
CSI-AperiodicTriggerStateList	402
CSI-FrequencyOccupation	403
CSI-IM-Resource	404
CSI-IM-ResourceId	405
CSI-IM-ResourceSet	405
CSI-IM-ResourceSetId	406
CSI-MeasConfig	406
CSI-ReportConfig	408
CSI-ReportConfigId	413
CSI-ResourceConfig	413
CSI-ResourceConfigId	414
CSI-ResourcePeriodicityAndOffset	414

–	CSI-RS-ResourceConfigMobility	415
–	CSI-RS-ResourceMapping	417
–	CSI-SemiPersistentOnPUSCH-TriggerStateList.....	418
–	CSI-SSB-ResourceSet.....	419
–	CSI-SSB-ResourceSetId.....	419
–	DedicatedNAS-Message.....	419
–	DMRS-DownlinkConfig	420
–	DMRS-UplinkConfig.....	421
–	DownlinkConfigCommon.....	423
–	DownlinkConfigCommonSIB	424
–	DownlinkPreemption.....	426
–	DRB-Identity	427
–	DRX-Config.....	427
–	DRX-ConfigSecondaryGroup.....	429
–	FilterCoefficient	430
–	FreqBandIndicatorNR.....	430
–	FrequencyInfoDL	431
–	FrequencyInfoDL-SIB.....	432
–	FrequencyInfoUL	432
–	FrequencyInfoUL-SIB.....	433
–	HighSpeedConfig	434
–	Hysteresis	435
–	InvalidSymbolPattern.....	435
–	I-RNTI-Value.....	436
–	LBT-FailureRecoveryConfig	436
–	LocationInfo	437
–	LocationMeasurementInfo.....	437
–	LogicalChannelConfig	439
–	LogicalChannelIdentity.....	442
–	MAC-CellGroupConfig	442
–	MeasConfig	444
–	MeasGapConfig	445
–	MeasGapSharingConfig.....	447
–	MeasId.....	448
–	MeasIdleConfig.....	448
–	MeasIdToAddModList.....	452
–	MeasObjectCLI	452
–	MeasObjectEUTRA.....	454
–	MeasObjectId	456
–	MeasObjectNR	457
–	MeasObjectNR-SL.....	462
–	MeasObjectToAddModList	463
–	MeasObjectUTRA-FDD.....	463
–	MeasResultCellListSFTD-NR.....	464
–	MeasResultCellListSFTD-EUTRA	465
–	MeasResults	465
–	MeasResult2EUTRA.....	470
–	MeasResult2NR.....	471
–	MeasResultIdleEUTRA	471
–	MeasResultIdleNR.....	472
–	MeasResultSCG-Failure	473
–	MeasResultsSL	474
–	MeasTriggerQuantityEUTRA.....	475
–	MobilityStateParameters.....	475
–	MsgA-ConfigCommon.....	476
–	MsgA-PUSCH-Config.....	477
–	MultiFrequencyBandListNR.....	480
–	MultiFrequencyBandListNR-SIB	481
–	NeedForGapsConfigNR.....	481
–	NextHopChainingCount.....	483
–	NG-5G-S-TMSI	483
–	NPN-Identity	484

–	NPN-IdentityInfoList	485
–	NR-NS-PmaxList	486
–	NZP-CSI-RS-Resource	486
–	NZP-CSI-RS-ResourceId	488
–	NZP-CSI-RS-ResourceSet	488
–	NZP-CSI-RS-ResourceSetId	489
–	P-Max	489
–	PCI-List	490
–	PCI-Range	490
–	PCI-RangeElement	490
–	PCI-RangeIndex	491
–	PCI-RangeIndexList	491
–	PDCCCH-Config	492
–	PDCCCH-ConfigCommon	493
–	PDCCCH-ConfigSIB1	495
–	PDCCCH-ServingCellConfig	496
–	PDCCP-Config	497
–	PDSCH-Config	503
–	PDSCH-ConfigCommon	508
–	PDSCH-ServingCellConfig	508
–	PDSCH-TimeDomainResourceAllocationList	510
–	PHR-Config	511
–	PhysCellId	512
–	PhysicalCellGroupConfig	513
–	PLMN-Identity	518
–	PLMN-IdentityInfoList	518
–	PLMN-IdentityList2	519
–	PRB-Id	520
–	PTRS-DownlinkConfig	520
–	PTRS-UplinkConfig	521
–	PUCCH-Config	522
–	PUCCH-ConfigCommon	528
–	PUCCH-ConfigurationList	529
–	PUCCH-PathlossReferenceRS-Id	530
–	PUCCH-PowerControl	530
–	PUCCH-SpatialRelationInfo	532
–	PUCCH-SpatialRelationInfo-Id	533
–	PUCCH-TPC-CommandConfig	533
–	PUSCH-Config	534
–	PUSCH-ConfigCommon	540
–	PUSCH-PowerControl	540
–	PUSCH-ServingCellConfig	544
–	PUSCH-TimeDomainResourceAllocationList	545
–	PUSCH-TPC-CommandConfig	547
–	Q-OffsetRange	547
–	Q-QualMin	548
–	Q-RxLevMin	548
–	QuantityConfig	548
–	RACH-ConfigCommon	550
–	RACH-ConfigCommonTwoStepRA	553
–	RACH-ConfigDedicated	556
–	RACH-ConfigGeneric	560
–	RACH-ConfigGenericTwoStepRA	561
–	RA-Prioritization	563
–	RadioBearerConfig	563
–	RadioLinkMonitoringConfig	567
–	RadioLinkMonitoringRS-Id	568
–	RAN-AreaCode	568
–	RateMatchPattern	568
–	RateMatchPatternId	570
–	RateMatchPatternLTE-CRS	571
–	ReferenceTimeInfo	571

STANDARD PREVIEW

(standards.iteh.ai)

ETSI TS 138 331 V16.6.0 (2021-10)

1. <https://standards.iteh.ai/catalog/standards/sist/07acf3d2-1e79-4e7d-8e6d-2b7c72949d72/etsi-ts-138-331-v16-6-0-2021-10>

–	<i>RejectWaitTime</i>	573
–	<i>RepetitionSchemeConfig</i>	573
–	<i>ReportConfigId</i>	574
–	<i>ReportConfigInterRAT</i>	574
–	<i>ReportConfigNR</i>	578
–	<i>ReportConfigNR-SL</i>	585
–	<i>ReportConfigToAddModList</i>	587
–	<i>ReportInterval</i>	587
–	<i>ReselectionThreshold</i>	588
–	<i>ReselectionThresholdQ</i>	588
–	<i>ResumeCause</i>	588
–	<i>RLC-BearerConfig</i>	589
–	<i>RLC-Config</i>	590
–	<i>RLF-TimersAndConstants</i>	592
–	<i>RNTI-Value</i>	593
–	<i>RSRP-Range</i>	593
–	<i>RSRQ-Range</i>	594
–	<i>RSSI-Range</i>	594
–	<i>SCellIndex</i>	594
–	<i>SchedulingRequestConfig</i>	595
–	<i>SchedulingRequestId</i>	596
–	<i>SchedulingRequestResourceConfig</i>	596
–	<i>SchedulingRequestResourceId</i>	597
–	<i>ScramblingId</i>	598
–	<i>SCS-SpecificCarrier</i>	598
–	<i>SDAP-Config</i>	599
–	<i>SearchSpace</i>	600
–	<i>SearchSpaceId</i>	605
–	<i>SearchSpaceZero</i>	605
–	<i>SecurityAlgorithmConfig</i>	606
–	<i>SemiStaticChannelAccessConfig</i>	606
–	<i>Sensor-LocationInfo</i>	607
–	<i>ServCellIndex</i>	607
–	<i>ServingCellConfig</i>	608
–	<i>ServingCellConfigCommon</i>	617
–	<i>ServingCellConfigCommonSIB</i>	619
–	<i>ShortI-RNTI-Value</i>	620
–	<i>ShortMAC-I</i>	621
–	<i>SINR-Range</i>	621
–	<i>SI-RequestConfig</i>	621
–	<i>SI-SchedulingInfo</i>	622
–	<i>SK-Counter</i>	624
–	<i>SlotFormatCombinationsPerCell</i>	624
–	<i>SlotFormatIndicator</i>	626
–	<i>S-NSSAI</i>	629
–	<i>SpeedStateScaleFactors</i>	629
–	<i>SPS-Config</i>	630
–	<i>SPS-ConfigIndex</i>	631
–	<i>SPS-PUCCH-AN</i>	632
–	<i>SPS-PUCCH-AN-List</i>	632
–	<i>SRB-Identity</i>	632
–	<i>SRS-CarrierSwitching</i>	633
–	<i>SRS-Config</i>	634
–	<i>SRS-RSRP-Range</i>	645
–	<i>SRS-TPC-CommandConfig</i>	645
–	<i>SSB-Index</i>	646
–	<i>SSB-MTC</i>	647
–	<i>SSB-PositionQCL-Relation</i>	648
–	<i>SSB-ToMeasure</i>	648
–	<i>SS-RSSI-Measurement</i>	649
–	<i>SubcarrierSpacing</i>	650
–	<i>TAG-Config</i>	650