

ETSI TS 124 301 V17.7.0 (2022-07)



**Universal Mobile Telecommunications System(UMTS) ;
LTE ;
5G ;
Non-Access-Stratum (NAS)
protocol for Evolved Packet System (EPS);
Stage 3
(3GPP TS 24.301 version 17.7.0 Release 17)**



ReferenceRTS/TSGC-0124301vh70

Keywords5G,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards-portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our
Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2022.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	21
1 Scope	23
2 References	23
3 Definitions and abbreviations.....	26
3.1 Definitions	26
3.2 Abbreviations	33
4 General	35
4.1 Overview	35
4.2 Linkage between the protocols for EPS mobility management and EPS session management	35
4.2.A Handling of NAS signalling low priority indication	36
4.3 UE mode of operation	36
4.3.1 General.....	36
4.3.2 Change of UE mode of operation	38
4.3.2.1 General.....	38
4.3.2.2 Change of UE's usage setting.....	40
4.3.2.3 Change of voice domain preference for E-UTRAN.....	41
4.3.2.4 Change or determination of IMS registration status.....	42
4.3.2.5 Change of configuration regarding the use of SMS.....	44
4.4 NAS security	45
4.4.1 General.....	45
4.4.2 Handling of EPS security contexts	45
4.4.2.1 General.....	45
4.4.2.2 Establishment of a mapped EPS security context during intersystem handover	46
4.4.2.3 Establishment of secure exchange of NAS messages	47
4.4.2.4 Change of security keys	49
4.4.2.5 Derivation of keys at CS to PS SRVCC handover from A/Gb mode to S1 mode or from Iu mode to S1 mode	50
4.4.3 Handling of NAS COUNT and NAS sequence number	51
4.4.3.1 General	51
4.4.3.2 Replay protection	52
4.4.3.3 Integrity protection and verification.....	52
4.4.3.4 Ciphering and deciphering.....	52
4.4.3.5 NAS COUNT wrap around	52
4.4.4 Integrity protection of NAS signalling messages.....	53
4.4.4.1 General	53
4.4.4.2 Integrity checking of NAS signalling messages in the UE	53
4.4.4.3 Integrity checking of NAS signalling messages in the MME	54
4.4.5 Ciphering of NAS signalling messages	56
4.5 Disabling and re-enabling of UE's E-UTRA capability	56
4.6 Applicability of procedures	59
4.6.1 Relay nodes.....	59
4.7 EPS mobility management and EPS session management in NB-S1 mode	59
4.8 EPS mobility management and EPS session management in WB-S1 mode for IoT.....	60
4.8.1 UE not using satellite E-UTRAN access	60
4.8.2 UE using satellite E-UTRAN access	61
4.9 Disabling and re-enabling of UE's NB-IoT capability	61
4.10 Support of MUSIM features.....	62
4.11 Satellite access for CIoT.....	62
4.11.1 General.....	62
4.11.2 Handling list of "PLMNs not allowed to operate at the present UE location"	62

5	Elementary procedures for EPS mobility management.....	63
5.1	Overview	63
5.1.1	General.....	63
5.1.2	Types of EMM procedures	64
5.1.3	EMM sublayer states	65
5.1.3.1	General	65
5.1.3.2	EMM sublayer states in the UE.....	65
5.1.3.2.1	General	65
5.1.3.2.2	Main states.....	65
5.1.3.2.2.1	EMM-NUL	65
5.1.3.2.2.2	EMM-DEREGISTERED	65
5.1.3.2.2.3	EMM-REGISTERED-INITIATED	65
5.1.3.2.2.4	EMM-REGISTERED	65
5.1.3.2.2.5	EMM-DEREGISTERED-INITIATED	66
5.1.3.2.2.6	EMM-TRACKING-AREA-UPDATING-INITIATED	66
5.1.3.2.2.7	EMM-SERVICE-REQUEST-INITIATED.....	66
5.1.3.2.3	Substates of state EMM-DEREGISTERED	67
5.1.3.2.3.1	General.....	67
5.1.3.2.3.2	EMM-DEREGISTERED.NORMAL-SERVICE	67
5.1.3.2.3.3	EMM-DEREGISTERED.LIMITED-SERVICE	67
5.1.3.2.3.4	EMM-DEREGISTERED.ATTEMPTING-TO-ATTACH.....	67
5.1.3.2.3.5	EMM-DEREGISTERED.PLMN-SEARCH.....	67
5.1.3.2.3.6	EMM-DEREGISTERED.NO-IMSI	67
5.1.3.2.3.7	EMM-DEREGISTERED.ATTACH-NEEDED.....	67
5.1.3.2.3.8	EMM-DEREGISTERED.NO-CELL-AVAILABLE	67
5.1.3.2.3.9	EMM-DEREGISTERED.eCALL-INACTIVE.....	67
5.1.3.2.4	Substates of state EMM-REGISTERED	68
5.1.3.2.4.1	General.....	68
5.1.3.2.4.2	EMM-REGISTERED.NORMAL-SERVICE	68
5.1.3.2.4.3	EMM-REGISTERED.ATTEMPTING-TO-UPDATE	68
5.1.3.2.4.4	EMM-REGISTERED.LIMITED-SERVICE	68
5.1.3.2.4.5	EMM-REGISTERED.PLMN-SEARCH	68
5.1.3.2.4.6	EMM-REGISTERED.UPDATE-NEEDED	68
5.1.3.2.4.7	EMM-REGISTERED.NO-CELL-AVAILABLE	68
5.1.3.2.4.8	EMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM.....	68
5.1.3.2.4.9	EMM-REGISTERED.IMSI-DETACH-INITIATED	69
5.1.3.3	EPS update status	69
5.1.3.4	EMM sublayer states in the MME	69
5.1.3.4.1	EMM-DEREGISTERED.....	69
5.1.3.4.2	EMM-COMMON-PROCEDURE-INITIATED.....	69
5.1.3.4.3	EMM-REGISTERED	69
5.1.3.4.4	EMM-DEREGISTERED-INITIATED	70
5.1.4	Coordination between EMM and GMM.....	70
5.1.5	Coordination between EMM and MM.....	71
5.2	Behaviour of the UE in state EMM-DEREGISTERED and state EMM-REGISTERED	71
5.2.1	General.....	71
5.2.2	UE behaviour in state EMM-DEREGISTERED	71
5.2.2.1	General	71
5.2.2.2	Primary substate selection.....	72
5.2.2.2.1	Selection of the substate after power on.....	72
5.2.2.3	Detailed description of UE behaviour in state EMM-DEREGISTERED	72
5.2.2.3.1	NORMAL-SERVICE.....	72
5.2.2.3.2	LIMITED-SERVICE.....	72
5.2.2.3.3	ATTEMPTING-TO-ATTACH	72
5.2.2.3.4	PLMN-SEARCH.....	73
5.2.2.3.5	NO-IMSI	73
5.2.2.3.6	ATTACH-NEEDED.....	73
5.2.2.3.7	NO-CELL-AVAILABLE	73
5.2.2.3.8	eCALL-INACTIVE.....	74
5.2.2.4	Substate when back to state EMM-DEREGISTERED from another EMM state	74
5.2.3	UE behaviour in state EMM-REGISTERED.....	75
5.2.3.1	General.....	75

5.2.3.2	Detailed description of UE behaviour in state EMM-REGISTERED.....	75
5.2.3.2.1	NORMAL-SERVICE.....	75
5.2.3.2.2	ATTEMPTING-TO-UPDATE.....	75
5.2.3.2.3	LIMITED-SERVICE.....	76
5.2.3.2.4	PLMN-SEARCH.....	76
5.2.3.2.5	UPDATE-NEEDED.....	76
5.2.3.2.6	NO-CELL-AVAILABLE.....	77
5.2.3.2.7	ATTEMPTING-TO-UPDATE-MM.....	77
5.2.3.2.8	IMSI-DETACH-INITIATED.....	77
5.3	General on elementary EMM procedures.....	78
5.3.1	EMM modes and NAS signalling connection.....	78
5.3.1.1	Establishment of the NAS signalling connection.....	78
5.3.1.2	Release of the NAS signalling connection.....	79
5.3.1.2.1	General.....	79
5.3.1.2.2	UE is using EPS services with control plane CIoT EPS optimization.....	82
5.3.1.3	Suspend and resume of the NAS signalling connection.....	82
5.3.2	Lists of forbidden tracking areas.....	83
5.3.3	List of forbidden PLMNs for attach in S101 mode.....	83
5.3.3a	Forbidden PLMNs for EPS services.....	84
5.3.4	Equivalent PLMNs list.....	84
5.3.5	Handling of the periodic tracking area update timer and mobile reachable timer (S1 mode only).....	84
5.3.6	Handling of timer T3402.....	86
5.3.7	Handling of the Local Emergency Numbers List and the Extended Local Emergency Numbers List.....	86
5.3.7a	Specific requirements for UE configured to use timer T3245.....	87
5.3.7b	Specific requirements for UE when receiving non-integrity protected reject messages.....	88
5.3.8	Abnormal cases in the UE.....	91
5.3.9	Handling of NAS level mobility management congestion control.....	91
5.3.9A	Handling of congestion control for transport of user data via the control plane.....	92
5.3.10	Access class control.....	92
5.3.11	Power saving mode.....	93
5.3.12	Extended idle-mode DRX cycle.....	94
5.3.13	Interaction between power saving mode and extended idle mode DRX cycle.....	94
5.3.14	Dedicated core network.....	94
5.3.15	CIoT EPS optimizations.....	95
5.3.16	Restriction on use of enhanced coverage.....	96
5.3.17	Service Gap Control.....	97
5.3.18	Restricted local operator services.....	98
5.3.19	Core Network selection and redirection for UEs using CIoT optimizations.....	99
5.3.19.1	Core network selection.....	99
5.3.19.2	Redirection of the UE by the core network.....	99
5.3.20	UE radio capability signalling optimisation.....	99
5.3.21	Wake-up signal assistance.....	100
5.3.22	Handling multiple tracking area codes from the lower layers.....	101
5.4	EMM common procedures.....	102
5.4.1	GUTI reallocation procedure.....	102
5.4.1.1	General.....	102
5.4.1.2	GUTI reallocation initiation by the network.....	102
5.4.1.3	GUTI reallocation completion by the UE.....	103
5.4.1.4	GUTI reallocation completion by the network.....	103
5.4.1.5	Abnormal cases in the UE.....	103
5.4.1.6	Abnormal cases on the network side.....	104
5.4.2	Authentication procedure.....	105
5.4.2.1	General.....	105
5.4.2.2	Authentication initiation by the network.....	105
5.4.2.3	Authentication response by the UE.....	106
5.4.2.4	Authentication completion by the network.....	107
5.4.2.5	Authentication not accepted by the network.....	107
5.4.2.6	Authentication not accepted by the UE.....	108
5.4.2.7	Abnormal cases.....	109
5.4.3	Security mode control procedure.....	113
5.4.3.1	General.....	113
5.4.3.2	NAS security mode control initiation by the network.....	114

5.4.3.3	NAS security mode command accepted by the UE.....	116
5.4.3.4	NAS security mode control completion by the network	118
5.4.3.5	NAS security mode command not accepted by the UE.....	118
5.4.3.6	Abnormal cases in the UE.....	118
5.4.3.7	Abnormal cases on the network side.....	119
5.4.4	Identification procedure.....	119
5.4.4.1	General.....	119
5.4.4.2	Identification initiation by the network.....	120
5.4.4.3	Identification response by the UE	120
5.4.4.4	Identification completion by the network	120
5.4.4.5	Abnormal cases in the UE.....	120
5.4.4.6	Abnormal cases on the network side.....	121
5.4.5	EMM information procedure	122
5.4.5.1	General.....	122
5.4.5.2	EMM information procedure initiation by the network	122
5.4.5.3	EMM information procedure in the UE	122
5.4.5.4	Abnormal cases on the network side.....	122
5.5	EMM specific procedures	122
5.5.1	Attach procedure.....	122
5.5.1.1	General.....	122
5.5.1.2	Attach procedure for EPS services.....	124
5.5.1.2.1	General	124
5.5.1.2.2	Attach procedure initiation	124
5.5.1.2.3	EMM common procedure initiation	129
5.5.1.2.4	Attach accepted by the network.....	129
5.5.1.2.4A	Attach successful for EPS services and not accepted for SMS services.....	136
5.5.1.2.5	Attach not accepted by the network.....	137
5.5.1.2.5A	Attach for emergency bearer services not accepted by the network.....	143
5.5.1.2.5B	Attach for initiating a PDN connection for emergency bearer services not accepted by the network.....	145
5.5.1.2.5B1	Attach by a UE transferring an emergency PDU session using a standalone PDN CONNECTIVITY REQUEST message	145
5.5.1.2.5C	Attach for access to RLOS not accepted by the network.....	146
5.5.1.2.6	Abnormal cases in the UE	146
5.5.1.2.6A	Abnormal cases in the UE, SMS services not accepted.....	150
5.5.1.2.7	Abnormal cases on the network side	151
5.5.1.3	Combined attach procedure for EPS services and non-EPS services (S1 mode only)	152
5.5.1.3.1	General	152
5.5.1.3.2	Combined attach procedure initiation.....	153
5.5.1.3.3	EMM common procedure initiation	153
5.5.1.3.4	Combined attach accepted by the network	153
5.5.1.3.4.1	General.....	153
5.5.1.3.4.2	Combined attach successful	153
5.5.1.3.4.3	Combined attach successful for EPS services only.....	154
5.5.1.3.5	Combined attach not accepted by the network	156
5.5.1.3.6	Abnormal cases in the UE	161
5.5.1.3.7	Abnormal cases on the network side	162
5.5.2	Detach procedure	162
5.5.2.1	General.....	162
5.5.2.2	UE initiated detach procedure	163
5.5.2.2.1	UE initiated detach procedure initiation	163
5.5.2.2.2	UE initiated detach procedure completion for EPS services only	164
5.5.2.2.3	UE initiated combined detach procedure completion.....	165
5.5.2.2.4	Abnormal cases in the UE	165
5.5.2.2.5	Abnormal cases on the network side	167
5.5.2.3	Network initiated detach procedure	167
5.5.2.3.1	Network initiated detach procedure initiation	167
5.5.2.3.2	Network initiated detach procedure completion by the UE.....	168
5.5.2.3.3	Network initiated detach procedure completion by the network.....	173
5.5.2.3.4	Abnormal cases in the UE	173
5.5.2.3.5	Abnormal cases on the network side	174
5.5.3	Tracking area updating procedure (S1 mode only).....	175

5.5.3.1	General	175
5.5.3.2	Normal and periodic tracking area updating procedure	177
5.5.3.2.1	General	177
5.5.3.2.2	Normal and periodic tracking area updating procedure initiation	177
5.5.3.2.3	EMM common procedure initiation	184
5.5.3.2.4	Normal and periodic tracking area updating procedure accepted by the network	185
5.5.3.2.4A	Tracking area updating successful for EPS services and not accepted for SMS services	196
5.5.3.2.5	Normal and periodic tracking area updating procedure not accepted by the network	197
5.5.3.2.5A	Tracking area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network	205
5.5.3.2.5B	Tracking area updating for access to RLOS not accepted by the network	205
5.5.3.2.6	Abnormal cases in the UE	206
5.5.3.2.6A	Abnormal cases in the UE, SMS services not accepted	212
5.5.3.2.7	Abnormal cases on the network side	212
5.5.3.3	Combined tracking area updating procedure	214
5.5.3.3.1	General	214
5.5.3.3.2	Combined tracking area updating procedure initiation	215
5.5.3.3.3	EMM common procedure initiation	217
5.5.3.3.4	Combined tracking area updating procedure accepted by the network	217
5.5.3.3.4.1	General	217
5.5.3.3.4.2	Combined tracking area updating successful	218
5.5.3.3.4.3	Combined tracking area updating successful for EPS services only	219
5.5.3.3.5	Combined tracking area updating procedure not accepted by the network	221
5.5.3.3.6	Abnormal cases in the UE	229
5.5.3.3.7	Abnormal cases on the network side	230
5.5.4	eCall inactivity procedure	230
5.5.5	Tracking area update request message (for N1 mode only)	230
5.5.6	Attach request message (for N1 mode only)	230
5.6	EMM connection management procedures (S1 mode only)	231
5.6.1	Service request procedure	231
5.6.1.1	General	231
5.6.1.2	Service request procedure initiation	236
5.6.1.2.1	UE is not using EPS services with control plane CIoT EPS optimization	236
5.6.1.2.2	UE is using EPS services with control plane CIoT EPS optimization	237
5.6.1.3	EMM common procedure initiation	238
5.6.1.4	Service request procedure accepted by the network	238
5.6.1.4.1	UE is not using EPS services with control plane CIoT EPS optimization	238
5.6.1.4.2	UE is using EPS services with control plane CIoT EPS optimization	240
5.6.1.5	Service request procedure not accepted by the network	245
5.6.1.5A	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network	254
5.6.1.5B	Service request procedure for UE attached for access to RLOS not accepted by the network	254
5.6.1.6	Abnormal cases in the UE	255
5.6.1.7	Abnormal cases on the network side	262
5.6.2	Paging procedure	263
5.6.2.1	General	263
5.6.2.2	Paging for EPS services	263
5.6.2.2.1	Paging for EPS services through E-UTRAN using S-TMSI	263
5.6.2.2.2	Paging for EPS services through E-UTRAN using IMSI	266
5.6.2.3	Paging for CS fallback to A/Gb or Iu mode	267
5.6.2.3.1	General	267
5.6.2.3.2	Abnormal cases in the UE	268
5.6.2.3.3	Abnormal cases on the network side	268
5.6.2.4	Paging for SMS	268
5.6.3	Transport of NAS messages procedure	269
5.6.3.1	General	269
5.6.3.2	UE initiated transport of NAS messages	269
5.6.3.3	Network initiated transport of NAS messages	269
5.6.3.4	Abnormal cases in the UE	270
5.6.3.5	Abnormal cases on the network side	270
5.6.4	Generic transport of NAS messages procedure	270
5.6.4.1	General	270

5.6.4.2	UE initiated generic transport of NAS messages	270
5.6.4.3	Network initiated transport of NAS messages	271
5.6.4.4	Abnormal cases in the UE	271
5.6.4.5	Abnormal cases on the network side	271
5.7	Reception of an EMM STATUS message by an EMM entity	271
6	Elementary procedures for EPS session management	272
6.1	Overview	272
6.1.1	General	272
6.1.2	Types of ESM procedures	273
6.1.3	ESM sublayer states	274
6.1.3.1	General	274
6.1.3.2	ESM sublayer states in the UE	274
6.1.3.2.1	BEARER CONTEXT INACTIVE	274
6.1.3.2.2	BEARER CONTEXT ACTIVE	274
6.1.3.2.3	PROCEDURE TRANSACTION INACTIVE	274
6.1.3.2.4	PROCEDURE TRANSACTION PENDING	274
6.1.3.3	ESM sublayer states in the MME	275
6.1.3.3.1	BEARER CONTEXT INACTIVE	275
6.1.3.3.2	BEARER CONTEXT ACTIVE PENDING	275
6.1.3.3.3	BEARER CONTEXT ACTIVE	275
6.1.3.3.4	BEARER CONTEXT INACTIVE PENDING	275
6.1.3.3.5	BEARER CONTEXT MODIFY PENDING	275
6.1.3.3.6	PROCEDURE TRANSACTION INACTIVE	276
6.1.3.3.7	PROCEDURE TRANSACTION PENDING	276
6.1.4	Coordination between ESM and SM	276
6.1.4A	Coordination between ESM and 5GSM	277
6.1.5	Coordination between ESM and EMM for supporting ISR	277
6.2	IP address allocation	277
6.2.1	General	277
6.2.2	IP address allocation via NAS signalling	278
6.2A	IP header compression	279
6.3	General on elementary ESM procedures	279
6.3.1	Services provided by lower layers	279
6.3.2	Principles of address handling for ESM procedures	279
6.3.3	Abnormal cases in the UE	282
6.3.4	Abnormal cases in the network	283
6.3.5	Handling of APN based congestion control	283
6.3.5A	Handling of group specific session management congestion control	283
6.3.6	Handling of network rejection not due to APN based congestion control	284
6.3.7	Handling of WLAN offload control	284
6.3.8	Handling of serving PLMN rate control	284
6.3.9	Handling of APN rate control	285
6.3.10	Handling of 3GPP PS data off	285
6.3.11	Handling of Reliable Data Service	286
6.3.12	Handling of Ethernet PDN type	287
6.3.13	Handling of Uncrewed aerial vehicle identification, authentication, and authorization	287
6.3.13.1	General	287
6.3.13.2	Authentication and authorization of UAV	287
6.3.13.3	Authorization of C2 communication	287
6.3.13.4	Authorization of UAV flight	287
6.4	Network initiated ESM procedures	288
6.4.1	Default EPS bearer context activation procedure	288
6.4.1.1	General	288
6.4.1.2	Default EPS bearer context activation initiated by the network	288
6.4.1.3	Default EPS bearer context activation accepted by the UE	288
6.4.1.4	Default EPS bearer context activation not accepted by the UE	290
6.4.1.5	Abnormal cases in the UE	290
6.4.1.6	Abnormal cases on the network side	291
6.4.2	Dedicated EPS bearer context activation procedure	291
6.4.2.1	General	291
6.4.2.2	Dedicated EPS bearer context activation initiated by the network	292

6.4.2.3	Dedicated EPS bearer context activation accepted by the UE	292
6.4.2.4	Dedicated EPS bearer context activation not accepted by the UE	293
6.4.2.5	Abnormal cases in the UE	294
6.4.2.6	Abnormal cases on the network side	295
6.4.3	EPS bearer context modification procedure	295
6.4.3.1	General	295
6.4.3.2	EPS bearer context modification initiated by the network	296
6.4.3.3	EPS bearer context modification accepted by the UE	296
6.4.3.4	EPS bearer context modification not accepted by the UE	299
6.4.3.5	Abnormal cases in the UE	301
6.4.3.6	Abnormal cases on the network side	301
6.4.4	EPS bearer context deactivation procedure	302
6.4.4.1	General	302
6.4.4.2	EPS bearer context deactivation initiated by the network	302
6.4.4.3	EPS bearer context deactivation accepted by the UE	303
6.4.4.4	Abnormal cases in the UE	305
6.4.4.5	Abnormal cases on the network side	305
6.4.4.6	Local EPS bearer context deactivation without NAS signalling	306
6.5	UE requested ESM procedures	307
6.5.0	General	307
6.5.1	UE requested PDN connectivity procedure	308
6.5.1.1	General	308
6.5.1.2	UE requested PDN connectivity procedure initiation	309
6.5.1.3	UE requested PDN connectivity procedure accepted by the network	312
6.5.1.4	UE requested PDN connectivity procedure not accepted by the network	314
6.5.1.4.1	General	314
6.5.1.4.2	Handling of network rejection due to ESM cause #26	315
6.5.1.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	318
6.5.1.4A	Handling the maximum number of active EPS bearer contexts	324
6.5.1.4B	Void	324
6.5.1.4C	Handling the maximum number of active user plane radio bearers in NB-S1 mode	324
6.5.1.5	Abnormal cases in the UE	325
6.5.1.6	Abnormal cases on the network side	325
6.5.1.7	Handling PDN connectivity request for UE configured for dual priority	326
6.5.2	UE requested PDN disconnect procedure	327
6.5.2.1	General	327
6.5.2.2	UE requested PDN disconnection procedure initiation	327
6.5.2.3	UE requested PDN disconnection procedure accepted by the network	327
6.5.2.4	UE requested PDN disconnection procedure not accepted by the network	328
6.5.2.5	Abnormal cases in the UE	328
6.5.2.6	Abnormal cases on the network side	328
6.5.3	UE requested bearer resource allocation procedure	329
6.5.3.1	General	329
6.5.3.2	UE requested bearer resource allocation procedure initiation	329
6.5.3.3	UE requested bearer resource allocation procedure accepted by the network	330
6.5.3.4	UE requested bearer resource allocation procedure not accepted by the network	330
6.5.3.4.1	General	330
6.5.3.4.2	Handling of network rejection due to ESM cause #26	332
6.5.3.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	333
6.5.3.4A	Handling the maximum number of active EPS bearer contexts	335
6.5.3.5	Abnormal cases in the UE	336
6.5.3.6	Abnormal cases on the network side	336
6.5.4	UE requested bearer resource modification procedure	336
6.5.4.1	General	336
6.5.4.2	UE requested bearer resource modification procedure initiation	337
6.5.4.3	UE requested bearer resource modification procedure accepted by the network	340
6.5.4.4	UE requested bearer resource modification procedure not accepted by the network	340
6.5.4.4.1	General	340
6.5.4.4.2	Handling of network rejection due to ESM cause #26	343
6.5.4.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	344
6.5.4.5	Abnormal cases in the UE	346
6.5.4.6	Abnormal cases on the network side	347

6.5.5	Handling session management request for UE configured for dual priority	348
6.6	Miscellaneous procedures	348
6.6.1	Exchange of protocol configuration options	348
6.6.1.1	General	348
6.6.1.2	ESM information request procedure	349
6.6.1.2.1	General	349
6.6.1.2.2	ESM information request initiated by the network	349
6.6.1.2.3	ESM information request completion by the UE	350
6.6.1.2.4	ESM information request completion by the network	350
6.6.1.2.5	Abnormal cases in the UE	350
6.6.1.2.6	Abnormal cases on the network side	350
6.6.1.3	Exchange of protocol configuration options in other messages	350
6.6.2	Notification procedure	351
6.6.2.1	General	351
6.6.2.2	Notification procedure initiation by the network	351
6.6.2.3	Notification procedure in the UE	351
6.6.2.4	Abnormal cases on the network side	351
6.6.3	Remote UE Report procedure	351
6.6.3.1	General	351
6.6.3.2	Remote UE Report initiated by the UE	351
6.6.3.3	Remote UE Report completion by the network	352
6.6.3.4	Remote UE Report completion by the UE	352
6.6.3.5	Abnormal cases in the UE	352
6.6.3.6	Abnormal cases on the network side	352
6.6.4	Transport of user data via the control plane procedure	352
6.6.4.1	General	352
6.6.4.2	UE initiated transport of user data via the control plane	353
6.6.4.3	Network initiated transport of user data via the control plane	353
6.6.4.4	Abnormal cases in the UE	354
6.6.4.5	Abnormal cases on the network side	354
6.7	Reception of an ESM STATUS message by an ESM entity	354
7	Handling of unknown, unforeseen, and erroneous protocol data	355
7.1	General	355
7.2	Message too short	356
7.3	Unknown or unforeseen procedure transaction identity or EPS bearer identity	356
7.3.1	Procedure transaction identity	356
7.3.2	EPS bearer identity	357
7.4	Unknown or unforeseen message type	359
7.5	Non-semantic mandatory information element errors	359
7.5.1	Common procedures	359
7.5.2	EPS mobility management	360
7.5.3	EPS session management	360
7.6	Unknown and unforeseen IEs in the non-imperative message part	360
7.6.1	IEs unknown in the message	360
7.6.2	Out of sequence IEs	360
7.6.3	Repeated IEs	361
7.7	Non-imperative message part errors	361
7.7.1	Syntactically incorrect optional IEs	361
7.7.2	Conditional IE errors	361
7.8	Messages with semantically incorrect contents	361
8	Message functional definitions and contents	362
8.1	Overview	362
8.2	EPS mobility management messages	363
8.2.1	Attach accept	363
8.2.1.1	Message definition	363
8.2.1.2	GUTI	366
8.2.1.3	Location area identification	366
8.2.1.4	MS identity	366
8.2.1.5	EMM cause	366
8.2.1.6	T3402 value	366

8.2.1.7	T3423 value.....	366
8.2.1.8	Equivalent PLMNs.....	366
8.2.1.9	Emergency number list	366
8.2.1.9A	Extended emergency number list	366
8.2.1.10	EPS network feature support.....	366
8.2.1.11	Additional update result	367
8.2.1.12	T3412 extended value	367
8.2.1.13	T3324 value.....	367
8.2.1.14	Extended DRX parameters.....	367
8.2.1.15	DCN-ID.....	367
8.2.1.16	SMS services status.....	367
8.2.1.17	Non-3GPP NW provided policies	367
8.2.1.18	T3448 value.....	367
8.2.1.19	Network policy.....	367
8.2.1.20	T3447 value.....	367
8.2.1.21	Ciphering key data	368
8.2.1.22	UE radio capability ID	368
8.2.1.23	UE radio capability ID deletion indication.....	368
8.2.1.24	Negotiated WUS assistance information.....	368
8.2.1.25	Negotiated DRX parameter in NB-S1 mode.....	368
8.2.1.26	Negotiated IMSI offset.....	368
8.2.1.27	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	368
8.2.1.28	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service".....	368
8.2.2	Attach complete	368
8.2.3	Attach reject.....	369
8.2.3.1	Message definition	369
8.2.3.2	ESM message container	369
8.2.3.3	T3346 value.....	369
8.2.3.4	T3402 value.....	370
8.2.3.5	Extended EMM cause	370
8.2.3.6	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	370
8.2.3.7	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service".....	370
8.2.4	Attach request	370
8.2.4.1	Message definition	370
8.2.4.2	Old P-TMSI signature	373
8.2.4.3	Additional GUTI	373
8.2.4.4	Last visited registered TAI.....	373
8.2.4.5	DRX parameter	373
8.2.4.6	MS network capability	373
8.2.4.7	Old location area identification.....	373
8.2.4.8	TMSI status	373
8.2.4.9	Mobile station classmark 2.....	373
8.2.4.10	Mobile station classmark 3.....	373
8.2.4.11	Supported Codecs	373
8.2.4.12	Additional update type	373
8.2.4.13	Voice domain preference and UE's usage setting.....	374
8.2.4.14	Device properties	374
8.2.4.15	Old GUTI type	374
8.2.4.16	MS network feature support.....	374
8.2.4.17	TMSI based NRI container	374
8.2.4.18	T3324 value.....	374
8.2.4.19	T3412 extended value	374
8.2.4.20	Extended DRX parameters.....	374
8.2.4.21	UE additional security capability	374
8.2.4.22	UE status	374
8.2.4.23	Additional information requested.....	374
8.2.4.24	N1 UE network capability.....	374
8.2.4.25	UE radio capability ID availability IE.....	374
8.2.4.26	Requested WUS assistance information.....	375
8.2.4.27	DRX parameter in NB-S1 mode	375
8.2.4.28	Requested IMSI offset.....	375
8.2.5	Authentication failure	375

8.2.5.1	Message definition	375
8.2.5.2	Authentication failure parameter.....	375
8.2.6	Authentication reject.....	375
8.2.7	Authentication request	376
8.2.8	Authentication response.....	376
8.2.9	CS service notification.....	377
8.2.9.1	Message definition	377
8.2.9.2	CLI	377
8.2.9.3	SS Code.....	377
8.2.9.4	LCS indicator	377
8.2.9.5	LCS client identity	377
8.2.10	Detach accept.....	377
8.2.10.1	Detach accept (UE originating detach)	377
8.2.10.2	Detach accept (UE terminated detach)	378
8.2.11	Detach request	378
8.2.11.1	Detach request (UE originating detach)	378
8.2.11.2	Detach request (UE terminated detach).....	379
8.2.11.2.1	Message definition.....	379
8.2.11.2.2	EMM cause.....	379
8.2.11.2.3	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	379
8.2.11.2.4	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	379
8.2.12	Downlink NAS Transport.....	379
8.2.13	EMM information.....	380
8.2.13.1	Message definition	380
8.2.13.2	Full name for network.....	380
8.2.13.3	Short name for network.....	380
8.2.13.4	Local time zone.....	381
8.2.13.5	Universal time and local time zone	381
8.2.13.6	Network daylight saving time	381
8.2.14	EMM status.....	381
8.2.15	Extended service request	381
8.2.15.1	Message definition	381
8.2.15.2	CSFB response	382
8.2.15.3	EPS bearer context status	382
8.2.15.4	Device properties	382
8.2.15.5	UE request type	382
8.2.15.6	Paging restriction	382
8.2.16	GUTI reallocation command	383
8.2.16.1	Message definition	383
8.2.16.2	TAI list	383
8.2.16.3	DCN-ID.....	383
8.2.16.4	UE radio capability ID	383
8.2.16.5	UE radio capability ID deletion indication.....	383
8.2.17	GUTI reallocation complete	383
8.2.18	Identity request	384
8.2.19	Identity response.....	384
8.2.20	Security mode command	385
8.2.20.1	Message definition	385
8.2.20.2	IMEISV request	385
8.2.20.3	Replayed nonce _{UE}	386
8.2.20.4	Nonce _{MME}	386
8.2.20.5	Hash _{MME}	386
8.2.20.6	Replayed UE additional security capability	386
8.2.20.7	UE radio capability ID request.....	386
8.2.21	Security mode complete.....	386
8.2.21.1	Message definition	386
8.2.21.2	IMEISV	386
8.2.21.3	Replayed NAS message container	387
8.2.21.4	UE radio capability ID	387
8.2.22	Security mode reject	387
8.2.23	Security protected NAS message.....	387
8.2.24	Service reject	388

8.2.24.1	Message definition	388
8.2.24.2	T3442 value.....	388
8.2.24.3	T3346 value.....	388
8.2.24.4	T3448 value.....	388
8.2.24.5	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	388
8.2.24.6	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	388
8.2.25	Service request.....	389
8.2.26	Tracking area update accept.....	389
8.2.26.1	Message definition	389
8.2.26.2	T3412 value.....	392
8.2.26.3	GUTI.....	392
8.2.26.4	TAI list	392
8.2.26.5	EPS bearer context status	392
8.2.26.6	Location area identification.....	392
8.2.26.7	MS identity.....	392
8.2.26.8	EMM cause	392
8.2.26.9	T3402 value.....	392
8.2.26.10	T3423 value.....	392
8.2.26.11	Equivalent PLMNs.....	393
8.2.26.12	Emergency number list	393
8.2.26.12A	Extended emergency number list	393
8.2.26.13	EPS network feature support.....	393
8.2.26.14	Additional update result	393
8.2.26.15	T3412 extended value	393
8.2.26.16	T3324 value.....	393
8.2.26.17	Extended DRX parameters.....	393
8.2.26.18	DCN-ID.....	393
8.2.26.19	SMS services status.....	394
8.2.26.20	Non-3GPP NW provided policies	394
8.2.26.21	T3448 value.....	394
8.2.26.22	Network policy.....	394
8.2.26.23	T3447 value.....	394
8.2.26.24	Ciphering key data	394
8.2.26.25	UE radio capability ID	394
8.2.26.26	UE radio capability ID deletion indication.....	394
8.2.26.27	Negotiated WUS assistance information.....	394
8.2.26.28	Negotiated DRX parameter in NB-S1 mode	394
8.2.26.29	Negotiated IMSI offset.....	395
8.2.26.30	EPS additional request result.....	395
8.2.26.31	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	395
8.2.26.32	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	395
8.2.27	Tracking area update complete	395
8.2.28	Tracking area update reject.....	395
8.2.28.1	Message definition	395
8.2.28.2	T3346 value.....	396
8.2.28.3	Extended EMM cause	396
8.2.28.4	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	396
8.2.28.5	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	396
8.2.29	Tracking area update request	396
8.2.29.1	Message definition	396
8.2.29.2	Non-current native NAS key set identifier.....	399
8.2.29.3	GPRS ciphering key sequence number	399
8.2.29.4	Old P-TMSI signature.....	399
8.2.29.5	Additional GUTI	399
8.2.29.6	Nonce _{UE}	399
8.2.29.7	UE network capability.....	399
8.2.29.8	Last visited registered TAI.....	399
8.2.29.9	DRX parameter	400
8.2.29.10	UE radio capability information update needed.....	400
8.2.29.11	EPS bearer context status	400
8.2.29.12	MS network capability	400
8.2.29.13	Old location area identification	400

8.2.29.14	TMSI status	400
8.2.29.15	Mobile station classmark 2.....	400
8.2.29.16	Mobile station classmark 3.....	400
8.2.29.17	Supported Codecs	400
8.2.29.18	Additional update type	400
8.2.29.19	Voice domain preference and UE's usage setting.....	400
8.2.29.20	Old GUTI type	400
8.2.29.21	Device properties	401
8.2.29.22	MS network feature support.....	401
8.2.29.23	TMSI based NRI container	401
8.2.29.24	T3324 value.....	401
8.2.29.25	T3412 extended value	401
8.2.29.26	Extended DRX parameters.....	401
8.2.29.27	UE additional security capability	401
8.2.29.28	UE status	401
8.2.29.29	Additional information requested.....	401
8.2.29.30	N1 UE network capability.....	401
8.2.29.31	UE radio capability ID availability IE.....	401
8.2.29.32	DRX parameter in NB-S1 mode	401
8.2.29.33	Requested WUS assistance information.....	401
8.2.29.34	Requested IMSI offset.....	402
8.2.29.35	UE request type	402
8.2.29.36	Paging restriction	402
8.2.30	Uplink NAS Transport.....	402
8.2.31	Downlink generic NAS transport.....	402
8.2.31.1	Message definition	402
8.2.31.2	Additional information.....	403
8.2.32	Uplink generic NAS transport	403
8.2.32.1	Message definition	403
8.2.32.2	Additional information.....	403
8.2.33	CONTROL PLANE SERVICE REQUEST	403
8.2.33.1	Message definition	403
8.2.33.2	ESM message container	404
8.2.33.3	NAS message container	404
8.2.33.4	EPS bearer context status	404
8.2.33.5	Device properties	404
8.2.33.6	UE request type	404
8.2.33.7	Paging restriction	404
8.2.34	Service Accept	405
8.2.34.1	Message definition	405
8.2.34.2	EPS bearer context status	405
8.2.34.3	T3448 value.....	405
8.2.34.4	EPS additional request result.....	405
8.3	EPS session management messages	405
8.3.1	Activate dedicated EPS bearer context accept	405
8.3.1.1	Message definition	405
8.3.1.2	Protocol configuration options	406
8.3.1.3	NBIFOM container	406
8.3.1.4	Extended protocol configuration options	406
8.3.2	Activate dedicated EPS bearer context reject	406
8.3.2.1	Message definition	406
8.3.2.2	Protocol configuration options	407
8.3.2.3	NBIFOM container	407
8.3.2.4	Extended protocol configuration options	407
8.3.3	Activate dedicated EPS bearer context request.....	407
8.3.3.1	Message definition	407
8.3.3.2	Transaction identifier	408
8.3.3.3	Negotiated QoS	408
8.3.3.4	Negotiated LLC SAPI.....	408
8.3.3.5	Radio priority	408
8.3.3.6	Packet flow identifier	409
8.3.3.7	Protocol configuration options	409