



SLOVENSKI STANDARD

DSIST ETS 300 396-3:1999

01-a UFW1999

Df]nYa b]gbcj b]fUX]c`fH9HF5L!`HY b] bYnU H]j YnU`bYdcgfYXb]`bU]b`nj YnY
fB AC!`Dfcl`c`fUX]g_Y[Uj a Ygb]_UfB`cX`a cV]bYdcgHUY`Xc`a cV]bYdcgHUY
fA G!A G!

Terrestrial Trunked Radio (TETRA); Technical requirements for Direct Mode Operation (DMO); Part 3: Mobile Station to Mobile Station (MS-MS) Air Interface (AI) protocol

Ta slovenski standard je istoveten z: ETS 300 396-3 E1.% - , !\$'

ICS:

33.070.10	Prizemni snopovni radio (TETRA)	Terrestrial Trunked Radio (TETRA)
-----------	---------------------------------	-----------------------------------

DSIST ETS 300 396-3:1999

en



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 396-3

March 1998

Source: TETRA

Reference: DE/RES-06007-3

ICS: 33.020

Key words: Air interface, protocol, radio, TETRA

**Terrestrial Trunked Radio (TETRA);
Technical requirements for Direct Mode Operation (DMO);
Part 3: Mobile Station to Mobile Station (MS-MS)
Air Interface (AI) protocol**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.fr> - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1998. All rights reserved.

Contents

Foreword		11
1	Scope	13
2	Normative references	13
3	Definitions and abbreviations	13
3.1	Definitions	13
3.2	Abbreviations	15
4	Overview of protocol.....	16
4.1	General	16
4.2	The DM channel.....	16
4.3	DM call procedures.....	17
4.3.1	Constraints on the frame structure.....	17
4.3.2	Setting up a call.....	18
4.3.3	Changeover in a call.....	19
4.3.4	Pre-emption of a DM call.....	20
4.3.5	Terminating a call.....	21
4.3.6	DM short data call	21
4.4	DM protocol layering	22
5	Layer 3 service description.....	23
5.1	Introduction	23
5.2	Services offered.....	23
5.3	Primitive description.....	24
5.3.1	DMCC-COMplete primitive	24
5.3.2	DMCC-RELEASE primitive	24
5.3.3	DMCC-REPORT primitive	25
5.3.4	DMCC-SDS DATA primitive	25
5.3.5	DMCC-SDS REPORT primitive.....	26
5.3.6	DMCC-SDS UNITDATA primitive	26
5.3.7	DMCC-SETUP primitive	26
5.3.8	DMCC-TPNI primitive.....	27
5.3.9	DMCC-TX CEASED primitive.....	27
5.4	Parameter description.....	28
5.5	States for DMCC-SAP	31
6	Layer 3 protocol.....	32
6.1	Introduction	32
6.1.1	DMCC protocol states	32
6.1.1.1	IDLE.....	32
6.1.1.2	CALL SETUP NORMAL ORIGINATING	32
6.1.1.3	CALL SETUP NORMAL TERMINATING	33
6.1.1.4	CALL SETUP PRES_CHECK ORIGINATING	33
6.1.1.5	CALL SETUP PRES_CHECK TERMINATING	33
6.1.1.6	PRE-EMPTION.....	33
6.1.1.7	CALL ACTIVE TX OCCUPATION.....	33
6.1.1.8	CALL ACTIVE TX RESERVATION	33
6.1.1.9	CALL ACTIVE RX OCCUPATION.....	33
6.1.1.10	CALL ACTIVE RX RESERVATION.....	33
6.1.1.11	WAIT RSP OCCUPATION	33
6.1.1.12	WAIT RSP RESERVATION	33
6.1.1.13	ACK'D SHORT DATA INITIATED	33
6.1.1.14	UNACK'D SHORT DATA INITIATED.....	33
6.2	Circuit mode calls	34
6.2.1	Procedures for call set-up without presence check.....	35

	6.2.1.1	Outgoing call	35	
	6.2.1.2	Incoming call	36	
	6.2.1.3	Temporary group address.....	36	
6.2.2		Procedures for call set-up with presence check	37	
	6.2.2.1	Outgoing call	37	
	6.2.2.2	Incoming call	38	
6.2.3		Usage of DM-OCCUPIED PDU	39	
	6.2.3.1	Sending of DM-OCCUPIED PDU by master DM-MS	39	
	6.2.3.2	Late entry by slave DM-MS	39	
6.2.4		Procedures during occupation	39	
	6.2.4.1	Master DM-MS	39	
	6.2.4.2	Slave DM-MS	40	
	6.2.4.3	Transmitting Party Number Identification (TPNI)	41	
6.2.5		Procedures during reservation.....	42	
	6.2.5.1	Master DM-MS	42	
	6.2.5.2	Slave DM-MS	43	
	6.2.5.3	Pre-emption of short data sent as a transaction within a circuit mode call	44	
6.2.6		Procedures to set up a new call by pre-emption.....	45	
6.3		Short Data Service (SDS) procedures	46	
6.3.1		Sending short data.....	47	
	6.3.1.1	Sending short data on a free channel	47	
		6.3.1.1.1 Sending unacknowledged short data on a free channel	47	
		6.3.1.1.2 Sending acknowledged short data on a free channel	48	
	6.3.1.2	Sending short data by pre-emption	50	
	6.3.1.3	Sending short data during circuit mode transmission	51	
	6.3.1.4	Sending short data as a transaction within a circuit mode call.....	52	
		6.3.1.4.1 Pre-emption to send short data as a transaction within a circuit mode call....	52	
		6.3.1.4.2 Changeover to send short data as a transaction within a circuit mode call....	53	
		6.3.1.4.3 Sending the short data as master of the circuit mode call	53	
	6.3.2	Receiving short data	54	
		6.3.2.1 Receiving unacknowledged short data	54	
		6.3.2.2 Receiving acknowledged short data	54	
	6.3.3	Additional addressing	54	
	6.3.4	Extended error protection	55	
6.4		Usage of DMA-UNITDATA primitive	55	
7		Layer 2 service description	56	
	7.1	Introduction.....	56	
	7.2	Layer 2 architecture.....	56	
		7.2.1 Lower layer management in layer 2.....	57	
	7.3	Service descriptions	58	
		7.3.1 Services at the DMA-SAP.....	58	
		7.3.1.1 Services provided to layer 3.....	58	
		7.3.1.2 Service primitives at the DMA-SAP.....	59	
			7.3.1.2.1 DMA-REPORT primitive.....	59
			7.3.1.2.2 DMA-UNITDATA primitive.....	59
		7.3.2 Services at the DMC-SAP	60	
		7.3.2.1 Services provided to layer 3.....	60	
		7.3.2.2 Service primitives at the DMC-SAP	60	
			7.3.2.2.1 DMC-CONFIGURE primitive.....	61
			7.3.2.2.2 DMC-REPORT primitive	61
		7.3.3 Services at the DMD-SAP	61	
		7.3.3.1 Services provided to the U-plane application.....	61	
		7.3.3.2 Service primitives at the DMD-SAP	61	
			7.3.3.2.1 DMD-REPORT primitive	61
			7.3.3.2.2 DMD-UNITDATA primitive	62

7.4	Parameter listing	62
7.4.1	AI encryption information	62
7.4.2	AI encryption state	62
7.4.3	Call release	62
7.4.4	Call set-up after pre-emption or changeover	62
7.4.5	Changeover request held during occupation	62
7.4.6	Circuit mode information	63
7.4.7	Circuit mode type	63
7.4.8	Communication type	63
7.4.9	Destination address	63
7.4.10	Destination address type	63
7.4.11	DM-SDU	63
7.4.12	DM-SDU length	63
7.4.13	FCS flag	63
7.4.14	Half slot condition	63
7.4.15	Half slot content	63
7.4.16	Half slot importance	64
7.4.17	Half slot position	64
7.4.18	Half slot synchronization	64
7.4.19	Handle to the request	64
7.4.20	Immediate retransmission	64
7.4.21	Incomplete DM-SDS DATA/ACK received	64
7.4.22	Message type	64
7.4.23	New call pre-emption	64
7.4.24	Number of repeats	64
7.4.25	Priority	65
7.4.26	Priority of ongoing call	65
7.4.27	Recent user changeover request	65
7.4.28	Recent user priority	65
7.4.29	Report	65
7.4.30	Reservation time	65
7.4.31	SDS transaction type	65
7.4.32	Source address	65
7.4.33	Source address type	65
7.4.34	Stealing priority	65
7.4.35	Stolen indication	65
7.4.36	Type of pre-emption	66
7.4.37	Valid addresses	66
8	Layer 2 protocol	66
8.1	Introduction	66
8.1.1	Functions of lower MAC	66
8.1.2	Functions of upper MAC	66
8.2	Interface between lower and upper MAC	67
8.2.1	Logical channels defined at the DMV-SAP	67
8.2.2	Service primitives at the DMV-SAP	68
8.2.3	PDU mapping of the logical channels at the DMV-SAP	69
8.2.4	Scrambling mechanism	69
8.2.5	PDU error detection	70
8.2.6	Modes of operation	70
8.2.6.1	DM-MS modes of operation	70
8.2.6.1.1	Idle mode	70
8.2.6.1.2	Signalling mode	71
8.2.6.1.3	Traffic mode	71
8.2.6.2	Operation in traffic mode	72
8.2.6.2.1	Traffic transmission	73
8.2.6.2.2	Stealing mechanism	73
8.2.6.3	Selection of the mode of operation	73
8.3	Basic capabilities of the Physical Layer (PL)	74
8.3.1	DM-MS capabilities	74
8.3.1.1	DM only and dual mode capable MS operation	74
8.3.1.2	Dual watch capable MS operation	75
8.4	Usage of DM channel	75

8.4.1	Definition of DM channel.....	75
8.4.1.1	DM channel arrangement	75
8.4.1.2	DM channel A operation.....	75
8.4.1.3	DM channel B operation.....	76
8.4.2	DM channel states	76
8.4.2.1	DM channel state definitions.....	76
8.4.2.2	DM-MS channel surveillance procedures	77
8.4.2.2.1	Initial determination of DM channel state.....	77
8.4.2.2.2	DM-MS channel surveillance in idle mode	77
8.4.2.2.3	DM-MS channel surveillance at call set-up	78
8.4.2.3	Master DM-MS channel surveillance procedures during a call.....	79
8.4.2.4	Slave DM-MS channel surveillance procedures during a call.....	79
8.4.2.4.1	Slave MS channel surveillance during call transaction	79
8.4.2.4.2	Slave MS signal quality measurement during call transaction	79
8.4.2.4.3	Slave MS channel surveillance during reservation.....	79
8.4.2.5	Master MS surveillance procedures in frequency efficient mode	80
8.4.2.5.1	Surveillance of channel A.....	80
8.4.2.5.2	Surveillance of channel B.....	80
8.4.3	DM-MAC states	80
8.4.3.1	DM-MAC state definitions	80
8.4.3.2	Criteria for changing DM-MAC state	81
8.4.4	DM-MS channel monitoring procedures	82
8.4.4.1	DM channel during call set-up with presence check	82
8.4.4.2	DM channel in occupation during a circuit mode call	82
8.4.4.3	DM channel in reservation during a circuit mode call	82
8.4.4.4	DM channel in occupation during a SDS call	82
8.4.4.5	DM channel usage during pre-emption signalling.....	83
8.4.4.6	DM channel usage during timing change request signalling	83
8.4.5	Transmission of layer 3 messages by DM-MAC	83
8.4.5.1	Transmission of C-plane messages by DM-MAC.....	83
8.4.5.1.1	Transmitting DM-SETUP.....	83
8.4.5.1.2	Transmitting DM-SETUP PRES.....	84
8.4.5.1.3	Transmitting DM-CONNECT.....	84
8.4.5.1.4	Transmitting DM-DISCONNECT.....	85
8.4.5.1.5	Transmitting DM-CONNECT ACK	85
8.4.5.1.6	Transmitting DM-RELEASE	85
8.4.5.1.7	Transmitting DM-OCCUPIED.....	85
8.4.5.1.8	Transmitting DM-TX CEASED	86
8.4.5.1.9	Transmitting DM-TX REQUEST	86
8.4.5.1.10	Transmitting response to DM-TX REQUEST	86
8.4.5.1.11	Transmitting DM-PREEMPT	86
8.4.5.1.12	Transmitting response to DM-PREEMPT	87
8.4.5.1.13	Transmitting DM-SDS UDATA and DM-SDS DATA	87
8.4.5.1.14	Transmitting response to DM-SDS DATA.....	88
8.4.5.1.15	Transmitting DM-INFO	89
8.4.5.2	Transmission of U-plane messages by DM-MAC.....	89
8.4.6	Transmission of layer 2 messages generated by DM-MAC	89
8.4.6.1	Transmitting DM-RESERVED.....	89
8.4.6.2	Transmitting DM-SDS OCCUPIED	90