

ETSI TS 124 301 V17.9.0 (2023-01)



**Universal Mobile Telecommunications System (UMTS);
LTE;
5G;
Non-Access-Stratum (NAS)
protocol for Evolved Packet System (EPS);
Stage 3
(3GPP TS 24.301 version 17.9.0 Release 17)**



ReferenceRTS/TSGC-0124301vh90

Keywords5G,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	21
1 Scope	23
2 References	23
3 Definitions and abbreviations.....	26
3.1 Definitions	26
3.2 Abbreviations	34
4 General	35
4.1 Overview	35
4.2 Linkage between the protocols for EPS mobility management and EPS session management	36
4.2.A Handling of NAS signalling low priority indication	36
4.3 UE mode of operation	37
4.3.1 General.....	37
4.3.2 Change of UE mode of operation	38
4.3.2.1 General.....	38
4.3.2.2 Change of UE's usage setting.....	40
4.3.2.3 Change of voice domain preference for E-UTRAN.....	41
4.3.2.4 Change or determination of IMS registration status.....	42
4.3.2.5 Change of configuration regarding the use of SMS.....	44
4.4 NAS security	45
4.4.1 General.....	45
4.4.2 Handling of EPS security contexts	45
4.4.2.1 General.....	45
4.4.2.2 Establishment of a mapped EPS security context during intersystem handover	46
4.4.2.3 Establishment of secure exchange of NAS messages	47
4.4.2.4 Change of security keys	49
4.4.2.5 Derivation of keys at CS to PS SRVCC handover from A/Gb mode to S1 mode or from Iu mode to S1 mode	50
4.4.3 Handling of NAS COUNT and NAS sequence number	51
4.4.3.1 General	51
4.4.3.2 Replay protection	52
4.4.3.3 Integrity protection and verification.....	52
4.4.3.4 Ciphering and deciphering.....	52
4.4.3.5 NAS COUNT wrap around	52
4.4.4 Integrity protection of NAS signalling messages.....	53
4.4.4.1 General	53
4.4.4.2 Integrity checking of NAS signalling messages in the UE	53
4.4.4.3 Integrity checking of NAS signalling messages in the MME	54
4.4.5 Ciphering of NAS signalling messages	56
4.5 Disabling and re-enabling of UE's E-UTRA capability	56
4.6 Applicability of procedures	59
4.6.1 Relay nodes.....	59
4.7 EPS mobility management and EPS session management in NB-S1 mode	59
4.8 EPS mobility management and EPS session management in WB-S1 mode for IoT.....	60
4.8.1 UE not using satellite E-UTRAN access	60
4.8.2 UE using satellite E-UTRAN access	61
4.9 Disabling and re-enabling of UE's NB-IoT capability	61
4.10 Support of MUSIM features.....	62
4.11 Satellite access for CIoT.....	62
4.11.1 General.....	62
4.11.2 Handling list of "PLMNs not allowed to operate at the present UE location"	62
4.11.3 Handling multiple tracking area codes from the lower layers.....	63

5	Elementary procedures for EPS mobility management.....	64
5.1	Overview	64
5.1.1	General.....	64
5.1.2	Types of EMM procedures	65
5.1.3	EMM sublayer states	66
5.1.3.1	General	66
5.1.3.2	EMM sublayer states in the UE.....	66
5.1.3.2.1	General	66
5.1.3.2.2	Main states.....	66
5.1.3.2.2.1	EMM-NUL.....	66
5.1.3.2.2.2	EMM-DEREGISTERED	66
5.1.3.2.2.3	EMM-REGISTERED-INITIATED	66
5.1.3.2.2.4	EMM-REGISTERED	66
5.1.3.2.2.5	EMM-DEREGISTERED-INITIATED.....	67
5.1.3.2.2.6	EMM-TRACKING-AREA-UPDATING-INITIATED	67
5.1.3.2.2.7	EMM-SERVICE-REQUEST-INITIATED.....	67
5.1.3.2.3	Substates of state EMM-DEREGISTERED	68
5.1.3.2.3.1	General.....	68
5.1.3.2.3.2	EMM-DEREGISTERED.NORMAL-SERVICE	68
5.1.3.2.3.3	EMM-DEREGISTERED.LIMITED-SERVICE.....	68
5.1.3.2.3.4	EMM-DEREGISTERED.ATTEMPTING-TO-ATTACH.....	69
5.1.3.2.3.5	EMM-DEREGISTERED.PLMN-SEARCH.....	69
5.1.3.2.3.6	EMM-DEREGISTERED.NO-IMSI	69
5.1.3.2.3.7	EMM-DEREGISTERED.ATTACH-NEEDED.....	69
5.1.3.2.3.8	EMM-DEREGISTERED.NO-CELL-AVAILABLE	69
5.1.3.2.3.9	EMM-DEREGISTERED.eCALL-INACTIVE.....	69
5.1.3.2.4	Substates of state EMM-REGISTERED	69
5.1.3.2.4.1	General.....	69
5.1.3.2.4.2	EMM-REGISTERED.NORMAL-SERVICE	69
5.1.3.2.4.3	EMM-REGISTERED.ATTEMPTING-TO-UPDATE	69
5.1.3.2.4.4	EMM-REGISTERED.LIMITED-SERVICE	70
5.1.3.2.4.5	EMM-REGISTERED.PLMN-SEARCH	70
5.1.3.2.4.6	EMM-REGISTERED.UPDATE-NEEDED	70
5.1.3.2.4.7	EMM-REGISTERED.NO-CELL-AVAILABLE	70
5.1.3.2.4.8	EMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM.....	70
5.1.3.2.4.9	EMM-REGISTERED.IMSI-DETACH-INITIATED	70
5.1.3.3	EPS update status	70
5.1.3.4	EMM sublayer states in the MME	71
5.1.3.4.1	EMM-DEREGISTERED.....	71
5.1.3.4.2	EMM-COMMON-PROCEDURE-INITIATED.....	71
5.1.3.4.3	EMM-REGISTERED	71
5.1.3.4.4	EMM-DEREGISTERED-INITIATED	71
5.1.4	Coordination between EMM and GMM.....	72
5.1.5	Coordination between EMM and MM.....	73
5.2	Behaviour of the UE in state EMM-DEREGISTERED and state EMM-REGISTERED	73
5.2.1	General.....	73
5.2.2	UE behaviour in state EMM-DEREGISTERED	73
5.2.2.1	General	73
5.2.2.2	Primary substate selection.....	74
5.2.2.2.1	Selection of the substate after power on.....	74
5.2.2.3	Detailed description of UE behaviour in state EMM-DEREGISTERED	74
5.2.2.3.1	NORMAL-SERVICE.....	74
5.2.2.3.2	LIMITED-SERVICE.....	74
5.2.2.3.3	ATTEMPTING-TO-ATTACH	74
5.2.2.3.4	PLMN-SEARCH.....	75
5.2.2.3.5	NO-IMSI	75
5.2.2.3.6	ATTACH-NEEDED.....	75
5.2.2.3.7	NO-CELL-AVAILABLE	75
5.2.2.3.8	eCALL-INACTIVE.....	75
5.2.2.4	Substate when back to state EMM-DEREGISTERED from another EMM state	76
5.2.3	UE behaviour in state EMM-REGISTERED.....	76
5.2.3.1	General.....	76

5.2.3.2	Detailed description of UE behaviour in state EMM-REGISTERED.....	77
5.2.3.2.1	NORMAL-SERVICE.....	77
5.2.3.2.2	ATTEMPTING-TO-UPDATE.....	77
5.2.3.2.3	LIMITED-SERVICE.....	78
5.2.3.2.4	PLMN-SEARCH.....	78
5.2.3.2.5	UPDATE-NEEDED.....	78
5.2.3.2.6	NO-CELL-AVAILABLE.....	79
5.2.3.2.7	ATTEMPTING-TO-UPDATE-MM.....	79
5.2.3.2.8	IMSI-DETACH-INITIATED.....	79
5.3	General on elementary EMM procedures.....	80
5.3.1	EMM modes and NAS signalling connection.....	80
5.3.1.1	Establishment of the NAS signalling connection.....	80
5.3.1.2	Release of the NAS signalling connection.....	81
5.3.1.2.1	General.....	81
5.3.1.2.2	UE is using EPS services with control plane CIoT EPS optimization.....	84
5.3.1.3	Suspend and resume of the NAS signalling connection.....	84
5.3.2	Lists of forbidden tracking areas.....	85
5.3.3	List of forbidden PLMNs for attach in S101 mode.....	85
5.3.3a	Forbidden PLMNs for EPS services.....	86
5.3.4	Equivalent PLMNs list.....	86
5.3.5	Handling of the periodic tracking area update timer and mobile reachable timer (S1 mode only).....	86
5.3.6	Handling of timer T3402.....	88
5.3.7	Handling of the Local Emergency Numbers List and the Extended Local Emergency Numbers List.....	88
5.3.7a	Specific requirements for UE configured to use timer T3245.....	89
5.3.7b	Specific requirements for UE when receiving non-integrity protected reject messages.....	90
5.3.8	Abnormal cases in the UE.....	93
5.3.9	Handling of NAS level mobility management congestion control.....	93
5.3.9A	Handling of congestion control for transport of user data via the control plane.....	94
5.3.10	Access class control.....	94
5.3.11	Power saving mode.....	95
5.3.12	Extended idle-mode DRX cycle.....	96
5.3.13	Interaction between power saving mode and extended idle mode DRX cycle.....	96
5.3.14	Dedicated core network.....	96
5.3.15	CIoT EPS optimizations.....	97
5.3.16	Restriction on use of enhanced coverage.....	98
5.3.17	Service Gap Control.....	99
5.3.18	Restricted local operator services.....	100
5.3.19	Core Network selection and redirection for UEs using CIoT optimizations.....	101
5.3.19.1	Core network selection.....	101
5.3.19.2	Redirection of the UE by the core network.....	101
5.3.20	UE radio capability signalling optimisation.....	101
5.3.21	Wake-up signal assistance.....	102
5.3.22	Void.....	103
5.4	EMM common procedures.....	103
5.4.1	GUTI reallocation procedure.....	103
5.4.1.1	General.....	103
5.4.1.2	GUTI reallocation initiation by the network.....	104
5.4.1.3	GUTI reallocation completion by the UE.....	104
5.4.1.4	GUTI reallocation completion by the network.....	105
5.4.1.5	Abnormal cases in the UE.....	105
5.4.1.6	Abnormal cases on the network side.....	105
5.4.2	Authentication procedure.....	106
5.4.2.1	General.....	106
5.4.2.2	Authentication initiation by the network.....	107
5.4.2.3	Authentication response by the UE.....	107
5.4.2.4	Authentication completion by the network.....	108
5.4.2.5	Authentication not accepted by the network.....	108
5.4.2.6	Authentication not accepted by the UE.....	109
5.4.2.7	Abnormal cases.....	110
5.4.3	Security mode control procedure.....	114
5.4.3.1	General.....	114
5.4.3.2	NAS security mode control initiation by the network.....	115

5.4.3.3	NAS security mode command accepted by the UE.....	117
5.4.3.4	NAS security mode control completion by the network	119
5.4.3.5	NAS security mode command not accepted by the UE.....	119
5.4.3.6	Abnormal cases in the UE.....	119
5.4.3.7	Abnormal cases on the network side.....	120
5.4.4	Identification procedure.....	120
5.4.4.1	General.....	120
5.4.4.2	Identification initiation by the network.....	121
5.4.4.3	Identification response by the UE	121
5.4.4.4	Identification completion by the network	121
5.4.4.5	Abnormal cases in the UE.....	121
5.4.4.6	Abnormal cases on the network side.....	122
5.4.5	EMM information procedure	123
5.4.5.1	General.....	123
5.4.5.2	EMM information procedure initiation by the network	123
5.4.5.3	EMM information procedure in the UE	123
5.4.5.4	Abnormal cases on the network side.....	123
5.5	EMM specific procedures	123
5.5.1	Attach procedure.....	123
5.5.1.1	General.....	123
5.5.1.2	Attach procedure for EPS services.....	125
5.5.1.2.1	General	125
5.5.1.2.2	Attach procedure initiation	125
5.5.1.2.3	EMM common procedure initiation	130
5.5.1.2.4	Attach accepted by the network.....	130
5.5.1.2.4A	Attach successful for EPS services and not accepted for SMS services.....	137
5.5.1.2.5	Attach not accepted by the network.....	138
5.5.1.2.5A	Attach for emergency bearer services not accepted by the network.....	144
5.5.1.2.5B	Attach for initiating a PDN connection for emergency bearer services not accepted by the network.....	146
5.5.1.2.5B1	Attach by a UE transferring an emergency PDU session using a standalone PDN CONNECTIVITY REQUEST message	146
5.5.1.2.5C	Attach for access to RLOS not accepted by the network.....	147
5.5.1.2.6	Abnormal cases in the UE	147
5.5.1.2.6A	Abnormal cases in the UE, SMS services not accepted.....	151
5.5.1.2.7	Abnormal cases on the network side	152
5.5.1.3	Combined attach procedure for EPS services and non-EPS services (S1 mode only)	153
5.5.1.3.1	General	153
5.5.1.3.2	Combined attach procedure initiation.....	154
5.5.1.3.3	EMM common procedure initiation	154
5.5.1.3.4	Combined attach accepted by the network	154
5.5.1.3.4.1	General.....	154
5.5.1.3.4.2	Combined attach successful	154
5.5.1.3.4.3	Combined attach successful for EPS services only.....	155
5.5.1.3.5	Combined attach not accepted by the network	157
5.5.1.3.6	Abnormal cases in the UE	162
5.5.1.3.7	Abnormal cases on the network side	163
5.5.2	Detach procedure	163
5.5.2.1	General.....	163
5.5.2.2	UE initiated detach procedure	164
5.5.2.2.1	UE initiated detach procedure initiation.....	164
5.5.2.2.2	UE initiated detach procedure completion for EPS services only	165
5.5.2.2.3	UE initiated combined detach procedure completion.....	166
5.5.2.2.4	Abnormal cases in the UE	166
5.5.2.2.5	Abnormal cases on the network side	168
5.5.2.3	Network initiated detach procedure	168
5.5.2.3.1	Network initiated detach procedure initiation	168
5.5.2.3.2	Network initiated detach procedure completion by the UE.....	169
5.5.2.3.3	Network initiated detach procedure completion by the network.....	174
5.5.2.3.4	Abnormal cases in the UE	174
5.5.2.3.5	Abnormal cases on the network side	175
5.5.3	Tracking area updating procedure (S1 mode only).....	176

5.5.3.1	General	176
5.5.3.2	Normal and periodic tracking area updating procedure	178
5.5.3.2.1	General	178
5.5.3.2.2	Normal and periodic tracking area updating procedure initiation	178
5.5.3.2.3	EMM common procedure initiation	185
5.5.3.2.4	Normal and periodic tracking area updating procedure accepted by the network	186
5.5.3.2.4A	Tracking area updating successful for EPS services and not accepted for SMS services	197
5.5.3.2.5	Normal and periodic tracking area updating procedure not accepted by the network	198
5.5.3.2.5A	Tracking area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network	206
5.5.3.2.5B	Tracking area updating for access to RLOS not accepted by the network	206
5.5.3.2.6	Abnormal cases in the UE	207
5.5.3.2.6A	Abnormal cases in the UE, SMS services not accepted	213
5.5.3.2.7	Abnormal cases on the network side	213
5.5.3.3	Combined tracking area updating procedure	215
5.5.3.3.1	General	215
5.5.3.3.2	Combined tracking area updating procedure initiation	216
5.5.3.3.3	EMM common procedure initiation	218
5.5.3.3.4	Combined tracking area updating procedure accepted by the network	218
5.5.3.3.4.1	General	218
5.5.3.3.4.2	Combined tracking area updating successful	219
5.5.3.3.4.3	Combined tracking area updating successful for EPS services only	220
5.5.3.3.5	Combined tracking area updating procedure not accepted by the network	222
5.5.3.3.6	Abnormal cases in the UE	230
5.5.3.3.7	Abnormal cases on the network side	231
5.5.4	eCall inactivity procedure	231
5.5.5	Tracking area update request message (for N1 mode only)	231
5.5.6	Attach request message (for N1 mode only)	231
5.6	EMM connection management procedures (S1 mode only)	232
5.6.1	Service request procedure	232
5.6.1.1	General	232
5.6.1.2	Service request procedure initiation	237
5.6.1.2.1	UE is not using EPS services with control plane CIoT EPS optimization	237
5.6.1.2.2	UE is using EPS services with control plane CIoT EPS optimization	238
5.6.1.3	EMM common procedure initiation	239
5.6.1.4	Service request procedure accepted by the network	239
5.6.1.4.1	UE is not using EPS services with control plane CIoT EPS optimization	239
5.6.1.4.2	UE is using EPS services with control plane CIoT EPS optimization	241
5.6.1.5	Service request procedure not accepted by the network	246
5.6.1.5A	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network	255
5.6.1.5B	Service request procedure for UE attached for access to RLOS not accepted by the network	256
5.6.1.6	Abnormal cases in the UE	256
5.6.1.7	Abnormal cases on the network side	263
5.6.2	Paging procedure	264
5.6.2.1	General	264
5.6.2.2	Paging for EPS services	264
5.6.2.2.1	Paging for EPS services through E-UTRAN using S-TMSI	264
5.6.2.2.2	Paging for EPS services through E-UTRAN using IMSI	268
5.6.2.3	Paging for CS fallback to A/Gb or Iu mode	268
5.6.2.3.1	General	268
5.6.2.3.2	Abnormal cases in the UE	269
5.6.2.3.3	Abnormal cases on the network side	269
5.6.2.4	Paging for SMS	270
5.6.3	Transport of NAS messages procedure	270
5.6.3.1	General	270
5.6.3.2	UE initiated transport of NAS messages	271
5.6.3.3	Network initiated transport of NAS messages	271
5.6.3.4	Abnormal cases in the UE	271
5.6.3.5	Abnormal cases on the network side	271
5.6.4	Generic transport of NAS messages procedure	272
5.6.4.1	General	272

5.6.4.2	UE initiated generic transport of NAS messages	272
5.6.4.3	Network initiated transport of NAS messages	272
5.6.4.4	Abnormal cases in the UE	272
5.6.4.5	Abnormal cases on the network side	273
5.7	Reception of an EMM STATUS message by an EMM entity	273
6	Elementary procedures for EPS session management.....	273
6.1	Overview	273
6.1.1	General.....	273
6.1.2	Types of ESM procedures.....	274
6.1.3	ESM sublayer states.....	275
6.1.3.1	General	275
6.1.3.2	ESM sublayer states in the UE	275
6.1.3.2.1	BEARER CONTEXT INACTIVE	275
6.1.3.2.2	BEARER CONTEXT ACTIVE	275
6.1.3.2.3	PROCEDURE TRANSACTION INACTIVE.....	276
6.1.3.2.4	PROCEDURE TRANSACTION PENDING	276
6.1.3.3	ESM sublayer states in the MME.....	276
6.1.3.3.1	BEARER CONTEXT INACTIVE	276
6.1.3.3.2	BEARER CONTEXT ACTIVE PENDING.....	276
6.1.3.3.3	BEARER CONTEXT ACTIVE	276
6.1.3.3.4	BEARER CONTEXT INACTIVE PENDING.....	276
6.1.3.3.5	BEARER CONTEXT MODIFY PENDING.....	276
6.1.3.3.6	PROCEDURE TRANSACTION INACTIVE.....	277
6.1.3.3.7	PROCEDURE TRANSACTION PENDING	277
6.1.4	Coordination between ESM and SM	277
6.1.4A	Coordination between ESM and 5GSM.....	278
6.1.5	Coordination between ESM and EMM for supporting ISR.....	278
6.2	IP address allocation.....	279
6.2.1	General.....	279
6.2.2	IP address allocation via NAS signalling.....	279
6.2A	IP header compression.....	281
6.3	General on elementary ESM procedures	281
6.3.1	Services provided by lower layers	281
6.3.2	Principles of address handling for ESM procedures	281
6.3.3	Abnormal cases in the UE	283
6.3.4	Abnormal cases in the network.....	284
6.3.5	Handling of APN based congestion control.....	284
6.3.5A	Handling of group specific session management congestion control	285
6.3.6	Handling of network rejection not due to APN based congestion control	285
6.3.7	Handling of WLAN offload control	286
6.3.8	Handling of serving PLMN rate control	286
6.3.9	Handling of APN rate control	286
6.3.10	Handling of 3GPP PS data off	287
6.3.11	Handling of Reliable Data Service	288
6.3.12	Handling of Ethernet PDN type.....	288
6.3.13	Handling of Uncrewed aerial vehicle identification, authentication, and authorization	288
6.3.13.1	General	288
6.3.13.2	Authentication and authorization of UAV	288
6.3.13.3	Authorization of C2 communication.....	288
6.3.13.4	Void.....	289
6.4	Network initiated ESM procedures	289
6.4.1	Default EPS bearer context activation procedure	289
6.4.1.1	General	289
6.4.1.2	Default EPS bearer context activation initiated by the network.....	289
6.4.1.3	Default EPS bearer context activation accepted by the UE.....	290
6.4.1.4	Default EPS bearer context activation not accepted by the UE.....	292
6.4.1.5	Abnormal cases in the UE.....	292
6.4.1.6	Abnormal cases on the network side.....	292
6.4.2	Dedicated EPS bearer context activation procedure	293
6.4.2.1	General	293
6.4.2.2	Dedicated EPS bearer context activation initiated by the network.....	293

6.4.2.3	Dedicated EPS bearer context activation accepted by the UE	294
6.4.2.4	Dedicated EPS bearer context activation not accepted by the UE	295
6.4.2.5	Abnormal cases in the UE	296
6.4.2.6	Abnormal cases on the network side	297
6.4.3	EPS bearer context modification procedure	297
6.4.3.1	General	297
6.4.3.2	EPS bearer context modification initiated by the network	298
6.4.3.3	EPS bearer context modification accepted by the UE	298
6.4.3.4	EPS bearer context modification not accepted by the UE	300
6.4.3.5	Abnormal cases in the UE	303
6.4.3.6	Abnormal cases on the network side	303
6.4.4	EPS bearer context deactivation procedure	303
6.4.4.1	General	303
6.4.4.2	EPS bearer context deactivation initiated by the network	304
6.4.4.3	EPS bearer context deactivation accepted by the UE	305
6.4.4.4	Abnormal cases in the UE	307
6.4.4.5	Abnormal cases on the network side	307
6.4.4.6	Local EPS bearer context deactivation without NAS signalling	307
6.5	UE requested ESM procedures	309
6.5.0	General	309
6.5.1	UE requested PDN connectivity procedure	310
6.5.1.1	General	310
6.5.1.2	UE requested PDN connectivity procedure initiation	310
6.5.1.3	UE requested PDN connectivity procedure accepted by the network	314
6.5.1.4	UE requested PDN connectivity procedure not accepted by the network	315
6.5.1.4.1	General	315
6.5.1.4.2	Handling of network rejection due to ESM cause #26	317
6.5.1.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	320
6.5.1.4A	Handling the maximum number of active EPS bearer contexts	326
6.5.1.4B	Void	326
6.5.1.4C	Handling the maximum number of active user plane radio bearers in NB-S1 mode	326
6.5.1.5	Abnormal cases in the UE	326
6.5.1.6	Abnormal cases on the network side	327
6.5.1.7	Handling PDN connectivity request for UE configured for dual priority	328
6.5.2	UE requested PDN disconnect procedure	328
6.5.2.1	General	328
6.5.2.2	UE requested PDN disconnection procedure initiation	329
6.5.2.3	UE requested PDN disconnection procedure accepted by the network	329
6.5.2.4	UE requested PDN disconnection procedure not accepted by the network	329
6.5.2.5	Abnormal cases in the UE	330
6.5.2.6	Abnormal cases on the network side	330
6.5.3	UE requested bearer resource allocation procedure	331
6.5.3.1	General	331
6.5.3.2	UE requested bearer resource allocation procedure initiation	331
6.5.3.3	UE requested bearer resource allocation procedure accepted by the network	332
6.5.3.4	UE requested bearer resource allocation procedure not accepted by the network	332
6.5.3.4.1	General	332
6.5.3.4.2	Handling of network rejection due to ESM cause #26	334
6.5.3.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	335
6.5.3.4A	Handling the maximum number of active EPS bearer contexts	337
6.5.3.5	Abnormal cases in the UE	338
6.5.3.6	Abnormal cases on the network side	338
6.5.4	UE requested bearer resource modification procedure	338
6.5.4.1	General	338
6.5.4.2	UE requested bearer resource modification procedure initiation	339
6.5.4.3	UE requested bearer resource modification procedure accepted by the network	342
6.5.4.4	UE requested bearer resource modification procedure not accepted by the network	342
6.5.4.4.1	General	342
6.5.4.4.2	Handling of network rejection due to ESM cause #26	345
6.5.4.4.3	Handling of network rejection due to ESM cause other than ESM cause #26	346
6.5.4.5	Abnormal cases in the UE	348
6.5.4.6	Abnormal cases on the network side	349

6.5.5	Handling session management request for UE configured for dual priority	350
6.6	Miscellaneous procedures	351
6.6.1	Exchange of protocol configuration options	351
6.6.1.1	General	351
6.6.1.2	ESM information request procedure	351
6.6.1.2.1	General	351
6.6.1.2.2	ESM information request initiated by the network	352
6.6.1.2.3	ESM information request completion by the UE	352
6.6.1.2.4	ESM information request completion by the network	352
6.6.1.2.5	Abnormal cases in the UE	352
6.6.1.2.6	Abnormal cases on the network side	352
6.6.1.3	Exchange of protocol configuration options in other messages	352
6.6.2	Notification procedure	353
6.6.2.1	General	353
6.6.2.2	Notification procedure initiation by the network	353
6.6.2.3	Notification procedure in the UE	353
6.6.2.4	Abnormal cases on the network side	353
6.6.3	Remote UE Report procedure	354
6.6.3.1	General	354
6.6.3.2	Remote UE Report initiated by the UE	354
6.6.3.3	Remote UE Report completion by the network	354
6.6.3.4	Remote UE Report completion by the UE	354
6.6.3.5	Abnormal cases in the UE	354
6.6.3.6	Abnormal cases on the network side	355
6.6.4	Transport of user data via the control plane procedure	355
6.6.4.1	General	355
6.6.4.2	UE initiated transport of user data via the control plane	355
6.6.4.3	Network initiated transport of user data via the control plane	356
6.6.4.4	Abnormal cases in the UE	356
6.6.4.5	Abnormal cases on the network side	357
6.7	Reception of an ESM STATUS message by an ESM entity	357
7	Handling of unknown, unforeseen, and erroneous protocol data	358
7.1	General	358
7.2	Message too short	358
7.3	Unknown or unforeseen procedure transaction identity or EPS bearer identity	358
7.3.1	Procedure transaction identity	358
7.3.2	EPS bearer identity	360
7.4	Unknown or unforeseen message type	361
7.5	Non-semantic mandatory information element errors	362
7.5.1	Common procedures	362
7.5.2	EPS mobility management	362
7.5.3	EPS session management	362
7.6	Unknown and unforeseen IEs in the non-imperative message part	363
7.6.1	IEs unknown in the message	363
7.6.2	Out of sequence IEs	363
7.6.3	Repeated IEs	363
7.7	Non-imperative message part errors	363
7.7.1	Syntactically incorrect optional IEs	363
7.7.2	Conditional IE errors	364
7.8	Messages with semantically incorrect contents	364
8	Message functional definitions and contents	364
8.1	Overview	364
8.2	EPS mobility management messages	365
8.2.1	Attach accept	365
8.2.1.1	Message definition	365
8.2.1.2	GUTI	368
8.2.1.3	Location area identification	368
8.2.1.4	MS identity	368
8.2.1.5	EMM cause	368
8.2.1.6	T3402 value	368

8.2.1.7	T3423 value.....	368
8.2.1.8	Equivalent PLMNs.....	368
8.2.1.9	Emergency number list	368
8.2.1.9A	Extended emergency number list	368
8.2.1.10	EPS network feature support.....	368
8.2.1.11	Additional update result	369
8.2.1.12	T3412 extended value	369
8.2.1.13	T3324 value.....	369
8.2.1.14	Extended DRX parameters.....	369
8.2.1.15	DCN-ID.....	369
8.2.1.16	SMS services status.....	369
8.2.1.17	Non-3GPP NW provided policies	369
8.2.1.18	T3448 value.....	369
8.2.1.19	Network policy.....	369
8.2.1.20	T3447 value.....	369
8.2.1.21	Ciphering key data	370
8.2.1.22	UE radio capability ID	370
8.2.1.23	UE radio capability ID deletion indication.....	370
8.2.1.24	Negotiated WUS assistance information.....	370
8.2.1.25	Negotiated DRX parameter in NB-S1 mode.....	370
8.2.1.26	Negotiated IMSI offset.....	370
8.2.1.27	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	370
8.2.1.28	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	370
8.2.2	Attach complete	370
8.2.3	Attach reject.....	371
8.2.3.1	Message definition	371
8.2.3.2	ESM message container	371
8.2.3.3	T3346 value.....	371
8.2.3.4	T3402 value.....	372
8.2.3.5	Extended EMM cause	372
8.2.3.5A	Lower bound timer value	372
8.2.3.6	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	372
8.2.3.7	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	372
8.2.4	Attach request	372
8.2.4.1	Message definition	372
8.2.4.2	Old P-TMSI signature	375
8.2.4.3	Additional GUTI	375
8.2.4.4	Last visited registered TAI.....	375
8.2.4.5	DRX parameter	375
8.2.4.6	MS network capability	375
8.2.4.7	Old location area identification.....	375
8.2.4.8	TMSI status	375
8.2.4.9	Mobile station classmark 2.....	375
8.2.4.10	Mobile station classmark 3.....	375
8.2.4.11	Supported Codecs	375
8.2.4.12	Additional update type	375
8.2.4.13	Voice domain preference and UE's usage setting.....	376
8.2.4.14	Device properties	376
8.2.4.15	Old GUTI type	376
8.2.4.16	MS network feature support.....	376
8.2.4.17	TMSI based NRI container	376
8.2.4.18	T3324 value.....	376
8.2.4.19	T3412 extended value	376
8.2.4.20	Extended DRX parameters.....	376
8.2.4.21	UE additional security capability	376
8.2.4.22	UE status	376
8.2.4.23	Additional information requested.....	376
8.2.4.24	N1 UE network capability.....	376
8.2.4.25	UE radio capability ID availability IE.....	376
8.2.4.26	Requested WUS assistance information.....	377
8.2.4.27	DRX parameter in NB-S1 mode	377
8.2.4.28	Requested IMSI offset.....	377

8.2.5	Authentication failure	377
8.2.5.1	Message definition	377
8.2.5.2	Authentication failure parameter.....	377
8.2.6	Authentication reject.....	377
8.2.7	Authentication request	378
8.2.8	Authentication response.....	378
8.2.9	CS service notification.....	379
8.2.9.1	Message definition	379
8.2.9.2	CLI	379
8.2.9.3	SS Code.....	379
8.2.9.4	LCS indicator	379
8.2.9.5	LCS client identity	379
8.2.9.6	Void.....	379
8.2.10	Detach accept.....	380
8.2.10.1	Detach accept (UE originating detach)	380
8.2.10.2	Detach accept (UE terminated detach).....	380
8.2.11	Detach request	380
8.2.11.1	Detach request (UE originating detach)	380
8.2.11.2	Detach request (UE terminated detach).....	381
8.2.11.2.1	Message definition.....	381
8.2.11.2.2	EMM cause.....	381
8.2.11.2.3	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	381
8.2.11.2.4	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	382
8.2.11.2.5	Lower bound timer value.....	382
8.2.12	Downlink NAS Transport.....	382
8.2.13	EMM information	382
8.2.13.1	Message definition	382
8.2.13.2	Full name for network.....	383
8.2.13.3	Short name for network.....	383
8.2.13.4	Local time zone	383
8.2.13.5	Universal time and local time zone	383
8.2.13.6	Network daylight saving time	383
8.2.14	EMM status.....	384
8.2.15	Extended service request	384
8.2.15.1	Message definition	384
8.2.15.2	CSFB response	385
8.2.15.3	EPS bearer context status	385
8.2.15.4	Device properties	385
8.2.15.5	UE request type.....	385
8.2.15.6	Paging restriction	385
8.2.16	GUTI reallocation command	385
8.2.16.1	Message definition	385
8.2.16.2	TAI list	386
8.2.16.3	DCN-ID.....	386
8.2.16.4	UE radio capability ID	386
8.2.16.5	UE radio capability ID deletion indication.....	386
8.2.17	GUTI reallocation complete	386
8.2.18	Identity request	387
8.2.19	Identity response.....	387
8.2.20	Security mode command	388
8.2.20.1	Message definition	388
8.2.20.2	IMEISV request	388
8.2.20.3	Replayed nonce _{UE}	388
8.2.20.4	Nonce _{MME}	388
8.2.20.5	Hash _{MME}	388
8.2.20.6	Replayed UE additional security capability	389
8.2.20.7	UE radio capability ID request.....	389
8.2.21	Security mode complete.....	389
8.2.21.1	Message definition	389
8.2.21.2	IMEISV	389
8.2.21.3	Replayed NAS message container	389
8.2.21.4	UE radio capability ID	389

8.2.22	Security mode reject	389
8.2.23	Security protected NAS message.....	390
8.2.24	Service reject	390
8.2.24.1	Message definition	390
8.2.24.2	T3442 value.....	391
8.2.24.3	T3346 value.....	391
8.2.24.4	T3448 value.....	391
8.2.24.5	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	391
8.2.24.6	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	391
8.2.24.7	Lower bound timer value	391
8.2.25	Service request.....	391
8.2.26	Tracking area update accept.....	392
8.2.26.1	Message definition	392
8.2.26.2	T3412 value.....	395
8.2.26.3	GUTI.....	395
8.2.26.4	TAI list	395
8.2.26.5	EPS bearer context status	395
8.2.26.6	Location area identification.....	395
8.2.26.7	MS identity.....	395
8.2.26.8	EMM cause	395
8.2.26.9	T3402 value.....	395
8.2.26.10	T3423 value.....	395
8.2.26.11	Equivalent PLMNs.....	396
8.2.26.12	Emergency number list	396
8.2.26.12A	Extended emergency number list	396
8.2.26.13	EPS network feature support.....	396
8.2.26.14	Additional update result	396
8.2.26.15	T3412 extended value	396
8.2.26.16	T3324 value.....	396
8.2.26.17	Extended DRX parameters.....	396
8.2.26.18	DCN-ID.....	396
8.2.26.19	SMS services status.....	397
8.2.26.20	Non-3GPP NW provided policies	397
8.2.26.21	T3448 value.....	397
8.2.26.22	Network policy.....	397
8.2.26.23	T3447 value.....	397
8.2.26.24	Ciphering key data	397
8.2.26.25	UE radio capability ID	397
8.2.26.26	UE radio capability ID deletion indication.....	397
8.2.26.27	Negotiated WUS assistance information.....	397
8.2.26.28	Negotiated DRX parameter in NB-S1 mode	397
8.2.26.29	Negotiated IMSI offset.....	398
8.2.26.30	EPS additional request result.....	398
8.2.26.31	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	398
8.2.26.32	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	398
8.2.27	Tracking area update complete	398
8.2.28	Tracking area update reject.....	398
8.2.28.1	Message definition	398
8.2.28.2	T3346 value.....	399
8.2.28.3	Extended EMM cause	399
8.2.28.4	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	399
8.2.28.5	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	399
8.2.28.6	Lower bound timer value	399
8.2.29	Tracking area update request	399
8.2.29.1	Message definition	399
8.2.29.2	Non-current native NAS key set identifier.....	402
8.2.29.3	GPRS ciphering key sequence number	402
8.2.29.4	Old P-TMSI signature.....	402
8.2.29.5	Additional GUTI	402
8.2.29.6	Nonce _{UE}	402
8.2.29.7	UE network capability.....	402
8.2.29.8	Last visited registered TAI.....	402

8.2.29.9	DRX parameter	403
8.2.29.10	UE radio capability information update needed	403
8.2.29.11	EPS bearer context status	403
8.2.29.12	MS network capability	403
8.2.29.13	Old location area identification	403
8.2.29.14	TMSI status	403
8.2.29.15	Mobile station classmark 2	403
8.2.29.16	Mobile station classmark 3	403
8.2.29.17	Supported Codecs	403
8.2.29.18	Additional update type	403
8.2.29.19	Voice domain preference and UE's usage setting	403
8.2.29.20	Old GUTI type	403
8.2.29.21	Device properties	404
8.2.29.22	MS network feature support	404
8.2.29.23	TMSI based NRI container	404
8.2.29.24	T3324 value	404
8.2.29.25	T3412 extended value	404
8.2.29.26	Extended DRX parameters	404
8.2.29.27	UE additional security capability	404
8.2.29.28	UE status	404
8.2.29.29	Additional information requested	404
8.2.29.30	N1 UE network capability	404
8.2.29.31	UE radio capability ID availability IE	404
8.2.29.32	DRX parameter in NB-S1 mode	404
8.2.29.33	Requested WUS assistance information	404
8.2.29.34	Requested IMSI offset	405
8.2.29.35	UE request type	405
8.2.29.36	Paging restriction	405
8.2.30	Uplink NAS Transport	405
8.2.31	Downlink generic NAS transport	405
8.2.31.1	Message definition	405
8.2.31.2	Additional information	406
8.2.32	Uplink generic NAS transport	406
8.2.32.1	Message definition	406
8.2.32.2	Additional information	406
8.2.33	CONTROL PLANE SERVICE REQUEST	406
8.2.33.1	Message definition	406
8.2.33.2	ESM message container	407
8.2.33.3	NAS message container	407
8.2.33.4	EPS bearer context status	407
8.2.33.5	Device properties	407
8.2.33.6	UE request type	407
8.2.33.7	Paging restriction	407
8.2.34	Service Accept	408
8.2.34.1	Message definition	408
8.2.34.2	EPS bearer context status	408
8.2.34.3	T3448 value	408
8.2.34.4	EPS additional request result	408
8.2.34.5	Forbidden TAI(s) for the list of "forbidden tracking areas for roaming"	408
8.2.34.6	Forbidden TAI(s) for the list of "forbidden tracking areas for regional provision of service"	408
8.3	EPS session management messages	409
8.3.1	Activate dedicated EPS bearer context accept	409
8.3.1.1	Message definition	409
8.3.1.2	Protocol configuration options	409
8.3.1.3	NBIFOM container	409
8.3.1.4	Extended protocol configuration options	409
8.3.2	Activate dedicated EPS bearer context reject	409
8.3.2.1	Message definition	409
8.3.2.2	Protocol configuration options	410
8.3.2.3	NBIFOM container	410
8.3.2.4	Extended protocol configuration options	410
8.3.3	Activate dedicated EPS bearer context request	410