

ETSI TS 138 331 V17.3.0 (2023-01)



5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.3.0 Release 17)

<https://standards.iteh.ai/catalog/standards/sist/b7601d0f-da5b-4f8a-b799-732a04bbdac5/etsi-ts-138-331-v17-3-0-2023-01>



ReferenceRTS/TSGR-0238331vh30

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards.iteh.ai/> <https://portal.etsi.org/People/CommitteeSupportStaff.aspx> <https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	30
4 General	32
4.1 Introduction	32
4.2 Architecture	33
4.2.1 UE states and state transitions including inter RAT	33
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSysInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	48
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	54
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	56
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	58
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	58
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	59

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	59
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	59
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	59
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	59
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	59
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	60
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	60
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	60
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	60
5.2.2.5	Essential system information missing	60
5.2.2.6	T430 expiry	61
5.3	Connection control	61
5.3.1	Introduction	61
5.3.1.1	RRC connection control	61
5.3.1.2	AS Security	62
5.3.2	Paging	63
5.3.2.1	General	63
5.3.2.2	Initiation	63
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	63
5.3.3	RRC connection establishment	65
5.3.3.1	General	65
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	66
5.3.3.2	Initiation	66
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	67
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	67
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	71
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	71
5.3.3.7	T300 expiry	71
5.3.3.8	Abortion of RRC connection establishment	73
5.3.4	Initial AS security activation	74
5.3.4.1	General	74
5.3.4.2	Initiation	74
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	74
5.3.5	RRC reconfiguration	75
5.3.5.1	General	75
5.3.5.2	Initiation	76
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	76
5.3.5.4	Secondary cell group release	88
5.3.5.5	Cell Group configuration	88
5.3.5.5.1	General	88
5.3.5.5.2	Reconfiguration with sync	89
5.3.5.5.3	RLC bearer release	91
5.3.5.5.4	RLC bearer addition/modification	91
5.3.5.5.5	MAC entity configuration	92
5.3.5.5.6	RLF Timers & Constants configuration	93
5.3.5.5.7	SpCell Configuration	93
5.3.5.5.8	SCell Release	94
5.3.5.5.9	SCell Addition/Modification	95
5.3.5.5.10	BH RLC channel release	95
5.3.5.5.11	BH RLC channel addition/modification	95
5.3.5.5.12	Uu Relay RLC channel release	96
5.3.5.5.13	Uu Relay RLC channel addition/modification	96
5.3.5.6	Radio Bearer configuration	96
5.3.5.6.1	General	96
5.3.5.6.2	SRB release	97
5.3.5.6.3	SRB addition/modification	97
5.3.5.6.4	DRB release	99
5.3.5.6.5	DRB addition/modification	99
5.3.5.6.6	Multicast MRB release	102
5.3.5.6.7	Multicast MRB addition/modification	103

5.3.5.7	AS Security key update	103
5.3.5.8	Reconfiguration failure	105
5.3.5.8.1	Void	105
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	105
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	107
5.3.5.9	Other configuration	108
5.3.5.9a	MUSIM gap configuration	112
5.3.5.10	MR-DC release	113
5.3.5.11	Full configuration	113
5.3.5.12	BAP configuration	115
5.3.5.12a	IAB Other Configuration	116
5.3.5.12a.1	IP address management	116
5.3.5.12a.1.1	IP Address Release	116
5.3.5.12a.1.2	IP Address Addition/Modification	116
5.3.5.13	Conditional Reconfiguration	117
5.3.5.13.1	General	117
5.3.5.13.2	Conditional reconfiguration removal	118
5.3.5.13.3	Conditional reconfiguration addition/modification	118
5.3.5.13.4	Conditional reconfiguration evaluation	118
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	120
5.3.5.13.5	Conditional reconfiguration execution	120
5.3.5.13a	SCG activation	120
5.3.5.13b	SCG deactivation	121
5.3.5.13b1	SCG activation without SN message	121
5.3.5.13c	FR2 UL gap configuration	122
5.3.5.13d	Application layer measurement configuration	122
5.3.5.14	Sidelink dedicated configuration	123
5.3.5.15	L2 U2N Relay UE configuration	125
5.3.5.15.1	General	125
5.3.5.15.2	L2 U2N Remote UE Release	125
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	125
5.3.5.16	L2 U2N Remote UE configuration	126
5.3.6	Counter check	127
5.3.6.1	General	127
5.3.6.2	Initiation	127
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	127
5.3.7	RRC connection re-establishment	128
5.3.7.1	General	128
5.3.7.2	Initiation	128
5.3.7.3	Actions following cell selection while T311 is running	131
5.3.7.3a	Actions following relay selection while T311 is running	134
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	134
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	135
5.3.7.6	T311 expiry	137
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	137
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	137
5.3.8	RRC connection release	137
5.3.8.1	General	137
5.3.8.2	Initiation	138
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	138
5.3.8.4	T320 expiry	141
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	142
5.3.8.6	T346g expiry	142
5.3.9	RRC connection release requested by upper layers	142
5.3.9.1	General	142
5.3.9.2	Initiation	142
5.3.10	Radio link failure related actions	142
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	142
5.3.10.2	Recovery of physical layer problems	143
5.3.10.3	Detection of radio link failure	143
5.3.10.4	RLF cause determination	145
5.3.10.5	RLF report content determination	145

5.3.11	UE actions upon going to RRC_IDLE.....	149
5.3.12	UE actions upon PUCCH/SRS release request.....	151
5.3.13	RRC connection resume	151
5.3.13.1	General	151
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	152
5.3.13.1b	Conditions for initiating SDT.....	153
5.3.13.2	Initiation.....	153
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	156
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	158
5.3.13.5	Handling of failure to resume RRC Connection	163
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	164
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE.....	165
5.3.13.8	RNA update.....	165
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	165
5.3.13.10	Reception of the <i>RRCReject</i> by the UE.....	165
5.3.13.11	Inability to comply with <i>RRCResume</i>	165
5.3.13.12	Inter RAT cell reselection	166
5.3.14	Unified Access Control.....	166
5.3.14.1	General	166
5.3.14.2	Initiation.....	166
5.3.14.3	Void.....	168
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	168
5.3.14.5	Access barring check.....	168
5.3.15	RRC connection reject.....	169
5.3.15.1	Initiation.....	169
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	169
5.4	Inter-RAT mobility.....	170
5.4.1	Introduction.....	170
5.4.2	Handover to NR.....	170
5.4.2.1	General	170
5.4.2.2	Initiation.....	171
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	171
5.4.3	Mobility from NR.....	171
5.4.3.1	General	171
5.4.3.2	Initiation.....	172
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	172
5.4.3.4	Successful completion of the mobility from NR.....	172
5.4.3.5	Mobility from NR failure	173
5.5	Measurements.....	174
5.5.1	Introduction.....	174
5.5.2	Measurement configuration	176
5.5.2.1	General	176
5.5.2.2	Measurement identity removal.....	178
5.5.2.3	Measurement identity addition/modification	178
5.5.2.4	Measurement object removal	179
5.5.2.5	Measurement object addition/modification.....	180
5.5.2.6	Reporting configuration removal	182
5.5.2.7	Reporting configuration addition/modification.....	182
5.5.2.8	Quantity configuration	182
5.5.2.9	Measurement gap configuration.....	183
5.5.2.10	Reference signal measurement timing configuration	185
5.5.2.10a	RSSI measurement timing configuration	186
5.5.2.11	Measurement gap sharing configuration	186
5.5.3	Performing measurements	187
5.5.3.1	General	187
5.5.3.2	Layer 3 filtering	192
5.5.3.3	Derivation of cell measurement results.....	192
5.5.3.3a	Derivation of layer 3 beam filtered measurement	193
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	194

5.5.4	Measurement report triggering	194
5.5.4.1	General	194
5.5.4.2	Event A1 (Serving becomes better than threshold)	201
5.5.4.3	Event A2 (Serving becomes worse than threshold)	201
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	202
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	202
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	203
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	204
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	204
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	205
5.5.4.10	Event I1 (Interference becomes higher than threshold)	206
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	206
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	207
5.5.4.13	Void	207
5.5.4.14	Void	207
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	207
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	208
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	209
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	210
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	210
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	211
5.5.5	Measurement reporting	211
5.5.5.1	General	211
5.5.5.2	Reporting of beam measurement information	220
5.5.5.3	Sorting of cell measurement results	220
5.5.6	Location measurement indication	221
5.5.6.1	General	221
5.5.6.2	Initiation	221
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	222
5.5a	Logged Measurements	223
5.5a.1	Logged Measurement Configuration	223
5.5a.1.1	General	223
5.5a.1.2	Initiation	223
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	223
5.5a.1.4	T330 expiry	224
5.5a.2	Release of Logged Measurement Configuration	224
5.5a.2.1	General	224
5.5a.2.2	Initiation	224
5.5a.3	Measurements logging	224
5.5a.3.1	General	224
5.5a.3.2	Initiation	224
5.6	UE capabilities	227
5.6.1	UE capability transfer	227
5.6.1.1	General	227
5.6.1.2	Initiation	227
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	227
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	228
5.6.1.5	Void	231
5.7	Other	231
5.7.1	DL information transfer	231
5.7.1.1	General	231
5.7.1.2	Initiation	231
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	231
5.7.1a	DL information transfer for MR-DC	232
5.7.1a.1	General	232
5.7.1a.2	Initiation	232
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	232

5.7.2	UL information transfer	233
5.7.2.1	General	233
5.7.2.2	Initiation	233
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	233
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	233
5.7.2a	UL information transfer for MR-DC	234
5.7.2a.1	General	234
5.7.2a.2	Initiation	234
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	234
5.7.2b	UL transfer of IRAT information	234
5.7.2b.1	General	234
5.7.2b.2	Initiation	235
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	235
5.7.3	SCG failure information	235
5.7.3.1	General	235
5.7.3.2	Initiation	235
5.7.3.3	Failure type determination for (NG)EN-DC	236
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	237
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	237
5.7.3a	EUTRA SCG failure information	240
5.7.3a.1	General	240
5.7.3a.2	Initiation	240
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	240
5.7.3b	MCG failure information	241
5.7.3b.1	General	241
5.7.3b.2	Initiation	241
5.7.3b.3	Failure type determination	241
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	242
5.7.3b.5	T316 expiry	243
5.7.4	UE Assistance Information	244
5.7.4.1	General	244
5.7.4.2	Initiation	244
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	251
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	259
5.7.4.4	Relaxed measurement criterion for a stationary RedCap UE	260
5.7.4a	Void	260
5.7.5	Failure information	260
5.7.5.1	General	260
5.7.5.2	Initiation	261
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	261
5.7.6	DL message segment transfer	261
5.7.6.1	General	261
5.7.6.2	Initiation	262
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	262
5.7.7	UL message segment transfer	262
5.7.7.1	General	262
5.7.7.2	Initiation	262
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	263
5.7.8	Idle/inactive Measurements	263
5.7.8.1	General	263
5.7.8.1a	Measurement configuration	263
5.7.8.2	Void	264
5.7.8.2a	Performing measurements	264
5.7.8.3	T331 expiry or stop	267
5.7.8.4	Cell re-selection or cell selection while T331 is running	267
5.7.9	Mobility history information	267
5.7.9.1	General	267
5.7.9.2	Initiation	267
5.7.10	UE Information	271
5.7.10.1	General	271
5.7.10.2	Initiation	271
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	271

5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information.....	274
5.7.10.5	RA information determination	275
5.7.10.6	Actions for the successful handover report determination	278
5.7.12	IAB Other Information	281
5.7.12.1	General	281
5.7.12.2	Initiation	281
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	281
5.7.13	RLM/BFD relaxation	283
5.7.13.1	Relaxed measurement criterion for low mobility	283
5.7.13.2	Relaxed measurement criterion for good serving cell quality	283
5.7.14	UE Positioning Assistance Information	284
5.7.14.1	General	284
5.7.14.2	Initiation	284
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	284
5.7.15	Void	285
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	286
5.8	Sidelink	286
5.8.1	General	286
5.8.2	Conditions for NR sidelink communication/discovery operation	287
5.8.3	Sidelink UE information for NR sidelink communication/discovery	288
5.8.3.1	General	288
5.8.3.2	Initiation	288
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	293
5.8.4	Void	297
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery	297
5.8.5.1	General	297
5.8.5.2	Initiation	298
5.8.5.3	Transmission of SLSS	298
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	300
5.8.5a.1	General	300
5.8.5a.2	Initiation	300
5.8.6	Sidelink synchronisation reference	300
5.8.6.1	General	300
5.8.6.2	Selection and reselection of synchronisation reference	301
5.8.6.3	Sidelink communication transmission reference cell selection	303
5.8.7	Sidelink communication reception	303
5.8.8	Sidelink communication transmission	304
5.8.9	Sidelink RRC procedure	306
5.8.9.1	Sidelink RRC reconfiguration	306
5.8.9.1.1	General	306
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	307
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	308
5.8.9.1.4	Void	310
5.8.9.1.5	Void	310
5.8.9.1.6	Void	310
5.8.9.1.7	Void	310
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	310
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	310
5.8.9.1a	Sidelink radio bearer management	311
5.8.9.1a.1	Sidelink DRB release	311
5.8.9.1a.2	Sidelink DRB addition/modification	312
5.8.9.1a.3	Sidelink SRB release	313
5.8.9.1a.4	Sidelink SRB addition	314
5.8.9.2	Sidelink UE capability transfer	314
5.8.9.2.1	General	314
5.8.9.2.2	Initiation	314
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	314
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	315
5.8.9.3	Sidelink radio link failure related actions	315
5.8.9.4	Sidelink common control information	316

5.8.9.4.1	General	316
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	316
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message.....	316
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	317
5.8.9.6	Sidelink UE assistance information	318
5.8.9.6.1	General	318
5.8.9.6.2	Initiation	318
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	318
5.8.9.8	Remote UE information	319
5.8.9.8.1	General	319
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	320
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE.....	320
5.8.9.9	Uu message transfer in sidelink	321
5.8.9.9.1	General	321
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message.....	321
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	322
5.8.9.10	Notification Message	322
5.8.9.10.1	General	322
5.8.9.10.2	Initiation	322
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	322
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message.....	323
5.8.10	Sidelink measurement.....	323
5.8.10.1	Introduction.....	323
5.8.10.2	Sidelink measurement configuration.....	324
5.8.10.2.1	General	324
5.8.10.2.2	Sidelink measurement identity removal	324
5.8.10.2.3	Sidelink measurement identity addition/modification.....	325
5.8.10.2.4	Sidelink measurement object removal.....	325
5.8.10.2.5	Sidelink measurement object addition/modification	325
5.8.10.2.6	Sidelink reporting configuration removal.....	326
5.8.10.2.7	Sidelink reporting configuration addition/modification	326
5.8.10.2.8	Sidelink quantity configuration	326
5.8.10.3	Performing NR sidelink measurements.....	327
5.8.10.3.1	General	327
5.8.10.3.2	Derivation of NR sidelink measurement results.....	327
5.8.10.4	Sidelink measurement report triggering	327
5.8.10.4.1	General	327
5.8.10.4.2	Event S1 (Serving becomes better than threshold).....	328
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	329
5.8.10.5	Sidelink measurement reporting.....	329
5.8.10.5.1	General	329
5.8.11	Zone identity calculation	330
5.8.12	DFN derivation from GNSS	330
5.9	MBS Broadcast	336
5.9.1	Introduction.....	336
5.9.1.1	General	336
5.9.1.2	MCCH scheduling.....	337
5.9.1.3	MCCH information validity and notification of changes	337
5.9.2	MCCH information acquisition	337
5.9.2.1	General	337
5.9.2.2	Initiation.....	338
5.9.2.3	MCCH information acquisition by the UE.....	338
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	338
5.9.3	Broadcast MRB configuration	338
5.9.3.1	General	338
5.9.3.2	Initiation.....	339
5.9.3.3	Broadcast MRB establishment	339
5.9.3.4	Broadcast MRB release.....	339
5.9.4	MBS Interest Indication.....	339
5.9.4.1	General	339
5.9.4.2	Initiation.....	340
5.9.4.3	MBS frequencies of interest determination.....	340

5.9.4.4	MBS services of interest determination	341
5.9.4.5	Setting of the contents of MBS Interest Indication	341
6	Protocol data units, formats and parameters (ASN.1)	342
6.1	General	342
6.1.1	Introduction.....	342
6.1.2	Need codes and conditions for optional fields	342
6.1.3	General rules	345
6.2	RRC messages	345
6.2.1	General message structure	345
–	NR-RRC-Definitions.....	345
–	BCCH-BCH-Message	345
–	BCCH-DL-SCH-Message	346
–	DL-CCCH-Message	346
–	DL-DCCH-Message	347
–	MCCH-Message	347
–	PCCH-Message.....	348
–	UL-CCCH-Message	348
–	UL-CCCH1-Message	349
–	UL-DCCH-Message.....	349
6.2.2	Message definitions	351
–	CounterCheck.....	351
–	CounterCheckResponse.....	352
–	DedicatedSIBRequest.....	353
–	DLDedicatedMessageSegment.....	354
–	DLInformationTransfer	355
–	DLInformationTransferMRDC.....	356
–	FailureInformation.....	357
–	IABOtherInformation	358
–	LocationMeasurementIndication	361
–	LoggedMeasurementConfiguration	362
–	MBSBroadcastConfiguration	364
–	MBSInterestIndication	365
–	MCGFailureInformation.....	366
–	MeasurementReport	368
–	MeasurementReportAppLayer	368
–	MIB	370
–	MobilityFromNRCommand.....	371
–	Paging	373
–	RRCReestablishment	374
–	RRCReestablishmentComplete	375
–	RRCReestablishmentRequest	376
–	RRCReconfiguration	377
–	RRCReconfigurationComplete	384
–	RRCReject	386
–	RRCRelease.....	387
–	RRCResume.....	395
–	RRCResumeComplete	398
–	RRCResumeRequest	400
–	RRCResumeRequest1	400
–	RRCSetup	401
–	RRCSetupComplete	402
–	RRCSetupRequest.....	404
–	RRCSystemInfoRequest	405
–	SCGFailureInformation	407
–	SCGFailureInformationEUTRA.....	409
–	SecurityModeCommand	410
–	SecurityModeComplete	411
–	SecurityModeFailure.....	412
–	SIB1	412
–	SidelinkUEInformationNR	417
–	SystemInformation	422

–	<i>UEAssistanceInformation</i>	423
–	<i>UECapabilityEnquiry</i>	432
–	<i>UECapabilityInformation</i>	433
–	<i>UEInformationRequest</i>	434
–	<i>UEInformationResponse</i>	435
–	<i>UEPositioningAssistanceInfo</i>	450
–	<i>ULDedicatedMessageSegment</i>	452
–	<i>ULInformationTransfer</i>	453
–	<i>ULInformationTransferIRAT</i>	453
–	<i>ULInformationTransferMRDC</i>	454
6.3	RRC information elements	455
6.3.0	Parameterized types	455
–	<i>SetupRelease</i>	455
6.3.1	System information blocks	456
–	<i>SIB2</i>	456
–	<i>SIB3</i>	461
–	<i>SIB4</i>	463
–	<i>SIB5</i>	469
–	<i>SIB6</i>	472
–	<i>SIB7</i>	472
–	<i>SIB8</i>	473
–	<i>SIB9</i>	474
–	<i>SIB10</i>	475
–	<i>SIB11</i>	476
–	<i>SIB12</i>	476
–	<i>SIB13</i>	478
–	<i>SIB14</i>	479
–	<i>SIB15</i>	480
–	<i>SIB16</i>	480
–	<i>SIB17</i>	481
–	<i>SIB18</i>	483
–	<i>SIB20</i>	485
–	<i>SIB21</i>	486
6.3.1a	Positioning System information blocks	487
–	<i>PosSystemInformation-r16-IEs</i>	487
–	<i>PosSI-SchedulingInfo</i>	488
–	<i>SIBpos</i>	491
6.3.2	Radio resource control information elements	491
–	<i>AdditionalSpectrumEmission</i>	491
–	<i>Alpha</i>	491
–	<i>AMF-Identifier</i>	492
–	<i>ARFCN-ValueEUTRA</i>	492
–	<i>ARFCN-ValueNR</i>	492
–	<i>ARFCN-ValueUTRA-FDD</i>	493
–	<i>AvailabilityCombinationsPerCell</i>	493
–	<i>AvailabilityIndicator</i>	495
–	<i>BAP-RoutingID</i>	495
–	<i>BeamFailureRecoveryConfig</i>	496
–	<i>BeamFailureRecoveryRSConfig</i>	499
–	<i>BetaOffsets</i>	500
–	<i>BetaOffsetsCrossPri</i>	501
–	<i>BH-LogicalChannelIdentity</i>	501
–	<i>BH-LogicalChannelIdentity-Ext</i>	502
–	<i>BH-RLC-ChannelConfig</i>	502
–	<i>BH-RLC-ChannelID</i>	503
–	<i>BSR-Config</i>	503
–	<i>BWP</i>	504
–	<i>BWP-Downlink</i>	505
–	<i>BWP-DownlinkCommon</i>	506
–	<i>BWP-DownlinkDedicated</i>	506
–	<i>BWP-Id</i>	509
–	<i>BWP-Uplink</i>	509

–	BWP-UplinkCommon	510
–	BWP-UplinkDedicated	513
–	CandidateBeamRS	516
–	CellAccessRelatedInfo	517
–	CellAccessRelatedInfo-EUTRA-5GC	519
–	CellAccessRelatedInfo-EUTRA-EPC	519
–	CellGroupConfig	520
–	CellGroupId	530
–	CellIdentity	530
–	CellReselectionPriority	530
–	CellReselectionSubPriority	531
–	CFR-ConfigMulticast	531
–	CGI-InfoEUTRA	532
–	CGI-InfoEUTRALogging	532
–	CGI-InfoNR	533
–	CGI-Info-Logging	534
–	CLI-RSSI-Range	535
–	CodebookConfig	535
–	CommonLocationInfo	541
–	CondReconfigId	541
–	CondReconfigToAddModList	542
–	ConditionalReconfiguration	543
–	ConfiguredGrantConfig	543
–	ConfiguredGrantConfigIndex	552
–	ConfiguredGrantConfigIndexMAC	553
–	ConnEstFailureControl	553
–	ControlResourceSet	554
–	ControlResourceSetId	556
–	ControlResourceSetZero	556
–	CrossCarrierSchedulingConfig	557
–	CSI-AperiodicTriggerStateList	558
–	CSI-FrequencyOccupation	561
–	CSI-IM-Resource	561
–	CSI-IM-ResourceId	562
–	CSI-IM-ResourceSet	563
–	CSI-IM-ResourceSetId	563
–	CSI-MeasConfig	563
–	CSI-ReportConfig	565
–	CSI-ReportConfigId	572
–	CSI-ResourceConfig	573
–	CSI-ResourceConfigId	574
–	CSI-ResourcePeriodicityAndOffset	575
–	CSI-RS-ResourceConfigMobility	575
–	CSI-RS-ResourceMapping	578
–	CSI-SemiPersistentOnPUSCH-TriggerStateList	579
–	CSI-SSB-ResourceSet	580
–	CSI-SSB-ResourceSetId	581
–	DedicatedNAS-Message	581
–	DL-PPW-PreConfig	581
–	DMRS-BundlingPUCCH-Config	584
–	DMRS-BundlingPUSCH-Config	585
–	DMRS-DownlinkConfig	586
–	DMRS-UplinkConfig	587
–	DownlinkConfigCommon	589
–	DownlinkConfigCommonSIB	590
–	DownlinkPreemption	594
–	DRB-Identity	595
–	DRX-Config	595
–	DRX-ConfigSecondaryGroup	597
–	DRX-ConfigSL	598
–	EphemerisInfo	599
–	FeatureCombination	600

FeatureCombinationPreambles	601
FilterCoefficient	604
FreqBandIndicatorNR.....	604
FreqPriorityListDedicatedSlicing	604
FreqPriorityListSlicing	605
FrequencyInfoDL	606
FrequencyInfoDL-SIB.....	607
FrequencyInfoUL	608
FrequencyInfoUL-SIB.....	609
GapPriority	610
HighSpeedConfig	611
Hysteresis	612
HysteresisLocation.....	613
InvalidSymbolPattern.....	613
I-RNTI-Value.....	614
LBT-FailureRecoveryConfig	614
LocationInfo	615
LocationMeasurementInfo	615
LogicalChannelConfig	617
LogicalChannelIdentity.....	620
LTE-NeighCellsCRS-AssistInfoList.....	620
MAC-CellGroupConfig	622
MeasConfig	625
MeasGapConfig	627
MeasGapId.....	631
MeasGapSharingConfig.....	632
MeasId.....	633
MeasIdleConfig.....	633
MeasIdToAddModList.....	636
MeasObjectCLI	636
MeasObjectEUTRA	639
MeasObjectId	641
MeasObjectNR	641
MeasObjectNR-SL	649
MeasObjectRxTxDiff.....	649
MeasObjectToAddModList	650
MeasObjectUTRA-FDD.....	650
MeasResultCellListSFTD-NR.....	651
MeasResultCellListSFTD-EUTRA	652
MeasResults	652
MeasResult2EUTRA.....	659
MeasResult2NR.....	659
MeasResultIdleEUTRA	660
MeasResultIdleNR.....	661
MeasResultRxTxTimeDiff.....	662
MeasResultSCG-Failure	663
MeasResultsSL	663
MeasTriggerQuantityEUTRA.....	664
MobilityStateParameters.....	664
MRB-Identity.....	665
MsgA-ConfigCommon.....	665
MsgA-PUSCH-Config.....	666
MultiFrequencyBandListNR.....	669
MultiFrequencyBandListNR-SIB	670
MUSIM-GapConfig.....	670
MUSIM-GapId	671
MUSIM-GapInfo	672
NeedForGapsConfigNR	673
NeedForGapNCSG-ConfigEUTRA.....	674
NeedForGapNCSG-ConfigNR	675
NeedForGapNCSG-InfoEUTRA	675
NeedForGapNCSG-InfoNR.....	676