

# SLOVENSKI STANDARD

**DSIST ETS 300 752:2001**

**01-ZVfi UF-2001**

---

FUX]g\_UcdfYa U]b'g]ghYa ]'fF9GL!Df]nYa b]`YHg\_]hYY\_ca i b]\_UWg\_]g]ghYa  
fH: HGŁ!DcXUh\_]j'dU\_YhbYa 'bU ]bi

Radio Equipment and Systems (RES); Terrestrial Flight Telecommunications System (TFTS); Packet mode data

**Ta slovenski standard je istoveten z:      ETS 300 752 Edition 1**

---


**ICS:**

33.060.20	Sprejemna in oddajna oprema	Receiving and transmitting equipment
49.060	Ščap\as{A}^•[  b\æ ^ \dā}as{a]!^{\as{A}āc{a	Aerospace electric equipment and systems

**DSIST ETS 300 752:2001**

**en**





**EUROPEAN  
TELECOMMUNICATION  
STANDARD**

---

**ETS 300 752**

September 1997

Source: RES

Reference: DE/RES-05-01/2

ICS: 33.020

**Key words:** Aeronautical, data, packet mode, radio, TFTS

**Radio Equipment and Systems (RES);  
Terrestrial Flight Telecommunications System (TFTS);  
Packet mode data**

**ETSI**

European Telecommunications Standards Institute

**ETSI Secretariat**

**Postal address:** F-06921 Sophia Antipolis CEDEX - FRANCE

**Office address:** 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

**X.400:** c=fr, a=atlas, p=etsi, s=secretariat - **Internet:** secretariat@etsi.fr

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

---

**Copyright Notification:** No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1997. All rights reserved.



## Contents

Foreword .....	7
1 Scope .....	9
2 Normative references .....	9
3 Abbreviations.....	10
3.1 Definitions .....	10
3.2 Abbreviations .....	10
3.3 Symbols .....	11
4 Service definition .....	11
4.1 Packet mode services.....	11
5 Network architecture .....	12
5.1 Support of multiple network layer protocols .....	12
5.2 Data transmission .....	12
5.3 AT functionality .....	13
5.3.1 Interworking function .....	13
5.3.2 Location registration procedure.....	13
5.3.3 Dynamic resource management .....	13
5.4 GSS functionality .....	13
5.4.1 Administrative aspects .....	14
5.4.1.1 Data call phases and activities .....	14
5.4.1.2 Collection of data for call charging .....	15
5.5 CIF functionality .....	15
5.5.1 Interworking with GSSs .....	16
5.5.2 TFTS packet messages conversion.....	16
5.5.3 Address conversion.....	16
6 End to end data flow.....	17
6.1 CALL management procedures.....	17
6.1.1 AT originated call establishment .....	17
6.1.2 CIF originated call establishment .....	17
6.1.3 Data transfer.....	18
6.1.4 Handover procedures.....	18
6.1.5 Call clearing procedures.....	18
6.2 Scenarios .....	18
7 AT to GSS interface aspects .....	18
7.1 General .....	18
7.2 Layer 2 aspects.....	19
7.3 AT location registration procedure .....	20
7.4 Data transfer services provided by signalling layer 3 on the AT side .....	20
7.4.1 General.....	20
7.4.2 Service states at the AT side of the AT-GSS interface .....	21
7.5 Data transfer services provided by signalling layer 3 on the GSS side .....	21
7.5.1 General.....	21
7.5.2 Service states at the GSS side of the AT-GSS interface .....	21
7.6 Dynamic resource management.....	22
7.6.1 General.....	22
7.6.2 Varying throughput transmission.....	22
7.6.2.1 Aircraft-originated throughput modification.....	22
7.6.2.2 Ground initiated throughput modification.....	23
7.6.3 Decision strategy .....	24
7.6.3.1 Throughput increase.....	24
7.6.3.2 Throughput decrease .....	25

7.7	Elementary procedures for packet switched data transfer .....	25
7.7.1	General .....	25
7.7.2	DTM states .....	25
7.7.2.1	Call states at the AT side of the interface (see figure C.1) .....	25
7.7.2.2	Call states at the GSS side of the interface (see figure C.2) .....	25
7.7.2.3	Packet-switched DTM procedures .....	26
7.7.3	Aircraft location management .....	26
7.7.3.1	General .....	26
7.7.3.2	Location registration .....	26
7.7.3.2.1	General .....	26
7.7.3.2.2	Connection request .....	27
7.7.3.2.3	Connection confirmation .....	27
7.7.3.2.4	Connection rejection .....	27
7.7.3.2.5	Connection release .....	27
7.7.3.3	Location update .....	27
7.7.4	Aircraft originating call establishment procedures .....	27
7.7.4.1	General .....	27
7.7.4.2	Call request .....	28
7.7.4.3	Call connected .....	28
7.7.4.4	Call rejection .....	28
7.7.5	Ground originating call establishment procedures .....	28
7.7.5.1	General .....	28
7.7.5.2	Call connected .....	29
7.7.6	Call clearing .....	29
7.7.6.1	Exception conditions .....	29
7.7.6.2	Clearing initiated by the AT .....	29
7.7.6.3	Clearing initiated by the GSS .....	29
7.7.6.4	Completion of clearing .....	30
7.7.6.5	Clear collision .....	30
7.7.7	Miscellaneous procedures .....	30
7.7.7.1	Data transfer air-to-ground .....	30
7.7.7.2	Data transfer ground-to-air .....	30
7.7.7.3	Timer expiry .....	30
7.7.7.4	Handover .....	30
7.7.7.4.1	AT side .....	30
7.7.7.4.2	GSS side .....	31
7.7.7.5	Resource management .....	31
7.7.7.5.1	General .....	31
7.7.7.5.2	Throughput increase .....	31
7.7.7.5.3	Throughput decrease .....	32
7.8	Handling of error conditions .....	33
7.8.1	General treatment of error conditions .....	33
7.8.2	Message type error .....	33
7.8.3	Mandatory information element error .....	33
7.9	Message functional definitions and contents .....	34
7.9.1	DTM messages .....	34
7.9.1.1	Connect .....	34
7.9.1.2	Disconnect .....	35
7.9.1.3	Packet data transfer (PD1) .....	35
7.9.1.4	Packet data transfer (PD2) .....	36
7.9.2	Supplementary RRM messages .....	36
7.9.2.1	Throughput modification request .....	36
7.9.2.2	Throughput modification command .....	37
7.9.2.3	Throughput modification reject .....	37
7.10	General message format and information elements coding .....	37
7.10.1	Overview .....	38
7.10.2	Protocol discriminator .....	38
7.10.3	Transaction identifier .....	38
7.10.4	Message type .....	38
7.10.5	Supplementary RRM information elements .....	39
7.10.5.1	Capacity request .....	39
7.10.5.2	Slot allocation .....	40

7.10.6	DTM information elements .....	40
7.10.6.1	DTM-cause .....	40
7.10.6.2	Data information .....	41
7.11	List of system parameters.....	41
7.11.1	Timers for data transfer on the AT side .....	41
7.11.2	Timers for data transfer on the GSS side.....	41
7.12	Definition of primitive parameters .....	42
7.12.1	Primitive parameters for DTM .....	42
7.12.2	Additional primitive parameters for the RR service .....	42
8	Interworking at the GSS .....	43
8.1	General .....	43
8.2	Relay function description .....	43
8.3	DTM states at the GSS side of the AT-GSS and GSS-CIF interfaces .....	43
9	GSS to CIF interface aspects.....	44
9.1	General .....	44
9.2	Data transfer services provided by signalling layer 3 on GSS side .....	44
9.2.1	General GSS .....	44
9.2.2	Service state diagram GSS .....	45
9.3	Data transfer services provided by signalling layer 3 on the CIF side .....	45
9.3.1	General.....	45
9.3.2	Service state diagram CIF.....	45
9.4	Elementary procedures for packet switched DT .....	46
9.4.1	Overview.....	46
9.4.1.1	General .....	46
9.4.2	DTM states .....	46
9.4.2.1	Call states at the GSS side of the interface.....	46
9.4.2.2	Call states at the CIF side of the interface.....	46
9.4.2.3	Packet-switched DTM procedures.....	47
9.4.3	GSS originating call establishment procedures.....	47
9.4.3.1	Call request.....	47
9.4.3.2	Call connected .....	47
9.4.4	CIF originating call establishment procedures .....	48
9.4.4.1	Call request.....	48
9.4.4.2	Call connected .....	48
9.4.5	Call clearing.....	48
9.4.5.1	Clearing initiated by the CIF.....	48
9.4.5.2	Clearing initiated by the GSS.....	49
9.4.5.3	Completion of clearing.....	49
9.4.6	Miscellaneous procedures.....	49
9.4.6.1	Data transfer GSS-to-CIF .....	49
9.4.6.2	Data transfer ground to air.....	49
9.4.6.3	Handover .....	49
	9.4.6.3.1      GSS side .....	49
	9.4.6.3.2      CIF side.....	50
9.5	Handling of error conditions .....	50
9.5.1	General treatment of error conditions .....	50
9.5.2	Message type error .....	50
9.5.3	Mandatory information element error .....	50
9.6	Message functional definitions and contents .....	51
9.6.1	X.25 layer 3 sublayer.....	51
9.6.2	Data transfer management sublayer.....	51
9.6.2.1	Message type .....	51
9.6.2.2	Packet data transfer (PD1) .....	52
9.6.2.3	Packet data transfer (PD2) .....	52
9.6.2.4	Connect .....	52
9.6.2.5	Disconnect .....	52
9.7	General message format and information elements coding.....	53
9.7.1	CIF indicator .....	53
9.7.2	DTM cause .....	53
9.7.3	Data information .....	54
9.8	List of system parameters.....	54

9.8.1	Timers for data transfer on the GSS side .....	54
9.8.2	Timers for data transfer on the CIF side.....	54
9.9	Definition of primitive parameters.....	55
Annex A (informative): Information on expected usage of data service .....		56
A.1	Status update information.....	56
A.2	File transfer.....	56
A.3	Information update.....	56
A.4	Interactive services .....	56
Annex B (informative): Scenarios .....		57
Annex C (informative): SDL of TFTS layer 3 DTM processes.....		74
History .....		125