

ETSI TS 138 331 V16.12.0 (2023-04)



5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 16.12.0 Release 16)

<https://standards.iteh.ai/catalog/standards/sist/c15d4fef-0724-4a23-81fb-8fb3c314c50b/etsi-ts-138-331-v16-12-0-2023-04>



ReferenceRTS/TSGR-0238331vgc0

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards.iteh.ai/> <https://portal.etsi.org/People/CommitteeSupportStaff.aspx> <https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.

All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	20
1 Scope	21
2 References	21
3 Definitions, symbols and abbreviations	23
3.1 Definitions	23
3.2 Abbreviations	25
4 General	27
4.1 Introduction	27
4.2 Architecture	27
4.2.1 UE states and state transitions including inter RAT	27
4.2.2 Signalling radio bearers	30
4.3 Services	30
4.3.1 Services provided to upper layers	30
4.3.2 Services expected from lower layers	31
4.4 Functions	31
5 Procedures	32
5.1 General	32
5.1.1 Introduction.....	32
5.1.2 General requirements.....	32
5.1.3 Requirements for UE in MR-DC	32
5.2 System information	33
5.2.1 Introduction.....	33
5.2.2 System information acquisition	34
5.2.2.1 General UE requirements	34
5.2.2.2 SIB validity and need to (re)-acquire SIB	34
5.2.2.2.1 SIB validity.....	34
5.2.2.2.2 SI change indication and PWS notification	36
5.2.2.3 Acquisition of System Information	37
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	37
5.2.2.3.2 Acquisition of an SI message	38
5.2.2.3.3 Request for on demand system information	39
5.2.2.3.3a Request for on demand positioning system information	40
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	41
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	41
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	42
5.2.2.4 Actions upon receipt of System Information	42
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	42
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	42
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	46
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	46
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	46
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	47
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	47
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	47
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	48
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	49
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	49
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	49
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	49
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	50

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	50
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	50
5.2.2.5	Essential system information missing	50
5.3	Connection control	51
5.3.1	Introduction.....	51
5.3.1.1	RRC connection control	51
5.3.1.2	AS Security	51
5.3.2	Paging	53
5.3.2.1	General	53
5.3.2.2	Initiation.....	53
5.3.2.3	Reception of the <i>Paging message</i> by the UE	53
5.3.3	RRC connection establishment	54
5.3.3.1	General	54
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/V2X sidelink communication.....	54
5.3.3.2	Initiation.....	55
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message.....	55
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	55
5.3.3.5	Reception of the <i>RRCReject</i> by the UE.....	58
5.3.3.6	Cell re-selection or cell selection while T390, T300 or T302 is running (UE in RRC_IDLE)	58
5.3.3.7	T300 expiry	59
5.3.3.8	Abortion of RRC connection establishment.....	60
5.3.4	Initial AS security activation	60
5.3.4.1	General	60
5.3.4.2	Initiation.....	60
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE.....	61
5.3.5	RRC reconfiguration.....	61
5.3.5.1	General	61
5.3.5.2	Initiation.....	62
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	63
5.3.5.4	Secondary cell group release	70
5.3.5.5	Cell Group configuration	71
5.3.5.5.1	General	71
5.3.5.5.2	Reconfiguration with sync	71
5.3.5.5.3	RLC bearer release	73
5.3.5.5.4	RLC bearer addition/modification.....	73
5.3.5.5.5	MAC entity configuration	74
5.3.5.5.6	RLF Timers & Constants configuration	75
5.3.5.5.7	SpCell Configuration.....	75
5.3.5.5.8	SCell Release.....	76
5.3.5.5.9	SCell Addition/Modification	76
5.3.5.5.10	BH RLC channel release	76
5.3.5.5.11	BH RLC channel addition/modification.....	77
5.3.5.6	Radio Bearer configuration	77
5.3.5.6.1	General	77
5.3.5.6.2	SRB release	77
5.3.5.6.3	SRB addition/modification	78
5.3.5.6.4	DRB release.....	79
5.3.5.6.5	DRB addition/modification	80
5.3.5.7	AS Security key update.....	83
5.3.5.8	Reconfiguration failure	84
5.3.5.8.1	Void	84
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	84
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure)	86
5.3.5.9	Other configuration	87
5.3.5.10	MR-DC release	89
5.3.5.11	Full configuration.....	90
5.3.5.12	BAP configuration	91
5.3.5.12a	IAB Other Configuration	92
5.3.5.12a.1	IP address management	92
5.3.5.12a.1.1	IP Address Release	92
5.3.5.12a.1.2	IP Address Addition/Modification.....	92

5.3.5.13	Conditional Reconfiguration	93
5.3.5.13.1	General	93
5.3.5.13.2	Conditional reconfiguration removal	93
5.3.5.13.3	Conditional reconfiguration addition/modification	93
5.3.5.13.4	Conditional reconfiguration evaluation	94
5.3.5.13.5	Conditional reconfiguration execution	94
5.3.5.14	Sidelink dedicated configuration	95
5.3.6	Counter check	96
5.3.6.1	General	96
5.3.6.2	Initiation	96
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	96
5.3.7	RRC connection re-establishment	97
5.3.7.1	General	97
5.3.7.2	Initiation	98
5.3.7.3	Actions following cell selection while T311 is running	100
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	101
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	102
5.3.7.6	T311 expiry	103
5.3.7.7	T301 expiry or selected cell no longer suitable	103
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	104
5.3.8	RRC connection release	104
5.3.8.1	General	104
5.3.8.2	Initiation	104
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	104
5.3.8.4	T320 expiry	107
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	107
5.3.9	RRC connection release requested by upper layers	107
5.3.9.1	General	107
5.3.9.2	Initiation	107
5.3.10	Radio link failure related actions	108
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	108
5.3.10.2	Recovery of physical layer problems	108
5.3.10.3	Detection of radio link failure	108
5.3.10.4	RLF cause determination	110
5.3.10.5	RLF report content determination	110
5.3.11	UE actions upon going to RRC_IDLE	113
5.3.12	UE actions upon PUCCH/SRS release request	114
5.3.13	RRC connection resume	114
5.3.13.1	General	114
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/V2X sidelink communication	115
5.3.13.2	Initiation	115
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	117
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	118
5.3.13.5	T319 expiry or Integrity check failure from lower layers while T319 is running	122
5.3.13.6	Cell re-selection or cell selection while T390, T319 or T302 is running (UE in RRC_INACTIVE)	123
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE	123
5.3.13.8	RNA update	123
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	123
5.3.13.10	Reception of the <i>RRCReject</i> by the UE	123
5.3.13.11	Inability to comply with <i>RRCResume</i>	124
5.3.13.12	Inter RAT cell reselection	124
5.3.14	Unified Access Control	124
5.3.14.1	General	124
5.3.14.2	Initiation	124
5.3.14.3	Void	126
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	126
5.3.14.5	Access barring check	126
5.3.15	RRC connection reject	127
5.3.15.1	Initiation	127
5.3.15.2	Reception of the <i>RRCReject</i> by the UE	127

5.4	Inter-RAT mobility.....	128
5.4.1	Introduction.....	128
5.4.2	Handover to NR.....	128
5.4.2.1	General.....	128
5.4.2.2	Initiation.....	128
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE.....	129
5.4.3	Mobility from NR.....	129
5.4.3.1	General.....	129
5.4.3.2	Initiation.....	129
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	129
5.4.3.4	Successful completion of the mobility from NR.....	130
5.4.3.5	Mobility from NR failure.....	130
5.5	Measurements.....	131
5.5.1	Introduction.....	131
5.5.2	Measurement configuration.....	133
5.5.2.1	General.....	133
5.5.2.2	Measurement identity removal.....	135
5.5.2.3	Measurement identity addition/modification.....	135
5.5.2.4	Measurement object removal.....	136
5.5.2.5	Measurement object addition/modification.....	137
5.5.2.6	Reporting configuration removal.....	138
5.5.2.7	Reporting configuration addition/modification.....	139
5.5.2.8	Quantity configuration.....	139
5.5.2.9	Measurement gap configuration.....	139
5.5.2.10	Reference signal measurement timing configuration.....	141
5.5.2.10a	RSSI measurement timing configuration.....	141
5.5.2.11	Measurement gap sharing configuration.....	142
5.5.3	Performing measurements.....	142
5.5.3.1	General.....	142
5.5.3.2	Layer 3 filtering.....	146
5.5.3.3	Derivation of cell measurement results.....	147
5.5.3.3a	Derivation of layer 3 beam filtered measurement.....	148
5.5.4	Measurement report triggering.....	148
5.5.4.1	General.....	148
5.5.4.2	Event A1 (Serving becomes better than threshold).....	153
5.5.4.3	Event A2 (Serving becomes worse than threshold).....	154
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell).....	154
5.5.4.5	Event A4 (Neighbour becomes better than threshold).....	155
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2).....	156
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell).....	156
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold).....	157
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2).....	158
5.5.4.10	Event I1 (Interference becomes higher than threshold).....	159
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold).....	159
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold).....	159
5.5.4.13	Void.....	160
5.5.4.14	Void.....	160
5.5.5	Measurement reporting.....	160
5.5.5.1	General.....	160
5.5.5.2	Reporting of beam measurement information.....	167
5.5.5.3	Sorting of cell measurement results.....	168
5.5.6	Location measurement indication.....	169
5.5.6.1	General.....	169
5.5.6.2	Initiation.....	169
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message.....	170
5.5a	Logged Measurements.....	170
5.5a.1	Logged Measurement Configuration.....	170
5.5a.1.1	General.....	170
5.5a.1.2	Initiation.....	171
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE.....	171

5.5a.1.4	T330 expiry	171
5.5a.2	Release of Logged Measurement Configuration.....	171
5.5a.2.1	General	171
5.5a.2.2	Initiation.....	171
5.5a.3	Measurements logging.....	172
5.5a.3.1	General	172
5.5a.3.2	Initiation.....	172
5.6	UE capabilities	174
5.6.1	UE capability transfer	174
5.6.1.1	General	174
5.6.1.2	Initiation.....	174
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	174
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	175
5.6.1.5	Void.....	177
5.7	Other.....	177
5.7.1	DL information transfer	177
5.7.1.1	General	177
5.7.1.2	Initiation.....	178
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	178
5.7.1a	DL information transfer for MR-DC	178
5.7.1a.1	General	178
5.7.1a.2	Initiation.....	178
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message.....	178
5.7.2	UL information transfer	179
5.7.2.1	General	179
5.7.2.2	Initiation.....	179
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	179
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	179
5.7.2a	UL information transfer for MR-DC	180
5.7.2a.1	General	180
5.7.2a.2	Initiation.....	180
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	180
5.7.2b	UL transfer of IRAT information	180
5.7.2b.1	General	180
5.7.2b.2	Initiation.....	181
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	181
5.7.3	SCG failure information	181
5.7.3.1	General	181
5.7.3.2	Initiation.....	181
5.7.3.3	Failure type determination for (NG)EN-DC	182
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	183
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	183
5.7.3a	EUTRA SCG failure information	185
5.7.3a.1	General	185
5.7.3a.2	Initiation.....	185
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message.....	185
5.7.3b	MCG failure information	186
5.7.3b.1	General	186
5.7.3b.2	Initiation.....	186
5.7.3b.3	Failure type determination	186
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message.....	187
5.7.3b.5	T316 expiry	188
5.7.4	UE Assistance Information	189
5.7.4.1	General	189
5.7.4.2	Initiation.....	189
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	193
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE.....	198
5.7.4a	Void	199
5.7.5	Failure information	199
5.7.5.1	General	199
5.7.5.2	Initiation.....	199
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message.....	199

5.7.6	DL message segment transfer	200
5.7.6.1	General	200
5.7.6.2	Initiation	200
5.7.6.3	Reception of <i>DL DedicatedMessageSegment</i> by the UE	200
5.7.7	UL message segment transfer	200
5.7.7.1	General	200
5.7.7.2	Initiation	201
5.7.7.3	Actions related to transmission of <i>UL DedicatedMessageSegment</i> message	201
5.7.8	Idle/inactive Measurements	201
5.7.8.1	General	201
5.7.8.1a	Measurement configuration	201
5.7.8.2	Void	202
5.7.8.2a	Performing measurements	202
5.7.8.3	T331 expiry or stop	205
5.7.8.4	Cell re-selection or cell selection while T331 is running	205
5.7.9	Mobility history information	206
5.7.9.1	General	206
5.7.9.2	Initiation	206
5.7.10	UE Information	206
5.7.10.1	General	206
5.7.10.2	Initiation	207
5.7.10.3	Reception of the <i>UE InformationRequest</i> message	207
5.7.10.4	Actions upon successful completion of random-access procedure	209
5.7.10.5	RA information determination for RA report and RLF report	209
5.7.12	IAB Other Information	211
5.7.12.1	General	211
5.7.12.2	Initiation	211
5.7.12.3	Actions related to transmission of <i>IAB OtherInformation</i> message	211
5.8	Sidelink	213
5.8.1	General	213
5.8.2	Conditions for NR sidelink communication operation	213
5.8.3	Sidelink UE information for NR sidelink communication	214
5.8.3.1	General	214
5.8.3.2	Initiation	214
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	215
5.8.4	Void	216
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication	216
5.8.5.1	General	216
5.8.5.2	Initiation	217
5.8.5.3	Transmission of SLSS	217
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	219
5.8.5a.1	General	219
5.8.5a.2	Initiation	219
5.8.6	Sidelink synchronisation reference	219
5.8.6.1	General	219
5.8.6.2	Selection and reselection of synchronisation reference	219
5.8.6.3	Sidelink communication transmission reference cell selection	222
5.8.7	Sidelink communication reception	222
5.8.8	Sidelink communication transmission	223
5.8.9	Sidelink RRC procedure	225
5.8.9.1	Sidelink RRC reconfiguration	225
5.8.9.1.1	General	225
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	225
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	226
5.8.9.1.4	Void	228
5.8.9.1.5	Void	228
5.8.9.1.6	Void	228
5.8.9.1.7	Void	228
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	228
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	228
5.8.9.1a	Sidelink radio bearer management	228
5.8.9.1a.1	Sidelink DRB release	228

5.8.9.1a.2	Sidelink DRB addition/modification	230
5.8.9.1a.3	Sidelink SRB release	231
5.8.9.1a.4	Sidelink SRB addition	231
5.8.9.2	Sidelink UE capability transfer	232
5.8.9.2.1	General	232
5.8.9.2.2	Initiation	232
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	232
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	232
5.8.9.3	Sidelink radio link failure related actions	233
5.8.9.4	Sidelink common control information	233
5.8.9.4.1	General	233
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	233
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	233
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	235
5.8.10	Sidelink measurement	235
5.8.10.1	Introduction	235
5.8.10.2	Sidelink measurement configuration	236
5.8.10.2.1	General	236
5.8.10.2.2	Sidelink measurement identity removal	236
5.8.10.2.3	Sidelink measurement identity addition/modification	236
5.8.10.2.4	Sidelink measurement object removal	237
5.8.10.2.5	Sidelink measurement object addition/modification	237
5.8.10.2.6	Sidelink reporting configuration removal	237
5.8.10.2.7	Sidelink reporting configuration addition/modification	238
5.8.10.2.8	Sidelink quantity configuration	238
5.8.10.3	Performing NR sidelink measurements	238
5.8.10.3.1	General	238
5.8.10.3.2	Derivation of NR sidelink measurement results	239
5.8.10.4	Sidelink measurement report triggering	239
5.8.10.4.1	General	239
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	240
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	240
5.8.10.5	Sidelink measurement reporting	241
5.8.10.5.1	General	241
5.8.11	Zone identity calculation	242
5.8.12	DFN derivation from GNSS	242
6	Protocol data units, formats and parameters (ASN.1)	243
6.1	General	243
6.1.1	Introduction	243
6.1.2	Need codes and conditions for optional fields	243
6.1.3	General rules	246
6.2	RRC messages	246
6.2.1	General message structure	246
–	<i>NR-RRC-Definitions</i>	246
–	<i>BCCH-BCH-Message</i>	246
–	<i>BCCH-DL-SCH-Message</i>	247
–	<i>DL-CCCH-Message</i>	247
–	<i>DL-DCCH-Message</i>	248
–	<i>PCCH-Message</i>	248
–	<i>UL-CCCH-Message</i>	249
–	<i>UL-CCCH1-Message</i>	249
–	<i>UL-DCCH-Message</i>	250
6.2.2	Message definitions	252
–	<i>CounterCheck</i>	252
–	<i>CounterCheckResponse</i>	253
–	<i>DedicatedSIBRequest</i>	254
–	<i>DLDedicatedMessageSegment</i>	255
–	<i>DLInformationTransfer</i>	256
–	<i>DLInformationTransferMRDC</i>	257
–	<i>FailureInformation</i>	258
–	<i>IABOtherInformation</i>	259

–	<i>LocationMeasurementIndication</i>	262
–	<i>LoggedMeasurementConfiguration</i>	263
–	<i>MCGFailureInformation</i>	264
–	<i>MeasurementReport</i>	266
–	<i>MIB</i>	267
–	<i>MobilityFromNRCommand</i>	268
–	<i>Paging</i>	270
–	<i>RRCReestablishment</i>	271
–	<i>RRCReestablishmentComplete</i>	271
–	<i>RRCReestablishmentRequest</i>	272
–	<i>RRCReconfiguration</i>	273
–	<i>RRCReconfigurationComplete</i>	278
–	<i>RRCReject</i>	280
–	<i>RRCRelease</i>	281
–	<i>RRCResume</i>	285
–	<i>RRCResumeComplete</i>	287
–	<i>RRCResumeRequest</i>	289
–	<i>RRCResumeRequest1</i>	290
–	<i>RRCSetup</i>	291
–	<i>RRCSetupComplete</i>	292
–	<i>RRCSetupRequest</i>	293
–	<i>RRCSystemInfoRequest</i>	295
–	<i>SCGFailureInformation</i>	296
–	<i>SCGFailureInformationEUTRA</i>	297
–	<i>SecurityModeCommand</i>	298
–	<i>SecurityModeComplete</i>	299
–	<i>SecurityModeFailure</i>	300
–	<i>SIB1</i>	300
–	<i>SidelinkUEInformationNR</i>	304
–	<i>SystemInformation</i>	306
–	<i>UEAssistanceInformation</i>	307
–	<i>UECapabilityEnquiry</i>	314
–	<i>UECapabilityInformation</i>	315
–	<i>UEInformationRequest</i>	316
–	<i>UEInformationResponse</i>	317
–	<i>ULDedicatedMessageSegment</i>	326
–	<i>ULInformationTransfer</i>	327
–	<i>ULInformationTransferIRAT</i>	327
–	<i>ULInformationTransferMRDC</i>	328
6.3	RRC information elements	329
6.3.0	Parameterized types	329
–	<i>SetupRelease</i>	329
6.3.1	System information blocks	330
–	<i>SIB2</i>	330
–	<i>SIB3</i>	334
–	<i>SIB4</i>	335
–	<i>SIB5</i>	339
–	<i>SIB6</i>	342
–	<i>SIB7</i>	342
–	<i>SIB8</i>	343
–	<i>SIB9</i>	344
–	<i>SIB10</i>	345
–	<i>SIB11</i>	346
–	<i>SIB12</i>	346
–	<i>SIB13</i>	348
–	<i>SIB14</i>	349
6.3.1a	Positioning System information blocks	349
–	<i>PosSystemInformation-r16-IEs</i>	349
–	<i>PosSI-SchedulingInfo</i>	350
–	<i>SIBpos</i>	352
6.3.2	Radio resource control information elements	353
–	<i>AdditionalSpectrumEmission</i>	353

Alpha	353
AMF-Identifier	354
ARFCN-ValueEUTRA	354
ARFCN-ValueNR	354
ARFCN-ValueUTRA-FDD	355
AvailabilityCombinationsPerCell	355
AvailabilityIndicator	356
BAP-RoutingID	357
BeamFailureRecoveryConfig	357
BeamFailureRecoverySCellConfig	360
BetaOffsets	361
BH-LogicalChannelIdentity	362
BH-LogicalChannelIdentity-Ext	362
BH-RLC-ChannelConfig	363
BH-RLC-ChannelID	364
BSR-Config	364
BWP	365
BWP-Downlink	365
BWP-DownlinkCommon	366
BWP-DownlinkDedicated	367
BWP-Id	368
BWP-Uplink	369
BWP-UplinkCommon	369
BWP-UplinkDedicated	370
CellAccessRelatedInfo	373
CellAccessRelatedInfo-EUTRA-5GC	374
CellAccessRelatedInfo-EPC	375
CellGroupConfig	375
CellGroupId	380
CellIdentity	381
CellReselectionPriority	381
CellReselectionSubPriority	381
CGI-InfoEUTRA	382
CGI-InfoEUTRALogging	382
CGI-InfoNR	383
CGI-Info-Logging	384
CLI-RSSI-Range	384
CodebookConfig	385
CommonLocationInfo	388
CondReconfigId	389
CondReconfigToAddModList	390
ConditionalReconfiguration	390
ConfiguredGrantConfig	391
ConfiguredGrantConfigIndex	397
ConfiguredGrantConfigIndexMAC	397
ConnEstFailureControl	398
ControlResourceSet	398
ControlResourceSetId	401
ControlResourceSetZero	401
CrossCarrierSchedulingConfig	401
CSI-AperiodicTriggerStateList	403
CSI-FrequencyOccupation	404
CSI-IM-Resource	405
CSI-IM-ResourceId	406
CSI-IM-ResourceSet	406
CSI-IM-ResourceSetId	407
CSI-MeasConfig	407
CSI-ReportConfig	409
CSI-ReportConfigId	414
CSI-ResourceConfig	414
CSI-ResourceConfigId	415
CSI-ResourcePeriodicityAndOffset	415

–	CSI-RS-ResourceConfigMobility	416
–	CSI-RS-ResourceMapping	418
–	CSI-SemiPersistentOnPUSCH-TriggerStateList.....	419
–	CSI-SSB-ResourceSet.....	420
–	CSI-SSB-ResourceSetId.....	420
–	DedicatedNAS-Message.....	420
–	DMRS-DownlinkConfig	421
–	DMRS-UplinkConfig.....	422
–	DownlinkConfigCommon.....	424
–	DownlinkConfigCommonSIB	425
–	DownlinkPreemption.....	427
–	DRB-Identity	428
–	DRX-Config.....	428
–	DRX-ConfigSecondaryGroup.....	430
–	FilterCoefficient	431
–	FreqBandIndicatorNR.....	431
–	FrequencyInfoDL	432
–	FrequencyInfoDL-SIB.....	433
–	FrequencyInfoUL	433
–	FrequencyInfoUL-SIB.....	434
–	HighSpeedConfig	436
–	Hysteresis	436
–	InvalidSymbolPattern.....	437
–	I-RNTI-Value.....	438
–	LBT-FailureRecoveryConfig	438
–	LocationInfo	438
–	LocationMeasurementInfo	439
–	LogicalChannelConfig	440
–	LogicalChannelIdentity.....	443
–	MAC-CellGroupConfig	443
–	MeasConfig	445
–	MeasGapConfig	447
–	MeasGapSharingConfig	449
–	MeasId.....	450
–	MeasIdleConfig	450
–	MeasIdToAddModList.....	454
–	MeasObjectCLI	454
–	MeasObjectEUTRA.....	456
–	MeasObjectId	458
–	MeasObjectNR	459
–	MeasObjectNR-SL.....	464
–	MeasObjectToAddModList	465
–	MeasObjectUTRA-FDD.....	465
–	MeasResultCellListSFTD-NR.....	466
–	MeasResultCellListSFTD-EUTRA	467
–	MeasResults	467
–	MeasResult2EUTRA.....	472
–	MeasResult2NR.....	473
–	MeasResultIdleEUTRA	473
–	MeasResultIdleNR.....	474
–	MeasResultSCG-Failure	475
–	MeasResultsSL	476
–	MeasTriggerQuantityEUTRA.....	477
–	MobilityStateParameters.....	477
–	MsgA-ConfigCommon.....	478
–	MsgA-PUSCH-Config.....	479
–	MultiFrequencyBandListNR.....	482
–	MultiFrequencyBandListNR-SIB	483
–	NeedForGapsConfigNR.....	483
–	NextHopChainingCount.....	485
–	NG-5G-S-TMSI	485
–	NPN-Identity	486

–	NPN-IdentityInfoList	487
–	NR-NS-PmaxList	488
–	NZP-CSI-RS-Resource	488
–	NZP-CSI-RS-ResourceId	490
–	NZP-CSI-RS-ResourceSet	490
–	NZP-CSI-RS-ResourceSetId	491
–	P-Max	491
–	PCI-ARFCN-EUTRA	492
–	PCI-ARFCN-NR	492
–	PCI-List	492
–	PCI-Range	493
–	PCI-RangeElement	493
–	PCI-RangeIndex	494
–	PCI-RangeIndexList	494
–	PDCCCH-Config	494
–	PDCCCH-ConfigCommon	496
–	PDCCCH-ConfigSIB1	498
–	PDCCCH-ServingCellConfig	499
–	PDCCP-Config	500
–	PDSCH-Config	506
–	PDSCH-ConfigCommon	511
–	PDSCH-ServingCellConfig	511
–	PDSCH-TimeDomainResourceAllocationList	513
–	PHR-Config	514
–	PhysCellId	515
–	PhysicalCellGroupConfig	516
–	PLMN-Identity	520
–	PLMN-IdentityInfoList	521
–	PLMN-IdentityList2	522
–	PRB-Id	522
–	PTRS-DownlinkConfig	523
–	PTRS-UplinkConfig	523
–	PUCCH-Config	525
–	PUCCH-ConfigCommon	530
–	PUCCH-ConfigurationList	531
–	PUCCH-PathlossReferenceRS-Id	532
–	PUCCH-PowerControl	532
–	PUCCH-SpatialRelationInfo	534
–	PUCCH-SpatialRelationInfo-Id	535
–	PUCCH-TPC-CommandConfig	535
–	PUSCH-Config	536
–	PUSCH-ConfigCommon	542
–	PUSCH-PowerControl	543
–	PUSCH-ServingCellConfig	547
–	PUSCH-TimeDomainResourceAllocationList	548
–	PUSCH-TPC-CommandConfig	550
–	Q-OffsetRange	550
–	Q-QualMin	551
–	Q-RxLevMin	551
–	QuantityConfig	551
–	RACH-ConfigCommon	553
–	RACH-ConfigCommonTwoStepRA	556
–	RACH-ConfigDedicated	559
–	RACH-ConfigGeneric	563
–	RACH-ConfigGenericTwoStepRA	564
–	RA-Prioritization	566
–	RadioBearerConfig	566
–	RadioLinkMonitoringConfig	570
–	RadioLinkMonitoringRS-Id	571
–	RAN-AreaCode	571
–	RateMatchPattern	571
–	RateMatchPatternId	573

–	RateMatchPatternLTE-CRS	574
–	ReferenceTimeInfo	574
–	RejectWaitTime	576
–	RepetitionSchemeConfig	576
–	ReportConfigId	577
–	ReportConfigInterRAT	577
–	ReportConfigNR	581
–	ReportConfigNR-SL	588
–	ReportConfigToAddModList	590
–	ReportInterval	590
–	ReselectionThreshold	591
–	ReselectionThresholdQ	591
–	ResumeCause	591
–	RLC-BearerConfig	592
–	RLC-Config	593
–	RLF-TimersAndConstants	595
–	RNTI-Value	596
–	RSRP-Range	596
–	RSRQ-Range	597
–	RSSI-Range	597
–	SCellIndex	597
–	SchedulingRequestConfig	598
–	SchedulingRequestId	599
–	SchedulingRequestResourceConfig	599
–	SchedulingRequestResourceId	600
–	ScramblingId	601
–	SCS-SpecificCarrier	601
–	SDAP-Config	602
–	SearchSpace	603
–	SearchSpaceId	608
–	SearchSpaceZero	608
–	SecurityAlgorithmConfig	609
–	SemiStaticChannelAccessConfig	609
–	Sensor-LocationInfo	610
–	ServCellIndex	610
–	ServingCellConfig	611
–	ServingCellConfigCommon	620
–	ServingCellConfigCommonSIB	622
–	ShortI-RNTI-Value	623
–	ShortMAC-I	624
–	SINR-Range	624
–	SI-RequestConfig	624
–	SI-SchedulingInfo	625
–	SK-Counter	627
–	SlotFormatCombinationsPerCell	627
–	SlotFormatIndicator	629
–	S-NSSAI	632
–	SpeedStateScaleFactors	632
–	SPS-Config	633
–	SPS-ConfigIndex	634
–	SPS-PUCCH-AN	635
–	SPS-PUCCH-AN-List	635
–	SRB-Identity	635
–	SRS-CarrierSwitching	636
–	SRS-Config	637
–	SRS-RSRP-Range	648
–	SRS-TPC-CommandConfig	648
–	SSB-Index	649
–	SSB-MTC	650
–	SSB-PositionQCL-Relation	651
–	SSB-ToMeasure	651
–	SS-RSSI-Measurement	652