

ETSI TS 124 008 V17.9.0 (2023-07)



**Digital cellular telecommunications system (Phase 2+) (GSM);
Universal Mobile Telecommunications System (UMTS);**

**LTE;
5G;**

Mobile radio interface Layer 3 specification;

Core network protocols;

Stage 3

(3GPP TS 24.008 version 17.9.0 Release 17)



Reference

RTS/TSGC-0124008vh90

Keywords

5G,GSM,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards-portal.etsi.org/People/CommitteeSupportStaff.aspx> 44b9-96c8-

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	29
Introduction	29
1 Scope	30
1.1 Scope of the Technical Specification	30
1.2 Application to the interface structures.....	30
1.3 Structure of layer 3 procedures.....	30
1.4 Test procedures	31
1.5 Use of logical channels in A/Gb mode.....	31
1.6 Overview of control procedures	31
1.6.1 List of procedures	31
1.7 Applicability of implementations	33
1.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS).....	33
1.7.2 General Packet Radio Service (GPRS)	33
1.7.2.1 Packet services in GSM (A/Gb mode only)	33
1.7.2.2 Packet services in Iu mode (Iu mode only)	34
1.8 Handling of NAS signalling low priority indication	34
1.9 Restrictions	35
2 References	35
2.1 Definitions and abbreviations.....	42
2.1.1 Random values.....	43
2.1.2 Vocabulary.....	43
3 Radio Resource management procedures.....	48
4 Elementary procedures for Mobility Management.....	49
4.1 General	49
4.1.1 MM and GMM procedures	49
4.1.1.1 Types of MM and GMM procedures	49
4.1.1.1.1 Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	51
4.1.1.1.1a Integrity protection for emergency call (Iu mode only).....	53
4.1.1.2 MM-GMM co-ordination for GPRS MS's	53
4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I	53
4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II.....	54
4.1.1.2A Coordination between GMM and EMM	55
4.1.1.2B Coordination between GMM and 5GMM.....	55
4.1.1.3 Core Network System Information for MM (Iu mode only).....	55
4.1.1.4 Core Network System Information for GMM (Iu mode only).....	55
4.1.1.4.1 General	55
4.1.1.4.2 Control of Network Mode of Operation I.....	55
4.1.1.5 Access class control	56
4.1.1.6 Specific requirements for MS configured to use timer T3245	57
4.1.1.6A Specific requirements for the MS when receiving non-integrity protected reject messages	57
4.1.1.7 Handling of NAS level mobility management congestion control.....	63
4.1.1.8 Handling of security related parameters at switch on and switch off.....	64
4.1.1.9 Equivalent PLMNs list.....	64
4.1.1.10 Dedicated core network.....	64
4.1.2 MM sublayer states	65
4.1.2.1 MM sublayer states in the mobile station.....	65
4.1.2.1.1 Main states.....	65
4.1.2.1.2 Substates of the MM IDLE state	68
4.1.2.2 The update Status	70
4.1.2.3 MM sublayer states on the network side	70

4.1.3	GPRS mobility management (GMM) sublayer states.....	72
4.1.3.1	GMM states in the MS	72
4.1.3.1.1	Main states.....	72
4.1.3.1.2	Substates of state GMM-DEREGISTERED.....	73
4.1.3.1.3	Substates of state GMM-REGISTERED.....	73
4.1.3.2	GPRS update status	76
4.1.3.3	GMM mobility management states on the network side.....	76
4.1.3.3.1	Main States	77
4.1.3.3.2	Substates of state GMM-REGISTERED.....	77
4.2	Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state	78
4.2.1	Primary Service State selection	78
4.2.1.1	Selection of the Service State after Power On.....	78
4.2.1.2	Other Cases	79
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.	79
4.2.2.1	Service State, NORMAL SERVICE	79
4.2.2.2	Service State, ATTEMPTING TO UPDATE	80
4.2.2.3	Service State, LIMITED SERVICE.....	80
4.2.2.4	Service State, NO IMSI.....	81
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	81
4.2.2.6	Service State, SEARCH FOR PLMN	82
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	82
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE).....	82
4.2.2.9	Service State, eCALL INACTIVE.....	83
4.2.3	Service state when back to state MM IDLE from another state.....	83
4.2.4	Behaviour in state GMM-DEREGISTERED.....	84
4.2.4.1	Primary substate selection.....	84
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability.....	84
4.2.4.1.2	Other Cases.....	85
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED.....	85
4.2.4.2.1	Substate, NORMAL-SERVICE	85
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH	85
4.2.4.2.3	Substate, LIMITED-SERVICE	86
4.2.4.2.4	Substate, NO-IMSI	86
4.2.4.2.5	Substate, NO-CELL	86
4.2.4.2.6	Substate, PLMN-SEARCH	86
4.2.4.2.7	Substate, ATTACH-NEEDED	86
4.2.4.2.8	Substate, SUSPENDED (A/Gb mode only)	86
4.2.4.3	Substate when back to state GMM-DEREGISTERED from another GMM state	86
4.2.5	Behaviour in state GMM-REGISTERED.....	87
4.2.5.1	Detailed description of the MS behaviour in state GMM-REGISTERED.....	87
4.2.5.1.1	Substate, NORMAL-SERVICE	87
4.2.5.1.2	Substate, SUSPENDED (A/Gb mode only)	87
4.2.5.1.3	Substate, UPDATE-NEEDED.....	88
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE	88
4.2.5.1.5	Substate, NO-CELL-AVAILABLE	89
4.2.5.1.6	Substate, LIMITED-SERVICE	89
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM	89
4.2.5.1.8	Substate, PLMN-SEARCH	89
4.3	MM common procedures	89
4.3.1	TMSI reallocation procedure	89
4.3.1.0	General	89
4.3.1.1	TMSI reallocation initiation by the network	90
4.3.1.2	TMSI reallocation completion by the mobile station	90
4.3.1.3	TMSI reallocation completion in the network.....	90
4.3.1.4	Abnormal cases in the mobile station.....	90
4.3.1.5	Abnormal cases on the network side.....	91
4.3.2	Authentication procedure.....	91
4.3.2a	Authentication procedure used for a UMTS authentication challenge.....	91
4.3.2b	Authentication Procedure used for a GSM authentication challenge.....	92
4.3.2.1	Authentication request by the network.....	92
4.3.2.2	Authentication response by the mobile station.....	92
4.3.2.3	Authentication processing in the network	93

4.3.2.3a	128-bit circuit-switched GSM ciphering key	93
4.3.2.4	Ciphering key sequence number	93
4.3.2.5	Authentication not accepted by the network	94
4.3.2.5.1	Authentication not accepted by the MS	95
4.3.2.6	Abnormal cases	96
4.3.2.6.1	MS behaviour towards a network that has failed the authentication procedure.....	98
4.3.2.7	Handling of keys at intersystem change from Iu mode to A/Gb mode	98
4.3.2.7a	Use of established security contexts.....	99
4.3.2.8	Handling of keys at intersystem change from A/Gb mode to Iu mode	100
4.3.2.9	Void.....	101
4.3.2.10	Derivation of keys at SRVCC or vSRVCC handover from S1 mode	101
4.3.2.10.0	General	101
4.3.2.10.1	PDN connection with integrity protection	101
4.3.2.10.2	PDN connection without integrity protection	101
4.3.2.11	Derivation of keys at SRVCC handover from Iu mode to Iu mode	101
4.3.2.11.1	PDN connection with integrity protection	101
4.3.2.11.2	PDN connection without integrity protection	102
4.3.2.12	Derivation of keys at SRVCC handover from Iu mode to A/Gb mode.....	103
4.3.2.12.1	PDN connection with integrity protection	103
4.3.2.12.2	PDN connection without integrity protection.....	104
4.3.2.13	Derivation of keys at CS to PS SRVCC handover from A/Gb mode to Iu mode	104
4.3.2.14	Derivation of keys at 5G-SRVCC from NG-RAN to UTRAN	106
4.3.2.14.1	PDU session with integrity protection	106
4.3.2.14.2	PDU session without integrity protection.....	106
4.3.3	Identification procedure	106
4.3.3.0	General	106
4.3.3.1	Identity request by the network.....	106
4.3.3.2	Identification response by the mobile station.....	106
4.3.3.3	Abnormal cases in the mobile station.....	107
4.3.3.4	Abnormal cases on the network side	107
4.3.4	IMSI detach procedure.....	107
4.3.4.0	General	107
4.3.4.1	IMSI detach initiation by the mobile station	108
4.3.4.2	IMSI detach procedure in the network	108
4.3.4.3	IMSI detach completion by the mobile station.....	108
4.3.4.4	Abnormal cases	108
4.3.5	Abort procedure	109
4.3.5.1	Abort procedure initiation by the network	109
4.3.5.2	Abort procedure in the mobile station.....	109
4.3.6	MM information procedure.....	109
4.3.6.1	MM information procedure initiation by the network.....	109
4.3.6.2	MM information procedure in the mobile station	110
4.4	MM specific procedures	110
4.4.1	Location updating procedure	110
4.4.2	Periodic updating	112
4.4.3	IMSI attach procedure	113
4.4.4	Generic Location Updating procedure.....	113
4.4.4.1	Location updating initiation by the mobile station.....	113
4.4.4.1a	Network Request for Additional mobile station Capability Information	114
4.4.4.2	Identification request from the network.....	114
4.4.4.3	Authentication by the network	114
4.4.4.4	Security mode setting by the network	114
4.4.4.5	Location Update Attempt Counter	114
4.4.4.6	Location updating accepted by the network.....	115
4.4.4.7	Location updating not accepted by the network.....	117
4.4.4.8	Release of RR connection after location updating	118
4.4.4.9	Abnormal cases on the mobile station side	119
4.4.4.10	Abnormal cases on the network side.....	121
4.4.5	Void	121
4.4.6	Void	121
4.4.7	eCall inactivity procedure.....	121
4.5	Connection management sublayer service provision	122

4.5.1	MM connection establishment.....	122
4.5.1.1	MM connection establishment initiated by the mobile station.....	122
4.5.1.2	Abnormal cases.....	126
4.5.1.3	MM connection establishment initiated by the network.....	128
4.5.1.3.1	Mobile Terminating CM Activity.....	128
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$.....	128
4.5.1.3.3	Paging response in Iu mode (Iu mode only).....	129
4.5.1.3.4	Paging response for CS fallback.....	130
4.5.1.4	Abnormal cases.....	130
4.5.1.5	MM connection establishment for emergency calls.....	130
4.5.1.5a	MM connection establishment for emergency calls for CS fallback.....	131
4.5.1.6	Call re-establishment.....	131
4.5.1.6.1	Call re-establishment, initiation by the mobile station.....	132
4.5.1.6.2	Abnormal cases.....	134
4.5.1.7	Forced release during MO MM connection establishment.....	134
4.5.1.8	MM connection establishment due to SRVCC or vSRVCC handover.....	135
4.5.1.9	MM connection establishment due to Dual Radio Voice Call Continuity (DRVCC) access transfer.....	135
4.5.2	MM connection information transfer phase.....	135
4.5.2.1	Sending CM messages.....	136
4.5.2.2	Receiving CM messages.....	136
4.5.2.3	Abnormal cases.....	136
4.5.3	MM connection release.....	136
4.5.3.1	Release of associated RR connection.....	136
4.5.3.2	Uplink release in a voice group call.....	137
4.6	Receiving a MM STATUS message by a MM entity.....	137
4.7	Elementary mobility management procedures for GPRS services.....	137
4.7.1	General.....	137
4.7.1.1	Lower layer failure.....	137
4.7.1.2	Ciphering of messages (A/Gb mode only).....	137
4.7.1.2a	Integrity protection of layer 3 signalling messages (A/Gb mode only and when integrity protection is required).....	138
4.7.1.2a.1	General.....	138
4.7.1.2a.2	Integrity checking of GMM signalling messages in the MS.....	138
4.7.1.2a.3	Integrity checking of layer 3 signalling messages in the network.....	138
4.7.1.2a.4	Establishment of integrity protection of layer 3 signalling messages.....	139
4.7.1.2a.5	Optional establishment of integrity protection in the user plane.....	140
4.7.1.2a.6	Change of security keys.....	140
4.7.1.3	P-TMSI signature.....	140
4.7.1.4	Radio resource sublayer address handling.....	141
4.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only).....	141
4.7.1.5	P-TMSI handling.....	142
4.7.1.5.1	P-TMSI handling in A/Gb mode.....	142
4.7.1.5.2	P-TMSI handling in Iu mode.....	143
4.7.1.5.3	Void.....	143
4.7.1.5.4	Void.....	143
4.7.1.6	Change of network mode of operation.....	143
4.7.1.6.1	Change of network mode of operation in A/Gb mode (A/Gb mode only).....	143
4.7.1.6.2	Change of network mode of operation in Iu mode (Iu mode only).....	143
4.7.1.6.3	Change of network mode of operation at Iu mode to A/Gb mode inter-system change.....	144
4.7.1.6.4	Change of network mode of operation at A/Gb mode to Iu mode inter-system change.....	144
4.7.1.7	Intersystem change between A/Gb mode and Iu mode.....	145
4.7.1.7a	Intersystem change from S1 mode to A/Gb mode or S1 mode to Iu mode with ISR activated.....	146
4.7.1.7b	Intersystem change from S1 mode to A/Gb mode or S1 mode to Iu mode for eCall only MS capable of eCall over IMS.....	147
4.7.1.7c	Return to packet idle mode for eCall only MS capable of eCall over IMS.....	147
4.7.1.8	List of forbidden PLMNs for GPRS service.....	147
4.7.1.8a	Establishment of the PS signalling connection (Iu mode only).....	148
4.7.1.9	Release of the PS signalling connection (Iu mode only).....	148
4.7.1.10	Handling of 3GPP PS data off.....	149
4.7.2	GPRS Mobility management timers and UMTS PS signalling connection control.....	150
4.7.2.1	READY timer behaviour.....	150

4.7.2.1.1	READY timer behaviour (A/Gb mode only).....	150
4.7.2.1.2	Handling of READY timer in the MS in Iu mode and S1 mode	151
4.7.2.1.2a	Handling of READY timer in the network in Iu mode and S1 mode	151
4.7.2.2	Periodic routing area updating	152
4.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	154
4.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only).....	154
4.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only)	154
4.7.2.6	Cell Update triggered by low layers.....	154
4.7.2.7	Handling of timer T3302.....	155
4.7.2.8	Handling of timer T3324 (A/Gb mode, Iu mode and S1 mode).....	155
4.7.2.9	Power saving mode	156
4.7.2.10	Extended idle-mode DRX cycle.....	157
4.7.2.11	Interaction between power saving mode and extended idle mode DRX cycle	157
4.7.2.12	Extended coverage for GSM.....	157
4.7.3	GPRS attach procedure.....	158
4.7.3.1	GPRS attach procedure for GPRS services.....	160
4.7.3.1.1	GPRS attach procedure initiation	160
4.7.3.1.2	GMM common procedure initiation.....	161
4.7.3.1.3	GPRS attach accepted by the network.....	162
4.7.3.1.4	GPRS attach not accepted by the network.....	165
4.7.3.1.4a	GPRS attach for emergency bearer services not accepted by the network (UTRAN Iu mode only)	170
4.7.3.1.4b	Attach for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	171
4.7.3.1.5	Abnormal cases in the MS.....	171
4.7.3.1.6	Abnormal cases on the network side	174
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services	175
4.7.3.2.1	Combined GPRS attach procedure initiation.....	176
4.7.3.2.2	GMM Common procedure initiation	176
4.7.3.2.3	Combined GPRS attach accepted by the network	176
4.7.3.2.4	Combined GPRS attach not accepted by the network	178
4.7.3.2.5	Abnormal cases in the MS.....	182
4.7.3.2.6	Abnormal cases on the network side	183
4.7.4	GPRS detach procedure	183
4.7.4.0	General	183
4.7.4.1	MS initiated GPRS detach procedure.....	184
4.7.4.1.1	MS initiated GPRS detach procedure initiation.....	184
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only.....	184
4.7.4.1.3	MS initiated combined GPRS detach procedure completion.....	185
4.7.4.1.4	Abnormal cases in the MS.....	185
4.7.4.1.5	Abnormal cases on the network side	187
4.7.4.2	Network initiated GPRS detach procedure	188
4.7.4.2.1	Network initiated GPRS detach procedure initiation.....	188
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS.....	188
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network	193
4.7.4.2.4	Abnormal cases on the network side	193
4.7.5	Routing area updating procedure	194
4.7.5.1	Normal and periodic routing area updating procedure	197
4.7.5.1.1	Normal and periodic routing area updating procedure initiation	198
4.7.5.1.2	GMM Common procedure initiation	199
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network.....	200
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network.....	206
4.7.5.1.4a	Routing area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only).....	212
4.7.5.1.5	Abnormal cases in the MS.....	213
4.7.5.1.6	Abnormal cases on the network side	216
4.7.5.2	Combined routing area updating procedure	218
4.7.5.2.0	General	218
4.7.5.2.1	Combined routing area updating procedure initiation	218
4.7.5.2.2	GMM Common procedure initiation	220
4.7.5.2.3	Combined routing area updating procedure accepted by the network.....	220
4.7.5.2.4	Combined routing area updating not accepted by the network.....	223

4.7.5.2.5	Abnormal cases in the MS.....	227
4.7.5.2.6	Abnormal cases on the network side	228
4.7.6	P-TMSI reallocation procedure.....	229
4.7.6.0	General	229
4.7.6.1	P-TMSI reallocation initiation by the network.....	229
4.7.6.2	P-TMSI reallocation completion by the MS	229
4.7.6.3	P-TMSI reallocation completion by the network	229
4.7.6.3A	Abnormal cases in the MS	229
4.7.6.4	Abnormal cases on the network side.....	230
4.7.7	Authentication and ciphering procedure.....	231
4.7.7a	Authentication and ciphering procedure used for UMTS authentication challenge.....	231
4.7.7b	Authentication and ciphering procedure used for GSM authentication challenge	232
4.7.7c	Change of the ciphering algorithm at PS Handover	232
4.7.7.1	Authentication and ciphering initiation by the network	232
4.7.7.2	Authentication and ciphering response by the MS	234
4.7.7.3	Authentication and ciphering completion by the network.....	236
4.7.7.3a	128-bit packet-switched GSM ciphering key	237
4.7.7.3b	128-bit packet-switched GSM integrity key (in A/Gb mode and only if MS supports integrity protection)	237
4.7.7.4	GPRS ciphering key sequence number	238
4.7.7.5	Authentication not accepted by the network	239
4.7.7.5.1	Authentication not accepted by the MS	240
4.7.7.6	Abnormal cases	240
4.7.7.6.1	MS behaviour towards a network that has failed the authentication procedure.....	244
4.7.7.7	Use of established security contexts.....	245
4.7.7.8	Handling of keys at intersystem change from Iu mode to A/Gb mode	246
4.7.7.9	Handling of keys at intersystem change from A/Gb mode to Iu mode	246
4.7.7.10	Handling of keys at intersystem change from S1 mode to Iu mode or A/Gb mode.....	247
4.7.8	Identification procedure	249
4.7.8.1	Identification initiation by the network.....	249
4.7.8.2	Identification response by the MS.....	249
4.7.8.3	Identification completion by the network	249
4.7.8.3a	Abnormal cases in the MS	249
4.7.8.4	Abnormal cases on the network side	250
4.7.9	Paging procedure	251
4.7.9.1	Paging for GPRS services	251
4.7.9.1.1	Paging for GPRS services using P-TMSI.....	251
4.7.9.1.2	Paging for GPRS services using IMSI.....	252
4.7.9.2	Paging for non-GPRS services.....	253
4.7.10	Receiving a GMM STATUS message by a GMM entity	253
4.7.11	Void	253
4.7.12	GMM Information procedure	253
4.7.12.1	GMM information procedure initiation by the network.....	253
4.7.12.2	GMM information procedure in the mobile station	253
4.7.13	Service Request procedure (Iu mode only).....	253
4.7.13.1	Service Request procedure initiation.....	255
4.7.13.2	GMM common procedure initiation	256
4.7.13.3	Service request procedure accepted by the network.....	256
4.7.13.4	Service request procedure not accepted by the network.....	257
4.7.13.4a	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	261
4.7.13.5	Abnormal cases in the MS	262
4.7.13.6	Abnormal cases on the network side.....	264
4.7.14	Void	265
4.7.15	GMM eCall inactivity procedure	265
5	Elementary procedures for circuit-switched Call Control.....	266
5.1	Overview	266
5.1.1	General.....	266
5.1.2	Call Control States	274
5.1.2.1	Call states at the mobile station side of the interface	274
5.1.2.1.1	Null (State U0)	274

5.1.2.1.2	MM Connection pending (U0.1)	274
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$	274
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$	274
5.1.2.1.2c	CC-Establishment present (U0.4) \$(CCBS)\$	274
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$	274
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	274
5.1.2.1.3	Call initiated (U1)	274
5.1.2.1.4	Mobile originating call proceeding (U3)	275
5.1.2.1.5	Call delivered (U4)	275
5.1.2.1.6	Call present (U6)	275
5.1.2.1.7	Call received (U7)	275
5.1.2.1.8	Connect Request (U8)	275
5.1.2.1.9	Mobile terminating call confirmed (U9)	275
5.1.2.1.10	Active (U10)	275
5.1.2.1.11	Disconnect request (U11)	275
5.1.2.1.12	Disconnect indication (U12)	275
5.1.2.1.13	Release request (U19)	275
5.1.2.1.14	Mobile originating modify (U26)	275
5.1.2.1.15	Mobile terminating modify (U27)	275
5.1.2.2	Network call states	276
5.1.2.2.1	Null (State N0)	276
5.1.2.2.2	MM connection pending (N0.1)	276
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$	276
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$	276
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$	276
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$	276
5.1.2.2.2e	Recall present (N0.6) \$(CCBS)\$	276
5.1.2.2.3	Call initiated (N1)	276
5.1.2.2.4	Mobile originating call proceeding (N3)	276
5.1.2.2.5	Call delivered (N4)	276
5.1.2.2.6	Call present (N6)	276
5.1.2.2.7	Call received (N7)	277
5.1.2.2.8	Connect request (N8)	277
5.1.2.2.9	Mobile terminating call confirmed (N9)	277
5.1.2.2.10	Active (N10)	277
5.1.2.2.11	Not used	277
5.1.2.2.12	Disconnect indication (N12)	277
5.1.2.2.13	Release request (N19)	277
5.1.2.2.14	Mobile originating modify (N26)	277
5.1.2.2.15	Mobile terminating modify (N27)	277
5.1.2.2.16	Connect Indication (N28)	277
5.2	Call establishment procedures	277
5.2.1	Mobile originating call establishment	278
5.2.1.1	Call initiation	279
5.2.1.2	Receipt of a setup message	279
5.2.1.3	Receipt of a CALL PROCEEDING message	281
5.2.1.4	Notification of progressing mobile originated call	281
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment	281
5.2.1.4.2	Call progress in the PLMN/ISDN environment	282
5.2.1.5	Alerting	282
5.2.1.6	Call connected	282
5.2.1.7	Call rejection	283
5.2.1.8	Transit network selection	283
5.2.1.9	Traffic channel assignment at mobile originating call establishment	283
5.2.1.10	Call queuing at mobile originating call establishment	284
5.2.1.11	Speech Codec Selection	284
5.2.1.12	Cellular Text telephone Modem (CTM) selection	285
5.2.2	Mobile terminating call establishment	285
5.2.2.1	Call indication	285
5.2.2.2	Compatibility checking	286
5.2.2.3	Call confirmation	286
5.2.2.3.1	Response to SETUP	286

5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	287
5.2.2.3.3	Call failure procedures	288
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	288
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment	288
5.2.2.5	Call accept	288
5.2.2.6	Active indication	289
5.2.2.7	Traffic channel assignment at mobile terminating call establishment	289
5.2.2.8	Call queuing at mobile terminating call establishment	289
5.2.2.9	User connection attachment during a mobile terminating call	290
5.2.2.10	Speech Codec Selection	290
5.2.2.11	Cellular Text telephone Modem (CTM) selection	290
5.2.3	Network initiated MO call \$(CCBS)\$	290
5.2.3.1	Initiation	290
5.2.3.2	CC-Establishment present	290
5.2.3.2.1	Recall Alignment Procedure	292
5.2.3.3	CC-Establishment confirmation	293
5.2.3.4	Recall present	293
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment	294
5.2.4	Call establishment for SRVCC or vSRVCC	294
5.2.4.1	General	294
5.2.4.2	Call activation for SRVCC	294
5.2.4.2a	Call activation for vSRVCC	296
5.2.4.2b	Multimedia CAT and vSRVCC handover	297
5.2.4.3	Traffic channel assignment and user connection attachment	297
5.2.4.4	State verification	297
5.3	Signalling procedures during the "active" state	297
5.3.1	User notification procedure	297
5.3.2	Call rearrangements	298
5.3.3	Codec Change Procedure	298
5.3.4	Support of Dual Services	298
5.3.4.1	Service Description	298
5.3.4.2	Call establishment	298
5.3.4.2.1	Mobile Originating Establishment	298
5.3.4.2.2	Mobile Terminating Establishment	299
5.3.4.3	Changing the Call Mode	300
5.3.4.3.1	Initiation of in-call modification	300
5.3.4.3.2	Successful completion of in-call modification	300
5.3.4.3.3	Change of the channel configuration	301
5.3.4.3.4	Failure of in-call modification	301
5.3.4.4	Abnormal procedures	302
5.3.5	User initiated service level up- and downgrading (A/Gb mode and GERAN Iu mode only)	303
5.3.5.1	Initiation of service level up- and downgrading	303
5.3.5.2	Successful completion of service level up- and downgrading	303
5.3.5.3	Rejection of service level up- and downgrading	303
5.3.5.4	Time-out recovery	303
5.3.6	Support of multimedia calls	304
5.3.6.1	Service description	304
5.3.6.2	Call establishment	304
5.3.6.2.1	Mobile originated multimedia call establishment	304
5.3.6.2.2	Mobile terminating multimedia call	305
5.3.6.2.2.1	Fallback to speech	306
5.3.6.3	In-call modification in the "active" state	306
5.3.6.3.1	Void	306
5.3.6.3.2	Void	306
5.3.6.3.3	Void	306
5.3.6.4	Multimedia CAT during the alerting phase of a mobile originated call	306
5.3.6.5	DTMF transmission during a multimedia call	307
5.3.6.6	vSRVCC handover to a circuit-switched multimedia call	307
5.4	Call clearing	308
5.4.1	Terminology	308
5.4.2	Exception conditions	308
5.4.3	Clearing initiated by the mobile station	308

5.4.3.1	Initiation of call clearing	308
5.4.3.2	Receipt of a DISCONNECT message from the mobile station.....	308
5.4.3.3	Receipt of a RELEASE message from the network.....	309
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	309
5.4.3.5	Abnormal cases	309
5.4.4	Clearing initiated by the network.....	309
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"	309
5.4.4.1.1	Clearing when tones/announcements provided.....	309
5.4.4.1.2	Clearing when tones/announcements not provided	310
5.4.4.1.3	Completion of clearing.....	310
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"	311
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible"	311
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible"	311
5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible"	313
5.4.4.2.4	Receipt of a RELEASE message from the mobile station.....	313
5.4.4.2.5	Completion of clearing	314
5.4.5	Call clearing for SRVCC from CS to PS	314
5.5	Miscellaneous procedures	314
5.5.1	In-band tones and announcements	314
5.5.2	Call collisions	315
5.5.3	Status procedures	315
5.5.3.1	Status enquiry procedure.....	315
5.5.3.2	Reception of a STATUS message by a CC entity.....	315
5.5.3.2.1	STATUS message with incompatible state	315
5.5.3.2.2	STATUS message with compatible state	315
5.5.4	Call re-establishment, mobile station side	316
5.5.4.1	Indication from the mobility management sublayer.....	316
5.5.4.2	Reaction of call control	316
5.5.4.3	Completion of re-establishment	316
5.5.4.4	Unsuccessful outcome.....	316
5.5.5	Call re-establishment, network side	316
5.5.5.1	State alignment	316
5.5.6	Progress	317
5.5.7	DTMF protocol control procedure.....	317
5.5.7.1	Start DTMF request by the mobile station	317
5.5.7.2	Start DTMF response by the network	317
5.5.7.3	Stop DTMF request by the mobile station	318
5.5.7.4	Stop DTMF response by the network.....	318
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station.....	318
6	Support for packet services	319
6.1	GPRS Session management	319
6.1.1	General.....	319
6.1.2	Session management states.....	319
6.1.2.1	Session management states in the MS.....	320
6.1.2.1.1	PDP-INACTIVE.....	320
6.1.2.1.2	PDP-ACTIVE-PENDING	320
6.1.2.1.3	PDP-INACTIVE-PENDING	320
6.1.2.1.4	PDP-ACTIVE.....	320
6.1.2.1.5	PDP-MODIFY_PENDING	320
6.1.2.1.6	MBMS-ACTIVE-PENDING	320
6.1.2.1.7	MBMS-ACTIVE	320
6.1.2.2	Session management states on the network side	322
6.1.2.2.1	PDP-INACTIVE.....	322
6.1.2.2.2	PDP-ACTIVE-PENDING	322
6.1.2.2.3	PDP-INACTIVE-PENDING	322
6.1.2.2.4	PDP-ACTIVE.....	322
6.1.2.2.5	PDP-MODIFY-PENDING	322
6.1.2.2.6	MBMS-ACTIVE-PENDING	323
6.1.2.2.7	MBMS-INACTIVE-PENDING	323

6.1.2.2.8	MBMS-ACTIVE	323
6.1.2A	PDP address allocation	324
6.1.2A.1	General	324
6.1.2A.1.1	Interworking with PDN based on IP	324
6.1.2A.1.2	Interworking with PDN based on PPP	324
6.1.2A.2	IP address allocation via NAS signalling	325
6.1.3	Session Management procedures	325
6.1.3.0	General	325
6.1.3.1	PDP context activation	325
6.1.3.1.1	Successful PDP context activation initiated by the mobile station	326
6.1.3.1.2	Successful PDP context activation requested by the network	329
6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS	329
6.1.3.1.3.1	General	329
6.1.3.1.3.2	Handling of network rejection due to SM cause #26	330
6.1.3.1.3.3	Handling of network rejection due to SM cause other than SM cause #26	332
6.1.3.1.3A	Void	335
6.1.3.1.4	Unsuccessful PDP context activation requested by the network	335
6.1.3.1.5	Abnormal cases	335
6.1.3.1.6	Handling Activate PDP context request for MS configured for dual priority	337
6.1.3.2	Secondary PDP Context Activation Procedure	338
6.1.3.2.1	Successful Secondary PDP Context Activation Procedure Initiated by the MS	338
6.1.3.2.1a	Successful Secondary PDP Context Activation Procedure Requested by the network	339
6.1.3.2.2	Unsuccessful Secondary PDP Context Activation Procedure initiated by the MS	340
6.1.3.2.2.1	General	340
6.1.3.2.2.2	Handling of network rejection due to SM cause #26	340
6.1.3.2.2.3	Handling of network rejection due to SM cause other than SM cause #26	342
6.1.3.2.2a	Unsuccessful secondary PDP context activation requested by the network	343
6.1.3.2.3	Abnormal cases	344
6.1.3.3	PDP context modification procedure	347
6.1.3.3.1	Network initiated PDP Context Modification	348
6.1.3.3.2	MS initiated PDP Context Modification accepted by the network	349
6.1.3.3.3	MS initiated PDP Context Modification not accepted by the network	350
6.1.3.3.3.1	General	350
6.1.3.3.3.2	Handling of network rejection due to SM cause #26	351
6.1.3.3.3.3	Handling of network rejection due to SM cause other than SM cause #26	352
6.1.3.3.3a	Network initiated PDP Context Modification not accepted by the MS	354
6.1.3.3.4	Abnormal cases	354
6.1.3.4	PDP context deactivation procedure	359
6.1.3.4.1	PDP context deactivation initiated by the MS	359
6.1.3.4.2	PDP context deactivation initiated by the network	360
6.1.3.4.3	Abnormal cases	362
6.1.3.4a	Void	363
6.1.3.5	Void	363
6.1.3.5a	Notification procedure	363
6.1.3.5a.1	General	363
6.1.3.5a.2	Notification procedure initiation by the network	363
6.1.3.5a.3	Notification procedure in the MS	364
6.1.3.6	Receiving a SM STATUS message by a SM entity	364
6.1.3.7	Protocol configuration options	365
6.1.3.8	MBMS context activation	365
6.1.3.8.1	Successful MBMS context activation	366
6.1.3.8.2	Unsuccessful MBMS context activation requested by the MS	366
6.1.3.8.2.1	General	366
6.1.3.8.2.2	Handling of network rejection due to SM cause #26	366
6.1.3.8.2.3	Handling of network rejection due to SM cause other than SM cause #26	367
6.1.3.8.3	Unsuccessful MBMS context activation requested by the network	368
6.1.3.8.4	Abnormal cases	369
6.1.3.9	MBMS context deactivation	369
6.1.3.9.1	MBMS context deactivation initiated by the network	370
6.1.3.9.2	Abnormal cases	370
6.1.3.10	MBMS protocol configuration options	370
6.1.3.11	Handling of APN based congestion control	370

6.1.3.11A	Handling of group specific session management congestion control.....	371
6.1.3.12	Handling session management request for MS configured for dual priority.....	371
6.1.3.13	Handling of network rejection not due to APN based congestion control	372
6.1.3.14	Handling of WLAN offload control.....	372
6.2	void.....	372
6.3	Coordination between SM and GMM for supporting ISR	372
6.4	MSISDN notification procedure.....	373
7	Examples of structured procedures	373
8	Handling of unknown, unforeseen, and erroneous protocol data	373
8.1	General	373
8.2	Message too short.....	374
8.3	Unknown or unforeseen transaction identifier	374
8.3.1	Call Control	374
8.3.2	Session Management	375
8.4	Unknown or unforeseen message type	376
8.5	Non-semantic mandatory information element errors	376
8.5.1	Radio resource management.....	377
8.5.2	Mobility management.....	377
8.5.3	Call control	377
8.5.4	GMM mobility management.....	377
8.5.5	Session management.....	377
8.6	Unknown and unforeseen IEs in the non-imperative message part.....	378
8.6.1	IEs unknown in the message	378
8.6.2	Out of sequence IEs	378
8.6.3	Repeated IEs	378
8.7	Non-imperative message part errors.....	378
8.7.1	Syntactically incorrect optional IEs.....	378
8.7.2	Conditional IE errors	378
8.8	Messages with semantically incorrect contents.....	379
9	Message functional definitions and contents.....	379
9.1	Messages for Radio Resources management.....	380
9.2	Messages for mobility management.....	380
9.2.1	Authentication reject.....	381
9.2.2	Authentication request	382
9.2.2.1	Authentication Parameter AUTN.....	382
9.2.3	Authentication response.....	382
9.2.3.1	Authentication Response Parameter.....	383
9.2.3.2	Authentication Response Parameter (extension).....	383
9.2.3a	Authentication Failure	383
9.2.3a.1	Authentication Failure parameter.....	383
9.2.4	CM Re-establishment request.....	384
9.2.4.1	Location area identification.....	384
9.2.4.2	Mobile Station Classmark	384
9.2.4.3	Device properties	384
9.2.5	CM service accept.....	384
9.2.5a	CM service prompt \$(CCBS)\$.....	385
9.2.6	CM service reject.....	385
9.2.6.1	T3246 value.....	386
9.2.7	CM service abort.....	386
9.2.8	Abort.....	386
9.2.9	CM service request	387
9.2.9.1	Mobile Station Classmark	387
9.2.9.2	Priority	387
9.2.9.3	Additional update parameters.....	387
9.2.9.4	Device properties	388
9.2.10	Identity request	388
9.2.11	Identity response.....	388
9.2.12	IMSI detach indication.....	389
9.2.12.1	Mobile Station Classmark	389
9.2.13	Location updating accept.....	389

9.2.13.1	Follow on proceed.....	390
9.2.13.2	CTS permission.....	390
9.2.13.3	Equivalent PLMNs.....	390
9.2.13.4	Emergency Number List.....	390
9.2.13.5	Per MS T3212.....	390
9.2.13.6	Non-3GPP NW provided policies.....	390
9.2.14	Location updating reject.....	391
9.2.14.1	T3246 value.....	391
9.2.15	Location updating request.....	391
9.2.15.1	Location area identification.....	392
9.2.15.2	Mobile Station Classmark.....	392
9.2.15.3	Mobile Station Classmark for Iu mode.....	392
9.2.15.4	Additional update parameters.....	392
9.2.15.5	Device properties.....	392
9.2.15.6	MS network feature support.....	392
9.2.15a	MM information.....	393
9.2.15a.1	Full name for network.....	393
9.2.15a.2	Short name for network.....	393
9.2.15a.3	Local time zone.....	393
9.2.15a.4	Universal time and local time zone.....	393
9.2.15a.5	LSA Identity.....	394
9.2.15a.6	Network Daylight Saving Time.....	394
9.2.16	MM Status.....	394
9.2.17	TMSI reallocation command.....	394
9.2.18	TMSI reallocation complete.....	395
9.2.19	MM Null.....	395
9.3	Messages for circuit-switched call control.....	396
9.3.1	Alerting.....	396
9.3.1.1	Alerting (network to mobile station direction).....	396
9.3.1.1.1	Facility.....	397
9.3.1.1.2	Progress indicator.....	397
9.3.1.1.3	User-user.....	397
9.3.1.2	Alerting (mobile station to network direction).....	397
9.3.1.2.1	Facility.....	398
9.3.1.2.2	User-user.....	398
9.3.1.2.3	SS version.....	398
9.3.2	Call confirmed.....	398
9.3.2.1	Repeat indicator.....	399
9.3.2.2	Bearer capability 1 and bearer capability 2.....	399
9.3.2.3	Cause.....	400
9.3.2.4	CC Capabilities.....	400
9.3.2.5	Stream Identifier.....	400
9.3.2.6	Supported Codecs.....	400
9.3.3	Call proceeding.....	400
9.3.3.1	Repeat indicator.....	400
9.3.3.2	Bearer capability 1 and bearer capability 2.....	401
9.3.3.3	Facility.....	401
9.3.3.4	Progress Indicator.....	401
9.3.3.5	Priority granted.....	401
9.3.3.6	Network Call Control Capabilities.....	401
9.3.4	Congestion control.....	401
9.3.4.1	Cause.....	402
9.3.5	Connect.....	402
9.3.5.1	Connect (network to mobile station direction).....	402
9.3.5.1.1	Facility.....	402
9.3.5.1.2	Progress indicator.....	402
9.3.5.1.3	User-user.....	402
9.3.5.2	Connect (mobile station to network direction).....	402
9.3.5.2.1	Facility.....	403
9.3.5.2.2	User-user.....	403
9.3.5.2.3	SS version.....	403
9.3.5.2.4	Stream Identifier.....	403