

ETSI TS 138 331 V17.5.0 (2023-07)



5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.5.0 Release 17)
<https://standards.iteh.ai/catalog/standards/sist/1c477676-2a43-4d83-9b75-df518ae3f1c1/etsi-ts-138-331-v17-5-0-2023-07>



ReferenceRTS/TSGR-0238331vh50

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:
<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards-portal.etsi.org/People/CommitteeSupportStaff.aspx> 4d83-9b73-

If you find a security vulnerability in the present document, please report it through our
Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	30
4 General	32
4.1 Introduction	32
4.2 Architecture	33
4.2.1 UE states and state transitions including inter RAT	33
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	49
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	54
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	56
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	58
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	58
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	60

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	60
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	60
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	60
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	60
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	60
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	60
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	60
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	61
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	61
5.2.2.5	Essential system information missing	61
5.2.2.6	T430 expiry	61
5.3	Connection control	62
5.3.1	Introduction	62
5.3.1.1	RRC connection control	62
5.3.1.2	AS Security	63
5.3.2	Paging	64
5.3.2.1	General	64
5.3.2.2	Initiation	64
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	64
5.3.3	RRC connection establishment	66
5.3.3.1	General	66
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	66
5.3.3.2	Initiation	67
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	68
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	68
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	72
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	72
5.3.3.7	T300 expiry	72
5.3.3.8	Abortion of RRC connection establishment	74
5.3.4	Initial AS security activation	74
5.3.4.1	General	74
5.3.4.2	Initiation	75
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	75
5.3.5	RRC reconfiguration	76
5.3.5.1	General	76
5.3.5.2	Initiation	77
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	77
5.3.5.4	Secondary cell group release	89
5.3.5.5	Cell Group configuration	89
5.3.5.5.1	General	89
5.3.5.5.2	Reconfiguration with sync	90
5.3.5.5.3	RLC bearer release	92
5.3.5.5.4	RLC bearer addition/modification	92
5.3.5.5.5	MAC entity configuration	93
5.3.5.5.6	RLF Timers & Constants configuration	94
5.3.5.5.7	SpCell Configuration	94
5.3.5.5.8	SCell Release	96
5.3.5.5.9	SCell Addition/Modification	96
5.3.5.5.10	BH RLC channel release	97
5.3.5.5.11	BH RLC channel addition/modification	97
5.3.5.5.12	Uu Relay RLC channel release	97
5.3.5.5.13	Uu Relay RLC channel addition/modification	97
5.3.5.6	Radio Bearer configuration	98
5.3.5.6.1	General	98
5.3.5.6.2	SRB release	98
5.3.5.6.3	SRB addition/modification	98
5.3.5.6.4	DRB release	100
5.3.5.6.5	DRB addition/modification	101
5.3.5.6.6	Multicast MRB release	104
5.3.5.6.7	Multicast MRB addition/modification	104

5.3.5.7	AS Security key update	105
5.3.5.8	Reconfiguration failure	106
5.3.5.8.1	Void	106
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	106
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	108
5.3.5.9	Other configuration	109
5.3.5.9a	MUSIM gap configuration	113
5.3.5.10	MR-DC release	114
5.3.5.11	Full configuration	114
5.3.5.12	BAP configuration	116
5.3.5.12a	IAB Other Configuration	117
5.3.5.12a.1	IP address management	117
5.3.5.12a.1.1	IP Address Release	117
5.3.5.12a.1.2	IP Address Addition/Modification	117
5.3.5.13	Conditional Reconfiguration	118
5.3.5.13.1	General	118
5.3.5.13.2	Conditional reconfiguration removal	119
5.3.5.13.3	Conditional reconfiguration addition/modification	119
5.3.5.13.4	Conditional reconfiguration evaluation	119
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	121
5.3.5.13.5	Conditional reconfiguration execution	121
5.3.5.13a	SCG activation	122
5.3.5.13b	SCG deactivation	122
5.3.5.13b1	SCG activation without SN message	122
5.3.5.13c	FR2 UL gap configuration	123
5.3.5.13d	Application layer measurement configuration	123
5.3.5.14	Sidelink dedicated configuration	124
5.3.5.15	L2 U2N Relay UE configuration	126
5.3.5.15.1	General	126
5.3.5.15.2	L2 U2N Remote UE Release	127
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	127
5.3.5.16	L2 U2N Remote UE configuration	127
5.3.6	Counter check	128
5.3.6.1	General	128
5.3.6.2	Initiation	128
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	128
5.3.7	RRC connection re-establishment	129
5.3.7.1	General	129
5.3.7.2	Initiation	130
5.3.7.3	Actions following cell selection while T311 is running	133
5.3.7.3a	Actions following relay selection while T311 is running	135
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	135
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	136
5.3.7.6	T311 expiry	138
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	138
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	138
5.3.8	RRC connection release	139
5.3.8.1	General	139
5.3.8.2	Initiation	139
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	139
5.3.8.4	T320 expiry	143
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	143
5.3.8.6	T346g expiry	143
5.3.9	RRC connection release requested by upper layers	143
5.3.9.1	General	143
5.3.9.2	Initiation	143
5.3.10	Radio link failure related actions	144
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	144
5.3.10.2	Recovery of physical layer problems	144
5.3.10.3	Detection of radio link failure	144
5.3.10.4	RLF cause determination	146
5.3.10.5	RLF report content determination	147

5.3.11	UE actions upon going to RRC_IDLE.....	151
5.3.12	UE actions upon PUCCH/SRS release request.....	152
5.3.13	RRC connection resume	153
5.3.13.1	General	153
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	154
5.3.13.1b	Conditions for initiating SDT.....	154
5.3.13.2	Initiation.....	155
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	158
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	160
5.3.13.5	Handling of failure to resume RRC Connection	165
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	166
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE.....	166
5.3.13.8	RNA update.....	166
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	167
5.3.13.10	Reception of the <i>RRCReject</i> by the UE.....	167
5.3.13.11	Inability to comply with <i>RRCResume</i>	167
5.3.13.12	Inter RAT cell reselection	167
5.3.14	Unified Access Control.....	167
5.3.14.1	General	167
5.3.14.2	Initiation.....	168
5.3.14.3	Void.....	170
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	170
5.3.14.5	Access barring check.....	170
5.3.15	RRC connection reject.....	171
5.3.15.1	Initiation.....	171
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	171
5.4	Inter-RAT mobility.....	172
5.4.1	Introduction.....	172
5.4.2	Handover to NR.....	172
5.4.2.1	General	172
5.4.2.2	Initiation.....	173
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE.....	173
5.4.3	Mobility from NR.....	173
5.4.3.1	General	173
5.4.3.2	Initiation.....	174
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	174
5.4.3.4	Successful completion of the mobility from NR.....	174
5.4.3.5	Mobility from NR failure	175
5.5	Measurements.....	175
5.5.1	Introduction.....	175
5.5.2	Measurement configuration	178
5.5.2.1	General	178
5.5.2.2	Measurement identity removal.....	180
5.5.2.3	Measurement identity addition/modification	180
5.5.2.4	Measurement object removal	181
5.5.2.5	Measurement object addition/modification.....	181
5.5.2.6	Reporting configuration removal	184
5.5.2.7	Reporting configuration addition/modification.....	184
5.5.2.8	Quantity configuration	184
5.5.2.9	Measurement gap configuration.....	184
5.5.2.10	Reference signal measurement timing configuration	187
5.5.2.10a	RSSI measurement timing configuration	188
5.5.2.11	Measurement gap sharing configuration	188
5.5.3	Performing measurements	189
5.5.3.1	General	189
5.5.3.2	Layer 3 filtering	194
5.5.3.3	Derivation of cell measurement results.....	194
5.5.3.3a	Derivation of layer 3 beam filtered measurement	195
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	195

5.5.4	Measurement report triggering	196
5.5.4.1	General	196
5.5.4.2	Event A1 (Serving becomes better than threshold)	203
5.5.4.3	Event A2 (Serving becomes worse than threshold)	203
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	204
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	204
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	205
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	206
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	206
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	207
5.5.4.10	Event I1 (Interference becomes higher than threshold)	208
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	208
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	209
5.5.4.13	Void	209
5.5.4.14	Void	209
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	209
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	210
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	211
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	212
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	212
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	213
5.5.5	Measurement reporting	213
5.5.5.1	General	213
5.5.5.2	Reporting of beam measurement information	222
5.5.5.3	Sorting of cell measurement results	222
5.5.6	Location measurement indication	223
5.5.6.1	General	223
5.5.6.2	Initiation	224
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	224
5.5a	Logged Measurements	225
5.5a.1	Logged Measurement Configuration	225
5.5a.1.1	General	225
5.5a.1.2	Initiation	225
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	225
5.5a.1.4	T330 expiry	226
5.5a.2	Release of Logged Measurement Configuration	226
5.5a.2.1	General	226
5.5a.2.2	Initiation	226
5.5a.3	Measurements logging	226
5.5a.3.1	General	226
5.5a.3.2	Initiation	226
5.6	UE capabilities	229
5.6.1	UE capability transfer	229
5.6.1.1	General	229
5.6.1.2	Initiation	229
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	230
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	230
5.6.1.5	Void	233
5.7	Other	233
5.7.1	DL information transfer	233
5.7.1.1	General	233
5.7.1.2	Initiation	233
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	233
5.7.1a	DL information transfer for MR-DC	234
5.7.1a.1	General	234
5.7.1a.2	Initiation	234
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	234

5.7.2	UL information transfer	235
5.7.2.1	General	235
5.7.2.2	Initiation	235
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	235
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	236
5.7.2a	UL information transfer for MR-DC	236
5.7.2a.1	General	236
5.7.2a.2	Initiation	236
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	236
5.7.2b	UL transfer of IRAT information	237
5.7.2b.1	General	237
5.7.2b.2	Initiation	237
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	237
5.7.3	SCG failure information	237
5.7.3.1	General	237
5.7.3.2	Initiation	238
5.7.3.3	Failure type determination for (NG)EN-DC	238
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	239
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	240
5.7.3a	EUTRA SCG failure information	242
5.7.3a.1	General	242
5.7.3a.2	Initiation	242
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	242
5.7.3b	MCG failure information	243
5.7.3b.1	General	243
5.7.3b.2	Initiation	243
5.7.3b.3	Failure type determination	243
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	244
5.7.3b.5	T316 expiry	245
5.7.4	UE Assistance Information	246
5.7.4.1	General	246
5.7.4.2	Initiation	246
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	253
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	261
5.7.4.4	Relaxed measurement criterion for a stationary RedCap UE	262
5.7.4a	Void	262
5.7.5	Failure information	262
5.7.5.1	General	262
5.7.5.2	Initiation	263
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	263
5.7.6	DL message segment transfer	263
5.7.6.1	General	263
5.7.6.2	Initiation	264
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	264
5.7.7	UL message segment transfer	264
5.7.7.1	General	264
5.7.7.2	Initiation	264
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	265
5.7.8	Idle/inactive Measurements	265
5.7.8.1	General	265
5.7.8.1a	Measurement configuration	265
5.7.8.2	Void	266
5.7.8.2a	Performing measurements	266
5.7.8.3	T331 expiry or stop	269
5.7.8.4	Cell re-selection or cell selection while T331 is running	269
5.7.9	Mobility history information	269
5.7.9.1	General	269
5.7.9.2	Initiation	269
5.7.10	UE Information	273
5.7.10.1	General	273
5.7.10.2	Initiation	273
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	273

5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information.....	276
5.7.10.5	RA information determination	277
5.7.10.6	Actions for the successful handover report determination	280
5.7.12	IAB Other Information	283
5.7.12.1	General	283
5.7.12.2	Initiation	283
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	283
5.7.13	RLM/BFD relaxation.....	285
5.7.13.1	Relaxed measurement criterion for low mobility	285
5.7.13.2	Relaxed measurement criterion for good serving cell quality	285
5.7.14	UE Positioning Assistance Information.....	286
5.7.14.1	General	286
5.7.14.2	Initiation.....	286
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message.....	286
5.7.15	Void	287
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	288
5.8	Sidelink	288
5.8.1	General.....	288
5.8.2	Conditions for NR sidelink communication/discovery operation.....	289
5.8.3	Sidelink UE information for NR sidelink communication/discovery	290
5.8.3.1	General	290
5.8.3.2	Initiation.....	290
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	295
5.8.4	Void	299
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery	299
5.8.5.1	General	299
5.8.5.2	Initiation.....	300
5.8.5.3	Transmission of SLSS.....	300
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	302
5.8.5a.1	General	302
5.8.5a.2	Initiation.....	302
5.8.6	Sidelink synchronisation reference	302
5.8.6.1	General	302
5.8.6.2	Selection and reselection of synchronisation reference.....	303
5.8.6.3	Sidelink communication transmission reference cell selection	305
5.8.7	Sidelink communication reception	305
5.8.8	Sidelink communication transmission	306
5.8.9	Sidelink RRC procedure	308
5.8.9.1	Sidelink RRC reconfiguration.....	308
5.8.9.1.1	General	308
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message.....	309
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE.....	310
5.8.9.1.4	Void	312
5.8.9.1.5	Void	312
5.8.9.1.6	Void	312
5.8.9.1.7	Void	312
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE.....	312
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	312
5.8.9.1a	Sidelink radio bearer management.....	313
5.8.9.1a.1	Sidelink DRB release	313
5.8.9.1a.2	Sidelink DRB addition/modification	314
5.8.9.1a.3	Sidelink SRB release	315
5.8.9.1a.4	Sidelink SRB addition	316
5.8.9.2	Sidelink UE capability transfer	316
5.8.9.2.1	General	316
5.8.9.2.2	Initiation.....	316
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	316
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE.....	317
5.8.9.3	Sidelink radio link failure related actions.....	317
5.8.9.4	Sidelink common control information	318

5.8.9.4.1	General	318
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	318
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	318
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	319
5.8.9.6	Sidelink UE assistance information	320
5.8.9.6.1	General	320
5.8.9.6.2	Initiation	320
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	320
5.8.9.8	Remote UE information	321
5.8.9.8.1	General	321
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	322
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	322
5.8.9.9	Uu message transfer in sidelink	323
5.8.9.9.1	General	323
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	323
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	324
5.8.9.10	Notification Message	324
5.8.9.10.1	General	324
5.8.9.10.2	Initiation	324
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	324
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	325
5.8.10	Sidelink measurement	325
5.8.10.1	Introduction	325
5.8.10.2	Sidelink measurement configuration	326
5.8.10.2.1	General	326
5.8.10.2.2	Sidelink measurement identity removal	326
5.8.10.2.3	Sidelink measurement identity addition/modification	327
5.8.10.2.4	Sidelink measurement object removal	327
5.8.10.2.5	Sidelink measurement object addition/modification	327
5.8.10.2.6	Sidelink reporting configuration removal	328
5.8.10.2.7	Sidelink reporting configuration addition/modification	328
5.8.10.2.8	Sidelink quantity configuration	328
5.8.10.3	Performing NR sidelink measurements	329
5.8.10.3.1	General	329
5.8.10.3.2	Derivation of NR sidelink measurement results	329
5.8.10.4	Sidelink measurement report triggering	329
5.8.10.4.1	General	329
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	330
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	331
5.8.10.5	Sidelink measurement reporting	331
5.8.10.5.1	General	331
5.8.11	Zone identity calculation	332
5.8.12	DFN derivation from GNSS	332
5.9	MBS Broadcast	338
5.9.1	Introduction	338
5.9.1.1	General	338
5.9.1.2	MCCH scheduling	338
5.9.1.3	MCCH information validity and notification of changes	339
5.9.2	MCCH information acquisition	339
5.9.2.1	General	339
5.9.2.2	Initiation	339
5.9.2.3	MCCH information acquisition by the UE	340
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	340
5.9.3	Broadcast MRB configuration	340
5.9.3.1	General	340
5.9.3.2	Initiation	340
5.9.3.3	Broadcast MRB establishment	341
5.9.3.4	Broadcast MRB release	341
5.9.4	MBS Interest Indication	341
5.9.4.1	General	341
5.9.4.2	Initiation	341
5.9.4.3	MBS frequencies of interest determination	342

5.9.4.4	MBS services of interest determination	343
5.9.4.5	Setting of the contents of MBS Interest Indication	343
6	Protocol data units, formats and parameters (ASN.1)	344
6.1	General	344
6.1.1	Introduction.....	344
6.1.2	Need codes and conditions for optional fields	344
6.1.3	General rules	347
6.2	RRC messages	347
6.2.1	General message structure	347
–	NR-RRC-Definitions.....	347
–	BCCH-BCH-Message	347
–	BCCH-DL-SCH-Message	348
–	DL-CCCH-Message	348
–	DL-DCCH-Message	349
–	MCCH-Message	349
–	PCCH-Message.....	350
–	UL-CCCH-Message	350
–	UL-CCCH1-Message	351
–	UL-DCCH-Message.....	351
6.2.2	Message definitions	353
–	CounterCheck.....	353
–	CounterCheckResponse.....	354
–	DedicatedSIBRequest.....	355
–	DLDedicatedMessageSegment.....	356
–	DLInformationTransfer	357
–	DLInformationTransferMRDC.....	358
–	FailureInformation.....	359
–	IABOtherInformation	360
–	LocationMeasurementIndication	363
–	LoggedMeasurementConfiguration	364
–	MBSBroadcastConfiguration	366
–	MBSInterestIndication	367
–	MCGFailureInformation	368
–	MeasurementReport	370
–	MeasurementReportAppLayer	370
–	MIB	372
–	MobilityFromNRCommand.....	373
–	Paging	375
–	RRCReestablishment	376
–	RRCReestablishmentComplete	377
–	RRCReestablishmentRequest	378
–	RRCReconfiguration	379
–	RRCReconfigurationComplete	386
–	RRCReject	388
–	RRCRelease.....	389
–	RRCResume.....	398
–	RRCResumeComplete	401
–	RRCResumeRequest	402
–	RRCResumeRequest1	403
–	RRCSetup	404
–	RRCSetupComplete	405
–	RRCSetupRequest.....	407
–	RRCSystemInfoRequest	408
–	SCGFailureInformation	410
–	SCGFailureInformationEUTRA.....	411
–	SecurityModeCommand	412
–	SecurityModeComplete	413
–	SecurityModeFailure.....	414
–	SIB1	415
–	SidelinkUEInformationNR	420
–	SystemInformation	425

–	<i>UEAssistanceInformation</i>	426
–	<i>UECapabilityEnquiry</i>	435
–	<i>UECapabilityInformation</i>	436
–	<i>UEInformationRequest</i>	437
–	<i>UEInformationResponse</i>	438
–	<i>UEPositioningAssistanceInfo</i>	453
–	<i>ULDedicatedMessageSegment</i>	455
–	<i>ULInformationTransfer</i>	456
–	<i>ULInformationTransferIRAT</i>	456
–	<i>ULInformationTransferMRDC</i>	457
6.3	RRC information elements	458
6.3.0	Parameterized types	458
–	<i>SetupRelease</i>	458
6.3.1	System information blocks	459
–	<i>SIB2</i>	459
–	<i>SIB3</i>	464
–	<i>SIB4</i>	466
–	<i>SIB5</i>	472
–	<i>SIB6</i>	475
–	<i>SIB7</i>	475
–	<i>SIB8</i>	476
–	<i>SIB9</i>	477
–	<i>SIB10</i>	478
–	<i>SIB11</i>	479
–	<i>SIB12</i>	479
–	<i>SIB13</i>	481
–	<i>SIB14</i>	482
–	<i>SIB15</i>	483
–	<i>SIB16</i>	483
–	<i>SIB17</i>	484
–	<i>SIB18</i>	486
–	<i>SIB20</i>	488
–	<i>SIB21</i>	489
6.3.1a	Positioning System information blocks	490
–	<i>PosSystemInformation-r16-IEs</i>	490
–	<i>PosSI-SchedulingInfo</i>	491
–	<i>SIBpos</i>	494
6.3.2	Radio resource control information elements	494
–	<i>AdditionalSpectrumEmission</i>	494
–	<i>Alpha</i>	494
–	<i>AMF-Identifier</i>	495
–	<i>ARFCN-ValueEUTRA</i>	495
–	<i>ARFCN-ValueNR</i>	495
–	<i>ARFCN-ValueUTRA-FDD</i>	496
–	<i>AvailabilityCombinationsPerCell</i>	496
–	<i>AvailabilityIndicator</i>	498
–	<i>BAP-RoutingID</i>	498
–	<i>BeamFailureRecoveryConfig</i>	499
–	<i>BeamFailureRecoveryRSConfig</i>	502
–	<i>BetaOffsets</i>	503
–	<i>BetaOffsetsCrossPri</i>	504
–	<i>BH-LogicalChannelIdentity</i>	504
–	<i>BH-LogicalChannelIdentity-Ext</i>	505
–	<i>BH-RLC-ChannelConfig</i>	505
–	<i>BH-RLC-ChannelID</i>	506
–	<i>BSR-Config</i>	506
–	<i>BWP</i>	507
–	<i>BWP-Downlink</i>	508
–	<i>BWP-DownlinkCommon</i>	509
–	<i>BWP-DownlinkDedicated</i>	509
–	<i>BWP-Id</i>	512
–	<i>BWP-Uplink</i>	512

–	BWP-UplinkCommon	513
–	BWP-UplinkDedicated	516
–	CandidateBeamRS	519
–	CellAccessRelatedInfo	520
–	CellAccessRelatedInfo-EUTRA-5GC	522
–	CellAccessRelatedInfo-EUTRA-EPC	522
–	CellGroupConfig	523
–	CellGroupId	533
–	CellIdentity	533
–	CellReselectionPriority	533
–	CellReselectionSubPriority	534
–	CFR-ConfigMulticast	534
–	CGI-InfoEUTRA	535
–	CGI-InfoEUTRALogging	535
–	CGI-InfoNR	536
–	CGI-Info-Logging	537
–	CLI-RSSI-Range	538
–	CodebookConfig	538
–	CommonLocationInfo	544
–	CondReconfigId	544
–	CondReconfigToAddModList	545
–	ConditionalReconfiguration	546
–	ConfiguredGrantConfig	546
–	ConfiguredGrantConfigIndex	555
–	ConfiguredGrantConfigIndexMAC	556
–	ConnEstFailureControl	556
–	ControlResourceSet	557
–	ControlResourceSetId	559
–	ControlResourceSetZero	559
–	CrossCarrierSchedulingConfig	560
–	CSI-AperiodicTriggerStateList	561
–	CSI-FrequencyOccupation	564
–	CSI-IM-Resource	564
–	CSI-IM-ResourceId	565
–	CSI-IM-ResourceSet	566
–	CSI-IM-ResourceSetId	566
–	CSI-MeasConfig	566
–	CSI-ReportConfig	568
–	CSI-ReportConfigId	575
–	CSI-ResourceConfig	576
–	CSI-ResourceConfigId	577
–	CSI-ResourcePeriodicityAndOffset	578
–	CSI-RS-ResourceConfigMobility	578
–	CSI-RS-ResourceMapping	581
–	CSI-SemiPersistentOnPUSCH-TriggerStateList	582
–	CSI-SSB-ResourceSet	583
–	CSI-SSB-ResourceSetId	584
–	DedicatedNAS-Message	584
–	DL-PPW-PreConfig	584
–	DMRS-BundlingPUCCH-Config	587
–	DMRS-BundlingPUSCH-Config	588
–	DMRS-DownlinkConfig	589
–	DMRS-UplinkConfig	590
–	DownlinkConfigCommon	592
–	DownlinkConfigCommonSIB	593
–	DownlinkPreemption	597
–	DRB-Identity	598
–	DRX-Config	598
–	DRX-ConfigSecondaryGroup	600
–	DRX-ConfigSL	601
–	EphemerisInfo	602
–	FeatureCombination	603

FeatureCombinationPreambles	604
FilterCoefficient	607
FreqBandIndicatorNR.....	607
FreqPriorityListDedicatedSlicing	607
FreqPriorityListSlicing	608
FrequencyInfoDL	609
FrequencyInfoDL-SIB.....	610
FrequencyInfoUL	611
FrequencyInfoUL-SIB.....	612
GapPriority	613
HighSpeedConfig	614
Hysteresis	615
HysteresisLocation.....	616
InvalidSymbolPattern.....	616
I-RNTI-Value.....	617
LBT-FailureRecoveryConfig	617
LocationInfo	618
LocationMeasurementInfo	618
LogicalChannelConfig	620
LogicalChannelIdentity.....	623
LTE-NeighCellsCRS-AssistInfoList.....	623
MAC-CellGroupConfig	625
MeasConfig	628
MeasGapConfig	630
MeasGapId.....	634
MeasGapSharingConfig.....	635
MeasId.....	636
MeasIdleConfig.....	636
MeasIdToAddModList.....	639
MeasObjectCLI	639
MeasObjectEUTRA	642
MeasObjectId	644
MeasObjectNR	644
MeasObjectNR-SL	652
MeasObjectRxTxDiff.....	652
MeasObjectToAddModList	653
MeasObjectUTRA-FDD.....	653
MeasResultCellListSFTD-NR.....	654
MeasResultCellListSFTD-EUTRA	655
MeasResults	655
MeasResult2EUTRA.....	662
MeasResult2NR.....	662
MeasResultIdleEUTRA	663
MeasResultIdleNR.....	664
MeasResultRxTxTimeDiff.....	665
MeasResultSCG-Failure	666
MeasResultsSL	666
MeasTriggerQuantityEUTRA.....	667
MobilityStateParameters.....	667
MRB-Identity	668
MsgA-ConfigCommon.....	668
MsgA-PUSCH-Config.....	669
MultiFrequencyBandListNR.....	672
MultiFrequencyBandListNR-SIB	673
MUSIM-GapConfig.....	673
MUSIM-GapId	674
MUSIM-GapInfo	675
NeedForGapsConfigNR	676
NeedForGapNCSG-ConfigEUTRA.....	677
NeedForGapNCSG-ConfigNR	678
NeedForGapNCSG-InfoEUTRA	678
NeedForGapNCSG-InfoNR.....	679