

ETSI TS 138 331 V17.6.0 (2023-10)



**5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.6.0 Release 17)**

[ETSI TS 138 331 V17.6.0 \(2023-10\)](https://standards.iteh.ai/catalog/standards/sist/9e582b5e-cefb-46f6-aa69-5461960d9508/etsi-ts-138-331-v17-6-0-2023-10)

<https://standards.iteh.ai/catalog/standards/sist/9e582b5e-cefb-46f6-aa69-5461960d9508/etsi-ts-138-331-v17-6-0-2023-10>



ReferenceRTS/TSGR-0238331vh60

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:
<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2023-10)

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	30
4 General	32
4.1 Introduction	32
4.2 Architecture	33
4.2.1 UE states and state transitions including inter RAT	33
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements.....	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	49
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	54
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	56
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	58
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	58
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	60

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	60
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	60
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	60
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	60
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	60
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	60
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	60
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	61
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	61
5.2.2.5	Essential system information missing	61
5.2.2.6	T430 expiry	61
5.3	Connection control	62
5.3.1	Introduction	62
5.3.1.1	RRC connection control	62
5.3.1.2	AS Security	63
5.3.2	Paging	64
5.3.2.1	General	64
5.3.2.2	Initiation	64
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	64
5.3.3	RRC connection establishment	66
5.3.3.1	General	66
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	66
5.3.3.2	Initiation	67
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	68
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	68
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	72
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	72
5.3.3.7	T300 expiry	73
5.3.3.8	Abortion of RRC connection establishment	74
5.3.4	Initial AS security activation	75
5.3.4.1	General	75
5.3.4.2	Initiation	75
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	75
5.3.5	RRC reconfiguration	76
5.3.5.1	General	76
5.3.5.2	Initiation	77
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	77
5.3.5.4	Secondary cell group release	89
5.3.5.5	Cell Group configuration	89
5.3.5.5.1	General	89
5.3.5.5.2	Reconfiguration with sync	90
5.3.5.5.3	RLC bearer release	92
5.3.5.5.4	RLC bearer addition/modification	92
5.3.5.5.5	MAC entity configuration	94
5.3.5.5.6	RLF Timers & Constants configuration	94
5.3.5.5.7	SpCell Configuration	95
5.3.5.5.8	SCell Release	96
5.3.5.5.9	SCell Addition/Modification	96
5.3.5.5.10	BH RLC channel release	97
5.3.5.5.11	BH RLC channel addition/modification	97
5.3.5.5.12	Uu Relay RLC channel release	97
5.3.5.5.13	Uu Relay RLC channel addition/modification	97
5.3.5.6	Radio Bearer configuration	98
5.3.5.6.1	General	98
5.3.5.6.2	SRB release	98
5.3.5.6.3	SRB addition/modification	98
5.3.5.6.4	DRB release	100
5.3.5.6.5	DRB addition/modification	101
5.3.5.6.6	Multicast MRB release	104
5.3.5.6.7	Multicast MRB addition/modification	104

5.3.5.7	AS Security key update	105
5.3.5.8	Reconfiguration failure	106
5.3.5.8.1	Void	106
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	106
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	108
5.3.5.9	Other configuration	109
5.3.5.9a	MUSIM gap configuration	113
5.3.5.10	MR-DC release	114
5.3.5.11	Full configuration	114
5.3.5.12	BAP configuration	116
5.3.5.12a	IAB Other Configuration	117
5.3.5.12a.1	IP address management	117
5.3.5.12a.1.1	IP Address Release	117
5.3.5.12a.1.2	IP Address Addition/Modification	117
5.3.5.13	Conditional Reconfiguration	118
5.3.5.13.1	General	118
5.3.5.13.2	Conditional reconfiguration removal	119
5.3.5.13.3	Conditional reconfiguration addition/modification	119
5.3.5.13.4	Conditional reconfiguration evaluation	120
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	121
5.3.5.13.5	Conditional reconfiguration execution	121
5.3.5.13a	SCG activation	122
5.3.5.13b	SCG deactivation	122
5.3.5.13b1	SCG activation without SN message	123
5.3.5.13c	FR2 UL gap configuration	123
5.3.5.13d	Application layer measurement configuration	123
5.3.5.14	Sidelink dedicated configuration	125
5.3.5.15	L2 U2N Relay UE configuration	126
5.3.5.15.1	General	126
5.3.5.15.2	L2 U2N Remote UE Release	127
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	127
5.3.5.16	L2 U2N Remote UE Configuration	127
5.3.6	Counter check	128
5.3.6.1	General	128
5.3.6.2	Initiation	128
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	128
5.3.7	RRC connection re-establishment	129
5.3.7.1	General	129
5.3.7.2	Initiation	130
5.3.7.3	Actions following cell selection while T311 is running	133
5.3.7.3a	Actions following relay selection while T311 is running	135
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	135
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	136
5.3.7.6	T311 expiry	138
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	138
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	138
5.3.8	RRC connection release	139
5.3.8.1	General	139
5.3.8.2	Initiation	139
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	139
5.3.8.4	T320 expiry	143
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	143
5.3.8.6	T346g expiry	143
5.3.9	RRC connection release requested by upper layers	143
5.3.9.1	General	143
5.3.9.2	Initiation	144
5.3.10	Radio link failure related actions	144
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	144
5.3.10.2	Recovery of physical layer problems	144
5.3.10.3	Detection of radio link failure	144
5.3.10.4	RLF cause determination	146
5.3.10.5	RLF report content determination	147

5.3.11	UE actions upon going to RRC_IDLE.....	151
5.3.12	UE actions upon PUCCH/SRS release request.....	152
5.3.13	RRC connection resume	153
5.3.13.1	General	153
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	154
5.3.13.1b	Conditions for initiating SDT.....	154
5.3.13.2	Initiation.....	155
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	158
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	160
5.3.13.5	Handling of failure to resume RRC Connection	165
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	166
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE.....	167
5.3.13.8	RNA update.....	167
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	167
5.3.13.10	Reception of the <i>RRCReject</i> by the UE.....	167
5.3.13.11	Inability to comply with <i>RRCResume</i>	167
5.3.13.12	Inter RAT cell reselection	168
5.3.14	Unified Access Control.....	168
5.3.14.1	General	168
5.3.14.2	Initiation.....	168
5.3.14.3	Void.....	170
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	170
5.3.14.5	Access barring check.....	170
5.3.15	RRC connection reject.....	171
5.3.15.1	Initiation.....	171
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	171
5.4	Inter-RAT mobility.....	172
5.4.1	Introduction.....	172
5.4.2	Handover to NR.....	172
5.4.2.1	General	172
5.4.2.2	Initiation.....	173
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	173
5.4.3	Mobility from NR.....	173
5.4.3.1	General	173
5.4.3.2	Initiation.....	174
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	174
5.4.3.4	Successful completion of the mobility from NR.....	174
5.4.3.5	Mobility from NR failure	175
5.5	Measurements.....	176
5.5.1	Introduction.....	176
5.5.2	Measurement configuration	178
5.5.2.1	General	178
5.5.2.2	Measurement identity removal.....	180
5.5.2.3	Measurement identity addition/modification	180
5.5.2.4	Measurement object removal	181
5.5.2.5	Measurement object addition/modification.....	182
5.5.2.6	Reporting configuration removal	184
5.5.2.7	Reporting configuration addition/modification.....	184
5.5.2.8	Quantity configuration	184
5.5.2.9	Measurement gap configuration.....	185
5.5.2.10	Reference signal measurement timing configuration	187
5.5.2.10a	RSSI measurement timing configuration	188
5.5.2.11	Measurement gap sharing configuration	188
5.5.3	Performing measurements	189
5.5.3.1	General	189
5.5.3.2	Layer 3 filtering	194
5.5.3.3	Derivation of cell measurement results.....	195
5.5.3.3a	Derivation of layer 3 beam filtered measurement	195
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	196

5.5.4	Measurement report triggering	196
5.5.4.1	General	196
5.5.4.2	Event A1 (Serving becomes better than threshold)	203
5.5.4.3	Event A2 (Serving becomes worse than threshold)	203
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	204
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	204
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	205
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	206
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	207
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	207
5.5.4.10	Event I1 (Interference becomes higher than threshold)	208
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	209
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	209
5.5.4.13	Void	210
5.5.4.14	Void	210
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	210
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	210
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	211
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	212
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	212
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	213
5.5.5	Measurement reporting	214
5.5.5.1	General	214
5.5.5.2	Reporting of beam measurement information	222
5.5.5.3	Sorting of cell measurement results	223
5.5.6	Location measurement indication	224
5.5.6.1	General	224
5.5.6.2	Initiation	224
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	225
5.5a	Logged Measurements	225
5.5a.1	Logged Measurement Configuration	225
5.5a.1.1	General	225
5.5a.1.2	Initiation	226
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	226
5.5a.1.4	T330 expiry	226
5.5a.2	Release of Logged Measurement Configuration	226
5.5a.2.1	General	226
5.5a.2.2	Initiation	226
5.5a.3	Measurements logging	227
5.5a.3.1	General	227
5.5a.3.2	Initiation	227
5.6	UE capabilities	229
5.6.1	UE capability transfer	229
5.6.1.1	General	229
5.6.1.2	Initiation	230
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	230
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	231
5.6.1.5	Void	234
5.7	Other	234
5.7.1	DL information transfer	234
5.7.1.1	General	234
5.7.1.2	Initiation	234
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	234
5.7.1a	DL information transfer for MR-DC	235
5.7.1a.1	General	235
5.7.1a.2	Initiation	235
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	235

5.7.2	UL information transfer	236
5.7.2.1	General	236
5.7.2.2	Initiation	236
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	236
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	236
5.7.2a	UL information transfer for MR-DC	237
5.7.2a.1	General	237
5.7.2a.2	Initiation	237
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	237
5.7.2b	UL transfer of IRAT information	237
5.7.2b.1	General	237
5.7.2b.2	Initiation	238
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	238
5.7.3	SCG failure information	238
5.7.3.1	General	238
5.7.3.2	Initiation	238
5.7.3.3	Failure type determination for (NG)EN-DC	239
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	240
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	240
5.7.3a	EUTRA SCG failure information	243
5.7.3a.1	General	243
5.7.3a.2	Initiation	243
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	243
5.7.3b	MCG failure information	244
5.7.3b.1	General	244
5.7.3b.2	Initiation	244
5.7.3b.3	Failure type determination	244
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	245
5.7.3b.5	T316 expiry	246
5.7.4	UE Assistance Information	247
5.7.4.1	General	247
5.7.4.2	Initiation	247
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	254
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	262
5.7.4.4	Relaxed measurement criterion for a stationary RedCap UE	263
5.7.4a	Void	263
5.7.5	Failure information	263
5.7.5.1	General	263
5.7.5.2	Initiation	264
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	264
5.7.6	DL message segment transfer	264
5.7.6.1	General	264
5.7.6.2	Initiation	265
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	265
5.7.7	UL message segment transfer	265
5.7.7.1	General	265
5.7.7.2	Initiation	265
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	266
5.7.8	Idle/inactive Measurements	266
5.7.8.1	General	266
5.7.8.1a	Measurement configuration	266
5.7.8.2	Void	267
5.7.8.2a	Performing measurements	267
5.7.8.3	T331 expiry or stop	270
5.7.8.4	Cell re-selection or cell selection while T331 is running	270
5.7.9	Mobility history information	270
5.7.9.1	General	270
5.7.9.2	Initiation	270
5.7.10	UE Information	274
5.7.10.1	General	274
5.7.10.2	Initiation	274
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	274

5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information.....	277
5.7.10.5	RA information determination	278
5.7.10.6	Actions for the successful handover report determination	281
5.7.11	Void	284
5.7.12	IAB Other Information	284
5.7.12.1	General	284
5.7.12.2	Initiation	284
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	284
5.7.13	RLM/BFD relaxation	286
5.7.13.1	Relaxed measurement criterion for low mobility	286
5.7.13.2	Relaxed measurement criterion for good serving cell quality	286
5.7.14	UE Positioning Assistance Information	287
5.7.14.1	General	287
5.7.14.2	Initiation	287
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	287
5.7.15	Void	288
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	289
5.8	Sidelink	289
5.8.1	General	289
5.8.2	Conditions for NR sidelink communication/discovery operation	290
5.8.3	Sidelink UE information for NR sidelink communication/discovery	291
5.8.3.1	General	291
5.8.3.2	Initiation	291
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	296
5.8.4	Void	300
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery	300
5.8.5.1	General	300
5.8.5.2	Initiation	301
5.8.5.3	Transmission of SLSS	301
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	303
5.8.5a.1	General	303
5.8.5a.2	Initiation	303
5.8.6	Sidelink synchronisation reference	303
5.8.6.1	General	303
5.8.6.2	Selection and reselection of synchronisation reference	304
5.8.6.3	Sidelink communication transmission reference cell selection	306
5.8.7	Sidelink communication reception	306
5.8.8	Sidelink communication transmission	307
5.8.9	Sidelink RRC procedure	309
5.8.9.1	Sidelink RRC reconfiguration	309
5.8.9.1.1	General	309
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	310
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	311
5.8.9.1.4	Void	313
5.8.9.1.5	Void	313
5.8.9.1.6	Void	313
5.8.9.1.7	Void	313
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	313
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	313
5.8.9.1a	Sidelink radio bearer management	314
5.8.9.1a.1	Sidelink DRB release	314
5.8.9.1a.2	Sidelink DRB addition/modification	315
5.8.9.1a.3	Sidelink SRB release	316
5.8.9.1a.4	Sidelink SRB addition	317
5.8.9.2	Sidelink UE capability transfer	317
5.8.9.2.1	General	317
5.8.9.2.2	Initiation	317
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	317
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	318
5.8.9.3	Sidelink radio link failure related actions	318

5.8.9.4	Sidelink common control information	319
5.8.9.4.1	General	319
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	319
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	319
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	320
5.8.9.6	Sidelink UE assistance information	321
5.8.9.6.1	General	321
5.8.9.6.2	Initiation	321
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	321
5.8.9.8	Remote UE information	322
5.8.9.8.1	General	322
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	323
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	323
5.8.9.9	Uu message transfer in sidelink	324
5.8.9.9.1	General	324
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	324
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	325
5.8.9.10	Notification Message	325
5.8.9.10.1	General	325
5.8.9.10.2	Initiation	325
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	325
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	326
5.8.10	Sidelink measurement	326
5.8.10.1	Introduction	326
5.8.10.2	Sidelink measurement configuration	327
5.8.10.2.1	General	327
5.8.10.2.2	Sidelink measurement identity removal	327
5.8.10.2.3	Sidelink measurement identity addition/modification	328
5.8.10.2.4	Sidelink measurement object removal	328
5.8.10.2.5	Sidelink measurement object addition/modification	328
5.8.10.2.6	Sidelink reporting configuration removal	329
5.8.10.2.7	Sidelink reporting configuration addition/modification	329
5.8.10.2.8	Sidelink quantity configuration	329
5.8.10.3	Performing NR sidelink measurements	330
5.8.10.3.1	General	330
5.8.10.3.2	Derivation of NR sidelink measurement results	330
5.8.10.4	Sidelink measurement report triggering	330
5.8.10.4.1	General	330
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	331
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	332
5.8.10.5	Sidelink measurement reporting	332
5.8.10.5.1	General	332
5.8.11	Zone identity calculation	333
5.8.12	DFN derivation from GNSS	333
5.9	MBS Broadcast	339
5.9.1	Introduction	339
5.9.1.1	General	339
5.9.1.2	MCCH scheduling	340
5.9.1.3	MCCH information validity and notification of changes	340
5.9.2	MCCH information acquisition	340
5.9.2.1	General	340
5.9.2.2	Initiation	341
5.9.2.3	MCCH information acquisition by the UE	341
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	341
5.9.3	Broadcast MRB configuration	341
5.9.3.1	General	341
5.9.3.2	Initiation	342
5.9.3.3	Broadcast MRB establishment	342
5.9.3.4	Broadcast MRB release	342
5.9.4	MBS Interest Indication	342
5.9.4.1	General	342
5.9.4.2	Initiation	343

5.9.4.3	MBS frequencies of interest determination.....	343
5.9.4.4	MBS services of interest determination	344
5.9.4.5	Setting of the contents of MBS Interest Indication	344
6	Protocol data units, formats and parameters (ASN.1)	345
6.1	General	345
6.1.1	Introduction.....	345
6.1.2	Need codes and conditions for optional fields	345
6.1.3	General rules	348
6.2	RRC messages	348
6.2.1	General message structure	348
–	NR-RRC-Definitions.....	348
–	BCCH-BCH-Message	348
–	BCCH-DL-SCH-Message	349
–	DL-CCCH-Message	349
–	DL-DCCH-Message	350
–	MCCH-Message	350
–	PCCH-Message.....	351
–	UL-CCCH-Message	351
–	UL-CCCH1-Message	352
–	UL-DCCH-Message.....	352
6.2.2	Message definitions	354
–	CounterCheck.....	354
–	CounterCheckResponse.....	355
–	DedicatedSIBRequest.....	356
–	DLDedicatedMessageSegment.....	357
–	DLInformationTransfer.....	358
–	DLInformationTransferMRDC.....	359
–	FailureInformation.....	360
–	IABOtherInformation	361
–	LocationMeasurementIndication	364
–	LoggedMeasurementConfiguration	365
–	MBSBroadcastConfiguration	367
–	MBSInterestIndication	368
–	MCGFailureInformation	369
–	MeasurementReport	371
–	MeasurementReportAppLayer	371
–	MIB	373
–	MobilityFromNRCommand	374
–	Paging	376
–	RRCReestablishment	377
–	RRCReestablishmentComplete	378
–	RRCReestablishmentRequest	379
–	RRCReconfiguration	380
–	RRCReconfigurationComplete	387
–	RRCReject	389
–	RRCRelease.....	390
–	RRCResume.....	399
–	RRCResumeComplete	402
–	RRCResumeRequest	403
–	RRCResumeRequest1	404
–	RRCSetup	405
–	RRCSetupComplete	406
–	RRCSetupRequest.....	408
–	RRCSystemInfoRequest	409
–	SCGFailureInformation	411
–	SCGFailureInformationEUTRA.....	412
–	SecurityModeCommand	413
–	SecurityModeComplete	414
–	SecurityModeFailure.....	415
–	SIB1	416
–	SidelinkUEInformationNR	421

–	SystemInformation	426
–	UEAssistanceInformation	427
–	UECapabilityEnquiry	436
–	UECapabilityInformation	437
–	UEInformationRequest	438
–	UEInformationResponse	439
–	UEPositioningAssistanceInfo	454
–	ULDedicatedMessageSegment	456
–	ULInformationTransfer	457
–	ULInformationTransferIRAT	457
–	ULInformationTransferMRDC	458
6.3	RRC information elements	459
6.3.0	Parameterized types	459
–	SetupRelease	459
6.3.1	System information blocks	460
–	SIB2	460
–	SIB3	465
–	SIB4	467
–	SIB5	473
–	SIB6	476
–	SIB7	476
–	SIB8	477
–	SIB9	478
–	SIB10	479
–	SIB11	480
–	SIB12	480
–	SIB13	482
–	SIB14	483
–	SIB15	484
–	SIB16	484
–	SIB17	485
–	SIB18	487
–	SIB20	489
–	SIB21	490
6.3.1a	Positioning System information blocks	491
–	PosSystemInformation-r16-IEs	491
–	PosSI-SchedulingInfo	492
–	SIBpos	495
6.3.2	Radio resource control information elements	495
–	AdditionalSpectrumEmission	495
–	Alpha	496
–	AMF-Identifier	496
–	ARFCN-ValueEUTRA	496
–	ARFCN-ValueNR	497
–	ARFCN-ValueUTRA-FDD	497
–	AvailabilityCombinationsPerCell	497
–	AvailabilityIndicator	499
–	BAP-RoutingID	499
–	BeamFailureRecoveryConfig	500
–	BeamFailureRecoveryRSConfig	503
–	BetaOffsets	504
–	BetaOffsetsCrossPri	505
–	BH-LogicalChannelIdentity	505
–	BH-LogicalChannelIdentity-Ext	506
–	BH-RLC-ChannelConfig	506
–	BH-RLC-ChannelID	507
–	BSR-Config	507
–	BWP	508
–	BWP-Downlink	509
–	BWP-DownlinkCommon	510
–	BWP-DownlinkDedicated	510
–	BWP-Id	513

–	BWP-Uplink	513
–	BWP-UplinkCommon	514
–	BWP-UplinkDedicated	517
–	CandidateBeamRS	520
–	CellAccessRelatedInfo	521
–	CellAccessRelatedInfo-EUTRA-5GC	523
–	CellAccessRelatedInfo-EUTRA-EPC	523
–	CellGroupConfig	524
–	CellGroupId	534
–	CellIdentity	534
–	CellReselectionPriority	534
–	CellReselectionSubPriority	535
–	CFR-ConfigMulticast	535
–	CGI-InfoEUTRA	536
–	CGI-InfoEUTRALogging	536
–	CGI-InfoNR	537
–	CGI-Info-Logging	538
–	CLI-RSSI-Range	539
–	CodebookConfig	539
–	CommonLocationInfo	545
–	CondReconfigId	545
–	CondReconfigToAddModList	546
–	ConditionalReconfiguration	547
–	ConfiguredGrantConfig	547
–	ConfiguredGrantConfigIndex	556
–	ConfiguredGrantConfigIndexMAC	557
–	ConnEstFailureControl	557
–	ControlResourceSet	558
–	ControlResourceSetId	560
–	ControlResourceSetZero	560
–	CrossCarrierSchedulingConfig	561
–	CSI-AperiodicTriggerStateList	562
–	CSI-FrequencyOccupation	565
–	CSI-IM-Resource	565
–	CSI-IM-ResourceId	566
–	CSI-IM-ResourceSet	567
–	CSI-IM-ResourceSetId	567
–	CSI-MeasConfig	567
–	CSI-ReportConfig	569
–	CSI-ReportConfigId	576
–	CSI-ResourceConfig	577
–	CSI-ResourceConfigId	578
–	CSI-ResourcePeriodicityAndOffset	578
–	CSI-RS-ResourceConfigMobility	579
–	CSI-RS-ResourceMapping	581
–	CSI-SemiPersistentOnPUSCH-TriggerStateList	583
–	CSI-SSB-ResourceSet	584
–	CSI-SSB-ResourceSetId	584
–	DedicatedNAS-Message	585
–	DL-PPW-PreConfig	585
–	DMRS-BundlingPUCCH-Config	588
–	DMRS-BundlingPUSCH-Config	588
–	DMRS-DownlinkConfig	589
–	DMRS-UplinkConfig	590
–	DownlinkConfigCommon	592
–	DownlinkConfigCommonSIB	593
–	DownlinkPreemption	597
–	DRB-Identity	598
–	DRX-Config	598
–	DRX-ConfigSecondaryGroup	600
–	DRX-ConfigSL	601
–	EphemerisInfo	602