

ETSI TS 136 331 V17.8.0 (2024-05)



**LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 36.331 version 17.8.0 Release 17)**

[ETSI TS 136 331 V17.8.0 \(2024-05\)](https://standards.iteh.ai/catalog/standards/etsi/d23b9cb7-ca20-4506-a497-3c0ac5bd1fc9/etsi-ts-136-331-v17-8-0-2024-05)

<https://standards.iteh.ai/catalog/standards/etsi/d23b9cb7-ca20-4506-a497-3c0ac5bd1fc9/etsi-ts-136-331-v17-8-0-2024-05>



ReferenceRTS/TSGR-0236331vh80

KeywordsLTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2024.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2024-05)

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	30
3.1 Definitions	30
3.2 Abbreviations	32
4 General	36
4.1 Introduction	36
4.2 Architecture	38
4.2.1 UE states and state transitions including inter RAT	38
4.2.2 Signalling radio bearers	42
4.3 Services	43
4.3.1 Services provided to upper layers	43
4.3.2 Services expected from lower layers	43
4.4 Functions	43
4.5 Data available for transmission for NB-IoT	45
5 Procedures	45
5.1 General	45
5.1.1 Introduction.....	45
5.1.2 General requirements.....	45
5.1.3 Requirements for UE in MR-DC	46
5.2 System information	47
5.2.1 Introduction.....	47
5.2.1.1 General	47
5.2.1.2 Scheduling.....	48
5.2.1.2a Scheduling for NB-IoT	48
5.2.1.3 System information validity and notification of changes	49
5.2.1.4 Indication of ETWS notification.....	51
5.2.1.5 Indication of CMAS notification.....	52
5.2.1.6 Notification of EAB parameters change	52
5.2.1.7 Access Barring parameters change in NB-IoT	52
5.2.1.8 Notification of UAC parameters change	53
5.2.2 System information acquisition	53
5.2.2.1 General	53
5.2.2.2 Initiation.....	54
5.2.2.3 System information required by the UE.....	54
5.2.2.4 System information acquisition by the UE.....	55
5.2.2.5 Essential system information missing	60
5.2.2.6 Actions upon reception of the <i>MasterInformationBlock</i> message.....	60
5.2.2.7 Actions upon reception of the <i>SystemInformationBlockType1</i> message	61
5.2.2.8 Actions upon reception of <i>SystemInformation</i> messages	63
5.2.2.9 Actions upon reception of <i>SystemInformationBlockType2</i>	64
5.2.2.10 Actions upon reception of <i>SystemInformationBlockType3</i>	65
5.2.2.11 Actions upon reception of <i>SystemInformationBlockType4</i>	66
5.2.2.12 Actions upon reception of <i>SystemInformationBlockType5</i>	66
5.2.2.13 Actions upon reception of <i>SystemInformationBlockType6</i>	67
5.2.2.14 Actions upon reception of <i>SystemInformationBlockType7</i>	67
5.2.2.15 Actions upon reception of <i>SystemInformationBlockType8</i>	67
5.2.2.16 Actions upon reception of <i>SystemInformationBlockType9</i>	68
5.2.2.17 Actions upon reception of <i>SystemInformationBlockType10</i>	68

5.2.2.18	Actions upon reception of <i>SystemInformationBlockType11</i>	68
5.2.2.19	Actions upon reception of <i>SystemInformationBlockType12</i>	69
5.2.2.20	Actions upon reception of <i>SystemInformationBlockType13</i>	70
5.2.2.21	Actions upon reception of <i>SystemInformationBlockType14</i>	70
5.2.2.22	Actions upon reception of <i>SystemInformationBlockType15</i>	70
5.2.2.23	Actions upon reception of <i>SystemInformationBlockType16</i>	70
5.2.2.24	Actions upon reception of <i>SystemInformationBlockType17</i>	70
5.2.2.25	Actions upon reception of <i>SystemInformationBlockType18</i>	70
5.2.2.26	Actions upon reception of <i>SystemInformationBlockType19</i>	71
5.2.2.27	Actions upon reception of <i>SystemInformationBlockType20</i>	71
5.2.2.28	Actions upon reception of <i>SystemInformationBlockType21</i>	71
5.2.2.29	Actions upon reception of <i>SystemInformationBlockType22-NB</i>	72
5.2.2.30	Actions upon reception of <i>SystemInformationBlockType23-NB</i>	72
5.2.2.31	Actions upon reception of <i>SystemInformationBlockType24</i>	72
5.2.2.32	Actions upon reception of <i>SystemInformationBlockType25</i>	72
5.2.2.33	Actions upon reception of <i>SystemInformationBlockType26</i>	72
5.2.2.33a	Actions upon reception of <i>SystemInformationBlockType26a</i>	72
5.2.2.34	Actions upon reception of <i>SystemInformationBlockPos</i>	72
5.2.2.35	Actions upon reception of <i>SystemInformationBlockType27</i>	73
5.2.2.36	Actions upon reception of <i>SystemInformationBlockType28</i>	73
5.2.2.37	Actions upon reception of <i>SystemInformationBlockType29</i>	73
5.2.2.38	Actions upon reception of <i>SystemInformationBlockType30</i>	73
5.2.2.39	Actions upon reception of <i>SystemInformationBlockType31</i>	73
5.2.2.40	Actions upon reception of <i>SystemInformationBlockType32</i>	73
5.2.3	Acquisition of an SI message	73
5.2.3a	Acquisition of an SI message by BL UE or UE in CE or a NB-IoT UE	74
5.2.3b	Acquisition of an SI message from MBMS-dedicated cell	75
5.3	Connection control	76
5.3.1	Introduction	76
5.3.1.1	RRC connection control	76
5.3.1.2	Security	78
5.3.1.2a	RN security	80
5.3.1.3	Connected mode mobility	80
5.3.1.4	Connection control in NB-IoT	81
5.3.2	Paging	82
5.3.2.1	General	82
5.3.2.2	Initiation	83
5.3.2.3	Reception of the <i>Paging</i> message by the UE	83
5.3.3	RRC connection establishment	85
5.3.3.1	General	85
5.3.3.1a	Conditions for establishing RRC Connection for sidelink communication/ discovery/ V2X sidelink communication/ NR sidelink communication	88
5.3.3.1b	Conditions for initiating EDT	89
5.3.3.1c	Conditions for initiating transmission using PUR	90
5.3.3.1d	Condition for establishing RRC Connection in NTN	90
5.3.3.2	Initiation	90
5.3.3.3	Actions related to transmission of <i>RRCCConnectionRequest</i> message	98
5.3.3.3a	Actions related to transmission of <i>RRCCConnectionResumeRequest</i> message	99
5.3.3.3b	Actions related to transmission of <i>RRCEarlyDataRequest</i> message	103
5.3.3.3c	UE actions upon receiving EDT fallback indication from lower layers	103
5.3.3.4	Reception of the <i>RRCCConnectionSetup</i> by the UE	104
5.3.3.4a	Reception of the <i>RRCCConnectionResume</i> by the UE	109
5.3.3.4b	Reception of the <i>RRCEarlyDataComplete</i> by the UE	115
5.3.3.5	Cell re-selection or cell selection while T300, T302, T303, T305, T306, T308 or T309 is running	116
5.3.3.6	T300 expiry	117
5.3.3.7	T302, T303, T305, T306, or T308 expiry or stop	119
5.3.3.8	Reception of the <i>RRCCConnectionReject</i> by the UE	120
5.3.3.9	Abortion of RRC connection establishment	121
5.3.3.9a	Abortion of early security reactivation	121
5.3.3.10	Handling of SSAC related parameters	121
5.3.3.11	Access barring check	122
5.3.3.12	EAB check	123

5.3.3.13	Access barring check for ACDC	124
5.3.3.14	Access Barring check for NB-IoT	125
5.3.3.15	Failure to deliver NAS information in RRCConnectionSetupComplete message	127
5.3.3.16	Integrity check failure from lower layers while T300 is running	127
5.3.3.17	Inability to comply with RRCConnectionResume	127
5.3.3.18	Early security reactivation	127
5.3.3.19	Timing alignment validation for transmission using PUR	128
5.3.3.20	Maintenance of PUR occasions	128
5.3.3.21	UE actions upon indication of out-of-date GNSS position	129
5.3.3.22	Void	129
5.3.4	Initial security activation	129
5.3.4.1	General	129
5.3.4.2	Initiation	129
5.3.4.3	Reception of the SecurityModeCommand by the UE	129
5.3.5	RRC connection reconfiguration	131
5.3.5.1	General	131
5.3.5.2	Initiation	131
5.3.5.3	Reception of an RRCConnectionReconfiguration not including the mobilityControlInfo by the UE	132
5.3.5.4	Reception of an RRCConnectionReconfiguration including the mobilityControlInfo by the UE (handover)	135
5.3.5.5	Reconfiguration failure	143
5.3.5.6	T304 expiry (handover failure)	143
5.3.5.7	Void	146
5.3.5.7a	T307 expiry (SCG change failure)	146
5.3.5.8	Radio Configuration involving full configuration option	146
5.3.5.9	Conditional reconfiguration	149
5.3.5.9.1	General	149
5.3.5.9.2	Conditional reconfiguration removal	149
5.3.5.9.3	Conditional reconfiguration addition/modification	149
5.3.5.9.4	Conditional reconfiguration evaluation	150
5.3.5.9.5	Conditional reconfiguration execution	150
5.3.5.9.6	VarConditionalReconfiguration remove	151
5.3.5.9.7	VarConditionalReconfiguration CPC remove	151
5.3.6	Counter check	151
5.3.6.1	General	151
5.3.6.2	Initiation	151
5.3.6.3	Reception of the CounterCheck message by the UE	152
5.3.7	RRC connection re-establishment	153
5.3.7.1	General	153
5.3.7.1a	Condition for re-establishing RRC Connection in NTN	154
5.3.7.2	Initiation	154
5.3.7.3	Actions following cell selection while T311 is running	156
5.3.7.4	Actions related to transmission of RRCConnectionReestablishmentRequest message	158
5.3.7.5	Reception of the RRCConnectionReestablishment by the UE	159
5.3.7.6	T311 expiry	163
5.3.7.7	T301 expiry or selected cell no longer suitable	163
5.3.7.8	Reception of RRCConnectionReestablishmentReject by the UE	163
5.3.8	RRC connection release	163
5.3.8.1	General	163
5.3.8.2	Initiation	164
5.3.8.3	Reception of the RRCConnectionRelease by the UE	164
5.3.8.4	T320 expiry	167
5.3.8.5	T322 expiry or stop	168
5.3.8.6	UE actions upon receiving the expiry of DataInactivityTimer	168
5.3.8.7	UE actions upon entering RRC_INACTIVE	168
5.3.8.8	T323 expiry	169
5.3.9	RRC connection release requested by upper layers	169
5.3.9.1	General	169
5.3.9.2	Initiation	169
5.3.10	Radio resource configuration	169
5.3.10.0	General	169

5.3.10.1	SRB addition/ modification.....	170
5.3.10.1a	SCG RLC bearer addition or reconfiguration for SRBs.....	172
5.3.10.2	DRB release	172
5.3.10.3	DRB addition/ modification.....	173
5.3.10.3a1	DC specific DRB addition or reconfiguration.....	175
5.3.10.3a2	LWA specific DRB addition or reconfiguration	178
5.3.10.3a3	LWIP specific DRB addition or reconfiguration.....	178
5.3.10.3a4	SCG RLC bearer addition or reconfiguration for DRBs in NE-DC	179
5.3.10.3a	SCell release.....	180
5.3.10.3b	SCell addition/ modification	180
5.3.10.3c	PSCell addition or modification.....	181
5.3.10.3d	SCell group release	181
5.3.10.3e	SCell group addition/ modification	181
5.3.10.4	MAC main reconfiguration	182
5.3.10.5	Semi-persistent scheduling reconfiguration	182
5.3.10.6	Physical channel reconfiguration	182
5.3.10.7	Radio Link Failure Timers and Constants reconfiguration	184
5.3.10.8	Time domain measurement resource restriction for serving cell.....	184
5.3.10.9	Other configuration	184
5.3.10.10	SCG reconfiguration	187
5.3.10.11	SCG dedicated resource configuration.....	190
5.3.10.12	Reconfiguration SCG or split DRB by <i>drb-ToAddModList</i>	190
5.3.10.13	Neighbour cell information reconfiguration.....	190
5.3.10.14	Void.....	191
5.3.10.15	Sidelink dedicated configuration.....	191
5.3.10.15a	V2X sidelink Communication dedicated configuration	192
5.3.10.16	T370 expiry	193
5.3.10.17	SRB release	193
5.3.10.18	Scheduling Request Configuration for NB-IoT	193
5.3.10.19	NE-DC release	193
5.3.11	Radio link failure related actions	194
5.3.11.1	Detection of physical layer problems in RRC_CONNECTED	194
5.3.11.1a	Early detection of physical layer problems in RRC_CONNECTED	194
5.3.11.1b	Detection of physical layer improvements in RRC_CONNECTED	194
5.3.11.2	Recovery of physical layer problems	194
5.3.11.2a	Recovery of early detection of physical layer problems	194
5.3.11.2b	Cancellation of physical layer improvements in RRC_CONNECTED	195
5.3.11.3	Detection of radio link failure	195
5.3.11.3a	Detection of early-out-of-sync event.....	198
5.3.11.3b	Detection of early-in-sync event	198
5.3.12	UE actions upon leaving RRC_CONNECTED or RRC_INACTIVE	198
5.3.13	UE actions upon PUCCH/ SPUCCH/ SRS release request	201
5.3.13a	UE actions upon SR release request for NB-IoT	201
5.3.13b	UE actions upon PUR release request.....	201
5.3.14	Proximity indication	202
5.3.14.1	General	202
5.3.14.2	Initiation.....	202
5.3.14.3	Actions related to transmission of <i>ProximityIndication</i> message.....	202
5.3.15	Void	203
5.3.16	Unified Access Control.....	203
5.3.16.1	General	203
5.3.16.2	Initiation.....	203
5.3.16.3	Void.....	206
5.3.16.4	T302, T309 expiry or stop (Barring alleviation)	206
5.3.16.5	Access barring check.....	207
5.3.17	RAN notification area update	208
5.3.17.1	General	208
5.3.17.2	Initiation.....	208
5.3.17.3	Inter RAT cell reselection or CN type change	208
5.3.18	T317 expiry.....	209
5.4	Inter-RAT mobility.....	209
5.4.1	Introduction.....	209

5.4.2	Handover to E-UTRA	209
5.4.2.1	General	209
5.4.2.2	Initiation	210
5.4.2.3	Reception of the <i>RRCConnectionReconfiguration</i> by the UE	210
5.4.2.4	Reconfiguration failure	213
5.4.2.5	T304 expiry (handover to E-UTRA failure)	214
5.4.3	Mobility from E-UTRA	214
5.4.3.1	General	214
5.4.3.2	Initiation	215
5.4.3.3	Reception of the <i>MobilityFromEUTRACommand</i> by the UE	215
5.4.3.4	Successful completion of the mobility from E-UTRA	216
5.4.3.5	Mobility from E-UTRA failure	217
5.4.4	Handover from E-UTRA preparation request (CDMA2000)	218
5.4.4.1	General	218
5.4.4.2	Initiation	218
5.4.4.3	Reception of the <i>HandoverFromEUTRAPreparationRequest</i> by the UE	218
5.4.5	UL handover preparation transfer (CDMA2000)	219
5.4.5.1	General	219
5.4.5.2	Initiation	219
5.4.5.3	Actions related to transmission of the <i>ULHandoverPreparationTransfer</i> message	219
5.4.5.4	Failure to deliver the <i>ULHandoverPreparationTransfer</i> message	219
5.4.6	Inter-RAT cell change order to E-UTRAN	219
5.4.6.1	General	219
5.4.6.2	Initiation	220
5.4.6.3	UE fails to complete an inter-RAT cell change order	220
5.5	Measurements	220
5.5.1	Introduction	220
5.5.2	Measurement configuration	222
5.5.2.1	General	222
5.5.2.2	Measurement identity removal	223
5.5.2.2a	Measurement identity autonomous removal	224
5.5.2.3	Measurement identity addition/ modification	224
5.5.2.4	Measurement object removal	225
5.5.2.5	Measurement object addition/ modification	226
5.5.2.6	Reporting configuration removal	228
5.5.2.7	Reporting configuration addition/ modification	229
5.5.2.8	Quantity configuration	229
5.5.2.9	Measurement gap configuration	229
5.5.2.9a	Measurement gap configuration for RSTD measurements with dense PRS configuration	231
5.5.2.10	Discovery signals measurement timing configuration	231
5.5.2.11	RSSI measurement timing configuration	231
5.5.2.12	Measurement gap sharing configuration	232
5.5.2.13	NR measurement timing configuration	232
5.5.3	Performing measurements	233
5.5.3.1	General	233
5.5.3.2	Layer 3 filtering	237
5.5.3.3	Derivation of NR cell quality	238
5.5.3.4	Derivation of NR beam quality	238
5.5.4	Measurement report triggering	239
5.5.4.1	General	239
5.5.4.2	Event A1 (Serving becomes better than threshold)	245
5.5.4.3	Event A2 (Serving becomes worse than threshold)	246
5.5.4.4	Event A3 (Neighbour becomes offset better than PCell/ PSCell)	246
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	247
5.5.4.6	Event A5 (PCell/ PSCell becomes worse than threshold1 and neighbour becomes better than threshold2)	248
5.5.4.6a	Event A6 (Neighbour becomes offset better than SCell)	249
5.5.4.7	Event B1 (Inter RAT neighbour becomes better than threshold)	249
5.5.4.8	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	250
5.5.4.9	Event C1 (CSI-RS resource becomes better than threshold)	251
5.5.4.10	Event C2 (CSI-RS resource becomes offset better than reference CSI-RS resource)	251

5.5.4.11	Event W1 (WLAN becomes better than a threshold).....	252
5.5.4.12	Event W2 (All WLAN inside WLAN mobility set becomes worse than threshold1 and a WLAN outside WLAN mobility set becomes better than threshold2)	252
5.5.4.13	Event W3 (All WLAN inside WLAN mobility set becomes worse than a threshold).....	253
5.5.4.14	Event V1 (The channel busy ratio is above a threshold).....	254
5.5.4.15	Event V2 (The channel busy ratio is below a threshold).....	254
5.5.4.16	Event H1 (The Aerial UE height is above a threshold).....	255
5.5.4.17	Event H2 (The Aerial UE height is below a threshold).....	255
5.5.4.18	Void.....	256
5.5.4.19	Void.....	256
5.5.5	Measurement reporting	256
5.5.5.1	General	256
5.5.5.2	Determination of available NR measurement results	263
5.5.5.3	Selection of NR sorting quality	263
5.5.6	Measurement related actions.....	264
5.5.6.1	Actions upon handover and re-establishment.....	264
5.5.6.2	Speed dependant scaling of measurement related parameters.....	265
5.5.7	Inter-frequency RSTD measurement indication	265
5.5.7.1	General	265
5.5.7.2	Initiation.....	266
5.5.7.3	Actions related to transmission of <i>InterFreqRSTDMeasurementIndication</i> message.....	266
5.5.8	Measurements in NB-IoT	267
5.6	Other.....	267
5.6.0	General.....	267
5.6.1	DL information transfer	268
5.6.1.1	General	268
5.6.1.2	Initiation.....	268
5.6.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	268
5.6.2	UL information transfer	269
5.6.2.1	General	269
5.6.2.2	Initiation.....	269
5.6.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	269
5.6.2.4	Failure to deliver <i>ULInformationTransfer</i> message.....	270
5.6.2a	UL information transfer for MR-DC	270
5.6.2a.1	General	270
5.6.2a.2	Initiation.....	270
5.6.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	270
5.6.2a.4	Void.....	271
5.6.3	UE capability transfer	271
5.6.3.1	General	271
5.6.3.2	Initiation.....	271
5.6.3.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	271
5.6.4	CSFB to 1x Parameter transfer	276
5.6.4.1	General	276
5.6.4.2	Initiation.....	276
5.6.4.3	Actions related to transmission of <i>CSFBParametersRequestCDMA2000</i> message.....	276
5.6.4.4	Reception of the <i>CSFBParametersResponseCDMA2000</i> message.....	276
5.6.5	UE Information.....	276
5.6.5.1	General	276
5.6.5.2	Initiation.....	277
5.6.5.3	Reception of the <i>UEInformationRequest</i> message	277
5.6.6	Logged Measurement Configuration	279
5.6.6.1	General	279
5.6.6.2	Initiation.....	280
5.6.6.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	280
5.6.6.4	T330 expiry	280
5.6.7	Release of Logged Measurement Configuration.....	281
5.6.7.1	General	281
5.6.7.2	Initiation.....	281
5.6.8	Measurements logging.....	281
5.6.8.1	General	281
5.6.8.2	Initiation.....	281

5.6.9	In-device coexistence indication.....	285
5.6.9.1	General.....	285
5.6.9.2	Initiation.....	285
5.6.9.3	Actions related to transmission of <i>InDeviceCoexIndication</i> message.....	286
5.6.10	UE Assistance Information.....	288
5.6.10.1	General.....	288
5.6.10.2	Initiation.....	288
5.6.10.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	290
5.6.11	Mobility history information.....	292
5.6.11.1	General.....	292
5.6.11.2	Initiation.....	292
5.6.12	RAN-assisted WLAN interworking.....	293
5.6.12.1	General.....	293
5.6.12.2	Dedicated WLAN offload configuration.....	293
5.6.12.3	WLAN offload RAN evaluation	293
5.6.12.4	T350 expiry or stop	294
5.6.12.5	Cell selection/ re-selection while T350 is running	294
5.6.13	SCG failure information	294
5.6.13.1	General.....	294
5.6.13.2	Initiation.....	294
5.6.13.3	Actions related to transmission of <i>SCGFailureInformation</i> message	295
5.6.13.4	Failure type determination in NE-DC	295
5.6.13.5	Setting the contents of <i>MeasResultSCG-FailureMRDC</i>	296
5.6.13a	NR SCG failure information.....	297
5.6.13a.1	General.....	297
5.6.13a.2	Initiation.....	297
5.6.13a.3	Actions related to transmission of <i>SCGFailureInformationNR</i> message	297
5.6.14	LTE-WLAN Aggregation.....	298
5.6.14.1	Introduction.....	298
5.6.14.2	Reception of LWA configuration.....	298
5.6.14.3	Release of LWA configuration	298
5.6.15	WLAN connection management.....	299
5.6.15.1	Introduction.....	299
5.6.15.2	WLAN connection status reporting.....	299
5.6.15.2.1	General	299
5.6.15.2.2	Initiation	299
5.6.15.2.3	Actions related to transmission of <i>WLANConnectionStatusReport</i> message	300
5.6.15.3	T351 Expiry (WLAN connection attempt timeout)	300
5.6.15.4	WLAN status monitoring.....	300
5.6.16	RAN controlled LTE-WLAN interworking.....	301
5.6.16.1	General.....	301
5.6.16.2	WLAN traffic steering command.....	301
5.6.17	LTE-WLAN aggregation with IPsec tunnel	302
5.6.17.1	General.....	302
5.6.17.2	LWIP reconfiguration	302
5.6.17.3	LWIP release.....	302
5.6.18	Void.....	303
5.6.19	Application layer measurement reporting.....	303
5.6.19.1	General.....	303
5.6.19.2	Initiation.....	303
5.6.20	Idle/Inactive Measurements.....	303
5.6.20.1	General.....	303
5.6.20.1a	Measurement configuration.....	303
5.6.20.2	Performing measurements.....	304
5.6.20.3	T331 expiry or stop	307
5.6.20.4	Cell re-selection or selection while T331 is running.....	307
5.6.21	Failure information	308
5.6.21.1	General.....	308
5.6.21.2	Initiation.....	308
5.6.21.3	Actions related to transmission of <i>FailureInformation</i> message.....	308
5.6.22	UL message segment transfer	309
5.6.22.1	General.....	309

5.6.22.2	Initiation.....	309
5.6.22.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message.....	309
5.6.23	PUR Configuration Request	310
5.6.23.1	General.....	310
5.6.23.2	Initiation.....	310
5.6.23.3	Actions related to transmission of <i>PURConfigurationRequest</i> message.....	310
5.6.24	Neighbour Relation Reporting for SON ANR in NB-IoT	311
5.6.24.0	General.....	311
5.6.24.1	Initiation.....	311
5.6.25	DL message segment transfer	312
5.6.25.1	General.....	312
5.6.25.2	Initiation.....	312
5.6.25.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	312
5.6.26	MCG failure information	313
5.6.26.1	General.....	313
5.6.26.2	Initiation.....	313
5.6.26.3	Failure type determination	313
5.6.26.4	Actions related to transmission of <i>MCGFailureInformation</i> message.....	314
5.6.26.5	T316 expiry	315
5.6.27	Void	315
5.6.28	UL transfer of IRAT information	315
5.6.28.1	General.....	315
5.6.28.2	Initiation.....	316
5.6.28.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	316
5.7	Generic error handling.....	316
5.7.1	General.....	316
5.7.2	ASN.1 violation or encoding error.....	316
5.7.3	Field set to a not comprehended value.....	316
5.7.4	Mandatory field missing	317
5.7.5	Not comprehended field.....	318
5.8	MBMS.....	318
5.8.1	Introduction.....	318
5.8.1.1	General.....	318
5.8.1.2	Scheduling.....	318
5.8.1.3	MCCH information validity and notification of changes.....	319
5.8.2	MCCH information acquisition	320
5.8.2.1	General.....	320
5.8.2.2	Initiation.....	320
5.8.2.3	MCCH information acquisition by the UE.....	320
5.8.2.4	Actions upon reception of the <i>MBSFNAreaConfiguration</i> message	321
5.8.2.5	Actions upon reception of the <i>MBMSCountingRequest</i> message.....	321
5.8.3	MBMS PTM radio bearer configuration.....	321
5.8.3.1	General.....	321
5.8.3.2	Initiation.....	321
5.8.3.3	MRB establishment	321
5.8.3.4	MRB release.....	321
5.8.4	MBMS Counting Procedure	321
5.8.4.1	General.....	321
5.8.4.2	Initiation.....	322
5.8.4.3	Reception of the <i>MBMSCountingRequest</i> message by the UE	322
5.8.5	MBMS interest indication.....	323
5.8.5.1	General.....	323
5.8.5.2	Initiation.....	323
5.8.5.3	Determine MBMS frequencies of interest.....	324
5.8.5.3a	Determine MBMS services of interest	325
5.8.5.4	Actions related to transmission of <i>MBMSInterestIndication</i> message	325
5.8a	SC-PTM	326
5.8a.1	Introduction.....	326
5.8a.1.1	General.....	326
5.8a.1.2	SC-MCCH scheduling	326
5.8a.1.3	SC-MCCH information validity and notification of changes.....	326
5.8a.1.4	Procedures.....	327

5.8a.2	SC-MCCH information acquisition	327
5.8a.2.1	General	327
5.8a.2.2	Initiation	327
5.8a.2.3	SC-MCCH information acquisition by the UE	327
5.8a.2.4	Actions upon reception of the <i>SCPTMConfiguration</i> message	328
5.8a.3	SC-PTM radio bearer configuration	328
5.8a.3.1	General	328
5.8a.3.2	Initiation	328
5.8a.3.3	SC-MRB establishment	328
5.8a.3.4	SC-MRB release	329
5.9	RN procedures	329
5.9.1	RN reconfiguration	329
5.9.1.1	General	329
5.9.1.2	Initiation	329
5.9.1.3	Reception of the <i>RNReconfiguration</i> by the RN	329
5.10	Sidelink	330
5.10.1	Introduction	330
5.10.1a	Conditions for sidelink communication operation	330
5.10.1b	Conditions for PS related sidelink discovery operation	331
5.10.1c	Conditions for non-PS related sidelink discovery operation	331
5.10.1d	Conditions for V2X sidelink communication operation	331
5.10.2	Sidelink UE information	331
5.10.2.1	General	331
5.10.2.2	Initiation	332
5.10.2.3	Actions related to transmission of <i>SidelinkUEInformation</i> message	337
5.10.3	Sidelink communication monitoring	339
5.10.4	Sidelink communication transmission	341
5.10.5	Sidelink discovery monitoring	342
5.10.6	Sidelink discovery announcement	343
5.10.6a	Sidelink discovery announcement pool selection	346
5.10.6b	Sidelink discovery announcement reference carrier selection	346
5.10.7	Sidelink synchronisation information transmission	347
5.10.7.1	General	347
5.10.7.2	Initiation	348
5.10.7.3	Transmission of SLSS	350
5.10.7.4	Transmission of <i>MasterInformationBlock-SL</i> or <i>MasterInformationBlock-SL-V2X</i> message	352
5.10.7.5	Void	353
5.10.8	Sidelink synchronisation reference	353
5.10.8.1	General	353
5.10.8.2	Selection and reselection of synchronisation reference	353
5.10.8a	Selection and reselection of synchronisation carrier frequency	356
5.10.9	Sidelink common control information	359
5.10.9.1	General	359
5.10.9.2	Actions related to reception of <i>MasterInformationBlock-SL</i> / <i>MasterInformationBlock-SL-V2X</i> message	359
5.10.10	Sidelink relay UE operation	359
5.10.10.1	General	359
5.10.10.2	AS-conditions for relay related sidelink communication transmission by sidelink relay UE	360
5.10.10.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink relay UE	360
5.10.10.4	Sidelink relay UE threshold conditions	360
5.10.11	Sidelink remote UE operation	360
5.10.11.1	General	360
5.10.11.2	AS-conditions for relay related sidelink communication transmission by sidelink remote UE	361
5.10.11.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink remote UE	361
5.10.11.4	Selection and reselection of sidelink relay UE	361
5.10.11.5	Sidelink remote UE threshold conditions	362
5.10.12	V2X sidelink communication monitoring	362
5.10.13	V2X sidelink communication transmission	363
5.10.13.1	Transmission of V2X sidelink communication	363
5.10.13.1a	Transmission of P2X related V2X sidelink communication	365
5.10.13.2	V2X sidelink communication transmission pool selection	366
5.10.13.3	V2X sidelink communication transmission reference cell selection	367

5.10.14	DFN derivation from GNSS	368
5.10.15	Void	368
5.10.16	Sidelink synchronisation information transmission for NR sidelink communication.....	368
6	Protocol data units, formats and parameters (tabular & ASN.1).....	369
6.1	General	369
6.2	RRC messages.....	371
6.2.1	General message structure	371
–	<i>EUTRA-RRC-Definitions</i>	371
–	<i>BCCH-BCH-Message</i>	371
–	<i>BCCH-BCH-Message-MBMS</i>	371
–	<i>BCCH-DL-SCH-Message</i>	372
–	<i>BCCH-DL-SCH-Message-BR</i>	372
–	<i>BCCH-DL-SCH-Message-MBMS</i>	372
–	<i>MCCH-Message</i>	372
–	<i>PCCH-Message</i>	373
–	<i>DL-CCCH-Message</i>	373
–	<i>DL-DCCCH-Message</i>	374
–	<i>UL-CCCH-Message</i>	374
–	<i>UL-DCCCH-Message</i>	374
–	<i>SC-MCCH-Message</i>	375
6.2.2	Message definitions	376
–	<i>CounterCheck</i>	376
–	<i>CounterCheckResponse</i>	377
–	<i>CSFBParametersRequestCDMA2000</i>	378
–	<i>CSFBParametersResponseCDMA2000</i>	378
–	<i>DLDedicatedMessageSegment</i>	379
–	<i>DLInformationTransfer</i>	379
–	<i>FailureInformation</i>	380
–	<i>HandoverFromEUTRAPreparationRequest (CDMA2000)</i>	381
–	<i>InDeviceCoexIndication</i>	383
–	<i>InterFreqRSTDMeasurementIndication</i>	385
–	<i>LoggedMeasurementConfiguration</i>	387
–	<i>MasterInformationBlock</i>	389
–	<i>MasterInformationBlock-MBMS</i>	390
–	<i>MBMSCountingRequest</i>	391
–	<i>MBMSCountingResponse</i>	391
–	<i>MBMSInterestIndication</i>	392
–	<i>MBSFNAreaConfiguration</i>	393
–	<i>MCGFailureInformation</i>	394
–	<i>MeasReportAppLayer</i>	395
–	<i>MeasurementReport</i>	396
–	<i>MobilityFromEUTRACommand</i>	396
–	<i>Paging</i>	400
–	<i>ProximityIndication</i>	402
–	<i>PURConfigurationRequest</i>	403
–	<i>RNReconfiguration</i>	404
–	<i>RNReconfigurationComplete</i>	404
–	<i>RRCCConnectionReconfiguration</i>	405
–	<i>RRCCConnectionReconfigurationComplete</i>	415
–	<i>RRCCConnectionReestablishment</i>	417
–	<i>RRCCConnectionReestablishmentComplete</i>	418
–	<i>RRCCConnectionReestablishmentReject</i>	419
–	<i>RRCCConnectionReestablishmentRequest</i>	419
–	<i>RRCCConnectionReject</i>	420
–	<i>RRCCConnectionRelease</i>	421
–	<i>RRCCConnectionRequest</i>	428
–	<i>RRCCConnectionResume</i>	429
–	<i>RRCCConnectionResumeComplete</i>	432
–	<i>RRCCConnectionResumeRequest</i>	433
–	<i>RRCCConnectionSetup</i>	433
–	<i>RRCCConnectionSetupComplete</i>	434

–	RRCEarlyDataComplete	438
–	RRCEarlyDataRequest	438
–	SCGFailureInformation	439
–	SCGFailureInformationNR	440
–	SCPTMConfiguration	442
–	SCPTMConfiguration-BR	442
–	SecurityModeCommand	443
–	SecurityModeComplete	444
–	SecurityModeFailure	444
–	SidelinkUEInformation	445
–	SystemInformation	448
–	SystemInformationBlockType1	449
–	SystemInformationBlockType1-MBMS	460
–	UEAssistanceInformation	462
–	UECapabilityEnquiry	466
–	UECapabilityInformation	468
–	ULDedicatedMessageSegment	469
–	UEInformationRequest	470
–	UEInformationResponse	471
–	ULHandoverPreparationTransfer (CDMA2000)	478
–	ULInformationTransfer	478
–	ULInformationTransferIRAT	479
–	ULInformationTransferMRDC	480
–	WLANConnectionStatusReport	480
6.3	RRC information elements	481
6.3.0	Parameterized types	481
–	SetupRelease	481
6.3.1	System information blocks	481
–	SystemInformationBlockPos	481
–	SystemInformationBlockType2	482
–	SystemInformationBlockType3	487
–	SystemInformationBlockType4	492
–	SystemInformationBlockType5	493
–	SystemInformationBlockType6	499
–	SystemInformationBlockType7	501
–	SystemInformationBlockType8	502
–	SystemInformationBlockType9	507
–	SystemInformationBlockType10	507
–	SystemInformationBlockType11	508
–	SystemInformationBlockType12	509
–	SystemInformationBlockType13	510
–	SystemInformationBlockType14	510
–	SystemInformationBlockType15	511
–	SystemInformationBlockType16	512
–	SystemInformationBlockType17	513
–	SystemInformationBlockType18	514
–	SystemInformationBlockType19	514
–	SystemInformationBlockType20	517
–	SystemInformationBlockType21	520
–	SystemInformationBlockType24	521
–	SystemInformationBlockType25	525
–	SystemInformationBlockType26	527
–	SystemInformationBlockType26a	528
–	SystemInformationBlockType27	529
–	SystemInformationBlockType28	529
–	SystemInformationBlockType29	530
–	SystemInformationBlockType30	530
–	SystemInformationBlockType31	531
–	SystemInformationBlockType32	532
6.3.2	Radio resource control information elements	533
–	Alpha	533
–	AntennaInfo	533