INTERNATIONAL STANDARD

ISO 13185-4

First edition 2020-05

Intelligent transport systems — Vehicle interface for provisioning and support of ITS Services —

Part 4:

Unified vehicle interface protocol (UVIP) conformance test specification

Systèmes de transport intelligents - Interface véhicule pour la fourniture et le support de services —

Partie 4: Spécification d'essai de conformité du protocole d'interface véhicule unifié (PIVU)

ISO 13185-4:2020

https://standards.iteh.ai/catalog/standards/iso/73993ae1-c3cc-426b-8bf9-180579cf59f4/iso-13185-4-2020



iTeh Standards (https://standards.iteh.ai) Document Preview

ISO 13185-4:2020

https://standards.iteh.ai/catalog/standards/iso/73993ae1-c3cc-426b-8bf9-180579cf59f4/iso-13185-4-2020



COPYRIGHT PROTECTED DOCUMENT

© ISO 2020

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office CP 401 • Ch. de Blandonnet 8 CH-1214 Vernier, Geneva Phone: +41 22 749 01 11 Fax: +41 22 749 09 47 Email: copyright@iso.org Website: www.iso.org

ii

Published in Switzerland

| Co | ntent | S | Page |
|------|------------|---|---------|
| For | eword | | viii |
| Intr | oductio | n | ix |
| 1 | Scop | e | 1 |
| 2 | • | native references | |
| | | | |
| 3 | | ns, definitions and abbreviated terms | |
| | 3.1 3.2 | Terms and definitions Abbreviated terms | |
| | _ | | |
| 4 | | entions | |
| 5 | | ormance test plan (CTP) basic principles and clustering | 2 |
| | 5.1 5.2 | Basic principles for CTC definition CTC structure | |
| | 3.2 | 5.2.1 CTC – General structure | |
| | | 5.2.2 Result criteria | |
| | 5.3 | CTC system setup | |
| | 5.4 | CTC clustering | |
| | | 5.4.1 General | |
| | | 5.4.2 Main CTC clusters | 5 |
| 6 | CT cl | uster 1 - Requesting V-ITS-SG and vehicle identification related information | 6 |
| | 6.1 | CTC_UC 1.1 - Browsing available V-ITS-SGs | |
| | | 6.1.1 Overview | |
| | | 6.1.2 Test purpose | 6 |
| | | 6.1.3 Configuration | 7 |
| | | 6.1.4 Preamble (setup state) | |
| | | 6.1.6 Postamble (setup state) | |
| | 6.2 | CTC_UC 1.2 – Browsing supported ECUs | |
| | 0.2 | 6.2.1 Overview 6.2.1 | |
| | | 6.2.2 Test purpose 150//3993ae1-c3cc-426b-8bf9-1805/9cf59f4/iso-13185-4 | -2020.8 |
| | | 6.2.3 Configuration | |
| | | 6.2.4 Preamble (setup state) | |
| | | 6.2.5 Test execution | |
| | () | 6.2.6 Postamble (setup state) | |
| | 6.3 | CTC_UC 1.3 – Browsing supported data Ids | |
| | | 6.3.2 Test purpose | |
| | | 6.3.3 Configuration | |
| | | 6.3.4 Preamble (setup state) | |
| | | 6.3.5 Test execution | |
| | | 6.3.6 Postamble (setup state) | 10 |
| 7 | CT cl | uster 2 - Requesting vehicle and ECU data values | 10 |
| | 7.1 | CTC_UC 2.1 - Requesting data ID values for single usage | 10 |
| | | 7.1.1 Overview | |
| | | 7.1.2 Test purpose | |
| | | 7.1.3 Configuration | |
| | | 7.1.4 Preamble (setup state) 7.1.5 Test execution | |
| | | 7.1.6 Postamble (setup state) | |
| | 7.2 | CTC_UC 2.2 – Requesting data ID values for repeated usage | |
| | , | 7.2.1 Overview | |
| | | 7.2.2 Test purpose | |
| | | 7.2.3 Configuration | 12 |
| | | 7.2.4 Preamble (setup state) | 12 |

ISO 13185-4:2020(E)

| | | 7.2.5 Test execution | 12 |
|-----------|---------|---|----------------------------------|
| | | 7.2.6 Postamble (setup state) | |
| | 7.3 | CTC_UC 2.3 – Requesting data ID text and data type information | 13 |
| | | 7.3.1 Overview | 13 |
| | 7.4 | CTC_UC 2.4 – Requesting data type definitions | 13 |
| | | 7.4.1 Overview | 13 |
| | 7.5 | CTC_UC 2.5 - Requesting all available text and data type information | |
| | | 7.5.1 Overview | |
| 0 | CT -I | | |
| 8 | | luster 3 - Requesting and clearing DTCs and related data | |
| | 8.1 | CTC_UC 3.1 – Requesting DTCs | |
| | | 8.1.1 Overview | |
| | | 8.1.2 Test purpose | |
| | | 8.1.3 Configuration | |
| | | 8.1.4 Preamble (setup state) | |
| | | 8.1.5 Test execution | |
| | 0.0 | 8.1.6 Postamble (setup state) | |
| | 8.2 | CTC_UC 3.2 – Requesting additional DTC data | |
| | | 8.2.1 Overview | |
| | | 8.2.2 Test purpose | |
| | | 8.2.3 Configuration | |
| | | 8.2.4 Preamble (setup state) | |
| | | 8.2.5 Test execution | |
| | | 8.2.6 Postamble (setup state) | |
| | 8.3 | CTC_UC 3.3 - Clearing DTCs | |
| | | 8.3.1 Overview A.A.C.M. Statut al. U.S. | |
| | | 8.3.2 Test purpose | |
| | | 8.3.3 Configuration | |
| | | 8.3.4 Preamble (setup state) | |
| | | 8.3.5 Test execution | |
| | | 8.3.6 Postamble (setup state) | |
| | 8.4 | CTC_UC 3.4 – SendOnChange – Provide DTC and status | |
| | | 8.4.1 Overview <u>ISO 13185-4-2020</u> | |
| 9 http | S CT cl | luster 4 – Unsolicited V-ITS-SG messages 2 - 23cc 426b - 8bf9 - 1805 79cf59f4/iso | -13185 ₁ 7 202 |
| | 9.1 | CTC_UC 4.1 - SendOnEvent — Emergency situation | 17 |
| | 7.1 | 9.1.1 Overview | |
| | 9.2 | CTC_UC 4.2 - SendOnEvent — Critical driving situation | |
| | 7.2 | 9.2.1 Overview | |
| | 9.3 | CTC_UC 4.3 - SendOnEvent — Safety situation | 17 |
| | 7.5 | 9.3.1 Overview | |
| | 9.4 | CTC_UC 4.4 – SendOnEvent — Warning situation | |
| | у.т | 9.4.1 Overview | |
| | 9.5 | CTC_UC 4.5 - SendOnEvent — Data ID value matches threshold | 18 |
| | 9.5 | 9.5.1 Overview | |
| | | | |
| 10 | CT cl | luster 5 - Real-time data transmission | |
| | 10.1 | CTC_UC 5.1 – Real-time data ID value measurement | |
| | | 10.1.1 Overview | |
| | 10.2 | CTC_UC 5.2 - Real-time DTC reporting | |
| | | 10.2.1 Overview | 18 |
| 11 | ርፐ ብ | luster 6 - Controlling /adjusting various equipment of the vehicle | 1Ω |
| | 11.1 | | |
| | 11.1 | 11.1.1 Overview | |
| | | 11.1.2 Test purpose | |
| | | 11.1.2 Test purpose 11.1.1.3 Configuration | |
| | | 11.1.4 Preamble (setup state) | |
| | | 11.1.5 Test execution | |
| | | 11.1.6 Postamble (setup state) | |
| | | 11.1.U I USLAIIIUIE ISELUD SLAIE I | |

| 11.2.1 Overview 11.2.2 Test purpose 11.2.3 Configuration 11.2.4 Preamble (setup state) 11.2.5 Test execution 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 - Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution 11.3.6 Postamble (setup state) | 20 20 20 20 21 21 21 21 21 21 21 22 22 |
|---|---|
| 11.2.3 Configuration 11.2.4 Preamble (setup state) 11.2.5 Test execution 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 - Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 20 20 20 21 21 21 21 21 21 21 22 22 |
| 11.2.3 Configuration 11.2.4 Preamble (setup state) 11.2.5 Test execution 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 - Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 20 20 20 21 21 21 21 21 21 21 22 22 |
| 11.2.4 Preamble (setup state) 11.2.5 Test execution 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 - Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 20 20 21 21 21 21 21 21 21 22 22 |
| 11.2.5 Test execution 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 – Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 20 21 21 21 21 21 21 21 22 22 |
| 11.2.6 Postamble (setup state) 11.3 CTC_UC 6.3 - Control charging for EV | 21 21 21 21 21 21 21 22 22 |
| 11.3 CTC_UC 6.3 - Control charging for EV 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 21 21 21 21 21 21 22 22 |
| 11.3.1 Overview 11.3.2 Test purpose 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | 21 21 21 21 22 22 22 |
| 11.3.2 Test purpose | 21 21 21 22 22 22 |
| 11.3.3 Configuration 11.3.4 Preamble (setup state) 11.3.5 Test execution | |
| 11.3.4 Preamble (setup state) | 21 22 22 |
| 11.3.4 Preamble (setup state) | 21 22 22 |
| 11.3.5 Test execution | 22 22 |
| | 22 |
| 11.5.0 Fostamble (setup state) | |
| | |
| 12 CT cluster 7 - Writing short- and long-term data to V-ITS-SG | 22 |
| 12.1 CTC_UC 7.1 – Write data to V-ITS-SG's memory | 22 |
| 12.1.1 Overview | |
| 12.1.2 Test purpose | |
| | |
| 12.1.3 Configuration | |
| 12.1.4 Preamble (setup state) | 23 |
| 12.1.5 Test execution | 23 |
| 12.1.6 Postamble (setup state) | 23 23 |
| 12.2 CTC_UC 7.2 – Write vehicle profile to V-ITS-SG's memory | 23 23 |
| 12.2.1 Overview | 23 23 23 |
| 12.3 CTC_UC 7.3 - Enable/disable functional system related data IDs | 23 23 23 |
| 12.3.1 Overview | 23 23 23 23 23 23 |
| 12.3.1 / UVCI VICW | 232323232324 |
| 12.4 CTC UC 7.4 Write data ID thresholds to V ITC CC's mamoury | 23 23 23 23 23 23 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 – Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 24 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 24 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 24 24 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview. 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 24 25 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 |
| 13.1 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration SOV SOV SCI-COCC-4200-8019-1803 /9CISV14/180-13180-4-202 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) 14 CT cluster 9 - V-ITS-SG special features 14.1 CTC_UC 9.1 - General data exchange | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) 14 CT cluster 9 - V-ITS-SG special features 14.1 CTC_UC 9.1 - General data exchange | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) 13.3.7 Fest execution 13.3.8 Preamble (setup state) 13.3.9 Preamble (setup state) 13.3.1 Overview 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) 13.3.7 Test execution 13.3.8 Postamble (setup state) 13.3.9 Fest execution 13.3.1 Overview 13.3.1 Overview 13.3.1 Overview 14.1 CTC_UC 9.1 - General data exchange 14.1 Overview 14.2 CTC_UC 9.2 - V-ITS-SG activation mode | 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 26 26 26 26 26 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview. 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG. 13.1.1 Overview. 13.1.2 Test purpose. 13.1.3 Configuration SG 393361-C3CC-4208-8019-1803/9C19/1803-1803-4200 13.1.4 Preamble (setup state). 13.1.5 Test execution. 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall. 13.3.1 Overview. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 13.3.7 Test execution. 13.3.8 Postamble (setup state). 13.9 Postamble (setup state). 14.1 CTC_UC 9.1 - General data exchange. 14.1 CTC_UC 9.2 - V-ITS-SG activation mode. 14.2.1 Overview. | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 25 26 26 26 26 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG. 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution 13.1.6 Postamble (setup state) 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status 13.2.1 Overview 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state) 13.3.5 Test execution 13.3.6 Postamble (setup state) 13.3.7 Test execution 13.3.8 Preamble (setup state) 13.9 CTC cluster 9 - V-ITS-SG special features 14.1 CTC_UC 9.1 - General data exchange 14.1.1 Overview 14.2 CTC_UC 9.2 - V-ITS-SG activation mode 14.2.1 Overview 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG | 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 26 26 26 26 26 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview. 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview. 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state). 13.1.5 Test execution 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall. 13.3.1 Overview. 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 13.3.7 Test execution. 13.3.8 Preamble (setup state). 13.3.9 Preamble (setup state). 13.10 Ureview. 13.11 CTC_UC 9.1 - General data exchange. 14.11 CTC_UC 9.2 - V-ITS-SG activation mode. 14.21 Overview. 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 25 27 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory 12.4.1 Overview. 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG 13.1.1 Overview. 13.1.2 Test purpose 13.1.3 Configuration 13.1.4 Preamble (setup state) 13.1.5 Test execution. 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall 13.3.1 Overview. 13.3.2 Test purpose 13.3.3 Configuration 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 13.3.7 Preamble (setup state). 13.3.8 Preamble (setup state). 13.3.9 Preamble (setup state). 13.3.1 Overview. 13.3.1 Overview. 13.3.2 Test execution. 13.3.3 Preamble (setup state). 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 14.1 CTC_UC 9.1 - General data exchange. 14.1.1 Overview. 14.2 CTC_UC 9.2 - V-ITS-SG activation mode. 14.2.1 Overview. 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. 14.3.2 Test purpose. | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 26 26 26 26 27 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1.1 Overview 13.1.2 Test purpose. 13.1.3 Configuration. 13.1.4 Preamble (setup state). 13.1.5 Test execution. 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 13.3.7 Test execution. 13.3.8 Preamble (setup state). 13.3.9 Test purpose. 13.3.1 Overview. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 14.1 CTC_UC 9.1 - General data exchange. 14.1.1 Overview. 14.2 CTC_UC 9.2 - V-ITS-SG sectivation mode. 14.2.1 Overview. 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. 14.3.2 Test purpose. 14.3.3 Configuration. | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 26 26 26 26 27 27 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview 13 CTC cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1 CTC_UC 8.1 - Secure access to V-ITS-SG. 13.1.1 Overview 13.1.2 Test purpose 13.1.3 Configuration. 13.1.4 Preamble (setup state). 13.1.5 Test execution. 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall. 13.3.1 Overview. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 14.1 CTC_UC 9.1 - General data exchange. 14.1.1 Overview. 14.2 CTC_UC 9.2 - V-ITS-SG activation mode. 14.2.1 Overview. 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. 14.3.2 Test purpose. 14.3.3 Configuration. 14.3.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. 14.3.2 Test purpose. 14.3.3 Configuration. 14.3.3 Preamble (setup state). | 23 23 23 23 23 24 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 27 27 27 27 27 |
| 12.4 CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory. 12.4.1 Overview 13 CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster. 13.1.1 Overview 13.1.2 Test purpose. 13.1.3 Configuration. 13.1.4 Preamble (setup state). 13.1.5 Test execution. 13.1.6 Postamble (setup state). 13.2 CTC_UC 8.2 - Request V-ITS-SG firewall status. 13.2.1 Overview. 13.3 CTC_UC 8.3 - Configuration of V-ITS-SG firewall. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 13.3.7 Test execution. 13.3.8 Preamble (setup state). 13.3.9 Test purpose. 13.3.1 Overview. 13.3.2 Test purpose. 13.3.3 Configuration. 13.3.4 Preamble (setup state). 13.3.5 Test execution. 13.3.6 Postamble (setup state). 14.1 CTC_UC 9.1 - General data exchange. 14.1.1 Overview. 14.2 CTC_UC 9.2 - V-ITS-SG sectivation mode. 14.2.1 Overview. 14.3 CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG. 14.3.1 Overview. 14.3.2 Test purpose. 14.3.3 Configuration. | 23 23 23 23 23 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 25 27 27 27 27 27 |

ISO 13185-4:2020(E)

| 15 | CT cl | uster 10 - | - Vehicle diagnostics | 28 |
|-----------|--------|------------|---|--------------------------|
| | 15.1 | CTC_UC | 10.1 – Perform functional group OBD | 28 |
| | | 15.1.1 | Overview | 28 |
| | | 15.1.2 | Test purpose | 28 |
| | | 15.1.3 | Configuration | 28 |
| | | 15.1.4 | Preamble (setup state) | 28 |
| | | 15.1.5 | Test execution | 28 |
| | | 15.1.6 | Postamble (setup state) | 29 |
| | 15.2 | CTC_UC | 10.2 - Perform enhanced OBD | 29 |
| | | 15.2.1 | Overview | 29 |
| | | 15.2.2 | Test purpose | 29 |
| | | 15.2.3 | Configuration | |
| | | 15.2.4 | Preamble (setup state) | |
| | | 15.2.5 | Test execution | |
| | | 15.2.6 | Postamble (setup state) | |
| | 15.3 | | 10.3 – Upload VSOCLogFile from V-ITS-SG | |
| | | 15.3.1 | Overview | |
| | | 15.3.2 | Test purpose | |
| | | 15.3.3 | Configuration | |
| | | 15.3.4 | Preamble (setup state) | |
| | | 15.3.5 | Test execution | |
| | | 15.3.6 | Postamble (setup state) | |
| 4.0 | om 1 | | | |
| 16 | | uster 11 · | - Electric vehicle system status | 31 |
| | 16.1 | | 11.1 – Monitor battery charge status | |
| | | 16.1.1 | Overview | |
| | | 16.1.2 | Test purpose Configuration | 31 |
| | | 16.1.3 | Configuration | 31 |
| | | 16.1.4 | Preamble (setup state) | 31 |
| | | 16.1.5 | Preamble (setup state) Test execution | 31 |
| | | 16.1.6 | Postamble (setup state) | 32 |
| | 16.2 | | 11.2 – Monitor connection between charging station and EV | |
| | | 16.2.1 | Overview <u>ISO 13185-4:2020</u> | 32 |
| | | | Test purposedd./72.003.a.d | iso131.85 32 2020 |
| | | 16.2.3 | Configuration | |
| | | 16.2.4 | Preamble (setup state) | |
| | | 16.2.5 | Test execution | |
| | | 16.2.6 | Postamble (setup state) | |
| | 16.3 | | 11.3 – Battery charge start/stop notification | |
| | | 16.3.1 | Overview | 33 |
| 17 | CT cli | uster 12 - | - V-ITS-SG maintenance | 33 |
| | 17.1 | CTC UC | 12.1 – Update core software of V-ITS-SG | 33 |
| | | 17.1.1 | | |
| | | 17.1.2 | Test purpose | |
| | | 17.1.3 | Configuration | |
| | | 17.1.4 | Preamble (setup state) | |
| | | 17.1.5 | Test execution | |
| | | 17.1.6 | Postamble (setup state) | |
| | 17.2 | | 12.2 – Perform a Reset in V-ITS-SG | |
| | 17.12 | 17.2.1 | Overview | |
| | | 17.2.2 | Test purpose | |
| | | 17.2.3 | Configuration | |
| | | 17.2.3 | Preamble (setup state) | |
| | | 17.2.4 | Test execution | |
| | | 17.2.5 | Postamble (setup state) | |
| | 17.3 | | 12.3 – Perform a reset in V-ITS-SG | |
| | 17.0 | 17.3.1 | | |
| | | | Test purpose | |
| | | 1/11/4 | 1 CUL DUI DUUC | |

| | 17.3.3 | Configuration | 35 |
|-------------|------------|--|----|
| | 17.3.4 | Configuration Preamble (setup state) | 35 |
| | 17.3.5 | Test execution | 36 |
| | 17.3.6 | Postamble (setup state) | 36 |
| 17.4 | CTC_UC | C 12.4 – Upload V-ITS-SG configuration file | 36 |
| | 1/41 | ()VATVIAW | 36 |
| | 17.4.2 | Test purpose Configuration Preamble (setup state) Test execution | 36 |
| | 17.4.3 | Configuration | 36 |
| | 17.4.4 | Preamble (setup state) | 36 |
| | 17.4.5 | Test execution | 36 |
| | 17.4.6 | Postamble (setup state) | 37 |
| 17.5 | CTC_UC | Postamble (setup state) | 37 |
| | 1751 | Overview | 37 |
| | 17.5.2 | Test purpose Configuration Preamble (setup state) Test execution | 37 |
| | 17.5.3 | Configuration | 37 |
| | 17.5.4 | Preamble (setup state) | 37 |
| | 17.5.5 | Test execution | 37 |
| | 17.5.6 | Postamble (setup state) | 38 |
| Rihliograph | 1 7 | | 30 |

iTeh Standards (https://standards.iteh.ai) Document Preview

ISO 13185-4:2020

https://standards.iteh.ai/catalog/standards/iso/73993ae1-c3cc-426b-8bf9-180579cf59f4/iso-13185-4-2020

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 204, *Intelligent transport systems*.

A list of all parts in the ISO 13185 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

Introduction

This document has been established to define the UVIP client and server conformance tests of a common protocol interface to a vehicle UVIP server to easily exchange vehicle information data amongst nomadic and/or mobile devices, cloud servers, vehicle servers and the vehicle's Electronic Control Units (ECUs).

NOTE The abbreviation "UVIP" (Unified Vehicle Interface Protocol) derives from the original abbreviation "UGP" (Unified Gateway Protocol) see ISO 13185-2. The name was changed to avoid confusion in regard to the need of a Gateway implementation in the vehicle.

To achieve this, it is based on the Open Systems Interconnection (OSI) Basic Reference Model specified in ISO/IEC 7498-1 and ISO/IEC 10731, which structures communication systems into seven layers.

This document can be used by vehicle manufacturers for future vehicle design to support the design of a UVIP server to interface with NDs.

The ND applications need vehicle information data through an in-vehicle interface access method.

This document supports ITS applications which are based on ND in vehicles to operate on a common software interface to a V-ITS-S to easily exchange vehicle information data among ND, vehicle V-ITS-S and ECUs.

Figure 1 shows an overview of the UVIP Client and Server API. A UVIP Client Application on a P-ITS-S communicates with a UVIP Server Application on a V-ITS-S. The UVIP Client Application implements the UVIP Client API using ISO 13185-2. The UVIP Server Application implements the UVIP Server API using ISO 13185-2.




Figure 1 — UVIP client on clouds and vehicle server

iTeh Standards (https://standards.iteh.ai) Document Preview

ISO 13185-4:2020

https://standards.iteh.ai/catalog/standards/iso/73993ae1-c3cc-426b-8bf9-180579cf59f4/iso-13185-4-2020

Intelligent transport systems — Vehicle interface for provisioning and support of ITS Services —

Part 4:

Unified vehicle interface protocol (UVIP) conformance test specification

1 Scope

This document specifies a conformance test for a UVIP server and client system developer assessment of self-conformance of the supplier's UVIP server and client system. The conformance test cases follow the use cases definition of ISO 13185-1 and the requirements stated in ISO 13185-2 and ISO 13185-3.

The purpose of this document is to provide information to the UVIP server and client system provider to build and test the UVIP server and client system against the conformance test cases.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 13185-1, Intelligent transport systems (ITS) — Vehicle interface for provisioning and support of ITS services — Part 1: General information and use case definition

ISO 13185-2, Intelligent transport systems — Vehicle interface for provisioning and support of ITS services — Part 2: Unified gateway protocol (UGP) requirements and specification for vehicle ITS station gateway (V-ITS-SG) interface

ISO 13185-3, Intelligent transport systems — Vehicle interface for provisioning and support of ITS Services — Part 3: Unified vehicle interface protocol (UVIP) server and client API specification

ISO 21217, Intelligent transport systems — Communications access for land mobiles (CALM) — Architecture

3 Terms, definitions and abbreviated terms

3.1 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 13185-1, ISO 13185-2, ISO 13185-3, and ISO 21217 apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at https://www.iso.org/obp
- IEC Electropedia: available at http://www.electropedia.org/

3.2 Abbreviated terms

For the purposes of this document, the abbreviations given in ISO 13185-1 and the following apply.

ISO 13185-4:2020(E)

CTC conformance test case

CTP conformance test plan

HVAC heating, ventilation and air conditioning

ND nomadic device

OBD on-board diagnostics

UC use case

4 Conventions

This document is based on the conventions discussed in the OSI Service Conventions in ISO/IEC $10731:1994^{[2]}$ as they apply for communication services. The vehicle data transfer protocol is applicable to OSI layers 5, 6 and 7.

5 Conformance test plan (CTP) basic principles and clustering

5.1 Basic principles for CTC definition

Basic principles have been established as a guideline to define the UVIP implementation conformance test cases:

- BP1: The primary objective of the CTC is to support a company which has developed UVIP server and client systems in the assessment of self-conformance of the UVIP server and client system.
- BP2: The CTC addresses the UVIP implementation.
- BP3: The CTC is a positive test in order to test the proper functioning of the UVIP implementation i.e., correct input data provides correct output data. 4:2020
- BP4: The person performing the CTC shall verify that the purpose of the use case is achieved following the descriptions of the UVIP regarding the implementation of the use case and the steps to enter the input and to obtain the output according to ISO 13185-1.
- BP5: The name of the CTC should be the same as the name of the use case (see ISO 13185-1) or requirement (see ISO 13185-2).
- BP6: Each CTC should have a preamble (setup state).
- BP7: Classification for each CTC is included in order to support the classification criteria specified for use cases and requirements.
- BP8: A CTC is only applicable if the use case or requirement is supported by the UVIP client.
- BP9: Some CTCs may require payment or a valid subscription before processing the next step.

CAUTION — The person performing the conformance test is responsible for entering valid data and correctly executing necessary actions in order to maintain the integrity of the implementation of the UVIP implementation between the UVIP client and the UVIP server (V-ITS-SG).

5.2 CTC structure

5.2.1 CTC - General structure

5.2.1.1 CTC reference number and title [CTC_...] [title]

Each CTC is structured by six (6) subclauses:

- Overview,
- Test purpose,
- Configuration,
- Preamble (setup state),
- Test execution.
- Postamble.

In the following, details and examples for each of these titles (ordered list) are given.

A reference to the corresponding CTC requirement is specified via a unique abbreviation, number and title as follows:

— [CTC_UC x.y] of ISO 13185-1; Teh Standards

where:

'x', 'y' are numeric numbers as assigned in ISO 13185-1.

5.2.1.2 Overview

This is a conformance test for checking the UC x.y followed by the subject description as specified in ISO 13185-2.

5.2.1.3 Test purpose

The test purpose gives a short description of the relevant CTCs and a reference to the corresponding requirement specified in ISO 13185-1 and ISO 13185-2.

NOTE The CTC approach depends on the definition of the referenced requirement in ISO 13185-1 and ISO 13185-2.

5.2.1.4 Configuration

The configuration describes the CTC scenario pre-requisites.

5.2.1.5 Preamble (setup state)

The "Preamble" defines preconditions which are used for preparation and initialisation of the UVIP with a view to performing the specific conformance test. For example, a precondition could be the successful establishment of a connection between the UVIP client and the UVIP server (V-ITS-SG).

5.2.1.6 Test execution

Test execution of a single CTC is organized in steps. These steps are described in the example in Table 1.

Table 1 — CTC execution example

| Step # | Description | | |
|--------|---|--|--|
| 1 | Description of 1st test step. | | |
| 2 | Description of 2 nd test step. | | |
| N | Description of N th test step. | | |

5.2.1.7 Postamble

The "Postamble" defines post conditions which are used to return the UVIP protocol implementation back to a definite state.

5.2.2 Result criteria

The CTC result criteria are composed of three different results as listed in Table 2.

Table 2 — CTC result criteria

| Result | Definition |
|------------|--|
| Pass | The CTC purpose was achieved as expected. |
| Deficiency | The CTC purpose was achieved with opportunities for improvement identified and documented in detail. |
| Fail | The CTC purpose was not achieved. Reason(s) shall be documented in detail. |

5.3 CTC system setup

Figure 2 shows the conformance test system setup.




Figure 2 — Conformance test system setup