

ü]fc_cdUgcj bc`X][]HJbc`ca fYÿ`Y`n`]bhY[f]fUb]a]`g]cf]hj Ua]`f6 !=G8 BŁĚ`Dfclc_c`
X][]HJbY`bUfc b]ý_Y`g][bU]nUW`Y`ýH`&fB GG&ŁĚ`GdYWZ]_UW`U`fYrY`d`Ugh]`j a Ygb]_U
i dcfUVb]_!ca fYÿ`Y`6 !=G8 B`nU`_fa]`Yb`Y`cgbcj bY[U`_]WU#bcg]`WUĚ`) "XY`. N[fUXVU
dfYg_i ýU`bY[U`b]nU]b`bUa Yb]`dfYg_i ýUb`U`fHGG/ HDŁĚ`GdYWZ]_UW`U`nUca fYÿ`Y`

Broadband Integrated Services Digital Network (B-ISDN); Digital Subscriber Signalling System No. two (DSS2) protocol; B-ISDN user-network interface layer 3 specification for basic call/bearer control; Part 5: Test Suite Structure and Test Purposes (TSS&TP) specification for the network

(standards.iteh.ai)

[SIST EN 300 443-5 V1.2.1:2003](https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003)

<https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>

Ta slovenski standard je istoveten z: EN 300 443-5 Version 1.2.1

ICS:

33.080	Digitalno omrežje z integriranimi storitvami (ISDN)	Integrated Services Digital Network (ISDN)
--------	---	--

SIST EN 300 443-5 V1.2.1:2003 en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST EN 300 443-5 V1.2.1:2003

<https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>

ETSI EN 300 443-5 V1.2.1 (2000-10)

European Standard (Telecommunications series)

**Broadband Integrated Services Digital Network (B-ISDN);
Digital Subscriber Signalling System No. two (DSS2) protocol;
B-ISDN user-network interface layer 3 specification
for basic call/bearer control;
Part 5: Test Suite Structure and Test Purposes (TSS&TP)
specification for the network**

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST EN 300 443-5 V1.2.1:2003](https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003)

<https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>



Reference

REN/SPAN-05143-5

KeywordsBC, B-ISDN, broadband, DSS2, ISDN, layer 3,
network, TSS&TP, UNI**ETSI**650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

iTeh **STANDARD PREVIEW**
(standards.iteh.ai)

SIST EN 300 443-5 V1.2.1:2003<https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>

Important notice

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <http://www.etsi.org/tb/status/>

If you find errors in the present document, send your comment to:
editor@etsi.fr

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2000.
All rights reserved.

Contents

Intellectual Property Rights	5
Foreword.....	5
1 Scope	6
2 References	6
3 Definitions and abbreviations.....	6
3.1 Definitions	6
3.1.1 Definitions related to conformance testing	6
3.1.2 Definitions related to EN 300 443-1	7
3.2 Abbreviations	7
4 Test Suite Structure (TSS).....	8
5 Test Purposes (TP)	9
5.1 Introduction	9
5.1.1 TP naming convention	9
5.1.2 Source of TP definition.....	9
5.1.3 Test strategy.....	9
5.1.4 Test of call states	9
5.2 TPs for the basic call/bearer control, layer 3, network.....	10
5.2.1 Signalling procedures at the coincident S _B /T _B and at the T _B reference points.....	10
5.2.1.1 Call/connection establishment at the originating interface.....	10
5.2.1.1.1 Connection identifier (VPCI/VCI) allocation/selection (01).....	10
5.2.1.1.1.1 Associated signalling (02).....	10
5.2.1.1.1.2 Non-associated signalling (03).....	11
5.2.1.1.2 QOS and traffic parameter selection procedures (04).....	12
5.2.1.1.3 Invalid call/connection control information (05).....	12
5.2.1.1.4 Call/connection proceeding (06).....	12
5.2.1.1.5 Call/connection confirmation indication (07).....	13
5.2.1.1.6 Call/connection acceptance (08).....	13
5.2.1.1.7 Call/connection rejection (09)	13
5.2.1.1.8 Transit network selection (10).....	14
5.2.1.2 Call/connection establishment at the destination interface.....	14
5.2.1.2.1 Incoming call/connection request (11)	14
5.2.1.2.2 Connection identifier (VPCI/VCI) allocation/selection (12).....	15
5.2.1.2.2.1 Associated signalling (13).....	15
5.2.1.2.2.2 Non-associated signalling (14).....	15
5.2.1.2.3 Call/connection confirmation (15).....	16
5.2.1.2.4 Call/connection acceptance (16).....	17
5.2.1.3 Call/connection clearing.....	17
5.2.1.3.1 Exception conditions (17).....	17
5.2.1.3.2 Clearing initiated by the user (18)	17
5.2.1.3.3 Clearing initiated by the network (19).....	18
5.2.1.3.4 Clear collision (20).....	18
5.2.1.4 Restart procedure	19
5.2.1.4.1 Sending RESTART (21).....	19
5.2.1.4.2 Receipt of RESTART (22)	19
5.2.1.4.3 Remote interface (23).....	22
5.2.1.5 Handling of error conditions	22
5.2.1.5.1 Error handling in N0 (24)	22
5.2.1.5.2 Error handling in N3 (25)	26
5.2.1.5.3 Error handling in N4 (26)	27
5.2.1.5.4 Error handling in N6 (27)	29
5.2.1.5.5 Error handling in N7 (28)	32
5.2.1.5.6 Error handling in N9 (29)	34
5.2.1.5.7 Error handling in N10 - incoming call (30).....	37

5.2.1.5.8	Error handling in N10 - outgoing call (31)	40
5.2.1.5.9	Error handling in N12 - incoming call (32)	44
5.2.1.5.10	Error handling in N12 - outgoing call (33)	46
5.2.1.5.11	Error handling in R0 (34)	48
5.2.1.5.12	Error handling in R1 (35)	51
5.2.1.6	Notification procedures (36)	53
5.2.2	Signalling procedures for interworking between N-ISDN and B-ISDN	54
5.2.2.1	Interworking N-ISDN -> B-ISDN (37)	54
5.2.2.2	Interworking B-ISDN -> N-ISDN (38)	54
6	Compliance	55
7	Requirements for a comprehensive testing service	55
	Bibliography	56
	History	57

iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST EN 300 443-5 V1.2.1:2003

<https://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://www.etsi.org/ipr>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This European Standard (Telecommunications series) has been produced by ETSI Technical Committee Services and Protocols for Advanced Networks (SPAN).

The present document is part 5 of a multi-part standard covering the Digital Subscriber Signalling System No. 2 (DSS2) protocol specification for the B-ISDN user-network interface layer 3 specification for basic call/bearer control, as described below:

- Part 1: "Protocol specification";
- Part 2: "Protocol Implementation Conformance Statement (PICS) proforma specification";
- Part 3: "Test Suite Structure and Test Purposes (TSS&TP) specification for the user";
- Part 4: "Abstract Test Suite (ATS) and partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma specification for the user";
- Part 5: "Test Suite Structure and Test Purposes (TSS&TP) specification for the network";**
- Part 6: "Abstract Test Suite (ATS) and partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma specification for the network".

National transposition dates

Date of adoption of this EN:	6 October 2000
Date of latest announcement of this EN (doa):	31 January 2001
Date of latest publication of new National Standard or endorsement of this EN (dop/e):	31 July 2001
Date of withdrawal of any conflicting National Standard (dow):	31 July 2001

1 Scope

The present document specifies the network Test Suite Structure and Test Purposes (TSS&TP) for the T_B reference point or coincident S_B and T_B reference point (as defined in ITU-T Recommendation I.413 [5]) of implementations conforming to the standards for the signalling user-network layer 3 specification for basic call/bearer control of the Digital Subscriber Signalling System No. two (DSS2) protocol for the pan-European Broadband Integrated Services Digital Network (B-ISDN), EN 300 443-1 [1].

A further part of the present document specifies the Abstract Test Suite (ATS) and partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma based on the present document.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.
- A non-specific reference to an ETS shall also be taken to refer to later versions published as an EN with the same number.

- ITel STANDARD PREVIEW**
(standards.iteh.ai)
- [1] ETSI EN 300 443-1 (V1.3): "Broadband Integrated Services Digital Network (B-ISDN); Digital Subscriber Signalling System No. two (DSS2) protocol; B-ISDN user-network interface layer 3 specification for basic call/bearer control; Part 1: Protocol specification [ITU-T Recommendation Q.2931 (1995), modified]".
<http://standards.iteh.ai/catalog/standards/sist/e0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>
- [2] ETSI EN 300 443-2 (V1.3): "Broadband Integrated Services Digital Network (B-ISDN); Digital Subscriber Signalling System No. two (DSS2) protocol; B-ISDN user-network interface layer 3 specification for basic call/bearer control; Part 2: Protocol Implementation Conformance Statement (PICS) proforma specification".
- [3] ISO/IEC 9646-1: "Information technology - Open Systems Interconnection - Conformance testing methodology and framework - Part 1: General concepts".
- [4] ISO/IEC 9646-2: "Information technology - Open Systems Interconnection - Conformance testing methodology and framework - Part 2: Abstract Test Suite specification".
- [5] ITU-T Recommendation I.413 (1993): "B-ISDN user-network interface".
- [6] ETSI ETS 300 406: "Methods for Testing and Specification (MTS); Protocol and profile conformance testing specifications; Standardization methodology".

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in EN 300 443-1 [1] and the following apply:

3.1.1 Definitions related to conformance testing

abstract test case: refer to ISO/IEC 9646-1 [3]

Abstract Test Method (ATM): refer to ISO/IEC 9646-1 [3]

Abstract Test Suite (ATS): refer to ISO/IEC 9646-1 [3]

Implementation Under Test (IUT): refer to ISO/IEC 9646-1 [3]

lower tester: refer to ISO/IEC 9646-1 [3]

Protocol Implementation Conformance Statement (PICS): refer to ISO/IEC 9646-1 [3]

PICS proforma: refer to ISO/IEC 9646-1 [3]

Protocol Implementation eXtra Information for Testing (PIXIT): refer to ISO/IEC 9646-1 [3]

PIXIT proforma: refer to ISO/IEC 9646-1 [3]

Test Purpose (TP): refer to ISO/IEC 9646-1 [3]

3.1.2 Definitions related to EN 300 443-1

network: DSS2 protocol entity at the Network side of the user-network interface where a T_B reference point or coincident S_B and T_B reference point applies

network (S_B/T_B): DSS2 protocol entity at the Network side of the user-network interface where a coincident S_B and T_B reference point applies

network (T_B): DSS2 protocol entity at the Network side of the user-network interface where a T_B reference point applies (user is the private ISDN)

STANDARD PREVIEW
(standards.iteh.ai)

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

ATM	Abstract Test Method
ATS	Abstract Test Suite
B-ISDN	Broadband Integrated Services Digital Network
DSS2	Digital Subscriber Signalling System No. two
IUT	Implementation Under Test
N0	Null call state
N1	Call Initiated call state
N10	Active call state
N12	Release Indication call state
N2	Overlap Sending call state
N3	Outgoing Call Proceeding call state
N4	Call Delivered call state
N6	Call Present call state
N7	Call Received call state
N9	Incoming Call Proceeding call state
N-ISDN	Narrowband Integrated Services Digital Network
PICS	Protocol Implementation Conformance Statement
PIXIT	Protocol Implementation eXtra Information for Testing
Rest 0	Restart Null state
Rest 1	Restart Request state
Rest 2	Restart state
TP	Test Purpose
TSS	Test Suite Structure
VC	Virtual Channel
VCI	Virtual Channel Identifier
VP	Virtual Path
VPC	Virtual Path Connection
VPCI	Virtual Path Connection Identifier

4 Test Suite Structure (TSS)

Signalling procedures at the coincident S_B/T_B and at the T_B reference points

Call/connection establishment at the originating interface

Connection identifier (VPCI/VCI) allocation/selection	(01)
Associated signalling.....	(02)
Non-associated signalling.....	(03)
QOS and traffic parameters selection procedures	(04)
Invalid call/connection control information	(05)
Call/connection proceeding.....	(06)
Call/connection confirmation indication	(07)
Call/connection acceptance	(08)
Call/connection rejection	(09)
Transit network selection	(10)

Call/connection establishment at the destination interface

Incoming call/connection request.....	(11)
Connection identifier (VPCI/VCI) allocation/selection	(12)
Associated signalling.....	(13)
Non-associated signalling.....	(14)
Call/connection confirmation.....	(15)
Call/connection acceptance.....	(16)

Call/connection clearing

Exception conditions	(17)
Clearing initiated by the user	(18)
Clearing initiated by the network	(19)
Clear collision	(20)

Restart procedure

Sending RESTART	(21)
Receipt of RESTART	(22)
Remote user.....	(23)

Handling of error conditions

Error handling in N0	(24)
Error handling in N3	(25)
Error handling in N4	(26)
Error handling in N6	(27)
Error handling in N7	(28)
Error handling in N9	(29)
Error handling in N10 - incoming call	(30)
Error handling in N10 - outgoing call	(31)
Error handling in N12 - incoming call	(32)
Error handling in N12 - outgoing call	(33)
Error handling in Rest 0	(34)
Error handling in Rest 1	(35)

Notification procedures

.....	(36)
-------	------

Signalling procedures for interworking between N-ISDN and B-ISDN

Interworking N-ISDN -> B-ISDN.....	(37)
Interworking B-ISDN -> N-ISDN.....	(38)

Figure 1: Test suite structure

5 Test Purposes (TP)

5.1 Introduction

For each test requirement a TP is defined.

5.1.1 TP naming convention

TPs are numbered, starting at 01, within each group. Groups are organized according to the TSS. Additional references are added to identify the actual test suite (see table 1).

Table 1: TP identifier naming convention scheme

Identifier:	<suite_id>_<group>_<nnn>		
<suite_id>	=	layer + type of IUT:	"L3BN" for L ayer 3 B asic call/bearer control, IUT = N etwork
<group>	=	group number:	two character field representing the group reference according to TSS
<nn>	=	sequential number:	(01-99)

5.1.2 Source of TP definition

The TPs are based on EN 300 443-1 [1].

5.1.3 Test strategy

As the base standard EN 300 443-1 [1] contains no explicit requirements for testing, the TPs were generated as a result of an analysis of the base standard and the PICS specification EN 300 443-2 [2].

The TPs are only based on conformance requirements related to the externally observable behaviour of the IUT, and are limited to conceivable situations to which a real implementation is likely to be faced (ETS 300 406 [6]).

5.1.4 Test of call states

Many TPs include a reference to the IUT's final call state after the realization of the TP. In these cases the TP includes the requirement to ensure that the IUT has entered this particular final call state. Ensuring that the IUT is in a particular call state shall be realized by following the procedures described in subclause 5.6.11 of EN 300 443-1 [1]. According to these procedures, the IUT on receipt of a STATUS ENQUIRY message, shall respond with a STATUS message indicating, in the fifth octet of the Call state information element, the current call state of the IUT. This exchange of messages is not mentioned explicitly in each TP but is considered to be implicit in the reference to the final call state. This way of phrasing the TPs has been used to avoid over-complicating the text and structure of the TPs and to improve the readability.

5.2 TPs for the basic call/bearer control, layer 3, network

All PICS items referred to in this subclause are as specified in EN 300 443-2 [2] unless indicated otherwise by another numbered reference.

Unless specified:

- the messages indicated are valid and contain at least the mandatory information elements and possibly optional information elements;
- the information elements indicated are valid and contain at least the mandatory parameters and possibly optional parameters.

5.2.1 Signalling procedures at the coincident S_B/T_B and at the T_B reference points

Test purposes for EN 300 443-1 [1] subclause 5.1.

5.2.1.1 Call/connection establishment at the originating interface

Test purposes for EN 300 443-1 [1] subclause 5.1.

5.2.1.1.1 Connection identifier (VPCI/VCI) allocation/selection (01)

Test purposes for EN 300 443-1 [1] subclause 5.1.2.

L3BN_01_01

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = VP associated signalling),

- sends a RELEASE COMPLETE message (Cause value = 36) and remains in N0.

Selection: Associated signalling at the originating side NOT supported. PICS: NOT MCn 1.1.

5.2.1.1.1.1 Associated signalling (02)

Test purposes for EN 300 443-1 [1] subclause 5.1.2.1.

Selection: Associated signalling at the originating side supported. PICS: MCn 1.1.

L3BN_02_01

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; any VCI), when a VCI is available in the VPC carrying the signalling VC,

- sends a CALL PROCEEDING message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; exclusive VCI, virtual channel identifier indicating a specific VCI) and enters N3.

L3BN_02_02

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; exclusive VCI, virtual channel identifier indicating a specific VCI), when the requested VCI is available in the VPC carrying the signalling VC,

- sends a CALL PROCEEDING message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; exclusive VCI, virtual channel identifier indicating the requested VCI) and enters N3.

L3BN_02_03

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; any VCI), when no VCI is available in the VPC carrying the signalling VC,

- sends a RELEASE COMPLETE message (Cause value = 45) and remains in N0.

L3BN_02_04

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = VP associated signalling, preferred exclusive = exclusive VPCI; exclusive VCI, virtual channel identifier indicating a specific VCI), when the requested VCI is not available in the VPC carrying the signalling VC,

- sends a RELEASE COMPLETE message (Cause value = 35) and remains in N0.

5.2.1.1.1.2 Non-associated signalling (03)

Test purposes for EN 300 443-1 [1] subclause 5.1.2.2.

L3BN_03_01

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; any VCI, virtual path connection identifier indicating a specific VPCI), when a VCI is available within the requested VPCI,

- sends a CALL PROCEEDING message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating the requested VPCI, virtual channel identifier indicating a specific VCI) and enters N3.

L3BN_03_02

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating a specific VPCI, virtual channel identifier indicating a specific VCI), when the requested VCI is available within the requested VPCI,

- sends a CALL PROCEEDING message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating the requested VPCI, virtual channel identifier indicating the requested VCI) and enters N3.

L3BN_03_03

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier absent), when a VCI is available within any VPCI,

- sends a CALL PROCEEDING message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating a specific VPCI, virtual channel identifier indicating a specific VCI) and enters N3.

iTeh STANDARD PREVIEW
(standards.iteh.ai)
SIST EN 300 443-5 V1.2.1:2003
<https://standards.iteh.ai/catalog/standards/sist/c0d95dd2-52bb-4455-927a-c98aca5aab81/sist-en-300-443-5-v1-2-1-2003>

L3BN_03_04

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; any VCI, virtual path connection identifier indicating a specific VPCI), when the requested VPCI is not available,

- sends a RELEASE COMPLETE message (Cause value = 35) and remains in N0.

L3BN_03_05

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating a specific VPCI, virtual channel identifier indicating a specific VCI), when the requested VPCI is not available,

- sends a RELEASE COMPLETE message (Cause value = 35) and remains in N0.

L3BN_03_06

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; any VCI, virtual path connection identifier indicating a specific VPCI, virtual channel identifier indicating a specific VCI), when no VCI is available within the requested VPCI,

- sends a RELEASE COMPLETE message (Cause value = 45) and remains in N0.

L3BN_03_07

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier present, VP associated signalling = explicit indication of VPCI, preferred exclusive = exclusive VPCI; exclusive VCI, virtual path connection identifier indicating a specific VPCI, virtual channel identifier indicating a specific VCI), when the requested VCI is not available within the requested VPCI,

- sends a RELEASE COMPLETE message (Cause value = 35) and remains in N0.

L3BN_03_08

Ensure that the IUT in N0, on receipt of a SETUP message (Connection identifier absent), when no VCI is available within any VPCI,

- sends a RELEASE COMPLETE message (Cause value = 45) and remains in N0.

5.2.1.1.2 QOS and traffic parameter selection procedures (04)

Test purposes for EN 300 443-1 [1] subclause 5.1.3.

L3BN_04_01

Ensure that the IUT in N0, on receipt of a SETUP message (Quality of service parameter present, requesting a QOS class that can not be provided),

- sends a RELEASE COMPLETE message (Cause value = 49) and remains in N0.

NOTE: There is only one non-reserved value for the QOS class defined in EN 300 443-1 [1].

L3BN_04_02

Ensure that the IUT in N0, on receipt of a SETUP message (ATM traffic descriptor present, requesting a peak cell rate that can not be provided),

- sends a RELEASE COMPLETE message (Cause value = 37) and remains in N0.

5.2.1.1.3 Invalid call/connection control information (05)

Test purposes for EN 300 443-1 [1] subclause 5.1.4.

L3BN_05_01

Ensure that the IUT in N0, on receipt of a SETUP message (Called party number present, indicating invalid call information, i.e. unassigned called party number),

- sends a RELEASE message (Cause value = 1) possibly preceded by a CALL PROCEEDING message and enters N12 or sends a RELEASE COMPLETE message (Cause value = 1) and remains in N0.

L3BN_05_02

Ensure that the IUT in N0, on receipt of a SETUP message (Called party number present, indicating invalid call information, i.e. no outgoing trunk direction exists for the called party number),

- sends a RELEASE message (Cause value = 3) possibly preceded by a CALL PROCEEDING message and enters N12 or sends a RELEASE COMPLETE message (Cause value = 3) and remains in N0.

L3BN_05_03

Ensure that the IUT in N0, on receipt of a SETUP message (Called party number present, indicating invalid call information, i.e. a called party number that has been changed),

- sends a RELEASE message (Cause value = 22) possibly preceded by a CALL PROCEEDING message and enters N12 or sends a RELEASE COMPLETE message (Cause value = 22) and remains in N0.

L3BN_05_04

Ensure that the IUT in N0, on receipt of a SETUP message (Called party number present, indicating invalid call information, i.e. an incomplete called party number),

- sends a RELEASE message (Cause value = 28) possibly preceded by a CALL PROCEEDING message and enters N12 or sends a RELEASE COMPLETE message (Cause value = 28) and remains in N0.

5.2.1.1.4 Call/connection proceeding (06)

Test purposes for EN 300 443-1 [1] subclause 5.1.5.

L3BN_06_01

Ensure that the IUT in N0, on receipt of a SETUP message (Broadband bearer capability requesting a service that is authorized and available),

- sends a CALL PROCEEDING message and enters N3.

L3BN_06_02

Ensure that the IUT in N0, on receipt of a SETUP message (Broadband bearer capability requesting a service that is not authorized),

- sends a RELEASE COMPLETE message (Cause value = 57) and remains in N0.

L3BN_06_03

Ensure that the IUT in N0, on receipt of a SETUP message (Broadband bearer capability requesting a service that is not available),

- sends a RELEASE COMPLETE message (Cause value = 58, 63 or 65) and remains in N0.

5.2.1.1.5 Call/connection confirmation indication (07)

Test purposes for EN 300 443-1 [1] subclause 5.1.6.

L3BN_07_01

Ensure that the IUT in N3, to indicate that user alerting has been initiated at the called user's side,

- sends an ALERTING message and enters N4.

5.2.1.1.6 Call/connection acceptance (08)

Test purposes for EN 300 443-1 [1] subclause 5.1.7.

L3BN_08_01

Ensure that the IUT in N3, to indicate that the call has been accepted at the called user's side,

- sends a CONNECT message and enters N10.

L3BN_08_02

Ensure that the IUT in N4, to indicate that the call has been accepted at the called user's side,

- sends a CONNECT message and enters N10.

L3BN_08_03

Ensure that the IUT in N10, on receipt of a CONNECT ACKNOWLEDGE message,

- sends no message and remains in N10.

5.2.1.1.7 Call/connection rejection (09)

Test purposes for EN 300 443-1 [1] subclauses 5.1.8, 5.2.5, 5.4 and annex B.

L3BN_09_01

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (Broadband bearer capability not supported),

- sends a RELEASE message (Cause value = 88) and enters N12.

L3BN_09_02

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (QOS class can not be provided),

- sends a RELEASE message (Cause value = 49) and enters N12.

L3BN_09_03

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (peak cell rate can not be provided),

- sends a RELEASE message (Cause value = 47) and enters N12.

L3BN_09_04

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (call rejected),

- sends a RELEASE message (Cause value = 21) and enters N12.

L3BN_09_05

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (user busy),

- sends a RELEASE message (Cause value = 17) and enters N12.

L3BN_09_06

Ensure that the IUT in N3, to indicate that the call has not been accepted at the called user's side (second expiry of T303),

- sends a RELEASE message (Cause value = 18) and enters N12.