

Draft **ETSI EN 304 113** V1.0.0 (2025-12)



**Maritime satellite Emergency Position Indicating
Radio Beacons (EPIRBs) for non-SOLAS vessels;
Technical characteristics and methods of measurement**

Document Preview

[ETSI EN 304 113 V1.0.0 \(2025-12\)](https://standards.iteh.ai/catalog/standards/etsi/cd76f955-3190-4dd4-8387-fe16d20301c3/etsi-en-304-113-v1-0-0-2025-12)

<https://standards.iteh.ai/catalog/standards/etsi/cd76f955-3190-4dd4-8387-fe16d20301c3/etsi-en-304-113-v1-0-0-2025-12>

Reference

DEN/ERM-TGMAR-636

Keywords

EPIRB, maritime, radio, SAR, testing

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed,
this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to
the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our
[Coordinated Vulnerability Disclosure \(CVD\)](#) program.

[ETSI EN 304 113 V1.0.0 \(2025-12\)](#)

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2025.
All rights reserved.

Contents

Intellectual Property Rights	8
Foreword.....	8
Modal verbs terminology.....	8
Introduction	9
1 Scope	10
2 References	10
2.1 Normative references	10
2.2 Informative references.....	11
3 Definition of terms, symbols and abbreviations.....	11
3.1 Terms.....	11
3.2 Symbols.....	12
3.3 Abbreviations	12
4 General Requirements	13
4.1 Introduction.....	13
4.2 General Construction	13
4.3 Operating Conditions	13
4.3.1 General.....	13
4.3.2 Conditions for activation	14
4.4 COSPAS-SARSAT.....	14
4.5 Lanyard	14
4.6 Controls	14
4.6.1 General.....	14
4.6.2 Operation whilst wearing gloves	15
4.7 Indicators	15
4.7.1 General.....	15
4.7.2 Operational Indicators.....	15
4.7.3 Visible strobe light.....	15
4.7.4 Night vision indicator	15
4.8 Self-test	16
4.8.1 General.....	16
4.8.2 Functional Self-test	16
4.8.3 GNSS Self-test.....	16
4.9 Equipment IDs	16
4.9.1 Hex ID	16
4.9.2 Self ID (AIS).....	16
4.9.3 Own Vessel ID.....	17
4.10 Operating Instructions.....	17
4.11 Battery Requirements	17
4.11.1 Battery life	17
4.11.2 Safety Precautions	17
4.11.2.1 Reverse Polarity	17
4.11.2.2 Carriage Requirements.....	17
4.12 Labelling.....	18
4.12.1 EPIRB labelling	18
4.12.2 Battery Labelling	18
4.13 Equipment manuals	18
5 Technical information	19
5.1 General	19
5.2 COSPAS-SARSAT	20
5.2.1 Beacon Types.....	20
5.2.2 First Generation Beacons (FGBs).....	20
5.2.3 Second Generation Beacons (SGBs).....	20
5.3 AIS position indication.....	21

5.3.1	Overview	21
5.3.2	AIS transmission characteristics	21
5.3.3	AIS messages.....	22
5.3.4	Loss of lock.....	22
5.4	121,5 MHz homing transmitter	22
5.5	Priorities of receive and transmit functions.....	22
5.6	Accessories and additional functionality	22
6	General conditions of measurement	22
6.1	Conformity testing.....	22
6.2	Unique identifiers (Hex ID and self ID).....	22
6.3	Artificial Antenna	23
6.3.1	For EPIRBs with an integral antenna.....	23
6.3.2	For testing the RF transmitter output	23
6.4	AIS TX Test Modulation.....	23
6.4.1	Standard test signal number 1	23
6.4.2	Standard test signal number 2	23
6.4.3	Standard test signal number 3	23
6.4.4	Unmodulated carrier	23
6.4.5	Generation of test signals.....	23
6.5	AIS Reference timing signal	24
6.6	Test conditions power sources and ambient temperatures.....	24
6.6.1	Normal and extreme test conditions.....	24
6.6.2	Test power sources.....	24
6.7	Normal test conditions	24
6.7.1	Normal temperature and humidity	24
6.7.2	Normal test voltage.....	24
6.8	Extreme test conditions	24
6.8.1	Extreme temperatures.....	24
6.8.2	Extreme test voltages.....	24
6.8.2.1	Upper extreme test voltage.....	24
6.8.2.2	Lower extreme test voltage	25
6.9	Reference Bandwidths for emission measurements	25
7	Environmental tests	25
7.1	Introduction	25
7.2	Procedure.....	25
7.3	Performance check	25
7.4	Drop test	25
7.4.1	Definition.....	25
7.4.2	Test conditions.....	25
7.4.3	Method of measurement	26
7.4.4	Required results	26
7.5	Temperature tests	26
7.5.1	Definition.....	26
7.5.2	Dry heat test.....	26
7.5.2.1	Method of measurement.....	26
7.5.2.2	Requirements	26
7.5.3	Damp heat test	27
7.5.3.1	Method of measurement.....	27
7.5.3.2	Required results.....	27
7.5.4	Low temperature test	27
7.5.4.1	Method of measurement.....	27
7.5.4.2	Required results.....	27
7.5.5	Low temperature battery endurance test	27
7.5.5.1	Determining the useful life of the battery	27
7.5.5.2	Method of measurement.....	27
7.5.5.3	Required results.....	28
7.6	Vibration test	28
7.6.1	Definition.....	28
7.6.2	Method of measurement	28
7.6.3	Required results	28

7.7	Saltwater spray test.....	29
7.7.1	Definition.....	29
7.7.2	Method of measurement	29
7.7.2.1	The spraying apparatus	29
7.7.2.2	Preparation of EUT	29
7.7.2.3	Test cycles.....	29
7.7.2.4	Conclusion of testing.....	30
7.7.3	Required results	30
7.8	Thermal shock test.....	30
7.8.1	Definition.....	30
7.8.2	Method of measurement	30
7.8.3	Required results	30
7.9	Bump test.....	30
7.9.1	Definition.....	30
7.9.2	Method of measurement	30
7.9.3	Required results	31
7.10	Compass safe distance test	31
7.10.1	Definition.....	31
7.10.2	Method of measurement	31
7.10.3	Requirements	32
7.11	Solar radiation test.....	32
7.11.0	Applicability	32
7.11.1	Definition.....	32
7.11.2	Method of measurement	32
7.11.3	Requirements	32
7.12	Oil resistance test.....	32
7.12.0	Applicability	32
7.12.1	Definition.....	33
7.12.2	Method of measurement	33
7.12.3	Requirements	33
7.13	Automatic activation and float upright test	33
7.13.1	Definition.....	33
7.13.2	Method of measurement	33
7.13.3	Requirements	33
7.14	Watertightness test	34
7.14.1	Definition.....	34
7.14.2	Method of measurement	34
7.14.3	Required results	34
8	Tests on the 121,5 MHz homing transmitter	34
8.1	Frequency error	34
8.1.1	Definition.....	34
8.1.2	Method of measurement	34
8.1.3	Limit	34
8.2	Audio modulation characteristics	35
8.2.1	Definition.....	35
8.2.2	Method of measurement	36
8.2.3	Limits.....	36
8.3	DST sweep rate and duty cycle	36
8.3.1	Definition.....	36
8.3.2	Method of measurement	37
8.3.3	Limits.....	37
8.4	Spectral carrier power ratio	37
8.4.1	Definition.....	37
8.4.2	Method of measurement	37
8.4.3	Limit	38
8.5	Maximum Effective Isotropic Radiated Peak Envelope Power (EIRPEP).....	38
8.5.1	Definition.....	38
8.5.2	Method of measurement under normal test conditions	38
8.5.3	Limit	39
8.6	Transmitter spectrum mask	39
8.6.1	Definition.....	39

8.6.2	Method of measurement	39
8.6.3	Limit	40
8.7	Radiation produced by operation of the test function.....	40
8.7.1	Definition.....	40
8.7.2	Method of measurement	40
8.7.2.0	General	40
8.7.2.1	Mandatory full-power test transmission.....	41
8.7.2.2	Optional low-power test transmission.....	41
8.7.3	Limits.....	41
9	Tests on the AIS transmitter.....	41
9.1	AIS Frequency error.....	41
9.1.1	Definition.....	41
9.1.2	Method of measurement	41
9.1.3	Limit	41
9.2	AIS Conducted power variation	41
9.2.1	Purpose	41
9.2.2	Definition.....	42
9.2.3	Method of measurement	42
9.2.4	Limit	42
9.3	AIS Transmitter spectrum mask	42
9.3.1	Definition.....	42
9.3.2	Method of measurement	42
9.3.3	Limit	43
9.4	AIS Transmitter transient behaviour (output power).....	43
9.4.1	Definition.....	43
9.4.2	Method of measurement	44
9.4.3	Limit	45
9.5	AIS Transmitter Transient Behaviour (frequency deviation).....	45
9.5.1	Definition.....	45
9.5.2	Method of measurement	45
9.5.3	Limit	46
9.6	AIS Synchronization accuracy	46
9.6.1	Definition.....	46
9.6.2	Method of measurement	46
9.6.3	Limit	47
9.7	AIS Effective Isotropic Radiated Power (EIRP).....	47
9.7.1	Definition	47
9.7.2	Method of measurement	48
9.7.3	Limits.....	48
10	Spurious emissions.....	49
10.1	Definition	49
10.2	Method of measurement.....	49
10.2.1	Modes of operation	49
10.2.2	Test method	49
10.2.3	Exclusion bands	49
10.2.3.1	Active mode	49
10.2.3.2	Standby or off.....	50
10.3	Limit.....	50
10.3.1	Activated mode	50
10.3.2	Standby or off	50
11	AIS VDL Link layer tests.....	50
11.1	Active mode tests	50
11.1.1	Method of measurement	50
11.1.2	Initialization period - Required results.....	50
11.1.3	Message content of Message 1 - Required results	50
11.1.4	Message content of first Message 14 - Required results.....	51
11.1.5	Message content of second Message 14 - Required results	51
11.1.6	Transmission schedule for Message 1 - Required results	51
11.1.7	Communication state of Message 1 - Required results	52
11.1.8	Transmission schedule of Message 14 - Required results.....	52

11.1.9	Transmission with lost GNSS - Required results.....	52
11.2	GNSS self-test	52
11.2.0	General.....	52
11.2.1	Method of measurement	53
11.2.2	Required results	53
11.3	Functional self-test	53
11.3.0	General.....	53
11.3.1	Method of measurement	53
11.3.2	Required results	53
12	GNSS receiver.....	54
12.1	General	54
12.2	Protection from specific interfering signals.....	54
12.3	Protection from internally generated interfering signals	54
12.3.1	Definition.....	54
12.3.2	Method of measurement	54
12.3.2.1	Test setup	54
12.3.2.2	Calibration of the test setup.....	55
12.3.2.3	Making the measurement	57
12.3.3	Required results	58
13	Lanyard Strength test.....	58
13.1	Definition	58
13.2	Method of measurement	58
13.3	Required result	59
14	Optical tests.....	59
14.1	Visible strobe light	59
14.1.1	Definition.....	59
14.1.2	Method of measurement	59
14.1.3	Required results	60
14.2	Optional night vision indicator.....	60
14.2.1	Definition.....	60
14.2.2	Method of measurement	60
14.2.3	Required results	61
Annex A (informative):	Maximum measurement uncertainty.....	62
Annex B (normative):	Additional Test Supports	63
B.1	EPIRB test support.....	63
Annex C (informative):	AIS message bursts	64
C.1	Active mode	64
C.2	GNSS self-test mode	65
C.3	Default message field values.....	66
Annex D (informative):	Grey-box testing of EPIRBs.....	67
D.1	Definitions.....	67
D.2	Test interface.....	67
D.3	Special test modes and functions	67
Annex E (informative):	Change History	68
History		69