

# ETSI TS 100 392-5 V2.3.1 (2012-08)



## **Terrestrial Trunked Radio (TETRA); Voice plus Data (V+D) and Direct Mode Operation (DMO); Part 5: Peripheral Equipment Interface (PEI)**

### **Document Preview**

[ETSI TS 100 392-5 V2.3.1 \(2012-08\)](https://standards.iteh.ai/catalog/standards/etsi/007d9d92-5536-43f4-804b-0c4d1641964f/etsi-ts-100-392-5-v2-3-1-2012-08)

<https://standards.iteh.ai/catalog/standards/etsi/007d9d92-5536-43f4-804b-0c4d1641964f/etsi-ts-100-392-5-v2-3-1-2012-08>

---

**Reference**RTS/TETRA-03208

---

---

**Keywords**data, interface, TETRA, V+D, voice

---

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

iteh Standards  
(<https://standards.iteh.ai>)  
Document Preview

---

**Important notice**

---

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

[http://portal.etsi.org/chaicor/ETSI\\_support.asp](http://portal.etsi.org/chaicor/ETSI_support.asp)

---

**Copyright Notification**

---

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2012.  
All rights reserved.

DECT<sup>TM</sup>, PLUGTESTS<sup>TM</sup>, UMTS<sup>TM</sup> and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.  
3GPP<sup>TM</sup> and LTE<sup>TM</sup> are Trade Marks of ETSI registered for the benefit of its Members and  
of the 3GPP Organizational Partners.  
GSM<sup>®</sup> and the GSM logo are Trade Marks registered and owned by the GSM Association.

# Contents

|                                                                              |    |
|------------------------------------------------------------------------------|----|
| Intellectual Property Rights .....                                           | 21 |
| Foreword.....                                                                | 21 |
| Introduction .....                                                           | 22 |
| 1 Scope .....                                                                | 23 |
| 2 References .....                                                           | 23 |
| 2.1 Normative references .....                                               | 23 |
| 2.2 Informative references .....                                             | 25 |
| 3 Symbols and abbreviations.....                                             | 25 |
| 3.1 Symbols.....                                                             | 25 |
| 3.2 Abbreviations .....                                                      | 26 |
| 4 Overview of TETRA PEI .....                                                | 29 |
| 4.1 Introduction .....                                                       | 29 |
| 4.2 Protocol architecture.....                                               | 30 |
| 4.3 Context model .....                                                      | 30 |
| 4.4 Void.....                                                                | 34 |
| 4.5 SDS Message stacks.....                                                  | 34 |
| 4.5.1 Status message texts.....                                              | 34 |
| 4.5.2 SDS 1 message texts .....                                              | 34 |
| 4.5.3 Status and SDS types 1, 2 and 3 .....                                  | 34 |
| 4.5.4 SDS type 4 .....                                                       | 35 |
| 4.6 Phone books .....                                                        | 35 |
| 4.7 Reserved status values considerations .....                              | 35 |
| 4.8 SDS-TL considerations .....                                              | 35 |
| 4.9 AT commands .....                                                        | 36 |
| 4.9.1 General on AT commands .....                                           | 36 |
| 4.9.2 AT command state .....                                                 | 38 |
| 4.9.3 AT circuit mode data state .....                                       | 38 |
| 4.9.4 TNP1 and packet data state.....                                        | 39 |
| 4.9.5 Transitions between states .....                                       | 39 |
| 4.9.5.1 Transition from AT command state to AT circuit mode data state ..... | 39 |
| 4.9.5.2 Transition from AT circuit mode data state to AT command state ..... | 39 |
| 4.9.5.3 Transition from AT command state to TNP1 or packet data state .....  | 40 |
| 4.9.5.4 Transition from TNP1 and packet data state to AT command state ..... | 40 |
| 4.10 TNP1 and IP network layer .....                                         | 40 |
| 4.10.1 General operation.....                                                | 40 |
| 4.10.2 IP addressing.....                                                    | 40 |
| 4.10.3 Local mode .....                                                      | 41 |
| 4.10.4 Wide mode.....                                                        | 41 |
| 4.11 TNP1 operation .....                                                    | 41 |
| 4.12 Link start up at the MT.....                                            | 42 |
| 5 Physical layer .....                                                       | 42 |
| 5.1 General on physical layer .....                                          | 42 |
| 5.2 Physical layer for V.24/V.28 .....                                       | 43 |
| 5.2.1 Electrical characteristics for V.24/V.28.....                          | 43 |
| 5.2.2 Physical connection .....                                              | 43 |
| 5.2.3 Character format .....                                                 | 44 |
| 5.2.4 Data transmission rate for V.24/V.28 .....                             | 44 |
| 5.3 Wire-line high rate connectivity technologies .....                      | 44 |
| 5.3.1 General.....                                                           | 44 |
| 5.3.2 Universal Serial Bus .....                                             | 45 |
| 5.3.3 USB On-The-Go.....                                                     | 46 |
| 5.4 Wireless high rate connectivity .....                                    | 46 |
| 5.4.1 General.....                                                           | 46 |

|          |                                                            |    |
|----------|------------------------------------------------------------|----|
| 5.4.2    | Wireless Security .....                                    | 46 |
| 5.4.3    | Certified Wireless USB .....                               | 47 |
| 5.4.4    | Bluetooth .....                                            | 47 |
| 6        | AT command set .....                                       | 47 |
| 6.1      | General on AT command set .....                            | 47 |
| 6.2      | Limitations .....                                          | 48 |
| 6.3      | SDS user data .....                                        | 48 |
| 6.4      | AT command syntax .....                                    | 49 |
| 6.4.1    | General on AT command syntax .....                         | 49 |
| 6.4.2    | Command line .....                                         | 49 |
| 6.4.2.0  | Command line structure .....                               | 49 |
| 6.4.2.1  | Prefix .....                                               | 49 |
| 6.4.2.2  | Body .....                                                 | 49 |
| 6.4.2.3  | Termination Character .....                                | 49 |
| 6.4.2.4  | Concatenating extended commands .....                      | 49 |
| 6.4.2.5  | Multiline extended commands .....                          | 49 |
| 6.4.3    | Command types .....                                        | 50 |
| 6.4.4    | Parameters .....                                           | 51 |
| 6.4.5    | AT command examples .....                                  | 51 |
| 6.4.6    | Information responses and result codes .....               | 52 |
| 6.4.6.1  | General on information responses and result codes .....    | 52 |
| 6.4.6.2  | Information Responses .....                                | 52 |
| 6.4.6.3  | Result Code .....                                          | 52 |
| 6.4.6.4  | AT result examples in verbose mode .....                   | 53 |
| 6.4.6.5  | AT result examples in numeric mode .....                   | 54 |
| 6.4.6.6  | Aborting information results and result codes .....        | 55 |
| 6.4.7    | Handling of unknown parameters .....                       | 55 |
| 6.5      | Existing V.250 commands for call control .....             | 56 |
| 6.5.1    | Commands .....                                             | 56 |
| 6.5.2    | Result Codes .....                                         | 56 |
| 6.5.3    | Dialled string and user identity .....                     | 57 |
| 6.6      | Existing V.250 commands for PEI control .....              | 57 |
| 6.7      | Existing V.250 commands for generic MT control .....       | 58 |
| 6.8      | Existing Hayes AT commands for PEI control .....           | 59 |
| 6.9      | Existing GSM commands for MT control .....                 | 59 |
| 6.10     | Modified PCCA wireless extended commands .....             | 59 |
| 6.11     | Modified Cellular commands for MT control .....            | 60 |
| 6.11.1   | General on cellular commands for MT control .....          | 60 |
| 6.11.2   | MT Capabilities +GCAP .....                                | 60 |
| 6.11.2.1 | General on +GCAP .....                                     | 60 |
| 6.11.2.2 | Description .....                                          | 60 |
| 6.11.2.3 | GCAP execution syntax .....                                | 60 |
| 6.11.2.4 | GCAP execution read syntax .....                           | 60 |
| 6.11.2.5 | GCAP execution read and unsolicited result code text ..... | 61 |
| 6.11.2.6 | GCAP test syntax .....                                     | 61 |
| 6.11.3   | Network registration +CREG .....                           | 61 |
| 6.11.3.1 | General on +CREG .....                                     | 61 |
| 6.11.3.2 | CREG set syntax .....                                      | 61 |
| 6.11.3.3 | Description of set command .....                           | 61 |
| 6.11.3.4 | CREG read syntax .....                                     | 61 |
| 6.11.3.5 | CREG read and unsolicited result code text .....           | 62 |
| 6.11.3.6 | CREG test syntax .....                                     | 62 |
| 6.11.3.7 | CREG test result syntax .....                              | 62 |
| 6.11.4   | Get MT TETRA identities +CNUM .....                        | 62 |
| 6.11.4.1 | General on +CNUM .....                                     | 62 |
| 6.11.4.2 | Description .....                                          | 62 |
| 6.11.4.3 | CNUM execution mode syntax .....                           | 62 |
| 6.11.4.4 | CNUM execution read mode syntax .....                      | 62 |
| 6.11.4.5 | CNUM execution read result code text .....                 | 62 |
| 6.11.4.6 | CNUM test syntax .....                                     | 63 |
| 6.11.5   | Get MT TETRA Identities (alternative commands) .....       | 63 |

|            |                                                                                   |    |
|------------|-----------------------------------------------------------------------------------|----|
| 6.11.5.1   | Get MT TETRA Fixed identity number(s): ITSI, and Gateway address(es) +CNUMF ..... | 63 |
| 6.11.5.1.1 | General on +CNUMF .....                                                           | 63 |
| 6.11.5.1.2 | Description .....                                                                 | 63 |
| 6.11.5.1.3 | CNUMF execution mode syntax .....                                                 | 63 |
| 6.11.5.1.4 | CNUMF execution read mode syntax .....                                            | 63 |
| 6.11.5.1.5 | CNUMF execution read result code text .....                                       | 63 |
| 6.11.5.1.6 | CNUMF test syntax .....                                                           | 63 |
| 6.11.5.2   | Get MT static group identities +CNUMS .....                                       | 64 |
| 6.11.5.2.1 | General on +CNUMS .....                                                           | 64 |
| 6.11.5.2.2 | Description .....                                                                 | 64 |
| 6.11.5.2.3 | CNUMS set or execution/set syntax .....                                           | 65 |
| 6.11.5.2.4 | CNUMS execution read or read syntax .....                                         | 65 |
| 6.11.5.2.5 | CNUMS execution read or execution/set and unsolicited result code text .....      | 65 |
| 6.11.5.2.6 | CNUMS test syntax .....                                                           | 67 |
| 6.11.5.2.7 | CNUMS test result syntax .....                                                    | 67 |
| 6.11.5.3   | Get MT dynamic group identities +CNUMD .....                                      | 67 |
| 6.11.5.3.1 | General on +CNUMD .....                                                           | 67 |
| 6.11.5.3.2 | Description .....                                                                 | 67 |
| 6.11.5.3.3 | CNUMD set or execution/set syntax .....                                           | 68 |
| 6.11.5.3.4 | CNUMD execution read or read syntax .....                                         | 68 |
| 6.11.5.3.5 | CNUMD execution read or execution/set and unsolicited result code text .....      | 69 |
| 6.11.5.3.6 | CNUMD test syntax .....                                                           | 69 |
| 6.11.5.3.7 | CNUMD test result syntax .....                                                    | 69 |
| 6.12       | SDS message stack commands .....                                                  | 70 |
| 6.12.1     | General on SDS message stack commands .....                                       | 70 |
| 6.12.2     | Delete message +CMGD .....                                                        | 70 |
| 6.12.2.1   | General on +CMGD .....                                                            | 70 |
| 6.12.2.2   | CMGD execution syntax .....                                                       | 70 |
| 6.12.2.3   | Description .....                                                                 | 70 |
| 6.12.2.4   | CMGD test syntax .....                                                            | 70 |
| 6.12.2.5   | CMGD test result syntax .....                                                     | 70 |
| 6.12.3     | List messages +CMGL .....                                                         | 71 |
| 6.12.3.1   | General on +CMGL .....                                                            | 71 |
| 6.12.3.2   | CMGL execution syntax .....                                                       | 71 |
| 6.12.3.3   | Description .....                                                                 | 71 |
| 6.12.3.4   | CMGL execution result code text .....                                             | 71 |
| 6.12.3.5   | CMGL test syntax .....                                                            | 72 |
| 6.12.4     | Read message +CMGR .....                                                          | 72 |
| 6.12.4.1   | General on +CMGR .....                                                            | 72 |
| 6.12.4.2   | CMGR execution syntax .....                                                       | 72 |
| 6.12.4.3   | Description .....                                                                 | 72 |
| 6.12.4.4   | CMGR execution result code text .....                                             | 72 |
| 6.12.4.5   | CMGR test syntax .....                                                            | 73 |
| 6.12.5     | Write message +CMGW .....                                                         | 73 |
| 6.12.5.1   | General on +CMGW .....                                                            | 73 |
| 6.12.5.2   | CMGW execution syntax .....                                                       | 73 |
| 6.12.5.3   | Description .....                                                                 | 73 |
| 6.12.5.4   | CMGW execution result code text .....                                             | 74 |
| 6.12.5.5   | CMGW test syntax .....                                                            | 74 |
| 6.12.6     | Message send from store +CMSS .....                                               | 74 |
| 6.12.6.1   | General on +CMSS .....                                                            | 74 |
| 6.12.6.2   | CMSS execution syntax .....                                                       | 74 |
| 6.12.6.3   | Description .....                                                                 | 75 |
| 6.12.6.4   | CMSS execution result code text .....                                             | 75 |
| 6.12.6.5   | CMSS test syntax .....                                                            | 75 |
| 6.12.7     | New message indication +CMTI .....                                                | 75 |
| 6.12.7.1   | General on +CMTI .....                                                            | 75 |
| 6.12.7.2   | Description .....                                                                 | 75 |
| 6.12.7.3   | CMTI unsolicited result code text .....                                           | 76 |
| 6.13       | SDS direct commands .....                                                         | 76 |
| 6.13.1     | General on SDS direct commands .....                                              | 76 |
| 6.13.2     | Send message +CMGS .....                                                          | 76 |

|          |                                                                 |    |
|----------|-----------------------------------------------------------------|----|
| 6.13.2.1 | General on +CMGS .....                                          | 76 |
| 6.13.2.2 | CMGS execution syntax .....                                     | 76 |
| 6.13.2.3 | Description .....                                               | 77 |
| 6.13.2.4 | CMGS execution and unsolicited result code text .....           | 77 |
| 6.13.2.5 | CMGS test syntax .....                                          | 77 |
| 6.13.3   | TETRA SDS Receive +CTSDSR .....                                 | 78 |
| 6.13.3.1 | General on +CTSDSR .....                                        | 78 |
| 6.13.3.2 | Description .....                                               | 78 |
| 6.13.3.3 | CTSDSR unsolicited result code text .....                       | 78 |
| 6.14     | TETRA MT control commands .....                                 | 78 |
| 6.14.1   | General on TETRA MT control commands .....                      | 78 |
| 6.14.2   | TETRA Broadcast +CTBCT .....                                    | 78 |
| 6.14.2.1 | General on +CTBCT .....                                         | 78 |
| 6.14.2.2 | Description .....                                               | 78 |
| 6.14.2.3 | CTBCT execution read and unsolicited result code text .....     | 79 |
| 6.14.2.4 | CTBCT execution read syntax .....                               | 79 |
| 6.14.2.5 | CTBCT test syntax .....                                         | 79 |
| 6.14.3   | TETRA Status Text Read +CTSTR .....                             | 79 |
| 6.14.3.1 | General on +CTSTR .....                                         | 79 |
| 6.14.3.2 | CTSTR execution syntax .....                                    | 79 |
| 6.14.3.3 | Description .....                                               | 79 |
| 6.14.3.4 | CTSTR execution result code text .....                          | 79 |
| 6.14.3.5 | CTSTR test syntax .....                                         | 79 |
| 6.14.4   | TETRA Service Profile +CTSP .....                               | 79 |
| 6.14.4.1 | General on +CTSP .....                                          | 79 |
| 6.14.4.2 | CTSP set syntax .....                                           | 80 |
| 6.14.4.3 | Description .....                                               | 80 |
| 6.14.4.4 | CTSP read syntax .....                                          | 82 |
| 6.14.4.5 | CTSP read result code text .....                                | 82 |
| 6.14.4.6 | CTSP test syntax .....                                          | 82 |
| 6.14.4.7 | CTSP test result syntax .....                                   | 82 |
| 6.14.5   | TETRA service definition for Circuit Mode services +CTSDC ..... | 83 |
| 6.14.5.1 | General on +CTSDC .....                                         | 83 |
| 6.14.5.2 | CTSDC set syntax .....                                          | 83 |
| 6.14.5.3 | Description .....                                               | 83 |
| 6.14.5.4 | CTSDC read syntax .....                                         | 83 |
| 6.14.5.5 | CTSDC read result code text .....                               | 83 |
| 6.14.5.6 | CTSDC test syntax .....                                         | 84 |
| 6.14.5.7 | CTSDC test result syntax .....                                  | 84 |
| 6.14.6   | TETRA service definition for SDS Service +CTSDS .....           | 84 |
| 6.14.6.1 | General on +CTSDS .....                                         | 84 |
| 6.14.6.2 | CTSDS set syntax .....                                          | 84 |
| 6.14.6.3 | Description .....                                               | 84 |
| 6.14.6.4 | CTSDS read syntax .....                                         | 85 |
| 6.14.6.5 | CTSDS read result code text .....                               | 85 |
| 6.14.6.6 | CTSDS test syntax .....                                         | 85 |
| 6.14.6.7 | CTSDS test result syntax .....                                  | 85 |
| 6.14.7   | TETRA operating mode +CTOM .....                                | 85 |
| 6.14.7.1 | General on +CTOM .....                                          | 85 |
| 6.14.7.2 | CTOM set syntax .....                                           | 85 |
| 6.14.7.3 | Description .....                                               | 85 |
| 6.14.7.4 | CTOM read syntax .....                                          | 86 |
| 6.14.7.5 | CTOM read and unsolicited result code text .....                | 86 |
| 6.14.7.6 | CTOM test syntax .....                                          | 86 |
| 6.14.7.7 | CTOM test result .....                                          | 86 |
| 6.14.8   | TETRA DM communication type +CTDCT .....                        | 86 |
| 6.14.8.1 | General on +CTDCT .....                                         | 86 |
| 6.14.8.2 | CTDCT set syntax .....                                          | 86 |
| 6.14.8.3 | Description .....                                               | 86 |
| 6.14.8.4 | CTDCT read syntax .....                                         | 86 |
| 6.14.8.5 | CTDCT read and unsolicited result code text .....               | 87 |
| 6.14.8.6 | CTDCT test syntax .....                                         | 87 |

|           |                                                             |    |
|-----------|-------------------------------------------------------------|----|
| 6.14.8.7  | CTDCT test result text .....                                | 87 |
| 6.14.9    | TETRA Transient communication type +CTTCT .....             | 87 |
| 6.14.9.1  | General on +CTTCT .....                                     | 87 |
| 6.14.9.2  | CTTCT set syntax .....                                      | 87 |
| 6.14.9.3  | Description .....                                           | 87 |
| 6.14.9.4  | CTTCT unsolicited result code text .....                    | 87 |
| 6.14.9.5  | CTTCT read syntax .....                                     | 87 |
| 6.14.9.6  | CTTCT read result syntax .....                              | 87 |
| 6.14.9.7  | CTTCT test syntax .....                                     | 87 |
| 6.14.9.8  | CTTCT test result syntax .....                              | 88 |
| 6.14.10   | TETRA DMO visible gateways/repeaters +CTDGR .....           | 88 |
| 6.14.10.1 | General on +CTDGR .....                                     | 88 |
| 6.14.10.2 | CTDGR set syntax .....                                      | 88 |
| 6.14.10.3 | Description .....                                           | 88 |
| 6.14.10.4 | CTDGR execution read and unsolicited result code text ..... | 88 |
| 6.14.10.5 | CTDGR execution read syntax .....                           | 88 |
| 6.14.10.6 | CTDGR test syntax .....                                     | 88 |
| 6.14.11   | TETRA DM Carrier Selection +CTDCS .....                     | 89 |
| 6.14.11.1 | General on +CTDCS .....                                     | 89 |
| 6.14.11.2 | CTDCS set syntax .....                                      | 89 |
| 6.14.11.3 | Description .....                                           | 89 |
| 6.14.11.4 | CTDCS read and unsolicited result code text .....           | 89 |
| 6.14.11.5 | CTDCS read syntax .....                                     | 89 |
| 6.14.11.6 | CTDCS test syntax .....                                     | 89 |
| 6.14.12   | MT Reboot R .....                                           | 89 |
| 6.14.12.1 | General on MT Reboot R .....                                | 89 |
| 6.14.12.2 | Description .....                                           | 90 |
| 6.14.12.3 | R execution syntax .....                                    | 90 |
| 6.14.13   | TETRA Broadcast +CTBCF .....                                | 90 |
| 6.14.13.1 | General on +CTBCF .....                                     | 90 |
| 6.14.13.2 | Description .....                                           | 90 |
| 6.14.13.3 | CTBCF set syntax .....                                      | 90 |
| 6.14.13.4 | CTBCF execute syntax .....                                  | 90 |
| 6.14.13.5 | CTBCF execute and unsolicited result code text .....        | 90 |
| 6.14.13.6 | CTBCF read syntax .....                                     | 90 |
| 6.14.13.7 | CTBCF test syntax .....                                     | 91 |
| 6.14.13.8 | CTBCF test result text .....                                | 91 |
| 6.14.14   | TETRA radio frequency sensitive area mode +CTRFSA .....     | 91 |
| 6.14.14.1 | General on +CTRFSA .....                                    | 91 |
| 6.14.14.2 | Description .....                                           | 91 |
| 6.14.14.3 | CTRFSA set syntax .....                                     | 91 |
| 6.14.14.4 | CTRFSA read syntax .....                                    | 91 |
| 6.14.14.5 | CTRFSA read and unsolicited result code text .....          | 92 |
| 6.14.14.6 | CTRFSA test syntax .....                                    | 92 |
| 6.14.14.7 | CTRFSA test result text .....                               | 92 |
| 6.15      | New TETRA call handling commands .....                      | 92 |
| 6.15.1    | General on new TETRA call handling commands .....           | 92 |
| 6.15.2    | TETRA Call Connect +CTCC .....                              | 92 |
| 6.15.2.1  | General on +CTCC .....                                      | 92 |
| 6.15.2.2  | Description .....                                           | 92 |
| 6.15.2.3  | CTCC unsolicited result code text .....                     | 92 |
| 6.15.3    | TETRA Call Release +CTCR .....                              | 92 |
| 6.15.3.1  | General on +CTCR .....                                      | 92 |
| 6.15.3.2  | Description .....                                           | 93 |
| 6.15.3.3  | CTCR unsolicited result code text .....                     | 93 |
| 6.15.4    | TETRA Incoming Call Notification +CTICN .....               | 93 |
| 6.15.4.1  | General on +CTICN .....                                     | 93 |
| 6.15.4.2  | Description .....                                           | 93 |
| 6.15.4.3  | CTICN unsolicited result code text .....                    | 93 |
| 6.15.5    | TETRA outgoing Call progress notification +CTOCP .....      | 94 |
| 6.15.5.1  | General on +CTOCP .....                                     | 94 |
| 6.15.5.2  | Description .....                                           | 94 |