

ETSI TS 101 376-4-13 V3.3.1 (2012-12)



**GEO-Mobile Radio Interface Specifications (Release 3);
Third Generation Satellite Packet Radio Service;
Part 4: Radio interface protocol specifications;
Sub-part 13: Radio Resource Control (RRC) protocol;
lu Mode;**

ETSI GMR-1 3G 44.118 (2-12)

<https://standards.iteh.ai/catalog/standards/etsi/6d13d130-7ece-4e8f-9583-60f0dc1afb30/etsi-ts-101-376-4-13-v3-3-1-2012-12>

Reference

RTS/SES-00328-4-13

Keywords3G, GMPRS, GMR, GPRS, GSM, GSO, MES,
mobile, MSS, radio, satellite, S-PCN**ETSI**650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

(<https://standards.iteh.ai>)
Document Preview

Important notice

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

http://portal.etsi.org/chaicor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2012.
All rights reserved.

DECTTM, PLUGTESTSTM, UMTSTM and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPPTM and LTETM are Trade Marks of ETSI registered for the benefit of its Members and
of the 3GPP Organizational Partners.
GSM[®] and the GSM logo are Trade Marks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	15
Foreword.....	15
Introduction	16
1 Scope	18
1.1 General	18
1.2 Scope of the present document.....	18
1.3 Application to the interface structures.....	18
1.4 Structure of layer 3 procedures.....	18
2 References	19
2.1 Normative references	19
2.2 Informative references.....	21
3 Definitions, symbols and abbreviations	21
3.1 Definitions.....	21
3.2 Abbreviations	22
3.3 Random values	22
3.4 Specification Notations	23
4 RRC Functions and Services provided to upper layers	23
4.1 RRC Functions	23
4.2 RRC Services provided to upper layers.....	24
5 Services expected from lower layers.....	24
5.1 Services required from layer 2 and physical layers.....	24
5.2 Signalling Radio Bearers.....	24
6 RRC Protocol modes and states	25
6.1 General	25
6.2 Relation between Iu mode and A/Gb mode.....	25
6.2.1 Handover between Iu and A/Gb modes.....	25
6.2.2 Cell reselection between Iu and A/Gb mode	25
6.2a Relation between GERAN Iu mode RRC and UTRA RRC	25
6.2a.1 Handover between GERAN Iu mode and UTRAN	25
6.2a.2 Cell reselection between GERAN Iu mode and UTRAN	25
6.3 RR modes of operation.....	26
6.4 RRC modes and states	26
6.4.1 RRC-Idle Mode	26
6.4.1.1 General	26
6.4.1.2 Transition from RRC-Idle Mode to RRC-Connected mode.....	26
6.4.2 RRC-Connected mode: RRC-Cell_Shared state	27
6.4.2.1 General	27
6.4.2.2 Transition from RRC-Cell_Shared state to RRC-Idle Mode.....	27
6.4.2.3 Transition from RRC-Cell_Shared state to RRC-Cell_Dedicated state	27
6.4.2.4 Transition from RRC-Cell_Shared state to RRC-GRA_PCH state.....	27
6.4.2.5 Radio resource allocation tasks.....	27
6.4.2.6 RRC connection mobility tasks.....	28
6.4.2.7 MES measurements.....	28
6.4.3 RRC-Connected mode: RRC-Cell_Dedicated state	28
6.4.3.1 General	28
6.4.3.2 Transition from RRC-Cell_Dedicated state to RRC-Cell_Shared state	28
6.4.3.3 Transition from RRC-Cell_Dedicated state to RRC-Idle Mode.....	28
6.4.3.4 Transition from RRC-Cell_Dedicated state to RRC-GRA_PCH state.....	28
6.4.3.5 Radio resource allocation tasks.....	28
6.4.3.6 RRC connection mobility tasks.....	29
6.4.3.7 MES measurements.....	29
6.4.4 RRC-Connected mode: RRC-GRA_PCH state	29

6.4.4.1	General	29
6.4.4.2	Transition from RRC-GRA_PCH state to RRC-Cell_Shared state.....	29
6.4.4.3	Transition from RRC-GRA_PCH state to RRC-Cell_Dedicated state.....	29
6.4.4.4	Radio resource allocation tasks	30
6.4.4.5	RRC connection mobility tasks.....	30
6.4.4.6	MES measurements.....	30
6.4.4.7	Transfer and update of system information.....	30
7	Radio Resource Control procedures.....	30
7.1	General	30
7.2	Change of channels in case of handover	30
7.2.1	Change of channel serving SRB1	30
7.2.2	Change of channel serving SRB2	31
7.2.3	Change of channel serving SRB3	31
7.2.4	Change of channel serving SRB4	31
7.3	System information broadcasting	31
7.3.1	General.....	31
7.3.2	Broadcast of Iu mode specific System Information.....	31
7.4	Paging procedure.....	31
7.4.1	General.....	31
7.4.2	Paging initiation in RRC-Idle mode, or RRC-GRA_PCH state.....	31
7.4.2.1	General	31
7.4.2.2	Initiation.....	32
7.4.2.3	Reception of a PAGING INDICATION service primitive	33
7.4.3	Paging initiation in RRC-Cell_Dedicated state.....	33
7.4.4	Abnormal cases.....	34
7.5	RRC Connection management procedures.....	34
7.5.1	RRC connection establishment	34
7.5.1.1	General	34
7.5.1.2	Initiation.....	35
7.5.1.3	RRC CONNECTION REQUEST message contents to set.....	35
7.5.1.4	Reception of an RRC CONNECTION REQUEST message by the GERAN	35
7.5.1.5	T300 timeout	35
7.5.1.6	Abortion of RRC connection establishment.....	36
7.5.1.7	Reception of an RRC CONNECTION SETUP message by the MES	36
7.5.1.8	Cell re-selection	37
7.5.1.9	Invalid RRC CONNECTION SETUP message	38
7.5.1.10	Reception of an RRC CONNECTION REJECT message by the MES	39
7.5.1.11	Invalid RRC CONNECTION REJECT message	39
7.5.2	RRC connection release	40
7.5.2.1	General	40
7.5.2.2	Initiation.....	40
7.5.2.3	Reception of an RRC CONNECTION RELEASE message by the MES.....	40
7.5.2.4	Invalid RRC CONNECTION RELEASE message.....	41
7.5.2.5	Cell re-selection or radio link failure	41
7.5.2.6	Reception of an RRC CONNECTION RELEASE COMPLETE message by GERAN	42
7.5.2.7	Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission.....	42
7.5.2.8	Detection of loss of dedicated physical channel by GERAN in RRC-Cell_Dedicated state.....	42
7.5.2.9	Failure to receive RRC CONNECTION RELEASE COMPLETE message by GERAN.....	42
7.6	Transmission of MES capability information.....	43
7.6.1	General.....	43
7.6.2	Initiation.....	43
7.6.3	Reception of an MES CAPABILITY INFORMATION message by the GERAN.....	44
7.6.4	Reception of the MES CAPABILITY INFORMATION CONFIRM message by the MES	44
7.6.5	Invalid MES CAPABILITY INFORMATION CONFIRM message	44
7.6.6	T304 timeout.....	45
7.7	MES capability enquiry	46
7.7.1	General.....	46
7.7.2	Initiation.....	46
7.7.3	Reception of an MES CAPABILITY ENQUIRY message by the MES	46
7.7.4	Invalid MES CAPABILITY ENQUIRY message	46

7.8	RRC Connection mobility procedures.....	47
7.8.1	Cell Update procedures.....	47
7.8.1.1	General.....	48
7.8.1.2	Initiation.....	48
7.8.1.3	CELL UPDATE message contents to set.....	51
7.8.1.4	Reception of an CELL UPDATE message by the GERAN.....	51
7.8.1.5	Reception of the CELL UPDATE CONFIRM message by the MES.....	52
7.8.1.6	Transmission of a response message to GERAN.....	54
7.8.1.7	Physical channel failure.....	57
7.8.1.8	Unsupported configuration by the MES.....	58
7.8.1.9	Invalid configuration.....	59
7.8.1.10	Incompatible simultaneous reconfiguration.....	61
7.8.1.10a	Security reconfiguration during Cell update procedure.....	62
7.8.1.11	Void.....	62
7.8.1.12	Invalid CELL UPDATE CONFIRM message.....	62
7.8.1.13	T302 expiry or cell reselection.....	63
7.8.1.14	T314 expiry.....	66
7.8.1.15	T315 expiry.....	66
7.8.1.16	Reception of the GERAN MOBILITY INFORMATION CONFIRM message by the GERAN.....	67
7.8.1.17	Inter-RAT cell reselection to GERAN <i>Iu mode</i>	67
7.8.1.17.1	General.....	67
7.8.1.17.2	Initiation.....	67
7.8.1.17.3	MES fails to complete an inter-RAT cell reselection.....	67
7.8.1.18	Inter-RAT cell reselection from GERAN <i>Iu mode</i>	68
7.8.1.18.1	General.....	68
7.8.1.18.2	Initiation.....	68
7.8.1.18.3	Successful cell reselection.....	68
7.8.1.18.4	MES fails to complete an inter-RAT cell reselection.....	68
7.8.2	GRA update procedure.....	69
7.8.2.1	General.....	69
7.8.2.2	Initiation.....	70
7.8.2.3	GRA UPDATE message contents to set.....	70
7.8.2.4	Reception of an GRA UPDATE message by the GERAN.....	71
7.8.2.5	Reception of the GRA UPDATE CONFIRM message by the MES.....	72
7.8.2.6	Transmission of a response message to GERAN.....	73
7.8.2.7	Invalid configuration.....	73
7.8.2.8	Incompatible simultaneous reconfiguration.....	74
7.8.2.9	Confirmation error of GRA ID list.....	74
7.8.2.10	Invalid CELL GRA UPDATE CONFIRM message.....	75
7.8.2.11	T302 expiry or cell reselection.....	76
7.8.3	GERAN mobility information.....	78
7.8.3.1	General.....	78
7.8.3.2	Initiation.....	78
7.8.3.3	Reception of GERAN MOBILITY INFORMATION message by the MES.....	79
7.8.3.4	Reception of an GERAN MOBILITY INFORMATION CONFIRM message by the GERAN.....	82
7.8.3.5	Cell re-selection.....	82
7.8.3.6	Incompatible simultaneous security reconfiguration.....	82
7.8.3.7	Invalid GERAN MOBILITY INFORMATION message.....	83
7.8.4	Inter-mode handover from GERAN <i>Iu mode</i>	83
7.9	Procedures for System Information transmission and Measurement reporting in RRC-Cell_Dedicated state.....	83
7.9.1	General.....	83
7.9.2	Measurement Report and Enhanced Measurement Report.....	83
7.9.2.1	Void.....	83
7.9.2.2	Parameters for Measurements and Reporting.....	83
7.9.2.2.1	General.....	83
7.9.2.2.2	Deriving the 3G Neighbour Cell list from the 3G Neighbour Cell Description.....	84
7.9.2.2.3	Deriving the GSM Neighbour Cell list from the BSICs and the BCCH Allocation.....	84
7.9.2.2.4	Deriving the Neighbour Cell list from the GSM Neighbour Cell list and the 3G Neighbour Cell list.....	84
7.9.2.2.5	Real Time Differences.....	84
7.9.2.2.6	Report Priority Description.....	84

7.9.2.2.7	The 3G Cell Reselection list	84
7.9.2.2.8	CCN Support description	84
7.9.3	Extended measurement report	84
7.10	Void	85
7.11	Void	85
7.12	Mapping of user data substreams onto timeslots in a multislot configuration	85
7.13	Application Procedures	85
7.13.1	LCS transfer	85
7.13.1.1	General	85
7.13.1.2	Initiation of LCS transfer procedure in the GERAN	85
7.13.1.3	Reception of LCS DOWNLINK INFORMATION message by the MES	85
7.13.1.4	Transmission of a response message by the MES	86
7.13.1.5	Reception of a response message by the GERAN	86
7.13.1.6	Invalid LCS DOWNLINK INFORMATION message	86
7.13.2	Position Reporting	87
7.13.2.1	General	87
7.13.2.2	Initiation of position reporting procedure in the GERAN	87
7.13.2.3	Reception of POSITION REPORT REQUEST message by the MES	87
7.13.2.4	Transmission of a response message by the MES	87
7.13.2.5	Reception of a response message by the GERAN	87
7.13.2.6	Invalid POSITION REPORT REQUEST message	87
7.13.2a	Autonomous Position Update	88
7.13.2a.1	General	88
7.13.2a.2	Enabling and Disabling of Autonomous Position Update	88
7.13.2a.3	Transmission of POSITION UPDATE INDICATION message by the MES	89
7.13.2a.4	Reception of POSITION UPDATE INDICATION message by the GERAN	89
7.13.3	RAB Upper Layer Reconfiguration	89
7.13.3.1	General	89
7.13.3.2	Initiation of RAB Upper Layer Reconfiguration procedure in the GERAN	89
7.13.3.3	Reception of RAB Upper Layer Reconfiguration message by the MES	89
7.13.3.4	Transmission of a response message by the MES	90
7.13.3.5	Reception of a response message by the GERAN	90
7.13.4	RAB Binding	90
7.13.4.1	General	90
7.13.4.2	Initiation of RAB Binding procedure in the MES	90
7.13.4.2.1	Adding a RAB Binding	90
7.13.4.2.2	Updating a RAB Binding	90
7.13.4.2.3	Removing a RAB Binding	91
7.13.4.3	Reception of RAB Binding Request message by the GERAN	91
7.13.4.4	Transmission of a response message by the GERAN	91
7.13.4.5	Reception of a response message by the MES	91
7.14	Radio Bearer control procedures	91
7.14.1	Reconfiguration procedures	91
7.14.1.1	General	93
7.14.1.2	Initiation	94
7.14.1.3	Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE message by the MES	95
7.14.1.4	Transmission of a response message by the MES, normal case	103
7.14.1.5	Reception of a response message by the GERAN, normal case	105
7.14.1.6	Unsupported configuration in the MES	107
7.14.1.7	Physical channel failure	107
7.14.1.8	Cell re-selection	108
7.14.1.9	Transmission of a response message by the MES, failure case	108
7.14.1.10	Reception of a response message by the GERAN, failure case	109
7.14.1.11	Invalid configuration	109
7.14.1.12	Incompatible simultaneous reconfiguration	109
7.14.1.12.1	Incompatible simultaneous security reconfiguration	110
7.14.1.12.2	Cell Update procedure during security reconfiguration	110
7.14.1.13	Invalid received message	111
7.14.1.14	Abnormal cases	111
7.14.2	MES initiated DTM procedures while in RRC-Cell_Dedicated-MAC-Dedicated state	113
7.14.2.1	General	113

7.14.2.2	Initiation of the DTM Request procedure by the MES	113
7.14.2.3	Reception of a GERAN Iu mode DTM REQUEST message by the GERAN	113
7.14.2.3.1	General	113
7.14.2.3.2	PDCH assignment	113
7.14.2.3.3	DTM Request rejection	114
7.14.2.3.4	Reception of a GERAN Iu mode DTM REJECT message by the MES, normal case.....	114
7.14.2.3.5	Invalid GERAN Iu mode DTM REJECT message.....	114
7.14.2.4	Abnormal cases	115
7.14.2.5	T3148 expiry.....	115
7.15	Signalling flow procedures.....	115
7.15.1	Signalling connection release procedure.....	115
7.15.1.1	General.....	115
7.15.1.2	Initiation of SIGNALLING CONNECTION RELEASE by the GERAN	116
7.15.1.3	Reception of SIGNALLING CONNECTION RELEASE by the MES	116
7.15.1.4	Invalid SIGNALLING CONNECTION RELEASE message.....	116
7.15.1.5	Invalid configuration.....	116
7.15.2	Signalling connection release indication procedure.....	117
7.15.2.1	General.....	117
7.15.2.2	Initiation.....	117
7.15.2.2a	RLC re-establishment, inter-mode handover or inter-RAT change	118
7.15.2.3	Reception of SIGNALLING CONNECTION RELEASE INDICATION by the GERAN	118
7.16	Security mode control	118
7.16.1	Security mode control.....	118
7.16.1.1	General.....	118
7.16.1.2	Initiation.....	119
7.16.1.2.1	Ciphering configuration change	119
7.16.1.2.2	Integrity protection configuration change.....	120
7.16.1.2.3	Reception of SECURITY MODE COMMAND message by the MES.....	122
7.16.1.2.4	Incompatible simultaneous security reconfiguration.....	128
7.16.1.2.5	Cell Update procedure during security reconfiguration.....	128
7.16.1.2.6	Invalid configuration	129
7.16.1.2.7	Reception of SECURITY MODE COMPLETE message by the GERAN.....	130
7.16.1.2.8	Invalid SECURITY MODE COMMAND message	132
7.17	Delivery of Non-Access stratum messages	132
7.17.1	Initial Direct transfer.....	132
7.17.1.1	General.....	132
7.17.1.2	Initiation of Initial direct transfer procedure in the MES	132
7.17.1.3	RLC re-establishment, inter-mode handover or inter-RAT change	134
7.17.1.4	Abortion of signalling connection establishment	134
7.17.1.5	Reception of INITIAL DIRECT TRANSFER message by the GERAN	134
7.17.2	Downlink Direct transfer	134
7.17.2.1	General.....	135
7.17.2.2	Initiation of downlink direct transfer procedure in the GERAN	135
7.17.2.3	Reception of a DOWNLINK DIRECT TRANSFER message by the MES.....	135
7.17.2.4	No signalling connection exists.....	135
7.17.2.5	Invalid DOWNLINK DIRECT TRANSFER message	136
7.17.3	Uplink Direct transfer	136
7.17.3.1	General.....	136
7.17.3.2	Initiation of uplink direct transfer procedure in the MES	136
7.17.3.3	RLC re-establishment, inter-mode handover or inter-RAT change	137
7.17.3.4	Reception of UPLINK DIRECT TRANSFER message by the GERAN	137
7.18	General procedures.....	137
7.18.1	Selection of initial MES identity.....	137
7.18.2	Actions when entering RRC-Idle mode from RRC-Connected mode	137
7.18.2a	Void	139
7.18.3	Maintenance of Hyper Frame Numbers.....	139
7.18.4	START value calculation.....	139
7.18.5	Integrity protection	140
7.18.5.0	General.....	140
7.18.5.1	Integrity protection in downlink.....	141
7.18.5.2	Integrity protection in uplink.....	142
7.18.5.3	Calculation of message authentication code	142