



**GEO-Mobile Radio Interface Specifications (Release 3);
Third Generation Satellite Packet Radio Service;
Part 4: Radio interface protocol specifications;
Sub-part 8: Mobile Radio Interface Layer 3 Specifications;
GMR-1 3G 44.008**

[ETSI TS 101 376-4-8 V3.3.1 \(2012-12\)](https://standards.iteh.ai/catalog/standards/etsi/f8eddecd-7e9d-4414-a6c5-2d7f20d71705/etsi-ts-101-376-4-8-v3-3-1-2012-12)

[https://standards.iteh.ai/catalog/standards/etsi/f8eddecd-7e9d-4414-a6c5-2d7f20d71705/etsi-ts-101-376-4-8-v3-3-1-2012-](https://standards.iteh.ai/catalog/standards/etsi/f8eddecd-7e9d-4414-a6c5-2d7f20d71705/etsi-ts-101-376-4-8-v3-3-1-2012-12)

Reference

RTS/SES-00328-4-8

Keywords

3G, GMPRS, GMR, GPRS, GSM, GSO,
interface, layer 3, management, MES, MMSS,
mobile, mobility, MSS, radio, satellite, S-PCN

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

(<https://standards.iteh.ai>)
Document Preview

Important notice

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

http://portal.etsi.org/chaicor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2012.
All rights reserved.

DECTTM, PLUGTESTSTM, UMTSTM and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPPTM and LTETM are Trade Marks of ETSI registered for the benefit of its Members and
of the 3GPP Organizational Partners.
GSM[®] and the GSM logo are Trade Marks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	13
Foreword.....	13
Introduction	14
1 Scope	16
1.1 Scope of the present document.....	16
1.2 Application to the interface structures.....	16
1.3 Structure of Layer 3 procedures	16
1.4 Use of logical channels.....	16
1.5 Overview of control procedures	17
1.5.1 List of procedures	17
1.6 Applicability of implementations	19
1.6.1 Packet services.....	19
2 References	20
2.1 Normative references	20
2.2 Informative references.....	22
3 Definitions and abbreviations.....	23
3.1 Definitions.....	23
3.2 Abbreviations	24
3.3 Random values	24
4 Radio resource management procedures.....	24
4.1 Overview/general	24
4.1.1 General (A/Gb mode only)	24
4.1.2 Services provided to upper layers	25
4.1.2.1 Idle mode	25
4.1.2.2 Establishment and release of an RR connection.....	25
4.1.2.3 RR connected mode	25
4.1.2.4 Packet idle mode (A/Gb mode only).....	25
4.1.2.5 Packet transfer mode (A/Gb mode only).....	25
4.1.3 Services required from data link and physical layers.....	25
4.1.4 RR states	25
4.1.5 Change of dedicated channels.....	25
4.1.6 Procedure for service request and contention resolution	25
4.2 Idle mode procedures	26
4.2.1 Mobile Earth Station (MES) side.....	26
4.2.2 Network side.....	26
4.2.2.1 System information broadcasting.....	26
4.2.2.1.1 Classes and segments	26
4.2.2.1.2 Transmission schedules	27
4.2.2.1.3 Change information	28
4.2.2.1.4 Encoding and decoding rules.....	28
4.2.2.1.5 Future extensions.....	31
4.2.2.1.6 Anchored(A) and Temporary(T) BCCH (A/Gb mode only)	31
4.2.2.1.7 Multiplexing of CCCH and PCCCH (A/Gb mode only)	31
4.2.2.1.7a Multiplexing of CCCH and PCCCH (Iu mode only)	32
4.2.2.2 GPS satellite ephemeris data broadcasting.....	32
4.2.2.2.1 GPS satellite ephemeris Earth Centered Earth fixed coordinates on GBCH	32
4.2.2.2.2 GPS satellite ephemeris Earth Centered Earth fixed coordinates on GBCH3	33
4.2.2.2.3 GPS satellite ephemeris Keplerian Coordinates on GBCH3	34
4.2.2.3 GPS almanac data transmission	35
4.3 RR connection establishment	35
4.3.1 RR connection establishment initiated by the Mobile Earth Station (MES): immediate assignment procedure	35
4.3.1.1 Spot beam selection to access the network	35

4.3.1.2	Permission to access the network.....	35
4.3.1.3	Initiation of the immediate assignment procedure (A/Gb mode only).....	35
4.3.1.3a	Initiation of the immediate assignment procedure (Iu mode only).....	37
4.3.1.4	Answer from the network.....	38
4.3.1.4.1	On receipt of a CHANNEL REQUEST message (A/Gb mode only).....	38
4.3.1.4.2	IMMEDIATE ASSIGNMENT from network for MES requesting circuit service (A/Gb mode only).....	38
4.3.1.4.3	Immediate Assignment from network for MES requesting packet service.....	38
4.3.1.4.4	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (A/Gb mode only).....	39
4.3.1.4.4a	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (Iu mode only).....	39
4.3.1.4.5	Extended immediate assignment procedure (A/Gb mode).....	42
4.3.1.4.6	Position verification procedure (A/Gb mode only).....	43
4.3.1.4.6a	Position verification procedure (Iu mode only).....	43
4.3.1.5	Assignment procedure completion (A/Gb mode only).....	44
4.3.1.6	Abnormal cases (A/Gb mode only).....	44
4.3.2	RR connection establishment initiation by the network: paging procedure.....	44
4.4	RR connection transfer phase (A/Gb mode only).....	44
4.5	RR connection release procedure (A/Gb mode only).....	44
4.6	Receiving an RR STATUS message by an RR entity.....	44
4.7	RR procedures on CCCH related to temporary block flow establishment.....	45
4.7.1	Packet paging procedure using CCCH.....	45
4.7.1.1	Packet paging initiation by the network.....	45
4.7.1.1a	Packet paging initiation by the network (Iu Mode only).....	46
4.7.1.2	On receipt of a packet paging request.....	46
4.7.1.3	Alerting initiation by the network (Iu mode only).....	46
4.7.1.4	Page response by the MES due to alerting (Iu mode only).....	47
4.7.2	Packet access procedure using CCCH.....	47
4.7.2.1	Entering the packet transfer mode: packet access procedure.....	47
4.7.2.1.1	Permission to access the network.....	47
4.7.2.1.2	Initiation of the packet access procedure: channel request (A/Gb mode only).....	48
4.7.2.1.2a	Initiation of the packet access procedure: channel request (Iu mode only).....	48
4.7.2.1.3	Packet immediate assignment.....	48
4.7.2.1.4	Packet access completion.....	51
4.7.2.1.5	Abnormal cases.....	51
4.7.2.2	Sending an RLC/MAC control message: single block packet access procedure.....	51
4.7.3	Packet downlink assignment procedure using CCCH (A/Gb mode only).....	51
4.7.3.1	Entering the packet transfer mode: packet downlink assignment procedure.....	51
4.7.3.1.1	General.....	51
4.7.3.1.2	Initiation of the packet downlink assignment procedure.....	52
4.7.3.1.3	Packet downlink assignment completion.....	53
4.7.3.1.4	Abnormal cases.....	53
4.7.3.2	Sending an RLC/MAC control message: single block packet downlink assignment procedure.....	53
4.8	GMPRS suspend procedure on CCCH (A/Gb mode only).....	53
4.8.1	Initiation of GMPRS suspend procedure.....	53
4.8.2	Completion of GMPRS suspend procedure.....	53
4.8.3	Abnormal cases.....	54
4.9	GMPRS resume procedure on CCCH (A/Gb mode only).....	54
4.9.1	Initiation of GMPRS resume procedure.....	54
4.9.2	Completion of GMPRS resume procedure.....	55
4.9.3	Abnormal cases.....	55
5	Elementary procedures for mobility management.....	55
5.1	General.....	55
5.1.1	MM and GMM procedures.....	55
5.1.1.1	Types of MM and GMM procedures.....	55
5.1.1.1.1	Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	55
5.1.1.1.1a	Integrity protection for emergency call (Iu mode only).....	55
5.1.1.2	MM-GMM co-ordination for GMPRS MESs (A/Gb mode only).....	55
5.1.1.2.1	GMPRS MS operating in mode A or B in a network that operates in mode I.....	55
5.1.1.2.2	GPRS MS operating in mode A or B in a network that operates in mode II or III.....	56

5.1.1.3	Core Network System Information for MM (Iu mode only).....	56
5.1.1.4	Core Network System Information for GMM (Iu mode only).....	56
5.1.2	MM sublayer states.....	56
5.1.3	GPRS mobility management (GMM) sublayer states.....	56
5.1.3.1	GMM states in the MES.....	56
5.1.3.1.1	Main states.....	56
5.1.3.1.2	Substates of state GMM-DEREGISTERED.....	57
5.1.3.1.3	Substates of state GMM-REGISTERED.....	58
5.1.3.2	GPRS update status.....	60
5.1.3.3	GMM mobility management states on the network side.....	61
5.1.3.3.1	Main States.....	61
5.1.3.3.2	Substates of state GMM-REGISTERED.....	61
5.2	Behaviour of the MES in MM idle state, GMM-DEREGISTERED state and GMM-REGISTERED state	62
5.2.1	Primary service state selection.....	62
5.2.1.1	Selection of the service state after power-on.....	62
5.2.1.2	Other cases.....	62
5.2.2	Detailed description of MES behaviour in MM idle state (A/Gb mode only)	63
5.2.3	Service state when back to state MM idle from another state (A/Gb mode only)	63
5.2.4	Service state after position verification.....	63
5.2.5	Behaviour in state GMM-DEREGISTERED.....	63
5.2.5.1	Primary substate selection.....	63
5.2.5.1.1	Selection of the substate after power on or enabling the MESs GPRS capability	63
5.2.5.1.2	Other cases	64
5.2.5.2	Detailed description of the MES behaviour in state GMM-DEREGISTERED	64
5.2.5.2.1	Substate, NORMAL-SERVICE	64
5.2.5.2.2	Substate, ATTEMPTING-TO-ATTACH	64
5.2.5.2.3	Substate, LIMITED-SERVICE	64
5.2.5.2.4	Substate, NO-IMSI	64
5.2.5.2.5	Substate, NO-CELL	64
5.2.5.2.6	Substate, PLMN-SEARCH	65
5.2.5.2.7	Substate, ATTACH-NEEDED	65
5.2.5.2.8	Substate, SUSPENDED (A/Gb mode only)	65
5.2.5.2.9	Substate, INVALID-POSITION (A/Gb mode only)	65
5.2.5.2.10	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	65
5.2.5.3	Substate when back to state GMM-DEREGISTERED from another GMM state	65
5.2.6	Behaviour in state GMM-REGISTERED.....	66
5.2.6.1	Detailed description of the MES behaviour in state GMM-REGISTERED	66
5.2.6.1.1	Substate, NORMAL-SERVICE	66
5.2.6.1.2	Substate, SUSPENDED (A/Gb mode only)	66
5.2.6.1.3	Substate, UPDATE-NEEDED.....	67
5.2.6.1.4	Substate, ATTEMPTING-TO-UPDATE	67
5.2.6.1.5	Substate, NO-CELL-AVAILABLE	67
5.2.6.1.6	Substate, LIMITED-SERVICE	67
5.2.6.1.7	Substate, ATTEMPTING-TO-UPDATE-MM	67
5.2.6.1.8	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	67
5.2.6.1.9	Substate, NORMAL-SERVICE-ILLUMINATION-INITIATED (A/Gb mode only)	67
5.2.6.1.10	Substate, ROUTING-AREA-UPDATE-DARK-BEAM (A/Gb mode only).....	67
5.2.6.1.11	Substate, ROUTING-AREA-UPDATE-ILLUMINATION-INITIATED (A/Gb mode only).....	68
5.3	MM common procedures	68
5.3.1	TMSI reallocation procedure (A/Gb mode only).....	68
5.3.2	Authentication procedure.....	68
5.3.3	Identification procedure.....	68
5.3.4	IMSI detach procedure (A/Gb mode only)	68
5.3.5	Abort procedure (A/Gb mode only).....	68
5.3.6	MM information procedure (A/Gb mode only)	68
5.4	MM specific procedures (A/Gb mode only).....	68
5.5	Connection management sublayer service provision (A/Gb mode only)	68
5.5.1	MM connection establishment.....	68
5.5.1.1	MM connection establishment initiated by the MES	68
5.5.1.2	Abnormal cases	68
5.5.1.3	MM connection establishment initiated by the network	69
5.5.1.4	Abnormal cases	69

5.5.1.5	MM connection establishment for emergency calls.....	69
5.5.1.6	Call reestablishment	69
5.5.1.7	Forced release during MO MM connection establishment	69
5.5.1.8	Optimal routing	69
5.5.2	MM connection information transfer phase	70
5.5.3	MM connection release	70
5.6	Receiving an MM STATUS message by an MM entity.....	70
5.7	Elementary mobility management procedures for GPRS services.....	70
5.7.1	General.....	70
5.7.1.1	Lower layer failure.....	70
5.7.1.2	Ciphering of messages (A/Gb mode only)	70
5.7.1.3	P-TMSI signature	70
5.7.1.4	Radio resource sublayer address handling	70
5.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only)	71
5.7.1.5	P-TMSI handling.....	71
5.7.1.6	Change of network mode of operation	71
5.7.1.7	Intersystem change between A/Gb mode and Iu mode	71
5.7.1.8	List of forbidden PLMNs for GPRS service	71
5.7.2	GPRS Mobility management timers and UMTS PS signalling connection control.....	71
5.7.2.1	READY timer behaviour.....	71
5.7.2.1.1	READY timer behaviour (A/Gb mode only).....	71
5.7.2.1.2	READY timer behaviour (Iu mode only)	71
5.7.2.2	Periodic routing area updating	71
5.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	73
5.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only).....	73
5.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only)	73
5.7.2.6	Cell Update triggered by low layers.....	73
5.7.3	GPRS attach procedure	73
5.7.3.1	GPRS attach procedure for GPRS services	74
5.7.3.1.1	GPRS attach procedure initiation	74
5.7.3.1.2	GMM common procedure initiation.....	74
5.7.3.1.3	GPRS attach accepted by the network.....	74
5.7.3.1.4	GPRS attach not accepted by the network.....	74
5.7.3.1.5	Abnormal cases in the MES	74
5.7.3.1.6	Abnormal cases on the network side	75
5.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services (A/Gb mode only)	75
5.7.4	GPRS detach procedure	75
5.7.4.1	MES initiated GPRS detach procedure	76
5.7.4.1.1	MES initiated GPRS detach procedure initiation	76
5.7.4.1.2	MES initiated GPRS detach procedure completion for GPRS services only.....	76
5.7.4.1.3	MES initiated combined GPRS detach procedure completion	76
5.7.4.1.4	Abnormal cases in the MES	76
5.7.4.2	Network initiated GPRS detach procedure.....	76
5.7.4.2.1	Network initiated GPRS detach procedure initiation	76
5.7.4.2.2	Network initiated GPRS detach procedure completion by the MES	76
5.7.4.2.3	Network initiated GPRS detach procedure completion by the network.....	76
5.7.4.2.4	Abnormal cases on the network side	76
5.7.5	Routing area updating procedure	77
5.7.5.1	Normal and periodic routing area updating procedure.....	79
5.7.5.1.1	Normal and periodic routing area updating procedure initiation	79
5.7.5.1.2	GMM Common procedure initiation	79
5.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network.....	79
5.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network.....	79
5.7.5.1.5	Abnormal cases in the MES	79
5.7.5.1.6	Abnormal cases on the network side	80
5.7.5.2	Combined routing area updating procedure	80
5.7.6	P-TMSI reallocation procedure.....	80
5.7.7	Authentication and ciphering procedure	81
5.7.8	Identification procedure	81
5.7.9	Paging procedure	81
5.7.9.1	Paging for GPRS services.....	81
5.7.9.1.1	Paging for packet services using P-TMSI.....	81

5.7.9.1.2	Paging for packet services using IMSI	81
5.7.9.2	Paging for non-GMPRS services	81
5.7.10	Receiving a GMM STATUS message by a GMM entity	81
5.7.11	Void	82
5.7.12	GMM Information procedure	82
5.7.13	Service Request procedure (Iu mode only)	82
6	Elementary procedures for circuit-switched call control (A/Gb mode only)	82
7	Support of packet services	82
8	Examples of structured procedures	82
8.1	General	82
8.1.1	Paging and alert request	82
8.1.2	Immediate assignment	82
8.1.3	Service request and contention resolution	82
8.1.4	Authentication	82
8.1.5	Ciphering mode setting (A/Gb mode only)	82
8.1.6	Transaction phase (A/Gb mode only)	82
8.1.7	Channel release (A/Gb mode only)	83
8.2	Abnormal cases (A/Gb mode only)	83
8.3	Selected examples (A/Gb mode only)	83
8.3.1	Location updating	83
8.3.2	Mobile originating call establishment	83
8.3.3	Mobile terminating call establishment	83
8.3.4	Call clearing	83
8.3.5	DTMF protocol control	83
8.3.6	Handover	83
8.3.7	In-call modification	83
8.3.8	Call reestablishment	83
8.3.9	Mobile-to-mobile call establishment	83
8.3.10	Multisatellite optimal routing for call establishment	83
9	Handling of unknown, unforeseen, and erroneous protocol data	84
10	Message functional definitions and contents	84
10.1	Messages for radio resources management	85
10.1.1	Additional assignment (A/Gb mode only)	86
10.1.2	Assignment command 1 and assignment command 2 (A/Gb mode only)	86
10.1.2.1	Assignment command 1	86
10.1.2.2	Assignment command 2	86
10.1.3	Assignment complete (A/Gb mode only)	86
10.1.4	Assignment failure (A/Gb mode only)	86
10.1.5	Channel mode modify (A/Gb mode only)	86
10.1.6	Channel mode modify acknowledge (A/Gb mode only)	86
10.1.7	Channel release (A/Gb mode only)	86
10.1.8	Channel request	86
10.1.8.1	Extended channel request (A/Gb mode only)	87
10.1.8.2	Channel request Type 1 (A/Gb mode only)	87
10.1.8.3	Channel request Type 2 (A/Gb mode only)	90
10.1.8.4	Channel Request Type 3 (Iu mode only)	92
10.1.9	Ciphering mode command (A/Gb mode only)	95
10.1.10	Ciphering mode complete (A/Gb mode only)	95
10.1.11	Classmark change (A/Gb mode only)	96
10.1.12	Classmark enquiry (A/Gb mode only)	96
10.1.13	Frequency redefinition (A/Gb mode only)	96
10.1.14	Handover access (A/Gb mode only)	96
10.1.15	Handover command (A/Gb mode only)	96
10.1.16	Handover complete (A/Gb mode only)	96
10.1.17	Handover failure (A/Gb mode only)	96
10.1.18	Immediate assignment	96
10.1.18.1	Immediate assignment (A/Gb mode only)	96
10.1.18.2	Extended immediate assignment (A/Gb mode only)	96
10.1.18.3	Immediate assignment Type 2 (A/Gb mode only)	96