

ETSI TS 124 281 V18.12.0 (2026-03)



TECHNICAL SPECIFICATION

LTE;
Mission Critical Video (MCVideo) signalling control;
Protocol specification
(3GPP TS 24.281 version 18.12.0 Release 18)

get full document from standards.iteh.ai



ReferenceRTS/TSGC-0124281vic0

KeywordsLTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed, this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our [Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2026.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Symbols.....	31
3.3 Abbreviations	31
4 General	32
4.1 MCVideo overview	32
4.2 URI and address assignments.....	33
4.3 MCVideo media	34
4.4 Warning header field	34
4.4.1 General.....	34
4.4.2 Warning texts.....	34
4.5 MCVideo session identity	39
4.6 MCVideo priority calls and alerts	39
4.6.1 MCVideo emergency group calls	39
4.6.2 MCVideo emergency private calls.....	41
4.6.3 MCVideo emergency alerts	42
4.6.4 MCVideo imminent peril group call.....	43
4.7 Communication security.....	44
4.7.1 Media security	44
4.7.2 Signalling security	44
4.8 Protection of sensitive application data	45
4.9 MCVideo client ID.....	46
4.10 Off-network MCVideo	46
4.11 MCVideo Resource Management	46
5 Functional entities	46
5.1 General	46
5.2 MCVideo client	47
5.3 MCVideo server	48
5.3.1 General.....	48
5.3.2 Functional connectivity models	49
5.3.3 Failure case	50
5.3.4 Management of MBMS bearers.....	50
5.3.5 Management of MBS sessions.....	50
5.4 MCVideo UE-to-network relay	50
5.5 MCVideo gateway server	51
5.5.1 General.....	51
5.6 MCVideo gateway UE	51
5.6.1 General.....	51
5.6.2 Functional connectivity models	52
5.6.3 QoS for MCVideo gateway UE	52
6 Common procedures.....	53
6.1 Introduction	53
6.2 MCVideo client procedures.....	53
6.2.0 Distinction of requests at the MCVideo client.....	53
6.2.0.1 SIP MESSAGE request.....	53
6.2.1 SDP offer generation	54

6.2.2	SDP answer generation	56
6.2.3	Commencement modes	57
6.2.3.1	Automatic commencement mode	57
6.2.3.1.1	Automatic commencement mode for private calls	57
6.2.3.1.2	Automatic commencement mode for group calls	57
6.2.3.2	Manual commencement mode	58
6.2.3.2.1	Manual commencement mode for private calls	58
6.2.3.2.2	Manual commencement mode for group calls	58
6.2.4	Leaving an MCVideo session initiated by MCVideo client	59
6.2.4.1	On-demand session case	59
6.2.5	Releasing an MCVideo session initiated by MCVideo client	59
6.2.5.1	On-demand session case	59
6.2.5.2	Pre-established session case	59
6.2.6	Receiving an MCVideo session release request	60
6.2.7	Void	60
6.2.8	Priority call conditions	60
6.2.8.0	General	60
6.2.8.1	MCVideo emergency group call conditions	60
6.2.8.1.1	SIP INVITE request for originating MCVideo emergency group calls	60
6.2.8.1.2	Resource-Priority header field for MCVideo emergency group calls	61
6.2.8.1.3	SIP re-INVITE request for cancelling MCVideo in-progress emergency group state	61
6.2.8.1.4	Receiving a SIP 2xx response to a SIP request for a priority call	62
6.2.8.1.5	Receiving a SIP 4xx response, SIP 5xx response or SIP 6xx response to a SIP request for a priority group call	63
6.2.8.1.6	Determining authorisation for initiating or cancelling an MCVideo emergency alert	63
6.2.8.1.7	Determining authorisation for cancelling the in-progress emergency state of an MCVideo group	64
6.2.8.1.8	Determining authorisation for originating a priority group call	64
6.2.8.1.9	SIP request for originating MCVideo imminent peril group calls	65
6.2.8.1.10	Determining authorisation for cancelling an imminent peril group call	65
6.2.8.1.11	SIP re-INVITE request for cancelling MCVideo in-progress imminent peril group state	65
6.2.8.1.12	Resource-Priority header field for MCVideo imminent peril group calls	66
6.2.8.1.13	Receiving a SIP INFO request in the dialog of a SIP request for a priority group call	66
6.2.8.1.14	SIP re-INVITE request for cancelling the in-progress emergency group state of a group by a third-party	67
6.2.8.1.15	Retrieving Resource-Priority header field values	67
6.2.8.1.16	Resource-priority header field namespaces for MCVideo	68
6.2.8.1.17	Priority group call conditions upon receiving call release	68
6.2.8.1.18	Emergency private call conditions upon receiving call release	69
6.2.8.1.19	SIP INVITE request for originating MCVideo emergency adhoc group calls	69
6.2.8.1.20	Receiving a SIP 2xx response to a SIP request for a priority call	69
6.2.8.1.21	Receiving a SIP 4xx response, SIP 5xx response or SIP 6xx response to a SIP request for a priority group call	69
6.2.8.1.22	Determining authorisation for originating a priority adhoc group call	70
6.2.8.1.23	SIP request for originating MCVideo imminent peril adhoc group calls	70
6.2.8.1.24	Handling receipt of a SIP re-INVITE request for priority adhoc group call origination status within a pre-established session	71
6.2.8.1.25	Priority adhoc group call conditions upon receiving call release	71
6.2.8.1.26	Determining authorisation for cancelling the in-progress imminent peril state of an MCVideo group	72
6.2.8.1.27	Determining authorisation for initiating or cancelling an MCVideo adhoc group emergency alert	72
6.2.8.2	Request for an originating broadcast group call	72
6.2.8.3	MCVideo emergency private call conditions	72
6.2.8.3.1	Authorisations	72
6.2.8.3.2	SIP request for originating MCVideo emergency private calls	74
6.2.8.3.3	Resource-Priority header field for MCVideo emergency private calls	74
6.2.8.3.4	Receiving a SIP 2xx response to a SIP request for an MCVideo emergency private call	74
6.2.8.3.5	Receiving a SIP 4xx response, SIP 5xx response or SIP 6xx response to a SIP request for an MCVideo emergency private call	75
6.2.8.3.6	SIP re-INVITE request for cancelling MCVideo emergency private call state	75
6.2.8.3.7	Receiving a SIP INFO request in the dialog of a SIP request for a priority private call	76

6.2.8.3.8	SIP re-INVITE request for cancelling the MCVideo emergency private call state by a third-party.....	76
6.2.8.3.9	Retrieving a KMS URI associated with an MCVideo ID.....	77
6.2.9	Location information.....	78
6.2.9.1	Location information for location reporting.....	78
6.2.10	Support for multiplexing.....	78
6.3	MCVideo server procedures.....	78
6.3.1	Distinction of requests sent to the MCVideo server.....	78
6.3.1.1	SIP INVITE request.....	79
6.3.1.2	SIP MESSAGE request.....	79
6.3.1.3	SIP SUBSCRIBE request.....	83
6.3.2	Participating MCVideo Function.....	84
6.3.2.1	Requests initiated by the served MCVideo user.....	84
6.3.2.1.1	SDP offer generation.....	84
6.3.2.1.2	SDP answer generation.....	84
6.3.2.1.3	Sending an INVITE request on receipt of an INVITE request.....	85
6.3.2.1.4	Response to an INVITE request.....	86
6.3.2.1.5	Sending a SIP BYE request on receipt of a SIP BYE request.....	86
6.3.2.1.6	Priority call conditions.....	87
6.3.2.1.7	Generating a SIP re-INVITE request on receipt of a SIP re-INVITE request.....	89
6.3.2.1.8	Sending a SIP INVITE request towards the non-controlling MCVideo function.....	90
6.3.2.2	Requests terminated to the served MCVideo user.....	91
6.3.2.2.1	SDP offer generation.....	91
6.3.2.2.2	SDP answer generation.....	91
6.3.2.2.3	SIP INVITE request towards the terminating MCVideo client.....	91
6.3.2.2.4	Response to a SIP INVITE request.....	92
6.3.2.2.5	Automatic Commencement Mode.....	92
6.3.2.2.6	Manual Commencement Mode.....	94
6.3.2.2.7	Void.....	96
6.3.2.2.8	SIP BYE request towards the terminating MCVideo client.....	96
6.3.2.2.9	Populate MIME bodies.....	96
6.3.2.2.10	Generating a SIP re-INVITE request towards the terminating MCVideo client.....	97
6.3.2.2.11	Generating a SIP MESSAGE request towards the terminating MCVideo client.....	97
6.3.2.3	Processing I_MESSAGES containing MKFC and MKFC-ID.....	97
6.3.2.3.1	General.....	97
6.3.2.3.2	Processing an I_MESSAGE containing MKFC and MKFC-ID.....	97
6.3.3	Controlling MCVideo function.....	98
6.3.3.1	Request initiated by the controlling MCVideo function.....	98
6.3.3.1.1	SDP offer generation.....	98
6.3.3.1.2	Sending an INVITE request.....	98
6.3.3.1.3	Receipt of a SIP response to a SIP INVITE request.....	99
6.3.3.1.4	Sending a SIP BYE request.....	99
6.3.3.1.5	Sending a SIP re-INVITE request for MCVideo emergency group call.....	100
6.3.3.1.6	Sending a SIP INVITE request for MCVideo emergency group call.....	101
6.3.3.1.7	Sending a SIP UPDATE request for Resource-Priority header field correction.....	102
6.3.3.1.8	Generating a SIP re-INVITE request.....	103
6.3.3.1.9	Generating a SIP re-INVITE request to cancel an in-progress emergency.....	103
6.3.3.1.10	Generating a SIP MESSAGE request for notification of in-progress emergency or imminent peril status.....	103
6.3.3.1.11	Populate mcvideo-info and location-info MIME bodies for emergency alert.....	104
6.3.3.1.12	Authorisations.....	105
6.3.3.1.13	Generating a SIP 403 response for priority call request rejection.....	109
6.3.3.1.14	Sending a SIP re-INVITE request for MCVideo imminent peril group call.....	110
6.3.3.1.15	Handling the expiry of timer TNG2 (in-progress emergency group call timer).....	110
6.3.3.1.16	Validate priority request parameters.....	111
6.3.3.1.17	Sending a SIP INFO request in the dialog of a SIP request for a priority call.....	111
6.3.3.1.18	Retrieving Resource-Priority header field values.....	112
6.3.3.1.19	Generating a SIP MESSAGE request to indicate successful receipt of an emergency alert or emergency cancellation.....	112
6.3.3.1.20	Generating a SIP MESSAGE request for notification of entry into or exit from an emergency alert area.....	113

6.3.3.1.21	Generating a SIP MESSAGE request for notification of entry into or exit from a group geographic area.....	114
6.3.3.1.22	Validate adhoc group priority request parameters	115
6.3.3.1.23	Populate mcvideo-info and location-info MIME bodies for adhoc group emergency alert	115
6.3.3.1.24	Generating a SIP MESSAGE request to containing the participant lists of an MCVideo adhoc group emergency alert	116
6.3.3.2	Requests terminated by the controlling MCVideo function	117
6.3.3.2.1	SDP answer generation.....	117
6.3.3.2.2	Receipt of a SIP INVITE request	117
6.3.3.2.3	Sending a SIP response to a SIP INVITE request	117
6.3.3.2.4	Receiving a SIP BYE request.....	118
6.3.3.3	Handling of the acknowledged call setup timer (TNG1)	119
6.3.3.4	Generating a SIP NOTIFY request	121
6.3.3.5	Handling of the group call timer (TNG3)	122
6.3.3.5.1	General	122
6.3.3.5.2	Interaction with the in-progress emergency group call timer (TNG2)	122
6.3.3.6	Generation of I_MESSAGES containing MKFC and MKFC-ID.....	123
6.3.3.6.1	General	123
6.3.3.6.2	Creation of an I_MESSAGE containing MKFC	123
6.3.4	Non-controlling MCVideo function of an MCVideo group	124
6.3.4.1	Request initiated by the non-controlling MCVideo function of an MCVideo group	124
6.3.4.1.1	SDP offer generation	124
6.3.4.1.2	Sending an INVITE request towards the MCVideo client	124
6.3.4.1.3	Sending a SIP INFO request.....	125
6.3.4.1.4	Sending an INVITE request towards the controlling MCVideo function.....	126
6.3.4.2	Requests terminated by the non-controlling MCVideo function of an MCVideo group	127
6.3.4.2.1	SDP answer generation.....	127
6.3.4.2.2	Sending a SIP response to the SIP INVITE request	127
6.3.4.3	Generating a SIP NOTIFY request	128
6.3.5	Retrieving and processing a group document	129
6.3.5.1	General	129
6.3.5.2	Rules for retrieving Group Document(s).....	130
6.3.5.3	Rules for joining a group session	131
6.3.5.4	Rules for initiating a prearranged group session	131
6.3.5.5	Determining the group members to invite.....	133
6.3.6	Affiliation check	133
6.3.7	Error handling	134
6.3.7.1	Public service identity does not exist	134
6.3.8	Session release policy	134
6.3.8.1	Session release policy for group call.....	134
6.3.8.2	Session release policy for private call	135
6.4	Implicit transmit media request	135
6.5	Handling of MIME bodies in a SIP message.....	135
6.6	Confidentiality and Integrity Protection	136
6.6.1	General.....	136
6.6.1.1	Applicability and exclusions	136
6.6.1.2	Performing XML content encryption	136
6.6.1.3	Performing integrity protection on an XML body	136
6.6.1.4	Verifying integrity of an XML body and decrypting XML elements	136
6.6.2	Confidentiality Protection.....	137
6.6.2.1	General	137
6.6.2.2	Keys used in confidentiality protection procedures	137
6.6.2.3	Procedures for sending confidentiality protected content	137
6.6.2.3.1	MCVideo client	137
6.6.2.3.2	MCVideo server	138
6.6.2.3.3	Content Encryption in XML elements.....	138
6.6.2.3.4	Attribute URI Encryption	138
6.6.2.4	Procedures for receiving confidentiality protected content.....	139
6.6.2.4.1	Determination of confidentiality protected content	139
6.6.2.4.2	Decrypting confidentiality protected content in XML elements	139
6.6.2.4.3	Decrypting confidentiality protected URIs in XML attributes	139
6.6.2.5	MCVideo server copying received XML content	140

6.6.3	Integrity Protection of XML documents	140
6.6.3.1	General	140
6.6.3.2	Keys used in integrity protection procedures	142
6.6.3.3	Sending integrity protected content	142
6.6.3.3.1	MCVideo client	142
6.6.3.3.2	MCVideo server	142
6.6.3.3.3	Integrity protection procedure	143
6.6.3.4	Receiving integrity protected content	143
6.6.3.4.1	Determination of integrity protected content	143
6.6.3.4.2	Verification of integrity protected content	143
6.7	Priority sharing	144
6.8	Support for multiple devices	144
6.9	Procedures at the MCVideo gateway	144
6.9.1	General	144
6.9.2	MCVideo gateway server acting as an exit point from an MCVideo system	144
6.9.3	MCVideo gateway server acting as an entry point in an MCVideo system	145
6.9.4	Local policies enforcement	145
7	Registration and service authorisation	145
7.1	General	145
7.2	MCVideo client procedures	146
7.2.1	SIP REGISTER request for service authorisation	146
7.2.1AA	SIP REGISTER request without service authorisation	147
7.2.1A	Common SIP PUBLISH procedure	147
7.2.2	SIP PUBLISH request for service authorisation and MCVideo service settings	148
7.2.3	Sending SIP PUBLISH for MCVideo service settings only	149
7.2.4	Determination of MCVideo service settings	149
7.2.5	Receiving a CSK key download message	150
7.3	MCVideo server procedures	151
7.3.1	General	151
7.3.1A	Confidentiality and Integrity Protection	151
7.3.2	SIP REGISTER request for service authorisation	153
7.3.3	SIP PUBLISH request for service authorisation and service settings	154
7.3.4	Receiving SIP PUBLISH request for MCVideo service settings only	156
7.3.5	Receiving SIP PUBLISH request with "Expires=0"	157
7.3.6	Subscription to and notification of MCVideo service settings	157
7.3.6.1	Receiving subscription to MCVideo service settings	157
7.3.6.2	Sending notification of change of MCVideo service settings	158
7.3.7	Sending a CSK key download message	158
7.4	Coding	159
7.4.1	Extension of MIME types	159
7.4.1.1	General	159
7.4.1.2	Extension of application/poc-settings+xml MIME type	159
7.4.1.2.1	Introduction	159
7.4.1.2.2	Syntax	159
7A	Migration procedures	160
7A.1	General	160
7A.2	MCVideo client procedures	160
7A.2.1	SIP REGISTER request for migration service authorization	160
7A.2.2	Receiving a CSK key download message	161
7A.2.3	Receiving a SIP MESSAGE for migration service deauthorization notification	162
7A.3	Partner MCVideo server procedures	162
7A.3.1	General	162
7A.3.2	Confidentiality and integrity protection	162
7A.3.3	SIP REGISTER request for initial authorization	163
7A.3.4	Sending a CSK key download message	164
7A.3.5	SIP MESSAGE request for migration service authorization response	164
7A.3.6	Sending SIP MESSAGE for MCVideo service authorization notification	164
7A.3.7	SIP MESSAGE request for migration service deauthorization notification	165
7A.4	Partner MCVideo gateway server procedures	165
7A.4.1	SIP MESSAGE from the partner MCVideo server	165

7A.4.2	SIP MESSAGE request from the primary MCVideo gateway server.....	165
7A.5	Primary MCVideo gateway server procedures.....	165
7A.5.1	SIP MESSAGE from the partner MCVideo gateway	165
7A.5.2	SIP MESSAGE request from the primary MCVideo server.....	166
7A.6	Primary MCVideo server procedures.....	166
7A.6.1	SIP MESSAGE request for migration service authorization request.....	166
7A.6.2	Receiving SIP MESSAGE for MCVideo service authorization notification	166
7A.6.3	SIP MESSAGE request for migration service deauthorization notification	167
8	Affiliation	167
8.1	General	167
8.2	Procedures	168
8.2.1	MCVideo client procedures	168
8.2.1.1	General	168
8.2.1.2	Affiliation status change procedure.....	168
8.2.1.3	Affiliation status determination procedure.....	169
8.2.1.4	Procedure for sending affiliation status change request in negotiated mode to target MCVideo user	170
8.2.1.5	Procedure for receiving affiliation status change request in negotiated mode from authorized MCVideo user	171
8.2.1.6	Subscription to group dynamic data.....	171
8.2.1.7	Rules based affiliation status change procedure.....	172
8.2.1.7.1	General	172
8.2.1.7.2	User profile defined rules	172
8.2.1.7.3	Group configuration defined rules.....	172
8.2.2	MCVideo server procedures	172
8.2.2.1	General	172
8.2.2.2	Procedures of MCVideo server serving the MCVideo user	173
8.2.2.2.1	General	173
8.2.2.2.2	Stored information.....	173
8.2.2.2.3	Receiving affiliation status change from MCVideo client procedure.....	174
8.2.2.2.4	Receiving subscription to affiliation status procedure.....	177
8.2.2.2.5	Sending notification of change of affiliation status procedure	177
8.2.2.2.6	Sending affiliation status change towards MCVideo server owning MCVideo group procedure	178
8.2.2.2.7	Affiliation status determination from MCVideo server owning MCVideo group procedure	180
8.2.2.2.8	Procedure for authorizing affiliation status change request in negotiated mode sent to served MCVideo user	182
8.2.2.2.9	Forwarding affiliation status change towards another MCVideo user procedure.....	183
8.2.2.2.10	Forwarding subscription to affiliation status towards another MCVideo user procedure	184
8.2.2.2.11	Affiliation status determination	185
8.2.2.2.12	Affiliation status change by implicit affiliation	186
8.2.2.2.13	Implicit affiliation status change completion.....	187
8.2.2.2.14	Implicit affiliation status change cancellation	187
8.2.2.2.15	Implicit affiliation to configured groups procedure.....	188
8.2.2.2.16	Forwarding subscription to group dynamic data towards the controlling MCVideo server procedure	189
8.2.2.3	Procedures of MCVideo server owning the MCVideo group	190
8.2.2.3.1	General	190
8.2.2.3.2	Stored information.....	191
8.2.2.3.3	Receiving group affiliation status change procedure.....	191
8.2.2.3.4	Receiving subscription to affiliation status procedure.....	193
8.2.2.3.5	Sending notification of change of affiliation status procedure	193
8.2.2.3.6	Implicit affiliation eligibility check procedure	194
8.2.2.3.7	Affiliation status change by implicit affiliation procedure	194
8.2.2.3.8	Affiliation eligibility check procedure.....	195
8.2.2.3.9	Receiving subscription to group dynamic data procedure.....	195
8.2.2.3.10	Sending notification of change of group dynamic data procedure	196
8.3	Coding	196
8.3.1	Extension of application/pidf+xml MIME type	196
8.3.1.1	Introduction.....	196
8.3.1.2	Syntax	197

8.3.2	Extension of application/simple-filter+xml MIME type.....	199
8.3.2.1	Introduction.....	199
8.3.2.2	Syntax	199
9	Group call.....	202
9.1	General	202
9.2	On-network group call.....	202
9.2.1	Prearranged group call.....	202
9.2.1.1	General	202
9.2.1.2	MCVideo client procedures	202
9.2.1.2.1	On-demand prearranged group call	202
9.2.1.2.3	End group call	210
9.2.1.2.4	Re-join procedure	210
9.2.1.3	Participating MCVideo function procedures.....	211
9.2.1.3.1	Originating procedures	211
9.2.1.3.2	Terminating Procedures.....	214
9.2.1.3.3	End group call at the originating participating MCVideo function	215
9.2.1.3.4	End group call at the terminating participating MCVideo function	216
9.2.1.3.5	Re-join procedures.....	216
9.2.1.3.6	Reception of a SIP re-INVITE request for terminating MCVideo client for priority call	216
9.2.1.4	Controlling MCVideo function procedures.....	217
9.2.1.4.1	Originating Procedures	217
9.2.1.4.2	Terminating Procedures.....	220
9.2.1.4.3	End group call at the terminating controlling MCVideo function	228
9.2.1.4.4	End group call initiated by the controlling MCVideo function	229
9.2.1.4.5	Re-join procedures.....	229
9.2.1.4.6	Late call entry initiated by controlling MCVideo function	230
9.2.1.4.7	Receipt of a SIP re-INVITE request.....	230
9.2.1.4.8	Handling of a SIP re-INVITE request for imminent peril session.....	234
9.2.1.5	Non-controlling function of an MCVideo group procedures	235
9.2.1.5.1	Originating procedures	235
9.2.1.5.2	Terminating procedures	236
9.2.1.5.3	Rejoin procedures	239
9.2.1.5.4	void.....	240
9.2.1.5.5	Initiating a temporary group session.....	240
9.2.2	Chat group (restricted) call	242
9.2.2.1	General	242
9.2.2.2	MCVideo client procedures	242
9.2.2.2.1	On-demand chat group call.....	242
9.2.2.2.2	End group call	249
9.2.2.3	Participating MCVideo function procedures.....	249
9.2.2.3.1	On-demand chat group call.....	249
9.2.2.4	Controlling MCVideo function procedures.....	254
9.2.2.4.1	On-demand chat group call.....	254
9.2.2.4.2	End group call at the terminating controlling MCVideo function	265
9.2.2.4.3	End group call initiated by the controlling MCVideo function	265
9.2.2.5	Non-controlling function of an MCVideo group procedures	265
9.2.2.5.1	Terminating procedures	265
9.2.3	Subscription to the conference event package	269
9.2.3.1	General	269
9.2.3.2	MCVideo client.....	269
9.2.3.3	Participating MCVideo function	270
9.2.3.4	Controlling MCVideo function	271
9.2.3.4.1	Receiving a subscription to the conference event package.....	271
9.2.3.4.2	Sending notifications to the conference event package	272
9.2.3.4.3	Sending subscriptions to the conference event package	272
9.2.3.4.4	Terminating a subscription	273
9.2.3.5	Non-controlling MCVideo function.....	274
9.2.3.5.1	Receiving subscriptions to the conference event package.....	274
9.2.3.5.2	Sending notifications to the conference event package	275
9.2.3.5.3	Sending a subscription to the conference event package.....	275
9.2.3.6	Coding.....	276

9.2.3.6.1	Extension of application/conference-info+xml MIME type	276
9.2.4	Remote change of an MCVideo user's selected group	276
9.2.4.1	General	276
9.2.4.2	Client procedures	276
9.2.4.2.1	Remote selected group change initiation	276
9.2.4.2.2	Target client procedures for handling remote selected group change request	278
9.2.4.3	Participating MCVideo function procedures	279
9.2.4.3.1	Originating procedures	279
9.2.4.3.2	Terminating procedures	281
9.2.4.4	Controlling MCVideo function procedures	281
9.2.5	Change of in-progress imminent peril state of the MCVideo group	283
9.2.5.1	General	283
9.2.5.2	Client procedures	283
9.2.5.2.1	MCVideo group in-progress imminent peril state cancel initiation	283
9.2.5.2.2	Reception of MCVideo group in-progress imminent peril state cancel notification	284
9.2.5.3	Participating MCVideo function procedures	284
9.2.5.3.1	Originating procedures	284
9.2.5.3.2	Terminating Procedures	286
9.2.5.4	Controlling MCVideo function procedures	286
9.2.5.4.1	Terminating Procedures	286
9.3	Off-network group call	287
9.3.1	General	287
9.3.1.1	Common Procedures	287
9.3.1.1.1	MONP MCVideo message transport	287
9.3.1.1.2	Session description	287
9.3.2	Basic call control	288
9.3.2.1	General	288
9.3.2.2	Basic call control state machine	288
9.3.2.3	Call Control states	289
9.3.2.3.1	S1: start-stop	289
9.3.2.3.2	S2: waiting for call announcement	290
9.3.2.3.3	S3: part of ongoing call	290
9.3.2.3.4	S4: pending user action without confirm indication	290
9.3.2.3.5	S5: pending user action with confirm indication	290
9.3.2.3.6	S6: ignoring incoming call announcements	290
9.3.2.3.7	S7: waiting for call announcement after call release	290
9.3.2.4	Procedures	290
9.3.2.4.1	General	290
9.3.2.4.2	Call Probe	291
9.3.2.4.3	Call setup	292
9.3.2.4.4	Periodic group call announcement	295
9.3.2.4.5	Call release	296
9.3.2.4.6	Merge of calls	299
9.3.2.4.7	Error handling	300
9.3.3	Call type control	300
9.3.3.1	General	300
9.3.3.2	Call type control state machine	300
9.3.3.3	Call type control states	301
9.3.3.3.1	T0: waiting for call to establish	301
9.3.3.3.2	T1: in-progress emergency group call	302
9.3.3.3.3	T2: in-progress basic group call	302
9.3.3.3.4	T3: in-progress imminent peril group call	302
9.3.3.4	Procedures	302
9.3.3.4.1	General	302
9.3.3.4.2	User initiated the call probe	302
9.3.3.4.3	Received GROUP CALL ANNOUNCEMENT message as a response to GROUP CALL PROBE message	303
9.3.3.4.4	Received GROUP CALL ANNOUNCEMENT with MCVideo user acknowledgement required	304
9.3.3.4.5	Received GROUP CALL ANNOUNCEMENT without MCVideo user acknowledgement required	304
9.3.3.4.6	Call started	305

9.3.3.4.7	Upgrade call	306
9.3.3.4.8	Downgrade call.....	308
9.3.3.4.9	Merge of two calls	312
9.3.3.4.10	Call release after call establishment	312
9.3.3.4.11	Call release or reject before call establishment	313
9.3.3.4.12	Error handling.....	313
9.4	Off-network Broadcast group call	313
9.4.1	General.....	313
9.4.2	Basic call control	313
9.4.2.1	General	313
9.4.2.2	Broadcast group call control state machine.....	313
9.4.2.3	Broadcast group call Control states.....	314
9.4.2.3.1	B1: start-stop	314
9.4.2.3.2	B2: in-progress broadcast group call	314
9.4.2.3.3	B3: pending user action.....	314
9.4.2.3.4	B4: ignoring same call ID.....	314
9.4.2.4	Procedures.....	315
9.4.2.4.1	User initiating a broadcast group call	315
9.4.2.4.2	Terminating UE receiving a GROUP CALL BROADCAST message when not participating in the in-progress broadcast group call.....	315
9.4.2.4.3	MCVideo user accepts the terminating call.....	316
9.4.2.4.4	MCVideo user rejects the terminating call	316
9.4.2.4.5	MCVideo user does not act on terminating call	316
9.4.2.4.6	Terminating user releasing the call.....	316
9.4.2.4.7	Originating user releasing the call	316
9.4.2.4.8	Receiving GROUP CALL BROADCAST END message	317
9.4.2.4.9	Originating UE retransmitting GROUP CALL BROADCAST message.....	317
9.4.2.4.10	Ignoring same call ID	317
9.4.2.4.11	Releasing the call.....	317
10	Private call.....	318
10.1	General	318
10.2	Private call in on-network	318
10.2.1	General.....	318
10.2.2	Private call with transmission control.....	318
10.2.2.1	General	318
10.2.2.2	MCVideo client procedures	319
10.2.2.2.1	Client originating procedures	319
10.2.2.2.2	Client terminating procedures	321
10.2.2.2.3	Client terminating procedures for reception of SIP re-INVITE request	323
10.2.2.2.4	MCVideo in-progress emergency cancel.....	324
10.2.2.2.5	Upgrade to MCVideo emergency private call	325
10.2.2.3	Participating MCVideo function procedures.....	326
10.2.2.3.1	Originating procedures	326
10.2.2.3.2	Terminating procedures.....	334
10.2.2.3.3	Receipt of SIP re-INVITE request by terminating participating function	336
10.2.2.4	Controlling MCVideo function procedures.....	337
10.2.2.4.1	Originating procedures	337
10.2.2.4.2	Terminating procedures.....	338
10.2.2.4.3	Receiving a SIP re-INVITE for upgrade to emergency private call	341
10.2.2.4.4	Receiving a SIP re-INVITE for cancellation of emergency private call	342
10.2.2.4.5	Sending a SIP re-INVITE for upgrade to emergency private call	344
10.2.2.4.6	Sending a SIP re-INVITE for cancellation of emergency private call.....	344
10.2.3	Private call without transmission control.....	345
10.2.3.1	MCVideo client procedures	345
10.2.3.2	Participating MCVideo function procedures.....	345
10.2.3.2.1	Originating procedures	345
10.2.3.2.2	Terminating procedures.....	345
10.2.3.3	Controlling MCVideo function procedures.....	346
10.2.3.3.1	Originating procedures	346
10.2.3.3.2	Terminating procedures.....	346
10.2.4	Ending the private call initiated by MCVideo client	346

10.2.4.1	MCVideo client procedures	346
10.2.4.1.1	On-demand private call	346
10.2.4.2	Participating MCVideo function procedures.....	346
10.2.4.2.1	Originating procedures	346
10.2.4.2.2	Terminating procedures.....	346
10.2.4.3	Controlling MCVideo function procedures.....	346
10.2.4.3.1	Terminating procedures.....	346
10.2.5	Ending the private call initiated by the MCVideo server.....	347
10.2.5.1	General.....	347
10.2.5.2	MCVideo client procedures	347
10.2.5.3	Participating MCVideo function procedures.....	347
10.2.5.3.1	Originating procedures	347
10.2.5.3.2	Terminating procedures.....	347
10.2.5.4	Controlling MCVideo function procedures.....	347
10.3	Off-network private call	347
10.3.1	General.....	347
10.3.1.1	Common procedures	347
10.3.1.1.1	Sending/Receiving a message	347
10.3.1.1.2	Session description	347
10.3.2	Basic call control	349
10.3.2.1	General	349
10.3.2.2	Private call control state machine.....	349
10.3.2.3	Private call control states	349
10.3.2.3.1	P0: start-stop.....	349
10.3.2.3.2	P1: ignoring same call id	349
10.3.2.3.3	P2: waiting for call response	350
10.3.2.3.4	P3: waiting for release response	350
10.3.2.3.5	P4: part of ongoing call	350
10.3.2.3.6	P5: pending.....	350
10.3.2.4	Procedures.....	350
10.3.2.4.1	General	350
10.3.2.4.2	Private call setup.....	350
10.3.2.4.3	Private call setup in automatic commencement mode.....	353
10.3.2.4.4	Private call setup in manual commencement mode.....	356
10.3.2.4.5	Private call release.....	360
10.3.2.4.6	Error handling.....	362
11	Emergency Alert	362
11.1	General	362
11.2	On-network emergency alert	362
11.2.1	Client procedures	362
11.2.1.1	Emergency alert origination.....	362
11.2.1.2	Emergency alert cancellation	364
11.2.1.3	MCVideo client receives an MCVideo emergency alert or call notification	365
11.2.1.4	MCVideo client receives notification of entry into or exit from a group geographic area.....	367
11.2.1.5	MCVideo client receives notification of entry into or exit from an emergency alert area	368
11.2.2	Participating MCVideo function procedures	368
11.2.2.1	Receipt of a SIP MESSAGE request for emergency notification from the served MCVideo client...368	
11.2.2.2	Receipt of a SIP MESSAGE request for emergency notification for terminating MCVideo client....370	
11.2.2.3	Receipt of a SIP MESSAGE request indicating successful delivery of emergency notification	370
11.2.3	Controlling MCVideo function procedures	371
11.2.3.1	Handling of a SIP MESSAGE request for emergency notification.....	371
11.2.3.2	Handling of a SIP MESSAGE request for emergency alert cancellation.....	372
11.2.3.3	Late emergency alert initiated by controlling MCVideo function.....	375
11.3	Off-network emergency alert	376
11.3.1	General.....	376
11.3.2	Basic state machine.....	376
11.3.2.1	General	376
11.3.2.2	Emergency alert state machine.....	376
11.3.2.3	Emergency alert states.....	376
11.3.2.3.1	E1: Not in emergency state.....	376
11.3.2.3.2	E2: Emergency state	376

11.3.3	Procedures.....	377
11.3.3.1	Originating user sending emergency alert.....	377
11.3.3.2	Emergency alert retransmission	377
11.3.3.3	Terminating user receiving emergency alert	377
11.3.3.4	Terminating user receiving retransmitted emergency alert	378
11.3.3.5	Originating user cancels emergency alert	378
11.3.3.6	Terminating user receives GROUP EMERGENCY ALERT CANCEL message	378
11.3.3.7	Implicit emergency alert cancel	379
12	Video Pull.....	379
12.1	General	379
12.2	On-network video pull.....	379
12.2.1	General.....	379
12.1A	On-network MCVideo adhoc group emergency alert	379
12.1A.1	Client procedures	379
12.1A.1.1	Ad hoc group emergency alert origination.....	379
12.1A.1.2	Ad hoc group emergency alert cancellation	381
12.1A.1.3	MCVideo client receives an MCVideo adhoc group emergency alert notification.....	382
12.1A.2	Participating MCVideo function procedures	383
12.1A.2.1	Receipt of a SIP MESSAGE request for adhoc group emergency notification from the served MCVideo client.....	383
12.1A.2.2	Receipt of a SIP MESSAGE request for adhoc group emergency notification for terminating MCVideo client.....	384
12.1A.2.3	Receipt of a SIP MESSAGE request indicating successful delivery of adhoc group emergency notification of originating MCVideo client.....	385
12.1A.2.4	Adhoc group emergency alert participants modify procedure initiated by participating MCVideo function	386
12.1A.3	Controlling MCVideo function procedures	386
12.1A.3.1	Handling of adhoc group emergency alert notification	386
12.1A.3.2	Handling of adhoc group emergency alert cancellation	387
12.1A.3.3	Handling of ongoing adhoc group emergency alert	388
12.1A.3.4	Handling of adhoc group emergency alert participants modify procedure initiated by participating MCVideo function	389
12.2.2	MCVideo client procedures	390
12.2.2.1	One-to-one video pull originating procedures.....	390
12.2.2.2	One-to-one video pull terminating procedures.....	390
12.2.2.3	One-to-one video pull release procedures	390
12.2.2.4	One-from-server video pull originating procedures	390
12.2.2.5	One-from-server video pull terminating procedures	390
12.2.2.6	One-from-server video pull release procedures	390
12.2.3	MCVideo server procedures	391
12.2.3.1	Participating MCVideo function procedures.....	391
12.2.3.1.1	One-to-one video pull originating procedures	391
12.2.3.1.2	One-to-one video pull terminating procedures	391
12.2.3.1.3	One-to-one video pull release procedures	391
12.2.3.1.4	One-from-server video pull originating procedures	391
12.2.3.1.5	One-from-server video pull terminating procedures.....	391
12.2.3.1.6	One-from-server video pull release procedures	391
12.2.3.2	Controlling MCVideo function procedures.....	391
12.2.3.2.1	One-to-one video pull originating procedures	391
12.2.3.2.2	One-to-one video pull terminating procedures	391
12.2.3.2.3	One-to-one video pull release procedures	392
12.2.3.2.4	One-from-server video pull originating procedures	392
12.2.3.2.5	One-from-server video pull terminating procedures.....	392
12.2.3.2.6	One-from-server video pull release procedures	392
12.3	Off-network video pull	392
12.3.1	General.....	392
12.3.2	MCVideo client procedures	392
12.3.2.1	Off network video pull setup.....	392
12.3.2.1.1	Initiating video pull	392
12.3.2.1.2	Video pull setup request accepted	393
12.3.2.2	Off network video pull setup in automatic commencement mode	393

12.3.2.2.1	Responding to video pull setup request when not participating in the ongoing call.....	393
12.3.2.2.2	Establishing the video pull call.....	393
13	Video Push	393
13.1	General	393
13.2	On-network video push	393
13.2.1	General.....	393
13.2.2	MCVideo client procedures	393
13.2.2.1	One-to-one video push originating procedures	393
13.2.2.2	One-to-one video push terminating procedures	394
13.2.2.3	One-to-one video push release procedures.....	394
13.2.2.4	One-to-server video push originating procedures	394
13.2.2.5	One-to-server video push release procedures.....	394
13.2.3	MCVideo server procedures	394
13.2.3.1	Participating MCVideo function procedures.....	394
13.2.3.1.1	One-to-one video push originating procedures.....	394
13.2.3.1.2	One-to-one video push terminating procedures	394
13.2.3.1.3	One-to-one video push release procedures	395
13.2.3.1.4	One-to-server video push originating procedures.....	395
13.2.3.1.5	One-to-server video push release procedures	395
13.2.3.2	Controlling MCVideo function procedures.....	395
13.2.3.2.1	One-to-one video push terminating procedures.....	395
13.2.3.2.2	One-to-one video push release procedures	395
13.2.3.2.3	One-to-server video push terminating procedures.....	396
13.2.3.2.4	One-to-server video push release procedures	396
13.3	Off-network video push.....	396
13.3.1	General.....	396
13.3.1.1	Common Procedures	396
13.3.1.1.1	Sending/Receiving a message	396
13.3.2	MCVideo client procedures	397
13.3.2.1	Video push to another MCVideo user.....	397
13.3.2.1.1	Private video push call setup	397
13.3.2.1.2	Private video push call setup in manual commencement mode.....	397
13.3.2.1.3	Private video push call release.....	397
13.3.2.1.4	Sending video push notification	397
13.3.2.1.5	Receiving video push notification	398
13.3.2.2	Remotely initiated video push.....	398
13.3.2.2.1	Initiating a remote video push request.....	398
13.3.2.2.2	Sending video push trying response	398
13.3.2.2.3	Private video push call setup	399
13.3.2.2.4	Private video push call setup in manual commencement mode.....	399
13.3.2.2.5	Private video push call release.....	399
13.3.2.2.6	Sending video push notification	399
13.3.2.2.7	Receiving video push notification	400
13.3.2.3	Remotely initiated video push to a group.....	400
13.3.2.3.1	Initiating a remote video push request to a group.....	400
13.3.2.3.2	Group video push call setup	400
13.3.3	Void	401
14	Capability information sharing.....	401
14.1	General	401
14.2	On-network capability information sharing	401
14.2.1	General.....	401
14.2.2	MCVideo client procedures	401
14.2.3	MCVideo server procedures	401
14.3	Off-network capability information sharing.....	401
14.3.1	General.....	401
14.3.2	MCVideo client procedures	401
14.3.3	MCVideo server procedures	401
15	Ambient viewing call	401
15.1	General	401
15.2	MCVideo client procedures.....	402