



**Digital cellular telecommunications system (Phase 2+) (GSM);
Universal Mobile Telecommunications System (UMTS);
LTE;
5G;
Universal Subscriber Identity Module (USIM)
Application Toolkit (USAT)
(3GPP TS 31.111 version 17.14.0 Release 17)**



ReferenceRTS/TSGC-0631111vhe0

Keywords5G,GSM,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards application](#).

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver repository](#).

Users should be aware that the present document may be revised or have its status changed, this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our [Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2025.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2025-06)

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	12
1 Scope	14
2 References	14
3 Definitions, abbreviations and symbols	17
3.1 Definitions	17
3.2 Abbreviations	17
3.3 Symbols.....	18
4 Overview of USAT	18
4.1 Profile Download	19
4.2 Proactive UICC	19
4.3 Data download to UICC	19
4.4 Menu selection	19
4.5 Call control by USIM	19
4.6 MO Short Message control by USIM.....	19
4.7 Event download.....	19
4.8 Security	20
4.9 Multiple card	20
4.10 Timer Expiration	20
4.11 Bearer Independent Protocol	20
4.12 Description of the access technology indicator mechanism	20
4.13 Description of the network search mode mechanism	20
4.14 Geographical location discovery	20
4.15 Operation in reduced USAT capable terminals	20
4.16 Tag allocation guidelines.....	21
4.17 USAT over the AT interface	21
4.18 USAT facilities provided by eCAT clients.....	21
4.19 Negotiation of Poll Interval	21
4.20 ProSe usage information reporting	21
4.21 5G ProSe usage information reporting	21
5 Profile download	21
5.1 Procedure.....	21
5.2 Structure and coding of TERMINAL PROFILE.....	22
5.3 Definition of display parameters in Profile download.....	27
6 Proactive UICC	28
6.1 Introduction	28
6.2 Identification of ME support	28
6.3 General procedure	28
6.4 Proactive UICC commands and procedures	28
6.4.1 DISPLAY TEXT	28
6.4.2 GET INKEY	28
6.4.3 GET INPUT.....	28
6.4.4 MORE TIME	28
6.4.5 PLAY TONE	28
6.4.6 POLL INTERVAL	28
6.4.7 REFRESH.....	28
6.4.7.1 EF _{IMSI} changing procedure	29
6.4.7.2 Generic Bootstrapping Procedure Request.....	29
6.4.7.3 EF _{UICCIARI} changing procedure	29
6.4.7.4 Steering of roaming and steering of roaming for I-WLAN procedure	29

6.4.7.5	Steering of roaming via NAS messages	30
6.4.7.6	Routing Indicator Data update via NAS messages	30
6.4.7.7	EF _{SUPL_NAI} changing procedure	30
6.4.7.8	EF _{DRI} changing procedure	30
6.4.7.9	EF _{5GNSWO_CONF} changing procedure	30
6.4.8	SET UP MENU	31
6.4.9	SELECT ITEM	31
6.4.10	SEND SHORT MESSAGE	31
6.4.11	SEND SS	32
6.4.12	SEND USSD	33
6.4.12.1	MMI Mode	33
6.4.12.2	Application Mode	34
6.4.13	SET UP CALL	34
6.4.14	POLLING OFF	35
6.4.15	PROVIDE LOCAL INFORMATION	35
6.4.16	SET UP EVENT LIST	38
6.4.17	PERFORM CARD APDU	38
6.4.18	POWER OFF CARD	38
6.4.19	POWER ON CARD	38
6.4.20	GET READER STATUS	38
6.4.21	TIMER MANAGEMENT	38
6.4.22	SET UP IDLE MODE TEXT	38
6.4.23	RUN AT COMMAND	38
6.4.24	SEND DTMF	38
6.4.25	LANGUAGE NOTIFICATION	38
6.4.26	LAUNCH BROWSER	38
6.4.27	OPEN CHANNEL	39
6.4.27.1	OPEN CHANNEL related to CS bearer	39
6.4.27.2	OPEN CHANNEL related to GPRS/UTRAN packet service/E-UTRAN/Satellite E-UTRAN/NG-RAN/Satellite NG-RAN	39
6.4.27.3	OPEN CHANNEL related to local bearer	40
6.4.27.4	OPEN CHANNEL related to Default (network) Bearer	40
6.4.27.5	OPEN CHANNEL related to (I-)WLAN bearer	40
6.4.27.6	OPEN CHANNEL related to Terminal Server Mode	41
6.4.27.7	OPEN CHANNEL related to UICC Server Mode	41
6.4.27.8	OPEN CHANNEL for IMS	41
6.4.28	CLOSE CHANNEL	42
6.4.29	RECEIVE DATA	42
6.4.30	SEND DATA	42
6.4.31	GET CHANNEL STATUS	42
6.4.32	SERVICE SEARCH	42
6.4.33	GET SERVICE INFORMATION	42
6.4.34	DECLARE SERVICE	42
6.4.35	RETRIEVE MULTIMEDIA MESSAGE	42
6.4.36	SUBMIT MULTIMEDIA MESSAGE	43
6.4.37	DISPLAY MULTIMEDIA MESSAGE	43
6.4.38	SET FRAMES	43
6.4.39	GET FRAME STATUS	43
6.4.40	Geographical Location Request	43
6.4.41	ACTIVATE	44
6.4.42	CONTACTLESS STATE CHANGED	44
6.4.43	COMMAND CONTAINER	44
6.4.44	ENCAPSULATED SESSION CONTROL	44
6.5	Common elements in proactive UICC commands	44
6.5.1	Command number	44
6.5.2	Device identities	44
6.5.3	Alpha identifier	44
6.5.4	Icon identifiers	44
6.5.5	Text attribute	44
6.5.6	Frame identifier	45
6.6	Structure of proactive UICC commands	45
6.6.1	DISPLAY TEXT	45

6.6.2	GET INKEY	45
6.6.3	GET INPUT	45
6.6.4	MORE TIME	45
6.6.5	PLAY TONE	45
6.6.6	POLL INTERVAL	45
6.6.7	SET-UP MENU	45
6.6.8	SELECT ITEM	45
6.6.9	SEND SHORT MESSAGE	45
6.6.10	SEND SS	46
6.6.11	SEND USSD	46
6.6.12	SET UP CALL	46
6.6.13	REFRESH	47
6.6.14	POLLING OFF	48
6.6.15	PROVIDE LOCAL INFORMATION	48
6.6.16	SET UP EVENT LIST	48
6.6.17	PERFORM CARD APDU	48
6.6.18	POWER OFF CARD	48
6.6.19	POWER ON CARD	48
6.6.20	GET READER STATUS	49
6.6.21	TIMER MANAGEMENT	49
6.6.22	SET UP IDLE MODE TEXT	49
6.6.23	RUN AT COMMAND	49
6.6.24	SEND DTMF COMMAND	49
6.6.25	LANGUAGE NOTIFICATION	49
6.6.26	LAUNCH BROWSER	49
6.6.27	OPEN CHANNEL	49
6.6.27.1	OPEN CHANNEL related to (I-)WLAN Bearer	49
6.6.27.2	OPEN CHANNEL for IMS	50
6.6.28	CLOSE CHANNEL	50
6.6.29	RECEIVE DATA	50
6.6.30	SEND DATA	50
6.6.31	GET CHANNEL STATUS	50
6.6.32	SERVICE SEARCH	50
6.6.33	GET SERVICE INFORMATION	50
6.6.34	DECLARE SERVICE	51
6.6.35	RETRIEVE MULTIMEDIA MESSAGE	51
6.6.36	SUBMIT MULTIMEDIA MESSAGE	51
6.6.37	DISPLAY MULTIMEDIA MESSAGE	51
6.6.38	SET FRAMES	51
6.6.39	GET FRAMES STATUS	51
6.6.40	Geographical Location Request	51
6.6.41	ACTIVATE	51
6.6.42	CONTACTLESS STATE CHANGED	51
6.6.43	COMMAND CONTAINER	51
6.6.44	ENCAPSULATED SESSION CONTROL	51
6.7	Command results	52
6.8	Structure of TERMINAL RESPONSE	52
6.8.0	Overall structure of TERMINAL RESPONSE	52
6.8.1	Command details	54
6.8.2	Device identities	54
6.8.3	Result	54
6.8.4	Duration	54
6.8.5	Text string	54
6.8.6	Item identifier	55
6.8.7	Local information	55
6.8.8	Call control requested action	56
6.8.9	Result data object 2	56
6.8.10	Card reader status	56
6.8.11	Card ATR	56
6.8.12	R-APDU	56
6.8.13	Timer identifier	56
6.8.14	Timer value	56

6.8.15	AT Response.....	56
6.8.16	Text string 2.....	56
6.8.17	Channel data.....	56
6.8.18	Channel status.....	56
6.8.19	Channel data length.....	56
6.8.20	Bearer description.....	57
6.8.21	Buffer size.....	57
6.8.22	Total Display Duration.....	57
6.8.23	Service Availability.....	57
6.8.24	Service Record.....	57
6.8.25	Other address (local address).....	57
6.8.26	Frames Information.....	57
6.9	Proactive UICC session and ME display interaction.....	57
6.10	Handling of unknown, unforeseen and erroneous messages.....	57
6.11	Proactive commands versus possible Terminal response.....	57
7	ENVELOPE Commands.....	59
7.1	Data download to UICC.....	59
7.1.1	SMS-PP data download.....	59
7.1.1.1	Procedure.....	59
7.1.1.1a	Procedure for SMS-PP data download via REGISTRATION ACCEPT or DL NAS TRANSPORT messages.....	59
7.1.1.2	Structure of ENVELOPE (SMS-PP DOWNLOAD).....	60
7.1.2	Cell Broadcast data download.....	61
7.1.2.1	Procedure.....	61
7.1.2.2	Structure of ENVELOPE (CELL BROADCAST DOWNLOAD).....	62
7.2	Menu Selection.....	62
7.3	Call Control and MO SMS control by USIM.....	62
7.3.1	Call Control by USIM.....	62
7.3.1.1	Procedure for mobile originated calls.....	62
7.3.1.2	Procedure for Supplementary Services and USSD.....	64
7.3.1.3	Indication to be given to the user.....	64
7.3.1.4	Interaction with Fixed Dialling Number.....	65
7.3.1.5	Support of Barred Dialling Number (BDN) service.....	66
7.3.1.6	Structure of ENVELOPE (CALL CONTROL).....	66
7.3.1.7	Procedure for PDP Context Activation.....	69
7.3.1.8	Procedure for EPS PDN connection Activation.....	70
7.3.1.9	Procedure for IMS communications establishment.....	70
7.3.1.10	Procedure for PDU session establishment.....	71
7.3.2	MO Short Message Control by USIM.....	71
7.3.2.1	Description.....	71
7.3.2.2	Structure of ENVELOPE (MO SHORT MESSAGE CONTROL).....	72
7.3.2.3	Indication to be given to the user.....	73
7.3.2.4	Interaction with Fixed Dialling Number.....	73
7.4	Timer Expiration.....	73
7.5	Event download.....	73
7.5.1	(I-)WLAN Access status event.....	74
7.5.1.1	Procedure.....	74
7.5.1.2	Structure of ENVELOPE (EVENT DOWNLOAD – (I-)WLAN Access Status).....	74
7.5.1A	MT Call event.....	74
7.5.1A.1	Procedure.....	74
7.5.1A.2	Structure of ENVELOPE (EVENT DOWNLOAD - MT call).....	74
7.5.2	Network Rejection event.....	76
7.5.2.1	Procedure.....	76
7.5.2.2	Structure of ENVELOPE (EVENT DOWNLOAD – Network Rejection).....	76
7.5.2A	Call connected event.....	77
7.5.2A.1	Procedure.....	77
7.5.2A.2	Structure of ENVELOPE (EVENT DOWNLOAD - call connected).....	77
7.5.3	CSG Cell Selection event.....	77
7.5.3.1	Procedure.....	78
7.5.3.2	Structure of ENVELOPE (EVENT DOWNLOAD – CSG Cell Selection).....	78
7.5.3A	Call disconnected event.....	79