
**Aircraft ground equipment — Nose
gear towbarless towing vehicle (TLTV)
— Design, testing and maintenance
requirements —**

**Part 1:
Main line aircraft**

*Matériels au sol pour aéronefs — Tracteur sans barre (TLTV) de train
avant — Exigences de conception, essais et entretien —*

Partie 1: Aéronefs de ligne

get full document from standards.iteh.ai



Sample Document

get full document from standards.iteh.ai



COPYRIGHT PROTECTED DOCUMENT

© ISO 2016, Published in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Ch. de Blandonnet 8 • CP 401
CH-1214 Vernier, Geneva, Switzerland
Tel. +41 22 749 01 11
Fax +41 22 749 09 47
copyright@iso.org
www.iso.org

Contents

Page

Foreword	v
Introduction	vi
1 Scope	1
2 Normative references	1
3 Terms and definitions	2
4 Design requirements	4
4.1 General	4
4.2 Towing loads	4
4.3 Pick-up and holding system	5
4.4 Oversteering protection	5
4.5 Nose wheels retention	6
4.6 Safety	6
4.6.1 General	6
4.6.2 Pick-up, release and associated loads	6
4.6.3 Acceleration, deceleration and associated loads	6
4.6.4 Emergency braking	7
4.6.5 Oversteer limits	7
4.6.6 Oversteer alerting and/or protection	7
4.7 Testing operations	8
4.7.1 Snubbing and jerking	8
4.7.2 Vibrations	8
4.7.3 Aircraft braking	8
4.7.4 Stability	8
4.8 Nose gear steering angle limit	9
4.9 Vehicle classification	9
4.10 Placarding	9
5 Testing requirements	9
5.1 General	9
5.2 Testing objectives	9
5.3 Aircraft configuration	10
5.4 Calibration	10
5.4.1 General	10
5.4.2 Aircraft calibration	10
5.4.3 TLTV calibration	13
5.4.4 Oversteering calibration	14
5.5 Testing procedures	14
5.5.1 General	14
5.5.2 Data recording	14
6 Evaluation	15
6.1 Evaluation criteria	15
6.2 Normal condition testing	15
6.2.1 Testing methods	15
6.2.2 Tests number	15
6.2.3 Pushback	15
6.2.4 Maintenance towing	16
6.2.5 Pick-up and release	16
6.2.6 Test evaluation	16
6.3 Stability testing	17
6.4 Extreme condition testing	17
6.4.1 Testing methods	17
6.4.2 Static load tests	17
6.4.3 Maximum acceleration and braking	17

6.5	Oversteer testing.....	18
7	Maintenance.....	18
7.1	General.....	18
7.2	Maintenance manual.....	19
7.3	Requirements.....	19
7.4	Calibration.....	20
7.5	Special tools.....	20
7.6	Training.....	20
7.7	Maintenance records.....	20
8	Quality control.....	21
9	Traceability and accountability.....	22
10	Modifications.....	22
11	Operating instructions.....	23
	Bibliography.....	24

Sample Document

get full document from standards.iteh.ai

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation on the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see the following URL: www.iso.org/iso/foreword.html.

The committee responsible for this document ISO/TC 20, *Aircraft and space vehicles*, Subcommittee SC 9, *Air cargo and ground equipment*.

This second edition cancels and replaces the first edition (ISO 20683-1:2005), which has been technically revised.

A list of all parts in the ISO 20683 series can be found on the ISO website.

Introduction

This document specifies design, testing, maintenance and associated requirements to be applied on towbarless aircraft towing vehicles to be used on main line civil transport aircraft in order to ensure their operation cannot result in damage to aircraft nose landing gears, their steering systems, or associated aircraft structure.

Throughout this document, the minimum essential criteria are identified by the use of the key word “shall”. Other recommended criteria are identified by the use of the key word “should” and, while not mandatory, are considered to be of primary importance in providing safe and serviceable towbarless tractors. Alternative solutions may be adopted only after careful consideration, extensive testing and thorough service evaluation have shown them to be equivalent.

Sample Document

get full document from standards.iteh.ai

Aircraft ground equipment — Nose gear towbarless towing vehicle (TLTV) — Design, testing and maintenance requirements —

Part 1: Main line aircraft

1 Scope

This document is applicable to towbarless aircraft towing vehicles (TLTVs) interfacing with the nose landing gear of main line civil transport aircraft with a maximum ramp mass over 50 000 kg (110 000 lb). The requirements for regional transport aircraft with a lower maximum ramp mass are specified in ISO 20683-2. It is not applicable to TLTVs which were manufactured before its date of publication.

It specifies general design requirements, testing and evaluation requirements, maintenance, calibration, documentation, records, tracing and accountability requirements in order to ensure that the loads induced by the tow vehicle will not exceed the design loads of the nose gear or its steering system, or reduce the certified safe life limit of the nose gear, or induce a stability problem during aircraft pushback and/or gate relocation or maintenance towing operations.

This document specifies requirements and procedures for towbarless tow vehicles (TLTVs) intended for aircraft pushback and gate relocation or maintenance towing only. It is not intended to allow for dispatch (operational) towing (see [Clause 3](#)). Dispatch towing imposes greater loads on nose gears and aircraft structure due to the combination of speed and additional passenger, cargo, and fuel loads.

This document does not apply to towbarless towing vehicles interfacing with aircraft main landing gear.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

Federal Aviation Regulations (FAR) 14 CFR Part 25, *Airworthiness Standards: Transport category airplanes*, paragraphs 25.301, *Loads*, and 25.509, *Towing loads*.¹⁾

Certification Specifications and Acceptable Means of Compliance for Large Aeroplanes CS-25, paragraphs 25.301, *Loads*, 25.509, *Towing loads*, 25.745(d), *Nose-wheel steering*, and AMC 25.745(d).²⁾

ISO 6966-1, *Aircraft ground equipment — Basic requirements — Part 1: General design requirements*

ISO 6966-2, *Aircraft ground equipment — Basic requirements — Part 2: Safety requirements*

1) FAR Part 25 constitute the U.S.A. Government transport aircraft airworthiness Regulations, and can be obtained from: US Government Printing Office, Mail Stop SSOP, Washington DC 20402-9328, U.S.A.

2) EASA CS25 constitute the European Governments transport aircraft airworthiness Regulations, and can be obtained from: European Aviation Safety Agency: Ottoplatz 1, D-50679 Cologne, Germany - <http://easa.europa.eu/official-publication/>.

3 Terms and definitions

For the purpose of this document, the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- IEC Electropedia: available at <http://www.electropedia.org/>
- ISO Online browsing platform: available at <http://www.iso.org/obp>

3.1 main line aircraft

civil passenger and/or freight transport aircraft with a *maximum ramp mass* (3.3) over 50 000 kg (110 000 lb)

3.2 regional aircraft

civil passenger and/or freight transport aircraft with a *maximum ramp mass* (3.3) between 10 000 kg (22 000 lb) and 50 000 kg (110 000 lb)

3.3 maximum ramp mass

maximum ramp weight
MRW

maximum mass allowable for an aircraft type when leaving its parking position either under its own power or towed, comprising maximum structural take-off mass (MTOW) and taxiing fuel allowance

3.4 pushback

moving a fully loaded aircraft [up to *maximum ramp mass* (3.3) (MRW)] from the parking position to the taxiway. movement includes pick-up, push back with turn, a stop, a short push or tow to align aircraft and nose wheels, and release

Note 1 to entry: Engines may or may not be operating. Aircraft movement is similar to a conventional pushback operation with a tow bar. Typical speed does not exceed 10 km/h⁻¹ (6 mph).

3.5 maintenance towing

movement of an aircraft for maintenance/remote parking purposes (e.g. from the parking position to a maintenance hangar)

Note 1 to entry: The aircraft is typically unloaded with minimal fuel load (reference light gross weight, LGW), with speeds up to 32 km/h⁻¹ (20 mph).

3.6 gate relocation towing

movement of an aircraft from one parking position to an adjacent one or one in the same general area

Note 1 to entry: The aircraft is typically unloaded with minimal fuel load (reference light gross weight, LGW), with speeds intermediate between pushback and maintenance towing.

3.7 dispatch towing operational towing

towing a revenue aircraft [loaded with passengers, fuel, and cargo up to *maximum ramp mass* (3.3) (MRW)] from the terminal gate/remote parking area, to a location near the active runway, or conversely

Note 1 to entry: The movement may cover several kilometres with speeds up to or over 32 km/h⁻¹ (20 mph), with several starts, stops and turns. Replaces typical taxiing operations prior to takeoff or after landing.

Note 2 to entry: In the definitions of the towing modes, the frequency of operation has not been included. This should not be interpreted to mean that no limitations are present. For limitations on the frequency of pushback and maintenance operations, refer to the appropriate airframe manufacturer's documentation or consult directly with the airframe manufacturer.

3.8

towbarless towing vehicle

TLTV

towing vehicle acting without tow bar on an aircraft's *nose landing gear* (3.9)

3.9

nose landing gear

NLG

aircraft nose landing gear in a tricycle landing gear layout

3.10

actual test gross weight

ATGW

reference aircraft mass for testing of the vehicle and aircraft, defined as the manufacturer's operating empty mass of the aircraft type concerned, plus fuel remaining in the tanks but lower than STGW

3.11

specified test gross weight

STGW

reference aircraft mass for testing of the vehicle and aircraft, defined as the manufacturer's operating empty mass of the aircraft concerned, plus at least 50 % of the maximum total fuel tanks capacity on the type, or its equivalent in mass (payload may be accounted if present, providing aircraft balance condition remains within limits)

3.12

maximum limits

limits (fore and aft tractive force, torsional, or angular) established by the airframe manufacturer as not-to-exceed values intended to preclude possible damage to *nose landing gear* (3.9) or structure

Note 1 to entry: Maximum limits are established by airframe manufacturer's documentation and may be different for towbarless or tow bar towing operations. All aircraft load limits are limit loads as defined in FAR/EASA CS paragraph 25.301 (a).

3.13

operational limits

limits (fore and aft tractive force, torsional, or angular) which are set at a lesser value than the *maximum limits* (3.12) established by the airframe manufacturer

3.14

aircraft family

grouping of aircraft types or subtypes, defined by their manufacturer, for which the same *maximum limits* (3.12) may be applied

Note 1 to entry: A family usually encompasses all sub-types of a given type, but may also include other types. Testing for one (usually the lightest) model of the family results in towbarless towing approval for the whole family. See airframe manufacturer's towbarless towing evaluation documentation.

3.15

TLTV setting

grouping of aircraft types or sub-types, defined by the TLTV manufacturer, for which a single *operational limits* (3.13) setting is used

Note 1 to entry: A single TLTV setting usually encompasses aircraft types or sub-types, which may be produced by different airframe manufacturers, in a same defined MRW range.