
**Road vehicles — Ergonomics aspects
of transport information and control
systems — Human machine interface
specifications for keyless ignition
systems**

*Véhicules routiers — Aspects ergonomiques des systèmes de
commande et d'information du transport — Spécifications d'interface
homme-machine pour des systèmes de démarrage sans clé*

(<https://standards.iteh.ai>)
Document Preview

ISO 21956:2019

<https://standards.iteh.ai/catalog/standards/iso/5ec3714e-426e-43ed-97e0-ca15913deec3/iso-21956-2019>



iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ISO 21956:2019

<https://standards.iteh.ai/catalog/standards/iso/5ec3714e-426e-43ed-97e0-ca15913deec3/iso-21956-2019>



COPYRIGHT PROTECTED DOCUMENT

© ISO 2019

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Fax: +41 22 749 09 47
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

Page

Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Design guidelines	3
4.1 Actuation of keyless ignition control.....	3
4.1.1 Actuation for emergency starting – Restarting the propulsion system after unintended engine stall.....	3
4.1.2 Actuation for starting – Design to avoid accidental starting – Stationary vehicle ..	3
4.1.3 Actuation for stopping while a vehicle with automatic start/stop is in run mode.	3
4.1.4 Actuation for stopping (commercial vehicles only) – Design to avoid accidental stopping - Stationary vehicle.....	3
4.1.5 Actuation for emergency stopping – Interruption of starting.....	3
4.2 Starting a propulsion system in case key code carrying device battery runs out.....	3
4.2.1 Operation methods.....	4
4.2.2 Instructions in case key code carrying device battery runs out.....	4
4.3 Alerts and information to the driver.....	4
4.3.1 Key left in vehicle.....	4
4.3.2 Missing key code carrying device when starting vehicle propulsion system.....	4
4.3.3 Ignition mode active at exit.....	5
4.3.4 Ignition mode active at exit (commercial vehicles only).....	5
4.3.5 Key code carrying device leaves the vehicle.....	5
4.3.6 Power shut off without key code carrying device.....	6
4.3.7 Power shut off when not in “parked” or without activated parking brake for automatic transmission vehicles.....	6
4.3.8 Power shut off when not in “parked” or “neutral” for automatic transmission vehicles (commercial vehicles only).....	7
4.3.9 Steering not unlocked.....	7
Annex A (informative) Keyless ignition control use cases	8
Bibliography	11