

Designation: D1388 - 18 D1388 - 23

# Standard Test Method for Stiffness of Fabrics<sup>1</sup>

This standard is issued under the fixed designation D1388; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\varepsilon$ ) indicates an editorial change since the last revision or reapproval.

This standard has been approved for use by agencies of the U.S. Department of Defense.

### 1. Scope Scope\*

- 1.1 This test method covers the measurement of stiffness properties of fabrics. Bending length is measured and flexural rigidity is calculated. Two procedures are provided.
- 1.1.1 Option A—Cantilever Test, employing the principle of cantilever bending of the fabric under its own mass.
- 1.1.2 Option B—Heart Loop Test, employing the principle of a loop formed in a fabric strip and hung vertically.
- 1.2 This test method applies to most fabrics including woven fabrics, air bag fabrics, blankets, napped fabrics, knitted fabrics, layered fabrics, pile fabrics. The fabrics may be untreated, heavily sized, coated, resin-treated, or otherwise treated.
- 1.2.1 This method may be used to determine the stiffness of nonwoven materials (for example, hydroentangled, dry laid, needlepunch, resin bonded, thermal, and wet laid) or refer to Test Method D5732. To determine the stiffness of medical textiles (for example, surgical mesh, films, and membranes), refer to Test Method F3260.

Note 1—The formula to calculate flexural rigidity in D5732-95 (2001) is incorrect and should not be used. Utilize the formula presented in 11.5 of Test Method D1388.

- 1.3 <u>Units—</u>The values stated in SI units are to be regarded as the standard. The <del>U.S. customary units may be approximate.</del>values given in parentheses after SI units are provided for information only and are not considered standard.
- 1.4 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of regulatory limitations prior to use.
- 1.5 This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.

### 2. Referenced Documents

2.1 ASTM Standards:<sup>2</sup>

<sup>&</sup>lt;sup>1</sup> This test method is under the jurisdiction of ASTM Committee D13 on Textiles and is the direct responsibility of Subcommittee D13.60 on Fabric Test Methods, Specific Physical Test Methods B.

Current edition approved July 1, 2018 Aug. 1, 2023. Published October 2018 August 2023. Originally approved in 1956. Last previous edition approved in 2014 2018 as D1388-14-18.1-1. DOI: 10.1520/D1388-18-10.1520/D1388-23.

<sup>&</sup>lt;sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

D123 Terminology Relating to Textiles

D1776 Practice for Conditioning and Testing Textiles

D2904 Practice for Interlaboratory Testing of a Textile Test Method that Produces Normally Distributed Data (Withdrawn 2008)<sup>3</sup>

D2906 Practice for Statements on Precision and Bias for Textiles (Withdrawn 2008)<sup>3</sup>

D3776 Test Methods for Mass Per Unit Area (Weight) of Fabric

D4850 Terminology Relating to Fabrics and Fabric Test Methods

D5732 Test Method for Stiffness of Nonwoven Fabrics Using the Cantilever Test (Withdrawn 2008)<sup>3</sup>

F3260 Test Method for Determining the Flexural Stiffness of Medical Textiles

### 3. Terminology

- 3.1 For all terminology relating to D13.59, Fabric Test Methods, General, refer to Terminology D4850.
- 3.1.1 The following terms are relevant to this standard: bending length, cross-machine direction, <del>CD,(CD), fabric, flexural rigidity, machine direction, MD,(MD), stiffness.</del>

Note 2—Machine direction (MD) may represent wale and warp directions and cross-machine direction (CD) may represent course and weft directions in knit fabrics or woven fabrics or both.

3.2 For all other terminology related to textiles, refer to Terminology D123.

### 4. Summary of Test Method Options

4.1 *Option A, Cantilever Test*—A specimen is slid at a specified rate in a direction parallel to its long dimension, until its leading edge projects from the edge of a horizontal surface. The length of the overhang is measured when the tip of the specimen is depressed under its own mass to the point where the line joining the toptip to the edge of the platform makes a 0.724 rad (41.5°) angle with the horizontal. From this measured length, the length and the specimen's fabric mass per unit area, the bending length and flexural rigidity are calculated.

Note 3—When the tip of the specimen reaches a plane inclined at 41.5° below the horizontal, the overhanging length is then twice the bending length.

- 4.1.1 The Cantilever Test option is the preferred procedure because it is simpler to perform. It is, however, not suitable for very limp fabrics or those that show a marked tendency to curl or twist at a cut edge (see Fig. 1 and Note 12).
- 4.2 *Option B, Heart Loop Test*—A strip of fabric is formed into a heart-shaped loop. The length of the loop is measured when it is hanging vertically under its own mass. From this measured length, the length and the specimen's fabric mass per unit area, the bending length and flexural rigidity are calculated.
- 4.2.1 The Heart Loop Test option is suitable for fabrics that show a tendency to curl or twist.




FIG. 1 Fabric Examples Not Suitable for Cantilever Test

<sup>&</sup>lt;sup>3</sup> The last approved version of this historical standard is referenced on www.astm.org.



- 4.3 The two methods will not necessarily give the same numerical values or rank different types of fabrics in the same order. Both options can provide a correlation with a subjective evaluation of a given fabric type. That is, a higher number represents a stiffer fabric.
- 5. Significance and Use
- 5.1 In general, these procedures are more suitable for testing woven fabrics than knit fabrics.
- 5.2 Both test options in this test method are considered satisfactory for acceptance testing of commercial shipments since current estimates of between-laboratory precision are acceptable and the method is used extensively in the trade for acceptance testing.
- 5.2.1 In case of a dispute arising from differences in reported test results when using this test method for acceptance testing of commercial shipments, the purchaser and the supplier should conduct comparative tests to determine if there is a statistical bias between their laboratories. Competent statistical assistance is recommended for the investigation of bias. As a minimum, the two parties should take a group of test specimens that are as homogeneous as possible and that are from a lot of material of the type in question. Test specimens should then be randomly assigned in equal numbers to each laboratory for testing. The average results from the two laboratories should be compared using the appropriate statistical analysis and an acceptable probability level chosen by the two parties before testing is begun. If a bias is found, either its cause must be found and corrected or the purchaser and the supplier must agree to interpret future test results with consideration to the known bias.
- 5.2 In general, these procedures are more suitable for testing woven fabrics than knit fabrics.
- 5.3 The Cantilever Test Option is the preferred procedure because it is simpler to perform. It is, however, not suitable for very limp fabrics or those that show a marked tendency to curl or twist at a cut edge.
- 5.4 The Heart Loop Test Option is suitable for fabrics that show a tendency to curl or twist.
- 5.5 Both options can provide a correlation with a subjective evaluation of a given fabric type. That is, a higher number represents a stiffer fabric.
- 5.3 The stiffness of a fabric may change with storage.
- 5.4 No evidence has been found showing that bending length is dependent on the width. width of the test specimen. The tendency for specimens to curl or twist will affect the result, because of the rigidity provided at the edge. edge of the specimen. Consequently, the wider the strip, the less important is the edge effect. For fabrics having only a slight tendency to curl, a 2.5 cm wide strip has been found to be satisfactory. As the tendency to curl increases, this width may be increased (see Note 10).
- 5.5 This method differs from Test Method F3260 which requires tracking of sample surface orientation, and is used to evaluate absorbable and partially absorbable medical textiles.

#### 6. Apparatus

- 6.1 Option A—Cantilever Bending Tester<sup>4</sup> (Fig. 42).
- 6.1.1 *Horizontal Platform*, with a minimum area of 38 mm by 200 mm (1.5 in. by 8 in.) and having a smooth, low-friction, flat surface such as polished metal or plastic.
- <u>6.1.2 Bend Angle Indicator</u>, inclined at an angle of 0.724 rad  $\pm$  0.01 rad (41.5°  $\pm$  0.5°) below the plane of the horizontal platform surface.
- 6.1.3 *Horizontal Platform*, *Movable Specimen Slide*, with a minimum area of 38-consisting of a metal bar not less than 25 mm by 200 mm (1.5(1 in. by 8 in.) by approximately 3 mm (1/8 in.) thick and having a smooth low-friction, flat surface such as polished

<sup>&</sup>lt;sup>4</sup> Apparatus is available commercially.






FIG. 12 Example of a Motorized Cantilever Test Apparatus Cantilever Bending Tester

metal or plastic. A leveling bubble shall be incorporated in the platform. mass of 270 g  $\pm$  5 g (0.6 lb  $\pm$  0.01 lb). A motorized specimen feed unit set to 120 mm/min  $\pm$  5 % (4.75 in./min  $\pm$  5 %) may be used.

6.1.1.1 Indicator, inclined at an angle of 0.724  $\pm$  0.01 rad (41.5  $\pm$  0.5°) below the plane of the platform surface.

6.1.1.2 Movable Slide, consisting of a metal bar not less than 25 by 200 mm (1 by 8 in.) by approximately 3 mm ( $\frac{1}{8}$  in.) thick and having a mass of 270  $\pm$  5 g (0.6  $\pm$  0.01 lb).

6.1.1.3 Scale and Reference Point, to measure the length of the overhang.

6.1.1.4 Specimen Feed Unit, motorized (see Fig. 1) set to 120 mm/min (4.75 in./min) ±5 %, or manual equivalent.

6.1.4 Cutting Die—Scale,  $\frac{25 \pm 1 \text{ mm}}{25 \pm 1 \text{ mm}}$  by  $\frac{200 \pm 1 \text{ mm}}{25 \pm 1 \text{ mm}}$  (1 ± 0.04 in. by 8 ± 0.04 in.) to measure the length of the overhang.

Note 4—The original instrument this method is based on included a scale demarcated in centimeters of bending length.

6.2 Cutting Die (optional)—25 mm  $\pm$  1 mm by 200  $\pm$  1 mm (1 in.  $\pm$  0.04 in. by 8 in.  $\pm$  0.04 in.).

6.3 Option B—Heart Loop Tester. Tester (Fig. 3.)

6.3.1 Clamp and Stand, for hanging the specimen.

Note 5—A convenient method for mounting and measuring the specimen involves the use of two bars 25 mm by 75 mm by 3 mm (1 in. by 3 in. by 0.125 in.), to which the strip is fastened and a clip for holding these bars and the attached strip in a suitable position in front of scale.

6.3.2 *Scale*, suitably mounted on the stand for measuring the length of the specimen loop and calibrated either in cm (in.) or directly in bending length.


Note 6—If a constant strip length is adopted, the scale may be calibrated to read directly in units of bending length.

6.2.3 Brass Bars, two,  $25 \times 75 \times 3 \pm 0.1$  mm  $(1 \times 3 \times 0.125 \pm 0.005$  in.).

6.2.4 Pressure Sensitive Tape.

6.2.5 Jig, constructed to allow positioning of the two bars with their inner edges parallel and at a distance from each other equal to the selected strip length (see Fig. 2).





Leveling Legs

FIG. 23 Example of a Heart Loop Tester

# iTeh Standards

6.4 Pressure Sensitive Tape.

# (https://standards.iteh.ai)

6.5 *Jig (optional)*, constructed to allow positioning of the two bars with their inner edges parallel and at a distance from each other equal to the selected strip length.

6.6 Balance, having a capacity and sensitivity to weigh within ± 0.1 % of the specimen weight being tested.

### 7. Sampling and Test Specimens

7.1 Lot Sample—As a lot sample for acceptance testing, randomly select the number of rolls or pieces of fabric directed in an applicable material specification or other agreement between the purchaser and the supplier. Consider the rolls or pieces of fabric to be the primary sampling units. In the absence of such an agreement, take the number of fabric rolls specified in Table 1.

Note 7—An adequate specification or other agreement between the purchaser and supplier requires taking into account the variability between rolls or pieces of fabric and between specimens from a swatch from a roll or piece of fabric to provide a sampling plan with a meaningful producer's risk, consumer's risk, acceptable quality level, and limiting quality level.

- 7.2 Laboratory Sample—For acceptance testing, take a swatch extending the width of the fabric and approximately 1 m (1 yd) along the machine direction (MD) from each roll or piece in the lot sample. For rolls of fabric, take a sample that will exclude fabric from the outer wrap of the roll or the inner wrap around the core of the roll of fabric, or any end piece.
- 7.3 Direction of Test—Consider the long dimension of the specimen as the direction of test.

TABLE 1 Number of Rolls, or Pieces, of Fabric in the Lot Sample

Number of Rolls or Pieces in Lot, Inclusive	Number of Rolls or Pieces in Lot Sample
1 to 3	all
4 to 24	4
25 to 50	5
over 50	10 % to a max of 10 rolls or pieces



- 7.4 *Number of Test Specimens*—From each laboratory sampling unit, take four specimens from the machine direction (MD) and four specimens from the cross-machine direction (CD) as applicable to a material specification or contract order.
- 7.5 *Cutting Test Specimens*—Cut the specimens to be used for the measurement of machine direction (MD) with the longer dimension parallel to the machine direction (MD). Cut the specimens to be used for the measurement of the cross-machine direction (CD) with the longer dimension parallel to the cross-machine direction (CD). Label to maintain specimen identity.
- 7.5.1 Take specimens, representing a broad distribution across the width and length, preferably along the diagonal of the laboratory sample, and no so no two machine direction (MD) specimens contain the same warp threads and no two cross-machine direction (CD) specimens contain the same weft threads. The specimens shall be taken no nearer the edge than one-tenth its width. Ensure specimens are free of folds, creases, or wrinkles. Avoid getting oil, water, grease, etc. on the specimens when handling.
- 7.5.2 Cantilever Test—Cut test specimens 2525 mm by 200 mm,  $\pm 1 \text{ mm}$  ( $\pm (1 \text{ in.})$  by 8 in.  $\pm 0.04$  in.).
- 7.5.3 Heart Loop Test—No standard size for the test specimen is required. Cut—When using two bars as described in Note 4test specimens 50 mm (2 in.), cut test specimens 5 cm (2 in.) longer than the selected strip length to allow for clamping at the ends. See—For other size bars, adjust the length of the strip length accordingly. As a starting point, use Table 2: to determine a suitable strip length for any given fabric.
- Note 8—Strip length, L, is the circumferential length of the unclamped portion of the specimen.
- 7.5.3.1 Select a specimen width at least 25 mm (1 in.) and no more than 75 mm (3 in.) with respect to the tendency of the fabric to curl. For fabrics having a slight tendency to curl, a  $25 \pm 1$  mm (1  $\pm 0.04$  in.) wide specimen has been found to be satisfactory. As the tendency to curl becomes greater, increase the width up to a maximum of 75 mm (3 in.).
- 7.5.3.1 Make several trial tests using various strip lengths selected from Table 2–to obtain an estimate of the loop length. Select a suitable strip length for a corresponding loop length from Table 23, such that the bending length is relatively independent of strip length.
- Note 3—Strip length is the circumferential length of the unclamped portion of the specimen.
- Note 4—Specimen strip widths greater than 75 mm (3 in.) have not been investigated and are not recommended since reliability of results are questionable.
- Note 9—The bending length using the heart loop option is not entirely independent of the strip length. In general, the bending length rises with the strip length up to a value that remains relatively constant as the strip length is further increased. An additional rise may further be encountered for much longer strip lengths. Whenever possible, compare fabrics in the range where bending length is independent of strip length.
- 7.5.3.2 Select a specimen width at least 25 mm (1 in.) and no more than 75 mm (3 in.) with respect to the tendency of the fabric to curl. For fabrics having a slight tendency to curl, a 25 mm  $\pm$  1 mm (1 in.  $\pm$  0.04 in.) wide specimen has been found to be satisfactory. As the tendency to curl becomes greater, increase the width up to a maximum of 75 mm (3 in.).
- Note 10—Specimen strip widths greater than 75 mm (3 in.) have not been investigated and are not recommended.
- 8. Preparation of Test Apparatus and Calibration
- 8.1 Option A—Cantilever Test:
- 8.1.1 Set the tester on a table or bench with the horizontal platform and inclined reference lines. Adjust the platform to horizontal as indicated by the leveling bubble.and adjust the platform so that it is level to horizontal.

TABLE 2 Strip Lengths for Various Fabric Types	
Bending length, cm	Strip length, cm
Less than 2	15

TABLE 23 Table of Bending Lengths for Heart Loop Test

Loop Length,	Bending Length, cm			
cm	15-cm Strip	20-cm Strip	25-cm Strip	
CIII	Length	Length	Length	
4.0	2.19			
4.2	2.07			
4.4	1.99			
4.6	1.86	3.44	5.43	
4.8	1.76	3.30	5.16	
5.0	1.65	3.17	4.91	
5.2	1.56	3.03	4.71	
5.4	1.45	2.90	4.53	
5.6	1.35	2.80	4.36	
5.8	1.25	2.67	4.20	
6.0	1.14	2.57	4.06	
6.2	1.04	2.47	3.92	
6.4	0.93	2.37	3.80	
6.6	0.81	2.26	3.67	
6.8	0.69	2.16	3.56	
7.0	0.53	2.06	3.45	
7.2		1.96	3.34	
7.4		1.86	3.21	
7.6		1.76	3.12	
7.8		1.66	3.02	
8.0			2.91	
8.2			2.82	
8.4			2.72	

8.1.2 Verify that the bend angle indicator is at the 0.724 rad (41.5°) angle marked on the scale.

## 8.2 Option B—Heart Loop Test: https://standards.itch.ai

8.2.1 A suitable procedure for mounting and measuring the specimen is the use of two brass bars to which the specimen strip is fastened. The bars and the attached specimen strip are clamped to the stand in a suitable vertical position in front of a scale calibrated either in cm (in.) or directly in bending length.

#### 9. Conditioning

ASTM D1388-23

nttps://standards.iten.ai/catalog/standards/sist/93dib2e3-5/35-43/b-aeii-e54153ci4b/3/astm-d1388-23

- 9.1 Precondition the specimens by bringing them to approximate moisture equilibrium in the standard atmosphere for preconditioning textiles as directed in Practice D1776, unless otherwise directed in a material specification or contract order.
- 9.2 After preconditioning, bring the test specimens to moisture equilibrium for testing in the standard atmosphere for testing textiles as directed in Practice D1776 or, if applicable, in the specified atmosphere in which the testing is to be performed, unless otherwise directed in a material specification or contract order.

#### 10. Procedure

- 10.1 Test the conditioned specimens in the standard atmosphere for testing textiles, which is  $21 \pm \text{textiles}$  as indicated in Practice D17761°C (70 ± 2°F) and 65 ± 2 % relative humidity, unless otherwise directed in a material specification or contract order.
- 10.2 Option A—Cantilever Test:
- 10.2.1 Remove the movable <u>specimen</u> slide. Place the specimen on the horizontal platform with the length of the specimen parallel to the platform edge. <u>Align the For instruments equipped with a reference point, align the leading edge of the specimen with the line scribed on the right-hand edge of the horizontal platform. <u>For all other instruments, align the leading edge of the specimen</u> with the edge of the horizontal platform edge (closest to the bend angle indicator).</u>

Note 11—When known, place the specimen face-side up.

10.2.2 Place the movable slide on the specimen, being careful not to change its initial position.