



Standard Test Method for Determination of the Microbial Condition of Paint, Paint Raw Materials, and Plant Areas¹

This standard is issued under the fixed designation D5588; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers a procedure for the determination of the microbial condition (contamination or sterility) of raw materials used in the manufacture of paint, and the microbial condition of paint and paint manufacturing areas.

1.2 The values in SI units are to be regarded as the standard. The values given in parentheses are for information only.

1.3 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Summary of Test Method

2.1 This test method outlines procedures to (1) obtain samples for sterility testing from wet or dry materials and plant sites, (2) conduct the sterility testing on those samples to see if they are contaminated, (3) evaluate the degree of contamination, if any, and (4) provide a guide for some indication of the type of contamination present (bacterial, fungal, yeast, etc.). This test method is not designed to include all the necessary precautions to maintain the level of sterility required to provide the most accurate results. Some familiarity with microbiological techniques is recommended.

3. Significance and Use

3.1 Spoilage of paint in the container is often related to the use of contaminated raw materials, water (particularly recycled washwater), vessels, piping, and equipment in the manufacturing plant. There is a need for a simple method to determine the presence or absence of microorganisms in plants that manufacture paints and coatings. Such a determination enables the manufacturer to establish the point of contamination (that is, raw materials or problem housekeeping areas in the plant) to help in solving the spoilage problem.

¹ This test method is under the jurisdiction of ASTM Committee D01 on Paint and Related Coatings, Materials, and Applications and is the direct responsibility of Subcommittee D01.28 on Biodeterioration.

Current edition approved June 1, 2008. Published June 2008. Originally approved in 1994. Last previous edition approved in 2002 as D5588 – 97 (2002). DOI: 10.1520/D5588-97R08.

NOTE 1—Some contamination in plant areas is to be expected, since microorganisms are ubiquitous and cannot generally be eliminated practically (it is what an in-can preservative is supposed to control). Excessive levels of contamination or contaminated raw materials can exceed the capability of the preservative. If you have excessive contamination in the plant, there are methods for decontamination including steam, preservatives, bleach, etc. These should be discussed with your biocide supplier and used with care. Recovery of spoiled or contaminated products is often not feasible, so an adequate level of the appropriate biocide in conjunction with good plant housekeeping practices are essential. Your biocide supplier can also help here.

3.2 This test method may be used by persons without basic microbiological training, but some training on aseptic techniques would be recommended.

NOTE 2—The reliability of the results obtained from this test method is extremely dependent on the techniques employed. Improper techniques can result in a sterile sample appearing to be contaminated, and even worse, a contaminated sample appearing to be sterile (see also 5.1). It is recommended that you consult with your biocide supplier, raw material supplier, or an independent testing laboratory to confirm questionable results.

4. Apparatus and Materials

4.1 *Balance*, capable of weighing to 0.10 g.

4.2 *Incubator*, or other device capable of maintaining a constant temperature between 28 and 32°C.

4.3 *Refrigerator*.

4.4 *Tryptic Soy Agar (TSA) Plates*,² pre-prepared.³ (See Note 3).

4.5 *Potato Dextrose Agar (PDA) Plates*,⁴ or *Malt Agar Plates*,⁵ acidified to pH 3.5 with lactic acid, pre-prepared.

² Please note that Tryptic Soy and Trypticase Soy are names used interchangeably. Pre-prepared TSA plates, BBL# 21185, are available from various microbiological supply companies.

³ Agar plates (media) may be purchased pre-prepared using the indicated Difco or BBL number from microbiological supply companies, or both. Media may also be prepared from the formulations given in the *Difco Manual* (Difco Laboratories, Detroit, MI) or from appropriate dehydrated media using standard microbiological techniques.

⁴ Pre-prepared plates available are Difco # 4360-22-0, or BBL # 96272. These pre-prepared plates are not acidified to pH 3.5, but may be used (see also Footnote 3).

⁵ Pre-prepared plates available are Difco # 4265-22-6. These are not acidified, but may be used (see also Footnote 3).

NOTE 3—If preparing plates, Tryptic Soy Agar media with TTC (triphenyltetrazolium chloride) indicator dye may also be used. In general, the TTC helps visualize contamination, but it has been reported on occasion to inhibit the growth of some bacteria. Interferences from pigments in materials being tested may make the color change difficult to see. If self-prepared plates are used with the TTC indicator, 0.01 % TTC indicator should be used and it must be added *after* autoclaving.

4.6 *Lactic Acid*.

4.7 *Sterile Swabs* in tubes, pre-prepared.

4.8 *Swab tubes, Culturette Tubes*, or a similar system (swab in a test tube with a transport medium)⁶, all sterile, pre-prepared can be used if transport of collected samples to the laboratory testing area is required.

4.9 *Sterile Diluent* (9 mL) in tubes, pre-prepared (0.85 % saline or other suitable diluent). These can be prepared from sterile tubes and sterile saline solution then stored in a refrigerator.

4.10 *Laminar Flow Hood, Sterile Room*, or at least a laboratory testing area that is relatively clean, free of blowing dust and dirt, etc., which can be used for streaking plates.

4.11 *Antiseptic Solution*, to help maintain sterility of testing area surfaces (4.10) (For example, 70 % ethanol solution.).

4.12 *Plastic or Rubber Laboratory Gloves*, optional, sterilized.

4.13 *Facial Mask*, optional.

4.14 *Sterile Spatulas or Sterile Tongue Depressors*, 150-mm, (6-in.) individually wrapped.

4.15 *Plastic Bag*,⁷ sterile.

5. General Sampling Guidelines

5.1 Take all reasonable precautions to avoid microbial contamination while obtaining samples. You may choose to wear a facial mask and sterilized gloves. (**Warning**—Do not touch the swab anywhere near the cotton tip, or near parts of the swab which could be immersed in the test sample. Microorganisms from the skin, clothing, and even air if exposed too long, can contaminate the sample. If the swab has a cap, do not touch any part of the swab except that cap. Confirm suspicious results with additional testing.)

5.2 Use a new sterile swab, tongue depressor or spatula for each sample. Do not reuse any sampling devices. If using gloves, dispose after use.

5.3 When taking samples, be sure to minimize the time sterile items are exposed to the air to avoid false contamination results.

5.4 Liquid materials may be sampled as outlined in Section 6. Alternately, a sterilized container may be used to transport the liquid sample to the sterile testing area. Be sure that no non-sterile items contact the liquid sample during sampling, handling, and movement to the testing area (for example, use sterile pipet, etc. for transfer of material to container, etc.).

⁶ Available from microbiological supply companies. Swab tubes or culturette tubes 9345 with Amies medium were used.

⁷ Sterile plastic packs are available from microbiological supply companies.

5.5 Dry materials may be sampled as in 6.3 or 9.1. To sample unopened, dry raw materials in bags, wipe a large area of the outside of the bag clean with a clean rag or paper towel. Using a clean knife, cut open the bag within the cleaned area. Sample as in 9.1, or using a sterile tongue depressor or sterile spatula, scoop 10 to 15 g into a sterile plastic bag,⁷ close and seal bag for transport to sterile testing area.

NOTE 4—To decrease the chances of inadvertent contamination, a suggestion would be to carefully wipe the area of the bag to be cut, and the knife used for cutting it, with isopropyl alcohol. **Warning:** Exercise care to avoid skin contact, since the isopropyl alcohol could carry hazardous materials through the skin. Also, avoid excess alcohol that could affect test results.

5.6 When testing open containers of raw materials, vats, drums, etc., there is no need to sterile equipment surfaces (see Section 6). However, be aware that any contamination observed may have been introduced after opening. Samples taken from equipment surfaces that show contamination do not necessarily mean that the material contained or being manufactured inside is also contaminated.

6. Sampling Procedure for Plant Areas

6.1 Establish a protocol for surveying probable areas of contamination. Make sure that such areas include pipes and hoses, especially if left with water standing, any storage and mixing vessels, pumps, drains, sumps, etc. Because recycled washwater is particularly susceptible to contamination, be sure to include it.

6.2 Sampling is best carried out when the area to be tested is wet. In wet areas, the swab is dipped into or wiped on the area (see Note 3), and then returned to a sterile tube (with or without transport media). This swab is then used for testing as described in Section 8 (see also Section 7).

6.3 Sampling dry areas provides information that is less conclusive, but can be carried out by swabbing the dry area with a sterile swab that has previously been dipped into sterile diluent. This swab is then used as described in Section 8.

7. Testing Transported Samples

7.1 If transport of collected samples to the laboratory testing area is required, then use the swab contained in the swab tubes, culturette tubes, or similar system (swab in a test tube with a transport medium), in place of the dry swab as described in 4.7. Any transport medium transferred to the agar or broth should not adversely affect the results.

7.2 Test swabs in tubes without media as soon as possible to avoid drying of swab and possibly killing any contaminating microorganisms. Test swabs in tubes with media within the time specified by the manufacturer (generally 48 to 72 h).

8. Testing Procedure for Liquid Samples or Swabs, or Both

8.1 Grasping the opposite end, dip the cotton end of a dry sterile swab into the liquid (or mixture from Procedure 9), remove the cover from a sterile tryptic soy agar (TSA) plate, and streak the agar surface with the wet swab. Make sure that this is done so that the streaks are in a set pattern (for example,