

---

---

**Traditional Chinese medicine —  
Detection of irradiated natural  
products by photostimulated  
luminescence**

*Médecine traditionnelle chinoise — Détection des produits naturels  
irradiés par luminescence photostimulée*

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

[ISO 22256:2020](https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020)

[https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-  
d3eb86d7afab/iso-22256-2020](https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020)



## iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 22256:2020

<https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020>



### **COPYRIGHT PROTECTED DOCUMENT**

© ISO 2020

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
CP 401 • Ch. de Blandonnet 8  
CH-1214 Vernier, Geneva  
Phone: +41 22 749 01 11  
Email: [copyright@iso.org](mailto:copyright@iso.org)  
Website: [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

	Page
<b>Foreword</b> .....	<b>iv</b>
<b>Introduction</b> .....	<b>v</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative reference</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>1</b>
<b>4 Principle</b> .....	<b>2</b>
<b>5 Apparatus</b> .....	<b>2</b>
<b>6 Procedure</b> .....	<b>2</b>
6.1 General.....	2
6.2 Sampling technique.....	2
6.2.1 General operation.....	2
6.2.2 Sample quantity.....	2
6.3 Instrumental calibration.....	3
6.3.1 Instrumental parameter.....	3
6.3.2 Dark count.....	3
6.3.3 Empty chamber test.....	3
6.3.4 Negative reference count.....	3
6.3.5 Positive reference count.....	3
6.4 Detection of the sample.....	3
6.4.1 Screening PSL.....	3
6.4.2 Calibrated PSL.....	3
6.4.3 F-factor calculating.....	3
6.5 Result evaluation.....	3
<b>7 Other requirements</b> .....	<b>4</b>
7.1 Limitation of application.....	4
7.2 Repeated determination.....	4
7.3 Cleaning of sample chamber.....	4
7.4 Cleaning of translucent glass.....	4
7.5 Influencing factors of threshold and F-factor.....	4
<b>Bibliography</b> .....	<b>5</b>

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see [www.iso.org/directives](http://www.iso.org/directives)).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see [www.iso.org/patents](http://www.iso.org/patents)).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see [www.iso.org/iso/foreword.html](http://www.iso.org/iso/foreword.html).

This document was prepared by Technical Committee ISO/TC 249, *Traditional Chinese medicine*.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at [www.iso.org/members.html](http://www.iso.org/members.html).

## Introduction

Ionizing radiation (gamma ray, X-ray or beam) is used extensively for the sterilization of medical devices and for a variety of other materials and products. However, irradiation of traditional natural products for sanitation purposes is not permitted by the regulations of most countries. It is necessary to set up a method to identify whether a product has been subjected to irradiation, because overexposure to irradiation can have negative effects on product quality. Irradiation detection methods will help to reduce international trade friction, assist governments in strengthening irradiation supervision and help enterprises to choose non-irradiated raw materials.

Currently, several independent methods are used to identify irradiated foodstuffs. Some of them can be used to identify irradiated natural products. After studying natural products and improving detection rules, photostimulated luminescence (PSL) has become one of the most suitable methods of detection. It is not only a screening method but also a confirmation method with application of F-factor. It can be used widely because of its simplicity and low cost.

## iTeh STANDARD PREVIEW (standards.iteh.ai)

[ISO 22256:2020](https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020)

<https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020>

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

ISO 22256:2020

<https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020>

# Traditional Chinese medicine — Detection of irradiated natural products by photostimulated luminescence

## 1 Scope

This document specifies a method using photostimulated luminescence (PSL) to detect the radiation status of natural products. It can be used to identify whether raw and traditionally processed Chinese medicinal materials and solid forms of manufactured product made from these materials have been irradiated by ionizing radiation (gamma, X-ray or beam). It is not applicable for use in testing liquid dosage forms or partially solid extracted dosage forms that do not contain directly crushed medicinal materials.

## 2 Normative reference

There are no normative references in this document.

## 3 Terms and definitions

For the purposes of this document the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at <https://www.iso.org/obp>
- IEC Electropedia: available at <http://www.electropedia.org/>

### 3.1

#### **photostimulated luminescence**

#### **PSL**

radiation-specific phenomenon resulting from energy stored by trapped charge carriers

Note 1 to entry: Release of this stored energy by optical stimulation can result in a detectable luminescence signal.

[SOURCE: EN 13751:2009, 2.1]

### 3.2

#### **PSL intensity**

amount of light detected during photostimulation, in photon count rate

[SOURCE: EN 13751:2009, 2.2]

### 3.3

#### **screening PSL**

*PSL intensity* (3.2) recorded from the sample as received or following preparation

[SOURCE: EN 13751:2009, 2.3]

### 3.4

#### **calibrated PSL**

*PSL intensity* (3.2) recorded from the test sample following irradiation to a known dose, after initial PSL measurement

[SOURCE: EN 13751:2009, 2.4]

### 3.5

#### **F-factor**

ratio of *calibrated PSL* (3.4) to *screening PSL* (3.3)

## 4 Principle

Most natural products that are either cultivated or wild contain silicate minerals, calcite or hydroxyapatite. When exposed to ionizing radiation, these materials store energy in charge carriers trapped in structural, interstitial or impurity sites. Trapped high-energy electrons can be released by stimulation with light, leaving electron holes in the crystal lattice. The energy thus released is detected as luminescence.

## 5 Apparatus

**5.1 PSL system**, consisting of pulsed stimulation sources (infrared ray), photon counting system, detector, sample chamber and computer for controlling unit.

**5.2 Disposable 5-cm Petri dishes**, with covers.

**5.3 Radiation source**, delivering  $^{60}\text{Co}$ -rays or X-rays used at a fixed radiation dose of 1 kGy before measurement of calibrated PSL. Alternative sources can be used if they are satisfactory.

**5.4 Negative/positive reference**, non-irradiated and irradiated (above 1 kGy) paprika powders or other suitable references used for instrumental calibration.

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

## 6 Procedure

ISO 22256:2020

<https://standards.iteh.ai/catalog/standards/sist/d2763493-7ff6-4b9d-a6cb-d3eb86d7afab/iso-22256-2020>

### 6.1 General

Avoid light exposure and cross-contamination when dispensing and handling samples.

Medicinal materials and manufactured product follow the same procedure.

### 6.2 Sampling technique

#### 6.2.1 General operation

Grind the material into fine powder and mix well. Weigh about 2 g sample, dispense it into the Petri dish to cover the base in a thin layer and put the lid on to keep out dust before the measurement. Three replicate test samples can be prepared in parallel.

As for samples which are difficult to grind into fine powder, such as the big candied pills, grind into small particles as much as possible and mix well.

#### 6.2.2 Sample quantity

For general samples, 2 g is appropriate. For high-density samples, the quantity of samples should be appropriately increased. For light and loose samples, the quantity of samples should be reduced. The sampling quantity requires the bottom of the Petri dishes to be covered completely.



## 6.3 Instrumental calibration

### 6.3.1 Instrumental parameter

The acquisition frequency is 1 time/s, and acquisition duration is 60 s.

### 6.3.2 Dark count

Photon count rate detected in the empty sample chamber with absence of stimulation shall be less than 50.

### 6.3.3 Empty chamber test

PSL intensity count of the empty Petri dish shall be less than 700. This step shall be repeated periodically, for example every 10 samples or upon the positive samples.

### 6.3.4 Negative reference count

Weigh 2 g non-irradiated reference of paprika powder and dispense into the Petri dish to cover the base in a thin layer. The count value shall be less than 700.

### 6.3.5 Positive reference count

Weigh 2 g irradiated reference of paprika powder and dispense into the Petri dish to cover the base in a thin layer. The count value shall be more than 5 000.

## 6.4 Detection of the sample

### 6.4.1 Screening PSL

Detect three replicate test samples and record their respective PSL values. If the results of the three replicate test samples are all below 700, calibrated PSL does not need to be conducted.

NOTE 700 is an empirical value, which is equivalent to the background level referring to the use of 5-cm Petri dishes.

### 6.4.2 Calibrated PSL

After the screening PSL detection, cover the lid of the dish to avoid loss or contamination, irradiate the samples in the  $^{60}\text{Co}$  or X-ray at 1 kGy dose, then determine their respective PSL values. During handling, care should be taken not to shake the sample.

### 6.4.3 F-factor calculating

Calculate the ratio of calibrated PSL value to the corresponding screening PSL value to get the F-factor, then calculate the average value.

## 6.5 Result evaluation

Use the criterion in [Table 1](#) to judge whether the sample is irradiated or not. If the F-factor in one or two test samples is less than 10, while the rest are more than 10, then three more test samples shall be prepared and analysed to exclude false-positive results. The result shall be determined by the average value of F-factor in these six samples.