
**Information technology — Trusted
Platform Module —**

**Part 4:
Commands**

Technologies de l'information — Module de plate-forme de confiance —

Partie 4: Commandes

iTeh STANDARD PREVIEW
(standards.iteh.ai)

ISO/IEC 11889-4:2009

<https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>

PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

ISO/IEC 11889-4:2009

<https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>



COPYRIGHT PROTECTED DOCUMENT

© ISO/IEC 2009

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Table of Contents

1. Scope	1
1.1 Key words	1
1.2 Statement Type	1
2. Normative references	2
3. Abbreviated Terms	3
4. Admin Startup and State	5
4.1 TPM_Init	5
4.2 TPM_Startup	6
4.3 TPM_SaveState	8
5. Admin Testing	10
5.1 TPM_SelfTestFull	10
5.2 TPM_ContinueSelfTest	10
5.3 TPM_GetTestResult	12
6. Admin Opt-in	13
6.1 TPM_SetOwnerInstall	13
6.2 TPM_OwnerSetDisable	13
6.3 TPM_PhysicalEnable	14
6.4 TPM_PhysicalDisable	15
6.5 TPM_PhysicalSetDeactivated	15
6.6 TPM_SetTempDeactivated	16
6.7 TPM_SetOperatorAuth	17
7. Admin Ownership	18
7.1 TPM_TakeOwnership	18
7.2 TPM_OwnerClear	20
7.3 TPM_ForceClear	22
7.4 TPM_DisableOwnerClear	23
7.5 TPM_DisableForceClear	24
7.6 TSC_PhysicalPresence	24
7.7 TSC_ResetEstablishmentBit	26
8. The Capability Commands	28
8.1 TPM_GetCapability	28
8.2 TPM_SetCapability	29
8.3 TPM_GetCapabilityOwner	30
9. Auditing	32
9.1 Audit Generation	32
9.2 Effect of audit failing	33
9.3 TPM_GetAuditDigest	34

ISO/IEC 11889-4:2009(E)

9.4	TPM_GetAuditDigestSigned	35
9.5	TPM_SetOrdinalAuditStatus	37
10.	Administrative Functions - Management	38
10.1	TPM_FieldUpgrade	38
10.2	TPM_SetRedirection	40
10.3	TPM_ResetLockValue	41
11.	Storage functions	43
11.1	TPM_Seal	43
11.2	TPM_Unseal	46
11.3	TPM_UnBind	49
11.4	TPM_CreateWrapKey	51
11.5	TPM_LoadKey2	53
11.6	TPM_GetPubKey	56
11.7	TPM_Sealx	57
12.	Migration	60
12.1	TPM_CreateMigrationBlob	60
12.2	TPM_ConvertMigrationBlob	63
12.3	TPM_AuthorizeMigrationKey	64
12.4	TPM_MigrateKey	66
12.5	TPM_CMK_SetRestrictions	67
12.6	TPM_CMK_ApproveMA	69
12.7	TPM_CMK_CreateKey	70
12.8	TPM_CMK_CreateTicket	72
12.9	TPM_CMK_CreateBlob	74
12.10	TPM_CMK_ConvertMigration	77
13.	Maintenance Functions (optional)	80
13.1	TPM_CreateMaintenanceArchive	81
13.2	TPM_LoadMaintenanceArchive	83
13.3	TPM_KillMaintenanceFeature	85
13.4	TPM_LoadManuMaintPub	86
13.5	TPM_ReadManuMaintPub	87
14.	Cryptographic Functions	88
14.1	TPM_SHA1Start	88
14.2	TPM_SHA1Update	89
14.3	TPM_SHA1Complete	89
14.4	TPM_SHA1CompleteExtend	90
14.5	TPM_Sign	91
14.6	TPM_GetRandom	93
14.7	TPM_StirRandom	93
14.8	TPM_CertifyKey	94

STANDARD PREVIEW
(standards.iteh.ai)

<https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>

14.9	TPM_CertifyKey2	98
15.	Endorsement Key Handling	101
15.1	TPM_CreateEndorsementKeyPair	101
15.2	TPM_CreateRevocableEK	102
15.3	TPM_RevokeTrust	104
15.4	TPM_ReadPubek	105
15.5	TPM_OwnerReadInternalPub	106
16.	Identity Creation and Activation	107
16.1	TPM_MakeIdentity	107
16.2	TPM_ActivateIdentity	110
17.	Integrity Collection and Reporting	113
17.1	TPM_Extend	113
17.2	TPM_PCRRead	114
17.3	TPM_Quote	115
17.4	TPM_PCR_Reset	116
17.5	TPM_Quote2	118
18.	Changing AuthData	120
18.1	TPM_ChangeAuth	120
18.2	TPM_ChangeAuthOwner	122
19.	Authorization Sessions	123
19.1	TPM_OIAP	123
19.1.1	Actions to validate an OIAP session	124
19.2	TPM_OSAP	125
19.2.1	Actions to validate an OSAP session	128
19.3	TPM_DSAP	129
19.4	TPM_SetOwnerPointer	132
20.	Delegation Commands	134
20.1	TPM_Delegate_Manage	134
20.2	TPM_Delegate_CreateKeyDelegation	137
20.3	TPM_Delegate_CreateOwnerDelegation	139
20.4	TPM_Delegate_LoadOwnerDelegation	142
20.5	TPM_Delegate_ReadTable	144
20.6	TPM_Delegate_UpdateVerification	145
20.7	TPM_Delegate_VerifyDelegation	147
21.	Non-volatile Storage	148
21.1	TPM_NV_DefineSpace	149
21.2	TPM_NV_WriteValue	152
21.3	TPM_NV_WriteValueAuth	154
21.4	TPM_NV_ReadValue	156
21.5	TPM_NV_ReadValueAuth	158

22. Session Management	160
22.1 TPM_KeyControlOwner	160
22.2 TPM_SaveContext	162
22.3 TPM_LoadContext	164
23. Eviction	167
23.1 TPM_FlushSpecific	167
24. Timing Ticks	169
24.1 TPM_GetTicks	169
24.2 TPM_TickStampBlob	170
25. Transport Sessions	172
25.1 TPM_EstablishTransport	172
25.2 TPM_ExecuteTransport	175
25.3 TPM_ReleaseTransportSigned	181
26. Monotonic Counter	184
26.1 TPM_CreateCounter	184
26.2 TPM_IncrementCounter	185
26.3 TPM_ReadCounter	186
26.4 TPM_ReleaseCounter	187
26.5 TPM_ReleaseCounterOwner	188
27. DAA commands	190
27.1 TPM_DAA_Join	190
27.2 TPM_DAA_Sign	205
28. Deprecated commands	215
28.1 Key commands	215
28.1.1 TPM_EvictKey	215
28.1.2 TPM_Terminate_Handle	216
28.2 Context management	217
28.2.1 TPM_SaveKeyContext	217
28.2.2 TPM_LoadKeyContext	218
28.2.3 TPM_SaveAuthContext	219
28.2.4 TPM_LoadAuthContext	220
28.3 DIR commands	220
28.3.1 TPM_DirWriteAuth	221
28.3.2 TPM_DirRead	222
28.4 Change Auth	222
28.4.1 TPM_ChangeAuthAsymStart	223
28.4.2 TPM_ChangeAuthAsymFinish	226
28.5 TPM_Reset	228
28.6 TPM_OwnerReadPubek	229
28.7 TPM_DisablePubekRead	230

iTech STANDARD PREVIEW
(standards.itech.ai)

<https://standards.itech.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>

28.8	TPM_LoadKey	231
29.	Deleted Commands	234
29.1	TPM_GetCapabilitySigned	234
29.2	TPM_GetOrdinalAuditStatus	234
29.3	TPM_CertifySelfTest	235
30.	Bibliography	237

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[ISO/IEC 11889-4:2009](https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009)

<https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>

List of Tables

Table 1. TPM_Init Incoming Parameters and Sizes	6
Table 2. TPM_Init Outgoing Parameters and Sizes	6
Table 3. TPM_SaveState Incoming Parameters and Sizes	9
Table 4. TPM_SaveState Outgoing Parameters and Sizes	9
Table 5. TPM_SelfTestFull Incoming Operands and Sizes	10
Table 6. TPM_SelfTestFull Outgoing Operands and Sizes	10
Table 7. TPM_ContinueSelfTest Incoming Operands and Sizes	10
Table 8. TPM_ContinueSelfTest Outgoing Operands and Sizes	11
Table 9. TPM_GetTestResult Incoming Operands and Sizes	12
Table 10. TPM_GetTestResult Outgoing Operands and Sizes	12
Table 11. TPM_SetOwnerInstall Incoming Operands and Sizes	13
Table 12. TPM_SetOwnerInstall Outgoing Operands and Sizes	13
Table 13. TPM_OwnerSetDisable Incoming Operands and Sizes	13
Table 14. TPM_OwnerSetDisable Outgoing Operands and Sizes	14
Table 15. TPM_PhysicalEnable Incoming Operands and Sizes	14
Table 16. TPM_PhysicalEnable Outgoing Operands and Sizes	14
Table 17. TPM_PhysicalDisable Incoming Operands and Sizes	15
Table 18. TPM_PhysicalDisable Outgoing Operands and Sizes	15
Table 19. TPM_PhysicalSetDeactivated Incoming Operands and Sizes	15
Table 20. TPM_PhysicalSetDeactivated Outgoing Operands and Sizes	15
Table 21. TPM_SetTemp Deactivated Incoming Operands and Sizes	16
Table 22. TPM_SetTemp Deactivated Outgoing Operands and Sizes	16
Table 23. TPM_SetOperatorAuth Incoming Operands and Sizes	17
Table 24. TPM_SetOperatorAuth Outgoing Operands and Sizes	17
Table 25. TPM_TakeOwnership Incoming Operands and Sizes	18
Table 26. TPM_TakeOwnership Outgoing Operands and Sizes	19
Table 27. TPM_OwnerClear Incoming Operands and Sizes	20
Table 28. TPM_OwnerClear Outgoing Operands and Sizes	20
Table 29. TPM_ForceClear Incoming Operands and Sizes	22
Table 30. TPM_ForceClear Outgoing Operands and Sizes	23
Table 31. TPM_DisableOwnerClear Incoming Operands and Sizes	23
Table 32. TPM_DisableOwnerClear Outgoing Operands and Sizes	23
Table 33. TPM_DisableForceClear Incoming Operands and Sizes	24
Table 34. TPM_DisableForceClear Outgoing Operands and Sizes	24
Table 35. TSC_PhysicalPresence Incoming Operands and Sizes	25
Table 36. TSC_PhysicalPresence Outgoing Operands and Sizes	25
Table 37. TCG_ResetEstablishmentBit Incoming Operands and Sizes	27
Table 38. TCG_ResetEstablishmentBit Outgoing Operands and Sizes	27
Table 39. TPM_GetCapability Incoming Parameters and Sizes	28

Table 40. TPM_GetCapability Outgoing Parameters and Sizes	28
Table 41. TPM_SetCapability Incoming Parameters and Sizes	29
Table 42. TPM_SetCapability Outgoing Parameters and Sizes	30
Table 43. TPM_GetCapabilityOwner Incoming Operands and Sizes	30
Table 44. TPM_GetCapabilityOwner Outgoing Operands and Sizes	31
Table 45. TPM_GetAuditDigest Incoming Parameters and Sizes	34
Table 46. TPM_GetAuditDigest Outgoing Parameters and Sizes	34
Table 47. TPM_GetAuditDigestSigned Incoming Parameters and Sizes	35
Table 48. TPM_GetAuditDigestSigned Outgoing Parameters and Sizes	36
Table 49. TPM_SetOrdinalAuditStatus Incoming Parameters and Sizes	37
Table 50. TPM_SetOrdinalAuditStatus Outgoing Parameters and Sizes	37
Table 51. TPM_FieldUpgrade Parameters	38
Table 52. TPM_SetRedirection Incoming Operands and Sizes	40
Table 53. TPM_SetRedirection Outgoing Operands and Sizes	40
Table 54. TPM_ResetLockValue Incoming Operands and Sizes	41
Table 55. TPM_ResetLockValue Outgoing Operands and Sizes	42
Table 56. TPM_Seal Incoming Operands and Sizes	44
Table 57. TPM_Seal Outgoing Operands and Sizes	44
Table 58. TPM_Unseal Incoming Operands and Sizes	46
Table 59. TPM_Unseal Outgoing Operands and Sizes	47
Table 60. TPM_UnBind Incoming Operands and Sizes	49
Table 61. TPM_UnBind Outgoing Operands and Sizes	50
Table 62. TPM_CreateWrapKey Incoming Operands and Sizes	51
Table 63. TPM_CreateWrapKey Outgoing Operands and Sizes	51
Table 64. TPM_WrapKey Incoming Operands and Sizes	54
Table 65. TPM_WrapKey Outgoing Operands and Sizes	54
Table 66. TPM_GetPubKey Incoming Operands and Sizes	56
Table 67. TPM_GetPubKey Outgoing Operands and Sizes	56
Table 68. TPM_Sealx Incoming Operands and Sizes	57
Table 69. TPM_Sealx Outgoing Operands and Sizes	58
Table 70. TPM_CreateMigrationBlob Incoming Operands and Sizes	61
Table 71. TPM_CreateMigrationBlob Outgoing Operands and Sizes	62
Table 72. TPM_ConvertMigrationBlob Incoming Operands and Sizes	63
Table 73. TPM_ConvertMigrationBlob Outgoing Operands and Sizes	64
Table 74. TPM_AuthorizeMigrationKey Incoming Operands and Sizes	65
Table 75. TPM_AuthorizeMigrationKey Outgoing Operands and Sizes	65
Table 76. TPM_MigrateKey Incoming Operands and Sizes	66
Table 77. TPM_MigrateKey Outgoing Operands and Sizes	67
Table 78. TPM_CMK_SetRestrictions Incoming Operands and Sizes	67
Table 79. TPM_CMK_SetRestrictions Outgoing Operands and Sizes	68

Table 80. TPM_CMK_ApproveMA Incoming Operands and Sizes	69
Table 81. TPM_CMK_ApproveMA Outgoing Operands and Sizes	69
Table 82. TPM_CMK_CreateKey Incoming Operands and Sizes	70
Table 83. TPM_CMK_CreateKey Outgoing Operands and Sizes	71
Table 84. TPM_CMK_CreateTicket Incoming Operands and Sizes	73
Table 85. TPM_CMK_CreateTicket Outgoing Operands and Sizes	73
Table 86. TPM_CMK_CreateBlob Incoming Operands and Sizes	74
Table 87. TPM_CMK_CreateBlob Outgoing Operands and Sizes	75
Table 88. TPM_CMK_ConvertMigration Incoming Operands and Sizes	77
Table 89. TPM_CMK_ConvertMigration Outgoing Operands and Sizes	78
Table 90. TPM_CreateMaintenanceArchive Incoming Operands and Sizes	81
Table 91. TPM_CreateMaintenanceArchive Outgoing Operands and Sizes	81
Table 92. TPM_LoadMaintenanceArchive Incoming Operands and Sizes	83
Table 93. TPM_LoadMaintenanceArchive Outgoing Operands and Sizes	83
Table 94. TPM_KillMaintenanceFeature Incoming Operands and Sizes	85
Table 95. TPM_KillMaintenanceFeature Outgoing Operands and Sizes	85
Table 96. TPM_LoadManuMaintPub Incoming Operands and Sizes	86
Table 97. TPM_LoadManuMaintPub Outgoing Operands and Sizes	86
Table 98. TPM_ReadManuMaintPub Incoming Operands and Sizes	87
Table 99. TPM_ReadManuMaintPub Outgoing Operands and Sizes	87
Table 100. TPM_SHA1Start Incoming Operands and Sizes	88
Table 101. TPM_SHA1Start Outgoing Operands and Sizes	88
Table 102. TPM_SHA1Update Incoming Operands and Sizes	89
Table 103. TPM_SHA1Update Outgoing Operands and Sizes	89
Table 104. TPM_SHA1Complete Incoming Operands and Sizes	89
Table 105. TPM_SHA1Complete Outgoing Operands and Sizes	90
Table 106. TPM_SHA1CompleteExtend Incoming Operands and Sizes	90
Table 107. TPM_SHA1CompleteExtend Outgoing Operands and Sizes	90
Table 108. TPM_Sign Incoming Operands and Sizes	91
Table 109. TPM_Sign Outgoing Operands and Sizes	91
Table 110. TPM_GetRandom Incoming Operands and Sizes	93
Table 111. TPM_GetRandom Outgoing Operands and Sizes	93
Table 112. TPM_StirRandom Incoming Operands and Sizes	93
Table 113. TPM_StirRandom Outgoing Operands and Sizes	94
Table 114. TPM_CertifyKey Incoming Operands and Sizes	95
Table 115. TPM_CertifyKey Outgoing Operands and Sizes	95
Table 116. TPM_CertifyKey2 Incoming Operands and Sizes	98
Table 117. TPM_CertifyKey2 Outgoing Operands and Sizes	99
Table 118. TPM_CreateEndorsementKeyPair Incoming Operands and Sizes	101
Table 119. TPM_CreateEndorsementKeyPair Outgoing Operands and Sizes	101

Table 120. TPM_CreateRevocableEK Incoming Operands and Sizes	103
Table 121. TPM_CreateRevocableEK Outgoing Operands and Sizes	103
Table 122. TPM_RevokeTrust Incoming Operands and Sizes	104
Table 123. TPM_RevokeTrust Outgoing Operands and Sizes	104
Table 124. TPM_ReadPubek Incoming Operands and Sizes	105
Table 125. TPM_ReadPubek Outgoing Operands and Sizes	105
Table 126. TPM_OwnerReadInternalPub Incoming Operands and Sizes	106
Table 127. TPM_OwnerReadInternalPub Outgoing Operands and Sizes	106
Table 128. TPM_MakeIdentity Incoming Operands and Sizes	107
Table 129. TPM_MakeIdentity Outgoing Operands and Sizes	108
Table 130. Properties of the new identity	108
Table 131. TPM_ActivateIdentity Incoming Parameters and Sizes	110
Table 132. TPM_ActivateIdentity Outgoing Parameters and Sizes	111
Table 133. TPM_Extend Incoming Operands and Sizes	113
Table 134. TPM_Extend Outgoing Operands and Sizes	113
Table 135. TPM_PCRRead Incoming Operands and Sizes	114
Table 136. TPM_PCRRead Outgoing Operands and Sizes	114
Table 137. TPM_Quote Incoming Operands and Sizes	115
Table 138. TPM_Quote Outgoing Operands and Sizes	115
Table 139. TPM_PCR_Reset Incoming Parameters and Sizes	117
Table 140. TPM_PCR_Reset Outgoing Parameters and Sizes	117
Table 141. TPM_Quote2 Incoming Operands and Sizes	118
Table 142. TPM_Quote2 Outgoing Operands and Sizes	118
Table 143. TPM_ChangeAuth Incoming Operands and Sizes	120
Table 144. TPM_ChangeAuth Outgoing Operands and Sizes	121
Table 145. TPM_ChangeAuthOwner Incoming Operands and Sizes	122
Table 146. TPM_ChangeAuthOwner Outgoing Operands and Sizes	122
Table 147. TPM_OIAP Incoming Operands and Sizes	123
Table 148. TPM-OIAP Outgoing Operands and Sizes	123
Table 149. TPM_OSAP Incoming Operands and Sizes	125
Table 150. TPM_OSAP Outgoing Operands and Sizes	125
Table 151. TPM_DSAP Incoming Operands and Sizes	129
Table 152. TPM_DSAP Outgoing Operands and Sizes	129
Table 153. TPM_SetOwnerPointer Incoming Operands and Sizes	132
Table 154. TPM_SetOwnerPointer Outgoing Operands and Sizes	133
Table 155. TPM_Delegate_Manage Incoming Operands and Sizes	135
Table 156. TPM_Delegate_Manage Outgoing Operands and Sizes	135
Table 157. TPM_Delegate_CreateKeyDelegation Incoming Operands and Sizes	137
Table 158. TPM_Delegate_CreateKeyDelegation Outgoing Operands and Sizes	138
Table 159. TPM_Delegate_CreateOwnerDelegation Incoming Operands and Sizes	140

Table 160. TPM_Delegate_CreateOwnerDelegation Outgoing Operands and Sizes	140
Table 161. TPM_Delegate_LoadOwnerDelegation Incoming Operands and Sizes	142
Table 162. TPM_Delegate_LoadOwnerDelegation Outgoing Operands and Sizes	143
Table 163. TPM_Delegate_ReadTable Incoming Operands and Sizes	144
Table 164. TPM_Delegate_ReadTable Outgoing Operands and Sizes	144
Table 165. TPM_Delegate_UpdateVerification Incoming Operands and Sizes	145
Table 166. TPM_Delegate_UpdateVerification Outgoing Operands and Sizes	146
Table 167. TPM_Delegate_VerifyDelegation Incoming Operands and Sizes	147
Table 168. TPM_Delegate_VerifyDelegation Outgoing Operands and Sizes	147
Table 169. TPM_NV_DefineSpace Incoming Operands and Sizes	149
Table 170. TPM_NV_DefineSpace Outgoing Operands and Sizes	149
Table 171. TPM_NV_WriteValue Incoming Operands and Sizes	152
Table 172. TPM_NV_WriteValue Outgoing Operands and Sizes	152
Table 173. TPM_NV_WriteValueAuth Incoming Operands and Sizes	154
Table 174. TPM_NV_WriteValueAuth Outgoing Operands and Sizes	155
Table 175. TPM_NV_ReadValue Incoming Operands and Sizes	156
Table 176. TPM_NV_ReadValue Outgoing Operands and Sizes	156
Table 177. TPM_NV_ReadValueAuth Incoming Operands and Sizes	158
Table 178. TPM_NV_ReadValueAuth Outgoing Operands and Sizes	158
Table 179. TPM_KeyControlOwner Incoming Parameters and Sizes	161
Table 180. TPM_KeyControlOwner Outgoing Parameters and Sizes	161
Table 181. TPM_SaveContext Incoming Parameters and Sizes	162
Table 182. TPM_SaveContext Outgoing Parameters and Sizes	162
Table 183. TPM_LoadContext Incoming Parameters and Sizes	164
Table 184. TPM_LoadContext Outgoing Parameters and Sizes	165
Table 185. TPM_FlushSpecific Incoming Parameters and Sizes	167
Table 186. TPM_FlushSpecific Outgoing Parameters and Sizes	167
Table 187. TPM_GetTicks Incoming Parameters and Sizes	169
Table 188. TPM_GetTicks Outgoing Parameters and Sizes	169
Table 189. TPM_TickStampBlob Incoming Parameters and Sizes	170
Table 190. TPM_TickStampBlob Outgoing Parameters and Sizes	171
Table 191. TPM_EstablishTransport Incoming Parameters and Sizes	172
Table 192. TPM_EstablishTransport Outgoing Parameters and Sizes	173
Table 193. TPM_ExecuteTransport Incoming Parameters and Sizes	175
Table 194. TPM_ExecuteTransport Outgoing Parameters and Sizes	176
Table 195. TPM_ReleaseTransportSigned Incoming Parameters and Sizes	181
Table 196. TPM_ReleaseTransportSigned Outgoing Parameters and Sizes	182
Table 197. TPM_CreateCounter Incoming Parameters and Sizes	184
Table 198. TPM_CreateCounter Outgoing Parameters and Sizes	184
Table 199. TPM_IncrementCounter Incoming Parameters and Sizes	185

Table 200. TPM_IncrementCounter Outgoing Parameters and Sizes	186
Table 201. TPM_ReadCounter Incoming Parameters and Sizes	186
Table 202. TPM_ReadCounter Outgoing Parameters and Sizes	187
Table 203. TPM_ReleaseCounter Incoming Parameters and Sizes	187
Table 204. TPM_ReleaseCounter Outgoing Parameters and Sizes	188
Table 205. TPM_ReleaseCounterOwner Incoming Parameters and Sizes	188
Table 206. TPM_ReleaseCounter Owner Outgoing Parameters and Sizes	189
Table 207. TPM_DAA_Join Incoming Parameters and Sizes	190
Table 208. TPM_DAA_Join Outgoing Operands and Sizes	190
Table 209. Input, Output and Saved Data Associated with Processing	191
Table 210. TPM_DAA_Sign Incoming Operands and Sizes	205
Table 211. TPM_DAA_Sign Outgoing Operands and Sizes	205
Table 212. Input, Output and Saved Data Associated with Processing	206
Table 213. TPM_EvictKey Incoming Operands and Sizes	215
Table 214. TPM_EvictKey Outgoing Operands and Sizes	215
Table 215. TPM_Terminate_Handle Incoming Operands and Sizes	216
Table 216. TPM_Terminate_Handle Outgoing Operands and Sizes	216
Table 217. TPM_SaveKeyContext Incoming Operands and Sizes	217
Table 218. TPM_SaveKeyContext Outgoing Operands and Sizes	217
Table 219. TPM_LoadKeyContext Incoming Operands and Sizes	218
Table 220. TPM_LoadKeyContext Outgoing Operands and Sizes	218
Table 221. TPM_SaveAuthContext Incoming Operands and Sizes	219
Table 222. TPM_SaveAuthContext Outgoing Operands and Sizes	219
Table 223. TPM_LoadAuthContext Incoming Operands and Sizes	220
Table 224. TPM_LoadAuthContext Outgoing Operands and Sizes	220
Table 225. TPM_DirWriteAuth Incoming Operands and Sizes	221
Table 226. TPM_DirWriteAuth Outgoing Operands and Sizes	221
Table 227. TPM_DirRead Incoming Operands and Sizes	222
Table 228. TPM_DirRead Outgoing Operands and Sizes	222
Table 229. TPM_ChangeAuthAsymStart Incoming Operands and Sizes	223
Table 230. TPM_ChangeAuthAsymStart Outgoing Operands and Sizes	224
Table 231. Field Descriptions for certifyInfo parameter	225
Table 232. TPM_ChangeAuthAsymFinish Incoming Operands and Sizes	226
Table 233. TPM_ChangeAuthAsymFinish Outgoing Operands and Sizes	227
Table 234. TPM_Reset Incoming Parameters and Sizes	228
Table 235. TPM_Reset Outgoing Parameters and Sizes	228
Table 236. TPM_OwnerReadPubek Incoming Operands and Sizes	229
Table 237. TPM_OwnerReadPubek Outgoing Operands and Sizes	229
Table 238. TPM_DisablePubekRead Incoming Operands and Sizes	230
Table 239. TPM_DisablePubekRead Outgoing Operands and Sizes	230

Table 240. TPM_LoadKey Incoming Operands and Sizes	232
Table 241. TPM_LoadKey Outgoing Operands and Sizes	232
Table 242. TPM_GetOrdinalAuditStatus Incoming Operands and Sizes	234
Table 243. TPM_GetOrdinalAuditStatus Outgoing Operands and Sizes	234
Table 244. TPM_CertifySelfTest Incoming Operands and Sizes	235
Table 245. TPM_CertifySelfTest Outgoing Operands and Sizes	235

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[ISO/IEC 11889-4:2009](https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009)

<https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>

Foreword

ISO (the International Organization for Standardization) and IEC (the International Electrotechnical Commission) form the specialized system for worldwide standardization. National bodies that are members of ISO or IEC participate in the development of International Standards through technical committees established by the respective organization to deal with particular fields of technical activity. ISO and IEC technical committees collaborate in fields of mutual interest. Other international organizations, governmental and non-governmental, in liaison with ISO and IEC, also take part in the work. In the field of information technology, ISO and IEC have established a joint technical committee, ISO/IEC JTC 1.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of the joint technical committee is to prepare International Standards. Draft International Standards adopted by the joint technical committee are circulated to national bodies for voting. Publication as an International Standard requires approval by at least 75 % of the national bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO and IEC shall not be held responsible for identifying any or all such patent rights.

ISO/IEC 11889-4 was prepared by the Trusted Computing Group (TCG) and was adopted, under the PAS procedure, by Joint Technical Committee ISO/IEC JTC 1, *Information technology*, in parallel with its approval by national bodies of ISO and IEC.

ISO/IEC 11889 consists of the following parts, under the general title *Information technology — Trusted Platform Module*:

- iTeh STANDARD PREVIEW**
(standards.iteh.ai)
- *Part 1: Overview*
 - *Part 2: Design principles*
 - *Part 3: Structures* <https://standards.iteh.ai/catalog/standards/sist/7ad5b4d-4655-4aff-81b1-32136ce0728f/iso-iec-11889-4-2009>
 - *Part 4: Commands*