<del>Designation: D6278-02</del> Designation: D 6278 - 07

An American National Standard

# Standard Test Method for Shear Stability of Polymer Containing Fluids Using a European Diesel Injector Apparatus<sup>1</sup>

This standard is issued under the fixed designation D 6278; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reapproval.

# 1. Scope\*

1.1 This test method covers the evaluation of the shear stability of polymer-containing fluids. The test method measures the percent viscosity loss at 100°C of polymer-containing fluids when evaluated by a diesel injector apparatus procedure that uses European diesel injector test equipment. The viscosity loss reflects polymer degradation due to shear at the nozzle.

Note 1—Test Method D 2603 has been used for similar evaluation of shear stability; limitations are as indicated in the significance statement. No detailed attempt has been undertaken to correlate the results of this test method with those of the sonic shear test method.

Note 2—This test method uses test apparatus as defined in CEC L-14-A-93. This test method differs from CEC-L-14-A-93 in the period of time required for calibration.

Note 3—Test Method D 5275 also shears oils in a diesel injector apparatus but may give different results.

Note—This test method has different calibration and operational requirements than Test Method D3945. 4—This test method has different calibration and operational requirements than withdrawn Test Method D 3945.

Note 5—Test Method D 7109 is a similar procedure that measures shear stability at both 30 and 90 injection cycles. This test method uses 30 injection cycles only.

1.2 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Specific precautionary statements are given in Section 8.

# 2. Referenced Documents

- 2.1 ASTM Standards: <sup>2</sup>
- D 445 Test Method for Kinematic Viscosity of Transparent and Opaque Liquids (and the Calculation of Dynamic Viscosity) D 2603Test Method for Sonic Shear Stability of Polymer-Containing Oils<sup>2</sup>
- D3945Test Method for Shear Stability of Polymer-Containing Fluids Using a Diesel Injector Nozzle Test Method for Sonic Shear Stability of Polymer-Containing Oils
- D 5275 Test Method for Fuel Injector Shear Stability Test (FISST) for Polymer Containing Fluids
- D 6299 Practice for Applying Statistical Quality Assurance Techniques to Evaluate Analytical Measurement System Performance
- D 7109 Test Method for Shear Stability of Polymer Containing Fluids Using a European Diesel Injector Apparatus at 30 and 90 Cycles
- 2.2 Coordination European Council (CEC) Standard:<sup>3</sup>
- CEC L-14-A-93 Evaluation of the Mechanical Shear Stability of Lubricating Oils Containing Polymers

## 3. Terminology

- 3.1 Definitions:
- 3.1.1 kinematic viscosity, n—a measure of the resistance to flow of a fluid under gravity.
- 3.2 Definitions of Terms Specific to This Standard:
- 3.2.1 *calibration pressure*, *n*—the recorded gauge pressure when calibration fluid RL34 or RL233 undergoes a viscosity loss of 2.75 to 2.85 mm<sup>2</sup>/s when the recorded gauge pressure is within the range of 13.0 to 18.0 MPa.

<sup>&</sup>lt;sup>1</sup> This test method is under the jurisdiction of ASTM Committee D02 on Petroleum Products and Lubricants and is the direct responsibility of Subcommittee D02.07 on Flow Properties.

Current edition approved April 10, 2002. Published June 2002. Originally published as D6278-98. Last previous edition D6278-98.

Current edition approved Dec. 1, 2007. Published January 2008. Originally approved in 1998. Last previous edition approved in 2002 as D 6278-02.

<sup>&</sup>lt;sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For Annual Book of ASTM Standards, Vol 05.01.volume information, refer to the standard's Document Summary page on the ASTM website.

<sup>&</sup>lt;sup>3</sup> Annual Book of ASTM Standards, Vol 05.02.

Available from CEC Secretariat, Madou Plaza, 25<sup>th</sup> floor, Place Madou 1, B-1210 Brussels, Belgium.



- 3.2.2 *viscosity loss*, *n*—the loss in viscosity determined from the difference in kinematic viscosity at 100°C of pre-sheared and post-sheared fluid.
  - 3.2.3 percent viscosity loss, n—viscosity loss, as defined in 3.2.2, divided by the pre-sheared viscosity, and reported as a percent.

#### 4. Summary of Test Method

4.1 A polymer-containing fluid is passed through a diesel injector nozzle at a shear rate that causes polymer molecules to degrade. The resultant degradation reduces the kinematic viscosity of the fluid under test. The percent viscosity loss is a measure of the mechanical shear stability of the polymer-containing fluid.

#### 5. Significance and Use

- 5.1 This test method evaluates the percent viscosity loss for polymer-containing fluids resulting from polymer degradation in the high shear nozzle device. Thermal or oxidative effects are minimized.
  - 5.2 This test method is used for quality control purposes by manufacturers of polymeric lubricant additives and their customers.
- 5.3 This test method is not intended to predict viscosity loss in field service in different field equipment under widely varying operating conditions, which may cause lubricant viscosity to change due to thermal and oxidative changes as well as by the mechanical shearing of polymer. However, when the field service conditions, primarily or exclusively, result in the degradation of polymer by mechanical shearing, there may be a correlation between the results from this test method and results from the field.

## 6. Apparatus

- 6.1 The apparatus consists of a fluid reservoir, a double-plunger pump with an electric motor drive, an atomization chamber with a diesel injector spray nozzle, and a fluid cooling vessel, installed in an area with an ambient temperature of 20 to 25°C (68 to 77°F). FigureFig. A1.1 shows the schematic representation of equipment.
- 6.1.1 Fluid Reservoir, In Fig. A1.1, (7)<sup>4</sup> is open on the top, has approximately a 250 mL capacity, has a 45-mm (1.772-in.) inner diameter, and is calibrated in units of volume. It is fitted with an internal fluid distributor as detailed in Fig. A1.2. A 40-mm (1.575-in.) diameter watch glass with serrated edges is an acceptable distributor plate. The distributor reduces the tendency of fluid channeling. Temperature is measured by a thermometer suspended in the center of the fluid reservoir. The bottom of the thermometer bulb shall be 10 to 15 mm above the entrance to the drain tube opening. Other temperature-measuring equipment positioned at the same location may also be used. The outlet is equipped with a three-way stopcock (8). The three-way stopcock is of a cone type with a nonexchangeable solid plug with an 8-mm (0.315-in.) nominal bore size. Transparent, plastic tubing, (10) in Fig. A1.1, is used to connect the three-way stopcock to the pump inlet.
- 6.1.2 *Double-Plunger Injection Pump*, In Fig. A1.1 (11) is defined as Bosch PE 2 A 90D 300/3 S2266. This pump is equipped with a stroke counter, (15), venting screw, (14), and flow rate adjusting screw, (12).
- 6.1.3 Injection Pump, driven by a three-phase electric motor, (13) in Fig. A1.1., A1.1, rated at a speed of 925  $\pm$  25 rpm.
- 6.1.3.1 This motor runs at 925 rpm on the 50 Hz current prevalent in Europe; it will run at approximately 1100 rpm on 60 Hz current. The 1100 rpm speed is not acceptable in this procedure. A suitable means shall be taken to ensure the prescribed 925  $\pm$  25 rpm speed to the injection pump. One acceptable method is to use a 6 to 5 speed reducer.
- 6.1.4 *Outlet of Injection Pump*, connected to the atomization chamber using high pressure steel tubing. The atomization chamber, (2) in Fig. A1.1, is defined in more detail in Fig. A1.3. To minimize foam generation, the spray chamber is designed so that the fluid under test exits from the nozzle into a chamber filled with the test fluid. A drain tube (17) fitted with a two-way stopcock is included to minimize contamination from the previous test during the system cleaning steps. The diesel injector nozzle is a Bosch DN 8 S 2-type pintle nozzle injector, number 0434 200 012, installed in a Bosch KD 43 SA 53/15 nozzle holder. The nozzle holder includes a filter cartridge.
- Note5—Take 6—Take great care to avoid damage to the precision parts of the fuel injection equipment (the plunger and barrel in the pump and the nozzle valve assembly). Service work on the equipment should be performed by a diesel fuel injector pump specialist or with reference to the manufacturer's service manual.<sup>5</sup>
- Note6—An 7—An unusual rapid rise in gauge pressure during testing may signify filter blockage. When this occurs, the filter cartridge shall be replaced.
- 6.1.5 A pressure sensing device (18), such as a glycerol-filled pressure gauge or *electronic*, *digital display pressure indicator*, shall be installed and separated from the line by a pressure snubber or needle valve to suitably dampen pressure surges. The pressure device shall be occasionally pressure tested to ensure accuracy.
- 6.1.6 Fluid Cooling Vessel, ((5) in Fig. A1.1), used to maintain the specified temperature of the test fluid, as indicated at the outlet of the fluid reservoir. This vessel is a glass container with exterior cooling jacket constructed so that the heat transfer surface of the jacket is spherical. The exterior jacket diameter,  $d_1$ , is approximately 50 mm (1.969 in.). The interior heat transfer surface,

<sup>&</sup>lt;sup>4</sup> Annual Book of ASTM Standards, Vol 05.03.

<sup>&</sup>lt;sup>4</sup> The number in parentheses refers to the legend in Fig. A1.1.

Available from CEC Secretariat, Madou Plaza, 25th floor, Place Madou 1, B-1210 Brussels, Belgium.

Repair Instructions for Diesel Injection Pumps Size A, B, K and Z, Bulletin WJP 101/1 B EP, Robert Bosch GmbH, 2800 South 25th Ave., Broadview, IL 60153.

 $d_2$ , is approximately 25 mm (0.984 in.) in diameter. The overall length, L, is approximately 180 mm (7.087 in.). A distributor plate, similar in design to the distributor plate in the fluid reservoir, is positioned in the upper portion of the fluid cooling vessel to ensure contact between the fluid and the cooling surface. The discharge from the fluid cooling vessel is through a three-way stopcock of the same design used on the discharge of the fluid reservoir. The exterior cooling jacket shall be supplied with an adjustable volume of cold water.

# 7. Materials

- 7.1 Diesel Fuel (No. 2), initially required to adjust the diesel injector nozzle valve opening pressure.
- 7.2 Calibration Fluid RL34, used to ensure that when the apparatus is adjusted within a prescribed pressure range, the correct viscosity loss is obtained.
- 7.3 Calibration Fluid RL233, used to ensure that when the apparatus is adjusted to within a prescribed pressure range, the correct viscosity loss is obtained.

Note 8—Both calibration fluids RL34 and RL233 meet the requirements of this test method and are equivalent. Both are acceptable during a transition period between suppliers. See research report for details of the equivalence testing.<sup>6</sup>

#### 8. Hazards

- 8.1 Warning—Use a safety shield between the high-pressure components and the operator during use of equipment.
- 8.2 Precaution —During operation, the line between the pump and nozzle, ((16) in Fig. A1.1), is under a pressure of at least 13.0 MPa (130 bar, or 1,885 psi). Pressures above the upper limit of 18.0 MPa (180 bar or 2611 psi) are possible if filter plugging occurs. Shut off the pump prior to tightening any fitting that is not properly sealed.

#### 9. Sampling

- 9.1 Approximately 600 mL of fluid is needed per test.
- 9.2 The test fluid shall be at room temperature, uniform in appearance, and free of any visible insoluble material prior to placing in the test equipment.
- 9.3 Water and insolubles shall be removed before testing, or filter blocking and nozzle wear may occur. Filter blocking can be detected by a sudden change in gauge pressure. The transport of insolubles to the shear zone will shorten nozzle life.

## 10. Calibration and Standardization

- 10.1 *Nozzle Adjustments*—If the nozzle to be used is new or has not been pre-calibrated, adjust the diesel injector nozzle holder with the nozzle in place. Adjust the nozzle using diesel fuel and a nozzle tester so that the valve opening pressure is 13.0 MPa (1885 psi) under static conditions. If the nozzle has been pre-calibrated with RL34 or RL233 calibration oil, adjust the valve opening pressure to the calibration pressure prescribed, which must be between 13.0 MPa and 18.0 MPa (2611 psi).
- 10.1.1 Install the nozzle and the nozzle holder in the test apparatus. The pintle/spray nozzle shall be tightly fitted in the chamber to avoid leakage of oil around the external surface of the spray nozzle.
  - 10.2 Measurement of Residual Undrained Volume, V<sub>res</sub>:
- 10.2.1 The residual undrained oil volume of the system is the volume of the system between the three-way stopcock below the fluid reservoir, (8) in Fig. A1.1, and the injector nozzle orifice, (1).  $V_{res}$  does not include the atomization chamber volume. When the residual undrained volume is known, go to 10.3.
  - 10.2.2 To determine residual undrained volume, first remove as much fluid as possible by briefly running the pump.
- 10.2.3 Remove the high-pressure lines, (16) in Fig. A1.1, and drain. Remove the plug at the end of the pump gallery to drain the remaining oil in the pump. Drain atomization chamber (2).
- 10.2.4 Reassemble the system and close all drains. The upper three-way stopcock (6) shall be open to the lower reservoir (7) and the lower three-way cock (8) shall be open to the pump suction (10).
- 10.2.5 Add 170 mL of RL34 or RL233 calibration oil to the lower reservoir (7) and observe the level. Start the pump and run for several minutes until the oil is transparent and free of suspended air.
- 10.2.6 Stop the pump. Drain the fluid in the atomization chamber into a beaker and then pour the fluid back into the lower reservoir; draining to waste will result in an error in the measurement of  $V_{res}$ . Allow the system to drain for 20 min and free air trapped in the transparent connecting tube between the lower reservoir and pump.
- 10.2.7 Observe the difference in oil level in the lower reservoir compared to that noted in 10.2.5. Record this difference as the residual volume,  $V_{res}$ .
- Note 79—Undrained residual volumes of 15 to 30 mL have been reported by various users of this test.  $V_{res}$  measurements in excess of this may occur when fluid in the atomization chamber is not poured back into the lower reservoir as in 10.2.6, or if the length of line (10) is excessive.
  - 10.2.8 Calculate the run volume,  $V_{run}$ , which is the subtractive difference between 170 mL and  $V_{res}$ .

<sup>&</sup>lt;sup>6</sup> The number in parentheses refers to the legend in Fig. A1.1.

<sup>&</sup>lt;sup>6</sup> Supporting data have been filed at ASTM International Headquarters and may be obtained by requesting Research Report RR:D02-1629.



- 10.3 Cleaning the Apparatus, Setting the Stroke Counter, and Adjusting the Pump Stroke:
- 10.3.1 Drain residual oil by way of drain line (17) from the atomization chamber into a waste container. Drain fluid in the cooling jacket by means of stopcock (6) (Fig. A1.1) and the fluid reservoir by means of stopcock (8), into suitable waste containers.
- 10.3.2 After fluid has drained, leave the stopcock on the drain line to the atomization chamber open and the three-way stopcock (6) positioned so that fluid in the cooling jacket drains to a waste container. Position stopcock (8) so that the drain is closed but the fluid reservoir is open to pump suction through line (10). Add a minimum of 50 mL of RL34 or RL233 to the fluid reservoir.

Note8—Steps\_10—Steps\_10.3.2-10.3.7 are representative of the first and second purges with 50 mL fluid that are needed to remove used oil from the apparatus prior to calibration and testing. For these steps, the stopcock below the atomization chamber and cooling jackets are set so that oil will flow into waste containers.

- 10.3.3 Free the apparatus of air in the line by use of the venting screw, (14), and by manual compression of the transparent flexible tube that connects the pump to the fluid reservoir.
  - 10.3.4 Set the stroke counter so that the pump will run a sufficient length of time to evacuate the fluid out of the fluid reservoir.
- 10.3.5 Start the pump. Observe the fluid level in the reservoir and stop the pump when all the fluid is out of the base of the reservoir but is still fully-retained in line (10).
- 10.3.6 Add a minimum of 50 mL of RL34 or RL233 fluid to the fluid reservoir a second time and operate the pump until the fluid reservoir is empty but line (10) is still filled with fluid.
  - 10.3.7 After all oil has drained, close the stopcock on the atomization chamber drain line (17), position stopcock (6) so that fluid will flow from the cooling jacket into the fluid reservoir.
    - 10.3.8 Remove the thermometer or temperature probe from the fluid reservoir.
- Note9—The 11—The thermometer and assembly can interfere with the obtainment of accurate volume measurements in the fluid reservoir, hence its removal is called for when the accurate determination of fluid volume is needed. A thermocouple or thermistor probe is a suitable alternative to a thermometer.
  - 10.3.9 Add a minimum amount of fluid equal to the sum of 30 mL plus  $V_{run}$ , determined in 10.2.8, to the fluid reservoir.
  - 10.3.10 Close the stopcock below the atomization chamber drain line (17) and position stopcock (6) so that the fluid will drain from the cooling jacket into the fluid reservoir.
- Note<del>10—The</del> 12—The atomization chamber drain line is always closed for the third cleaning run and all test runs.
  - 10.3.11 Free the apparatus of air in the line by manual compression of the flexible tube (10) that connects the pump to the fluid reservoir. The venting screw, (14), is also used for this purpose.
    - 10.3.12 Record the number on the stroke counter.
    - 10.3.13 Use a stopwatch or other timing device and run the pump for 1 min  $\pm$  1 s.
    - 10.3.14 Determine n, the difference in the stroke count from 10.3.12.
  - 10.3.15 Set the stroke counter shutoff to the product of three times n. The pump shall run for 3 min. Obtain a timing device to observe the time the stroke counter is on to ensure n is correct. Start the pump and allow oil to circulate until the impulse counter shuts down the instrument. In a catalogy standards (SIST) 1380369 and 14300 at 14300 at
    - 10.3.16 When all fluid has drained, adjust the volume of oil in the fluid reservoir so that the volume is equal to  $V_{run}$ .
    - 10.3.17 Set the impulse counter to 0.5 ( n).
    - 10.3.18 Close stopcock (6) so that fluid will be stored in the cooling jacket after the pump is started.
    - 10.3.19 Start the pump. When the pump stops and draining is complete, subtract the volume now in the fluid reservoir from  $V_{run}$ .
    - 10.3.20 If the difference is within  $\pm$  2.5 mL of 1/2 of  $V_{run}$ , proceed to 10.4.
  - 10.3.21 When the volume in the fluid reservoir is not within  $\pm$  2.5 mL of  $V_{run}$ , drain the fluid from the cooling jacket back into the fluid reservoir, adjust the pump stroke by means of the pump adjustment screw (12), and repeat steps beginning with 10.3.16.
- 10.4 *Warm-up*—A half-hour warm up period is required before proceeding to calibrate with RL34 or RL233. Set the stroke counter shut-off to 30 times *n* strokes, and start the pump.
- Note<del>11—This</del> 13—This warm up period is only required for the first within-day calibration.
  - 10.5 Removal of Fluid—Open the stopcock below the atomization chamber and drain to waste. Drain the fluid from the cooling jacket into a waste container. Position stopcock (8) so that all fluid in the fluid reservoir is removed to a waste container. When drainage is complete, position stopcock (8) so that the drain is closed and the pump inlet line (10) is open.
- 10.6 Calibration with RL34 Calibration with RL34 or RL233:
  - 10.6.1 Ensure that the ambient (room) temperature is between 20 to 25°C.
- 10.6.2 Add a minimum of 50 mL of RL34 or RL233 to the fluid reservoir. Position the three-way stopcock, (6) in Fig. A1.1, below the cooling vessel to discharge fluid into a suitable waste container and leave the stopcock open below the atomization chamber. Operate the pump until the fluid reservoir is empty but line (10) is still filled with fluid.
  - 10.6.3 Free the apparatus of air in the line by manual compression of the flexible tube that connects the pump to the fluid reservoir. When necessary, venting screw (14) is also used for this purpose.
  - 10.6.4 Add a minimum of 50 mL of test fluid to the fluid reservoir a second time and operate the pump until the fluid reservoir is empty again but line (10) is full.
    - 10.6.5 Close the stopcock below the atomization chamber, position the stopcock below the fluid reservoir so that the line to the