INTERNATIONAL STANDARD

First edition 2020-04

Intelligent transport systems — Partially automated lane change systems (PALS) — Functional / operational requirements and test procedures

Systèmes de transport intelligents — Systèmes de changement de voie partiellement automatisés (PALS) — Exigences fonctionnelles et opérationnelles et procédures d'essai

Document Preview

[<u>SO 21202:202</u>

https://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020



Reference number ISO 21202:2020(E)

iTeh Standards (https://standards.iteh.ai) Document Preview

<u>ISO 21202:2020</u>

https://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020



COPYRIGHT PROTECTED DOCUMENT

© ISO 2020

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office CP 401 • Ch. de Blandonnet 8 CH-1214 Vernier, Geneva Phone: +41 22 749 01 11 Fax: +41 22 749 09 47 Email: copyright@iso.org Website: www.iso.org

Published in Switzerland

Page

Contents

Forev	word		iv	
Intro	ductio	n	v	
1	Scon	e	1	
1 2	Norr		£	
Z	Normative references			
3	Terms and definitions			
4	Syml	bols and abbreviated terms		
	4.1	Symbols		
	4.2	Abbreviated term	3	
5	Classification			
	5.1	General		
		5.1.1 Type I systems		
		5.1.2 Type II systems		
6	Requirements			
	6.1	General	5	
	6.2	Functionality	5	
	6.3	State transitions	6	
		6.3.1 General	6	
		6.3.2 PALS off state	6	
		6.3.3 Transition from PALS off state to PALS stand-by state		
		6.3.4 Transition from PALS stand-by state to PALS off state	6	
		6.3.5 PALS stand-by state		
		6.3.0 PALS active state 6.3.7 Transition from PALS stand by state to PALS active state	0 7	
		6.3.8 Transition from PALS active state to PALS active state		
		639 Transition from PALS active state to PALS off state		
	6.4	Driver interface and override canabilities	7	
	011	6.4.1 System reaction		
		¹¹⁰ 6.4.2 ^{cata} Display elements	202-2020 8	
	6.5	Minimum performance		
		6.5.1 Duration of the lane change manoeuvre		
		6.5.2 Velocity for PALS operation		
		6.5.3 Operational limit		
	6.6	Failure reactions	8	
7	Performance evaluation test methods			
	7.1	Environmental conditions	9	
	7.2	 2 Test course conditions 3 Test vehicle conditions 		
	7.3			
	7.4	Test system installation and configuration	9	
	7.5	Test procedures	9	
		7.5.1 Parameters recoverable from data record		
		7.5.2 Lane change test (types I and II)		
		7.5.3 Gap search test (type II only)		
Bibli	ograpł	ıy		

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see <u>www.iso.org/</u> iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 204, Intelligent transport systems.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at <u>www.iso.org/members.html</u>.

O 21202:2020

https://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020

Introduction

In general, driving assist systems and automated driving systems equipped in a vehicle reduce the burden of the drivers and contribute to safe driving. For a lane change operation, there are many drivers who are not good at performing a lane change. To support such drivers, Partially Automated Lane Change Systems (PALS) execute an automatic lane change manoeuvre following the request of the driver and under the supervision of the driver, on a road with visible lane markings, where non-motorized vehicles and pedestrians are prohibited.

PALS acquire information not only on the position of the vehicle within the lane, but also on adjacent lanes and obstacles in the vicinity of the subject vehicle (SV). PALS evaluate whether or not a lane change to an adjacent lane is possible and send commands to the actuators which control lateral movement of the vehicle to perform a lane change. This document specifies how PALS support drivers for a lane change and describes PALS' operations.

iTeh Standards (https://standards.iteh.ai) Document Preview

ISO 21202:2020

https://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020

iTeh Standards (https://standards.iteh.ai) Document Preview

<u>ISO 21202:2020</u> https://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020

Intelligent transport systems — Partially automated lane change systems (PALS) — Functional / operational requirements and test procedures

1 Scope

This document contains the basic control strategy, minimum functionality requirements, basic driver interface elements, minimum requirements for reaction to failure, and performance test procedures for PALS.

PALS perform part or all of lane change tasks under the driver's initiation and supervision. PALS are intended to function on roads with visible lane markings, where non-motorized vehicles and pedestrians are prohibited (e.g. access controlled highway), and to perform a lane change into a lane with traffic moving in the same direction. Support on sections of roadway with temporary or irregular lane markings (such as roadwork zones) is not within the scope of this document.

This document does not describe functionalities based on combinations with longitudinal control systems such as those standardized in ISO 22839 (FVCMS) or ISO 15622 (ACC).

The driver always assumes responsibility for this system and the driver's decisions and operations take priority at all times.

Use of PALS is intended for light-duty and heavy-duty vehicles (heavy trucks and buses).

This document does not address any functional or performance requirements for detection sensors, nor any communication links for co-operative solutions.

2 Normative references

s://standards.iteh.ai/catalog/standards/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-202

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 15037-1, Road vehicles — Vehicle dynamics test methods — Part 1: General conditions for passenger cars

ISO 15037-2, Road vehicles — Vehicle dynamics test methods — Part 2: General conditions for heavy vehicles and buses

ISO 17387, Intelligent transport systems — Lane change decision aid systems (LCDAS) — Performance requirements and test procedures

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at https://www.iso.org/obp
- IEC Electropedia: available at <u>http://www.electropedia.org/</u>

3.1

subject vehicle

SV

vehicle equipped with the system in question and related to the topic of discussion

3.2

PALS state

one of several stages or phases of the system operation flow

Note 1 to entry: See Figure 1.

3.3

PALS off state

PALS state when the system is switched off

3.4

PALS stand-by state

PALS state when the system is switched on, but the activation criteria are not all met

3.5

PALS active state

PALS state when the system is switched on and the activation criteria are met

3.6

lane

one of the longitudinal strips into which a roadway is divided by *lane markings* (3.7)

3.7

lane marking

delineators, markings, or Botts' dots intentionally placed on the borderline of the lane (3.6)

3.8

lane change manoeuvre

lateral movement which the system automatically executes to change *lanes* (3.6) from its initial lane to an adjacent lane

3.9

lane change function

function of the system which includes both gap-searching and *lane change manoeuvre* (3.8)

3.10

time gap

value calculated from vehicle speed, *v*, and clearance, *c*, by the Formula: $t_{gap} = c/v$

Note 1 to entry: see Figure 1



Figure 1 — Time gap

3.11 time to collision TTC

estimated time that it would take a target vehicle to collide with the SV if the SV were in the target vehicle's path and the target vehicle's current closing speed remains constant

3.12

overtaking speed

difference between the SV's speed and the target vehicle's speed when the SV is overtaking the target vehicle

Note 1 to entry: A positive overtaking speed indicates that the SV is moving faster than the target vehicle.

3.13

gap searching

system function to search for sufficient gap between the SV and the other vehicle(s) in the adjacent target lane

4 Symbols and abbreviated terms

4.1 Symbols

See <u>Table 1</u>.

	Symbol	Definition	
	A _{PALS,l,max}	Maximum lateral acceleration which is allowed to be induced by a lane change manoeuvre	
	J _{PALS,l,max}	Maximum lateral jerk which is allowed to be induced by a lane change manoeuvre	
ps:	V _{max}	Maximum SV speed which PALS is required to function	
	$V_{\rm min}$ (ht	Minimum SV speed which PALS is required to function	
	V _{sv}	Velocity of SV	
	$V_{\rm rv}$	Velocity of the rearward vehicle VIEW	
	$V_{\rm fv}$	Velocity of the forward vehicle	
	<i>D</i> r //standards.iteh.ai/catalog/	Distance between the front edge of the rearward vehicle and the rear edge of the SV	
	D_{f}	Distance between the rear edge of the forward vehicle and the forward edge of the SV. The distance is equivalent to $V_{sv} \times T_{f.}$	
	T_{f}	Time gap between the forward vehicle and the SV	
	T _{col,r}	TTC between the rearward vehicle and the SV	
	T _{I,S}	Time from the initiation of the lane change function to the start of the lane change manoeuvre itself, in a free gap available condition	

Table 1 — Symbols

4.2 Abbreviated term

- ACC Adaptive cruise control
- HMI Human-machine interface
- LCDAS Lane Change Decision Aid Systems
- SV Subject vehicle
- TTC Time to collision

5 Classification

5.1 General

PALS are classified into two types by different tasks split between system and driver as shown in 5.1.1, and 5.1.2, and by a modified sequence of operations. In both types, the lane change manoeuvre is initiated and supervised by the driver and is terminated when the SV is brought totally inside the target lane.

In Type I systems, the driver intends to promptly change the lane as the driver evaluates the target lane to be free and the PALS receive a driver command to perform the lane change manoeuvre. The system performs the lane change unless it detects an adjacent vehicle that obstructs the lane change.

In Type II systems, the driver intends to change the lane as soon as a sufficient gap in the target lane becomes available. The driver authorizes the system to search for a sufficient gap and then to perform a lane change manoeuvre.

In both types, a lane change manoeuvre is only started when no hazardous obstacle is detected in the relevant range for Type I or Type II, respectively (see 5.1.1 and 5.1.2).

For both types, the point in time when the SV leaves the current lane is specified as the point in time when the preceding wheel of the SV crosses the inner edge of the lane marking.

Type I and II systems can be offered separately, or as a combined system with both types in one system.

Both types may be combined with a longitudinal control system such as ISO 15622 (ACC) to maintain an appropriate time gap behind a forward vehicle.

5.1.1 Type I systems

Type I systems perform a lane change corresponding to the driver's initiation by controlling the lateral manoeuvre of the vehicle when there is no obstacle detected at least in the blind spot area. Means to detect the blind spot area shall conform to the requirements of LCDAS Type I specified in ISO 17387.

The following actions shall be performed. ds/iso/f7b5792b-04b0-40a8-b0c4-ac9d7d7e4d2a/iso-21202-2020

- a) The driver monitors the target lane and initiates a lane change manoeuvre (e.g. by indicator or specific HMI) if he or she believes that there is no hazardous obstacle in the target lane.
- b) The system monitors the traffic situation at least in the blind spot area, (see ISO 17387:2008, LCDAS Type I) and if there is no interfering vehicle, the requested lane change manoeuvre can be executed. The system performs the lane change unless it detects an adjacent vehicle that obstructs the lane change. If a vehicle is detected in the adjacent lane, the PALS lane change function is cancelled and an additional driver initiation may be applied to start the lane change manoeuvre at a later time.
- c) The turn signal shall be activated no later than at the beginning of the lane change manoeuvre. The SV should not leave the current lane earlier than 3 s and shall not leave earlier than 1 s after activation of the turn signal.
- d) The driver shall be informed when the lane change manoeuvre starts.
- e) The system performs a lane change manoeuvre when the necessary activation conditions have been met.

5.1.2 Type II systems

If the driver initiates a lane change, Type II systems search the gap in the adjacent lane at least in the blind spot and closing range and automatically perform the lane change. Means to detect the blind spot and closing range shall conform to the requirements of LCDAS Type III C specified in ISO 17387.