



**Universal Mobile Telecommunications System (UMTS);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 25.331 version 8.25.0 Release 8)**



ReferenceRTS/TSGR-0225331v8p0

Keywords

UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

http://portal.etsi.org/chaicor/ETSI_support.asp

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2014.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.
GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://ipr.etsi.org>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**may not**", "**need**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	34
1 Scope	35
2 References	35
3 Definitions and abbreviations.....	38
3.1 Definitions	38
3.2 Abbreviations	39
4 General	42
4.1 Overview of the specification.....	42
4.2 RRC Layer Model	43
4.3 Protocol specification principles	46
5 RRC Functions and Services provided to upper layers	46
5.1 RRC Functions	46
5.2 RRC Services provided to upper layers.....	47
5.3 Primitives between RRC and upper layers.....	47
6 Services expected from lower layers.....	47
6.1 Services expected from Layer 2	47
6.2 Services expected from Layer 1.....	47
6.3 Signalling Radio Bearers.....	47
7 Protocol states	48
7.1 Overview of RRC States and State Transitions including GSM and E-UTRA	48
7.2 Processes in UE modes/states.....	49
7.2.1 UE Idle mode.....	49
7.2.2 UTRA RRC Connected mode.....	49
7.2.2.1 URA_PCH or CELL_PCH state	49
7.2.2.2 CELL_FACH state.....	50
7.2.2.3 CELL_DCH state.....	51
8 RRC procedures	52
8.1 RRC Connection Management Procedures	53
8.1.1 Broadcast of system information	53
8.1.1.1 General	53
8.1.1.1.1 System information structure.....	53
8.1.1.1.2 System information blocks	54
8.1.1.1.3 Segmentation and concatenation of system information blocks	60
8.1.1.1.4 Re-assembly of segments	61
8.1.1.1.5 Scheduling of system information.....	62
8.1.1.2 Initiation.....	62
8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE.....	62
8.1.1.4 Void.....	63
8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s).....	63
8.1.1.6 Actions upon reception of system information blocks	67
8.1.1.6.1 System Information Block type 1	68
8.1.1.6.2 System Information Block type 2	69
8.1.1.6.3 System Information Block type 3.....	69
8.1.1.6.4 System Information Block type 4.....	74
8.1.1.6.5 System Information Block type 5 and 5bis.....	74
8.1.1.6.6 System Information Block type 6.....	78
8.1.1.6.7 System Information Block type 7.....	81

8.1.1.6.8	Void	81
8.1.1.6.9	Void	81
8.1.1.6.10	Void	81
8.1.1.6.11	System Information Block type 11	81
8.1.1.6.11a	System Information Block type 11bis	83
8.1.1.6.12	System Information Block type 12	83
8.1.1.6.13	System Information Block type 13	85
8.1.1.6.14	System Information Block type 14	85
8.1.1.6.15	System Information Block type 15	85
8.1.1.6.15.0	System Information Block type 15bis	85
8.1.1.6.15.1	System Information Block type 15.1	86
8.1.1.6.15.1a	System Information Block type 15.1bis	86
8.1.1.6.15.2	System Information Block type 15.2	86
8.1.1.6.15.2a	System Information Block type 15.2bis	87
8.1.1.6.15.2b	System Information Block type 15.2ter	87
8.1.1.6.15.3	System Information Block type 15.3	87
8.1.1.6.15.3a	System Information Block type 15.3bis	88
8.1.1.6.15.4	System Information Block type 15.4	89
8.1.1.6.15.5	System Information Block type 15.5	89
8.1.1.6.15.6	System Information Block type 15.6	89
8.1.1.6.15.7	System Information Block type 15.7	89
8.1.1.6.15.8	System Information Block type 15.8	89
8.1.1.6.16	System Information Block type 16	90
8.1.1.6.17	System Information Block type 17	90
8.1.1.6.18	System Information Block type 18	90
8.1.1.6.19	System Information Block type 19	92
8.1.1.6.20	System Information Block type 20	92
8.1.1.7	Modification of system information	92
8.1.1.7.1	Modification of system information blocks using a value tag	92
8.1.1.7.2	Synchronised modification of system information blocks	93
8.1.1.7.3	Actions upon system information change	93
8.1.1.7.4	Actions upon expiry of a system information expiry timer	94
8.1.2	Paging	94
8.1.2.1	General	94
8.1.2.2	Initiation	94
8.1.2.3	Reception of a PAGING TYPE 1 message by the UE	95
8.1.3	RRC connection establishment	97
8.1.3.1	General	97
8.1.3.2	Initiation	97
8.1.3.3	RRC CONNECTION REQUEST message contents to set	98
8.1.3.4	Reception of an RRC CONNECTION REQUEST message by the UTRAN	100
8.1.3.5	Cell re-selection, T300 or T318 timeout	101
8.1.3.5a	Abortion of RRC connection establishment	102
8.1.3.6	Reception of an RRC CONNECTION SETUP message by the UE	102
8.1.3.7	Physical channel failure or cell re-selection	105
8.1.3.8	Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration	106
8.1.3.9	Reception of an RRC CONNECTION REJECT message by the UE	107
8.1.3.10	Invalid RRC CONNECTION REJECT message	110
8.1.4	RRC connection release	111
8.1.4.1	General	111
8.1.4.2	Initiation	111
8.1.4.3	Reception of an RRC CONNECTION RELEASE message by the UE	112
8.1.4.4	Invalid RRC CONNECTION RELEASE message	113
8.1.4.5	Cell re-selection or radio link failure	114
8.1.4.6	Expiry of timer T308, unacknowledged mode transmission	114
8.1.4.7	Void	115
8.1.4.8	Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN	115
8.1.4.9	Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission	115
8.1.4.10	Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state	115
8.1.4.11	Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN	115

8.1.4a	RRC connection release requested by upper layers	116
8.1.4a.1	General	116
8.1.4a.2	Initiation	116
8.1.5	Void	116
8.1.6	Transmission of UE capability information	116
8.1.6.1	General	116
8.1.6.2	Initiation	116
8.1.6.3	Reception of a UE CAPABILITY INFORMATION message by the UTRAN	118
8.1.6.4	Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE	118
8.1.6.5	Invalid UE CAPABILITY INFORMATION CONFIRM message	119
8.1.6.6	T304 timeout	119
8.1.7	UE capability enquiry	120
8.1.7.1	General	120
8.1.7.2	Initiation	120
8.1.7.3	Reception of a UE CAPABILITY ENQUIRY message by the UE	120
8.1.7.4	Invalid UE CAPABILITY ENQUIRY message	120
8.1.8	Initial Direct transfer	121
8.1.8.1	General	121
8.1.8.2	Initiation of Initial direct transfer procedure in the UE	121
8.1.8.2a	RLC re-establishment or inter-RAT change	123
8.1.8.2ab	Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i>	124
8.1.8.2b	Abortion of signalling connection establishment	124
8.1.8.2c	Inter-RAT handover from UTRAN to E-UTRAN	124
8.1.8.3	Reception of INITIAL DIRECT TRANSFER message by the UTRAN	124
8.1.9	Downlink Direct transfer	124
8.1.9.1	General	124
8.1.9.2	Initiation of downlink direct transfer procedure in the UTRAN	125
8.1.9.3	Reception of a DOWNLINK DIRECT TRANSFER message by the UE	125
8.1.9.3a	No signalling connection exists	125
8.1.9.4	Invalid DOWNLINK DIRECT TRANSFER message	126
8.1.10	Uplink Direct transfer	126
8.1.10.1	General	126
8.1.10.2	Initiation of uplink direct transfer procedure in the UE	126
8.1.10.2a	RLC re-establishment or inter-RAT change	127
8.1.10.2b	Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i>	127
8.1.10.2c	Inter-RAT handover from UTRAN to E-UTRAN	127
8.1.10.3	Reception of UPLINK DIRECT TRANSFER message by the UTRAN	128
8.1.11	UE dedicated paging	128
8.1.11.1	General	128
8.1.11.2	Initiation	128
8.1.11.3	Reception of a PAGING TYPE 2 message by the UE	128
8.1.11.4	Invalid PAGING TYPE 2 message	128
8.1.12	Security mode control	129
8.1.12.1	General	129
8.1.12.2	Initiation	129
8.1.12.2.1	Ciphering configuration change	129
8.1.12.2.2	Integrity protection configuration change	130
8.1.12.3	Reception of SECURITY MODE COMMAND message by the UE	132
8.1.12.3.1	New ciphering and integrity protection keys	136
8.1.12.4	Void	138
8.1.12.4a	Incompatible simultaneous security reconfiguration	138
8.1.12.4b	Cell update procedure during security reconfiguration	138
8.1.12.4c	Invalid configuration	139
8.1.12.5	Reception of SECURITY MODE COMPLETE message by the UTRAN	140
8.1.12.6	Invalid SECURITY MODE COMMAND message	142
8.1.13	Signalling connection release procedure	142
8.1.13.1	General	142
8.1.13.2	Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN	142
8.1.13.3	Reception of SIGNALLING CONNECTION RELEASE by the UE	143
8.1.13.4	Invalid SIGNALLING CONNECTION RELEASE message	143
8.1.13.5	Invalid configuration	143
8.1.14	Signalling connection release indication procedure	144

8.1.14.1	General	144
8.1.14.2	Initiation	144
8.1.14.2a	RLC re-establishment or inter-RAT change	146
8.1.14.3	Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN	146
8.1.14.4	Expiry of timer T323	146
8.1.15	Counter check procedure	146
8.1.15.1	General	147
8.1.15.2	Initiation	147
8.1.15.3	Reception of a COUNTER CHECK message by the UE	147
8.1.15.4	Reception of the COUNTER CHECK RESPONSE message by UTRAN	148
8.1.15.5	Cell re-selection	148
8.1.15.6	Invalid COUNTER CHECK message	148
8.1.16	Inter RAT handover information transfer	148
8.1.16.1	General	149
8.1.16.2	Initiation	149
8.1.16.3	INTER RAT HANDOVER INFO message contents to set	149
8.1.17	ETWS primary notification with security procedure	151
8.1.17.1	General	151
8.1.17.2	Initiation	151
8.1.17.3	Void	151
8.1.17.4	Reception of the ETWS PRIMARY NOTIFICATION WITH SECURITY message	151
8.1.17.5	Forward of the ETWS primary notification to the upper layers	151
8.1.17.6	Void	151
8.2	Radio Bearer control procedures	152
8.2.1	Radio bearer establishment	152
8.2.2	Reconfiguration procedures	152
8.2.2.1	General	154
8.2.2.2	Initiation	154
8.2.2.2a	Initiation of handover from GERAN <i>Iu mode</i>	156
8.2.2.3	Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message or Target cell HS-SCCH order by the UE	156
8.2.2.3a	Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN <i>Iu mode</i>	173
8.2.2.4	Transmission of a response message by the UE, normal case	174
8.2.2.5	Reception of a response message by the UTRAN, normal case	176
8.2.2.5a	Rejection by the UE	177
8.2.2.6	Unsupported configuration in the UE	178
8.2.2.7	Physical channel failure	178
8.2.2.8	Cell re-selection	179
8.2.2.9	Transmission of a response message by the UE, failure case	179
8.2.2.10	Reception of a response message by the UTRAN, failure case	180
8.2.2.11	Invalid configuration	180
8.2.2.12	Incompatible simultaneous reconfiguration	181
8.2.2.12a	Incompatible simultaneous security reconfiguration	181
8.2.2.12b	Cell update procedure during security reconfiguration	181
8.2.2.13	Invalid received message	182
8.2.2.14	Radio link failure	182
8.2.3	Radio bearer release	183
8.2.4	Transport channel reconfiguration	184
8.2.5	Transport format combination control	184
8.2.5.1	General	184
8.2.5.2	Initiation	184
8.2.5.3	Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE	184
8.2.5.4	Invalid configuration	186
8.2.5.5	Invalid TRANSPORT FORMAT COMBINATION CONTROL message	187
8.2.6	Physical channel reconfiguration	187
8.2.7	Physical Shared Channel Allocation [TDD only]	188
8.2.7.1	General	188
8.2.7.2	Initiation	188
8.2.7.3	Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE	188

8.2.7.4	Invalid PHYSICAL SHARED CHANNEL ALLOCATION message	190
8.2.8	PUSCH capacity request [TDD only]	191
8.2.8.1	General	191
8.2.8.2	Initiation	191
8.2.8.3	PUSCH CAPACITY REQUEST message contents to set	192
8.2.8.4	Reception of a PUSCH CAPACITY REQUEST message by the UTRAN	193
8.2.8.5	T310 expiry	193
8.2.9	Void	193
8.2.10	Uplink Physical Channel Control [TDD only]	193
8.2.10.1	General	193
8.2.10.2	Initiation	193
8.2.10.3	Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE	193
8.2.10.4	Invalid UPLINK PHYSICAL CHANNEL CONTROL message	194
8.2.11	Physical channel reconfiguration failure	194
8.2.11.1	General	195
8.2.11.2	Runtime error due to overlapping compressed mode configurations	195
8.2.11.3	Void	195
8.3	RRC connection mobility procedures	195
8.3.1	Cell and URA update procedures	195
8.3.1.1	General	198
8.3.1.2	Initiation	199
8.3.1.3	CELL UPDATE / URA UPDATE message contents to set	207
8.3.1.4	T305 expiry and the UE detects "out of service area"	211
8.3.1.4.1	Re-entering "in service area"	211
8.3.1.4.2	Expiry of timer T307	212
8.3.1.5	Reception of an CELL UPDATE/URA UPDATE message by the UTRAN	212
8.3.1.6	Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE	213
8.3.1.7	Transmission of a response message to UTRAN	223
8.3.1.7a	Physical channel failure	226
8.3.1.8	Unsupported configuration by the UE	228
8.3.1.9	Invalid configuration	229
8.3.1.9a	Incompatible simultaneous reconfiguration	230
8.3.1.9b	Security reconfiguration during Cell update procedure	231
8.3.1.10	Confirmation error of URA ID list	232
8.3.1.11	Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message	233
8.3.1.12	T302 expiry or cell reselection	233
8.3.1.13	T314 expiry	237
8.3.1.14	T315 expiry	237
8.3.1.15	Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	238
8.3.1.16	T320 Expiry	238
8.3.2	URA update	239
8.3.3	UTRAN mobility information	239
8.3.3.1	General	239
8.3.3.2	Initiation	239
8.3.3.3	Reception of UTRAN MOBILITY INFORMATION message by the UE	239
8.3.3.4	Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	243
8.3.3.5	Cell re-selection	243
8.3.3.5a	Incompatible simultaneous security reconfiguration	243
8.3.3.6	Invalid UTRAN MOBILITY INFORMATION message	244
8.3.3.7	T322 expiry	244
8.3.4	Active set update	245
8.3.4.1	General	245
8.3.4.2	Initiation	245
8.3.4.3	Reception of an ACTIVE SET UPDATE message by the UE	246
8.3.4.4	Unsupported configuration in the UE	249
8.3.4.5	Invalid configuration	249
8.3.4.5a	Void	250
8.3.4.5b	Incompatible simultaneous reconfiguration	250
8.3.4.6	Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN	250
8.3.4.7	Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN	250
8.3.4.8	Invalid ACTIVE SET UPDATE message	251
8.3.4.9	Reception of an ACTIVE SET UPDATE message in wrong state	251

8.3.5	Hard handover	251
8.3.5.1	Timing re-initialised hard handover	252
8.3.5.1.1	General	252
8.3.5.1.2	Initiation (FDD only)	252
8.3.5.2	Timing-maintained hard handover	253
8.3.5.2.1	General	253
8.3.5.2.2	Initiation (FDD only)	253
8.3.6	Inter-RAT handover to UTRAN	254
8.3.6.1	General	254
8.3.6.2	Initiation	254
8.3.6.3	Reception of HANDOVER TO UTRAN COMMAND message by the UE	255
8.3.6.4	Invalid Handover to UTRAN command message	260
8.3.6.4a	Unsupported configuration in HANDOVER TO UTRAN COMMAND message	260
8.3.6.5	UE fails to perform handover	260
8.3.6.6	Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN	261
8.3.7	Inter-RAT handover from UTRAN	261
8.3.7.1	General	261
8.3.7.2	Initiation	261
8.3.7.3	Reception of a HANDOVER FROM UTRAN COMMAND message by the UE	261
8.3.7.4	Successful completion of the inter-RAT handover	263
8.3.7.5	UE fails to complete requested handover	264
8.3.7.6	Invalid HANDOVER FROM UTRAN COMMAND message	264
8.3.7.7	Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN	265
8.3.7.8	Unsupported configuration in HANDOVER FROM UTRAN COMMAND message	265
8.3.7.8a	Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH	266
8.3.8	Inter-RAT cell reselection to UTRAN	266
8.3.8.1	General	266
8.3.8.2	Initiation	266
8.3.8.2a	Initiation of inter-RAT cell reselection from GERAN <i>Iu mode</i>	267
8.3.8.3	UE fails to complete an inter-RAT cell reselection	267
8.3.8.3a	UE fails to complete an inter-RAT cell reselection from GERAN <i>Iu mode</i>	267
8.3.9	Inter-RAT cell reselection from UTRAN	268
8.3.9.1	General	268
8.3.9.2	Initiation	268
8.3.9.2a	Initiation of inter-RAT cell reselection to GERAN <i>Iu mode</i>	268
8.3.9.3	Successful cell reselection	268
8.3.9.4	UE fails to complete an inter-RAT cell reselection	268
8.3.10	Inter-RAT cell change order to UTRAN	269
8.3.10.1	General	269
8.3.10.2	Initiation	269
8.3.10.3	UE fails to complete an inter-RAT cell change order	269
8.3.11	Inter-RAT cell change order from UTRAN	269
8.3.11.1	General	270
8.3.11.2	Initiation	270
8.3.11.3	Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE	270
8.3.11.4	Successful completion of the cell change order	271
8.3.11.5	Expiry of timer T309 or UE fails to complete requested cell change order	271
8.3.11.6	Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message	273
8.3.11.7	Invalid CELL CHANGE ORDER FROM UTRAN message	273
8.4	Measurement procedures	273
8.4.0	Measurement related definitions	273
8.4.1	Measurement control	275
8.4.1.1	General	275
8.4.1.2	Initiation	275
8.4.1.3	Reception of MEASUREMENT CONTROL by the UE	276
8.4.1.4	Unsupported measurement in the UE	283
8.4.1.4a	Configuration Incomplete	283
8.4.1.5	Invalid MEASUREMENT CONTROL message	283
8.4.1.6	Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state	284
8.4.1.6.1	Intra-frequency measurement	284
8.4.1.6.2	Inter-frequency measurement	285
8.4.1.6.3	Inter-RAT measurement	285

8.4.1.6.4	Quality measurement.....	286
8.4.1.6.5	UE internal measurement	286
8.4.1.6.6	Traffic volume measurement.....	286
8.4.1.6.7	UE positioning measurement.....	287
8.4.1.6a	Actions in CELL_FACH/CELL_PCH/URA_PCH state upon cell re-selection	289
8.4.1.7	Measurements after transition from CELL_FACH to CELL_DCH state	289
8.4.1.7.1	Intra-frequency measurement	289
8.4.1.7.2	Inter-frequency measurement	290
8.4.1.7.3	Inter-RAT measurement	290
8.4.1.7.4	Traffic volume measurement.....	290
8.4.1.7.5	UE positioning measurement.....	291
8.4.1.8	Measurements after transition from idle mode to CELL_DCH state	292
8.4.1.8.1	Intra-frequency measurement	292
8.4.1.8.2	Inter-frequency measurement	292
8.4.1.8.3	Inter-RAT measurement	292
8.4.1.8.4	Traffic volume measurement.....	292
8.4.1.8.5	UE positioning measurement.....	292
8.4.1.9	Measurements after transition from idle mode to CELL_FACH state.....	293
8.4.1.9.1	Intra-frequency measurement	293
8.4.1.9.2	Inter-frequency measurement	293
8.4.1.9.3	Inter-RAT measurement	293
8.4.1.9.4	Traffic volume measurement.....	293
8.4.1.9.5	UE positioning measurement.....	294
8.4.1.9a	Measurements after transition from connected mode to idle mode.....	294
8.4.1.9a.1	Intra-frequency measurement	294
8.4.1.9a.2	Inter-frequency measurement	294
8.4.1.9a.3	Inter-RAT measurement	294
8.4.1.9a.4	UE positioning measurement.....	295
8.4.1.9b	Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH.....	295
8.4.1.9b.1	Traffic volume measurement.....	295
8.4.1.9b.2	UE positioning measurement.....	295
8.4.1.9b.3	Inter-RAT measurement	296
8.4.1.9b.4	Intra-frequency measurement	296
8.4.1.9b.5	Inter-frequency measurement	296
8.4.1.9c	Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH	296
8.4.1.9c.1	Traffic volume measurement.....	296
8.4.1.9c.2	UE positioning measurement.....	297
8.4.1.9c.3	Inter-RAT measurement.....	297
8.4.1.10	Changes in measurement objects	297
8.4.1.10.1	Traffic volume measurement.....	297
8.4.1.10.2	Quality measurement.....	298
8.4.1.10.3	Intra-frequency, Inter-frequency and Inter-RAT measurements	298
8.4.1.11	Cell Reselection (FDD only and 1.28 Mcps TDD only).....	298
8.4.1.11.1	Traffic volume measurement.....	298
8.4.2	Measurement report	299
8.4.2.1	General	299
8.4.2.2	Initiation.....	299
8.4.3	Assistance Data Delivery	301
8.4.3.1	General	301
8.4.3.2	Initiation.....	301
8.4.3.3	Reception of ASSISTANCE DATA DELIVERY message by the UE.....	302
8.4.3.4	Invalid ASSISTANCE DATA DELIVERY message.....	302
8.5	General procedures.....	302
8.5.1	Selection of initial UE identity	302
8.5.2	Actions when entering idle mode from connected mode.....	303
8.5.3	Open loop power control upon establishment of DPCH	304
8.5.4	Physical channel establishment criteria in CELL_DCH state.....	305
8.5.4A	Physical channel establishment criteria for Enhanced Uplink in CELL_FACH state and Idle mode.....	305
8.5.5	Actions in "out of service area" and "in service area"	305
8.5.5.1	Detection of "out of service" area	305
8.5.5.1.1	Actions following detection of "out of service" area in URA_PCH or CELL_PCH state	305
8.5.5.1.2	Actions following detection of "out of service" area in CELL_FACH state.....	306

8.5.5.1.3	Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH	306
8.5.5.1.4	Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH	306
8.5.5.2	Detection of "in service" area.....	306
8.5.5.2.1	Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state	306
8.5.5.2.2	Actions following re-entry into "in service area" in CELL_FACH state	307
8.5.5.3	T316 expiry	307
8.5.5.4	T317 expiry	307
8.5.6	Radio link failure criteria and actions upon radio link failure	307
8.5.7	Open loop power control	308
8.5.8	Maintenance of Hyper Frame Numbers.....	313
8.5.9	START value calculation.....	313
8.5.10	Integrity protection	314
8.5.10.1	Integrity protection in downlink.....	315
8.5.10.2	Integrity protection in uplink.....	316
8.5.10.3	Calculation of message authentication code	317
8.5.11	FACH measurement occasion calculation	317
8.5.12	Establishment of Access Service Classes	319
8.5.13	Mapping of Access Classes to Access Service Classes	320
8.5.14	PLMN Type Selection	320
8.5.14a	Neighbour cells list narrowing for cell reselection	320
8.5.15	CFN calculation	320
8.5.15.1	Initialisation for CELL_DCH state after state transition.....	320
8.5.15.2	Initialisation in CELL_DCH state at hard handover	321
8.5.15.3	Initialisation for CELL_FACH	321
8.5.15.4	Initialisation after intersystem handover to UTRAN	321
8.5.15.5	Initialisation for MTCH and/or MSCH carried on S-CCPCH that may be soft combined	322
8.5.16	Configuration of CTCH occasions.....	322
8.5.17	PRACH selection.....	322
8.5.18	Selection of RACH TTI.....	323
8.5.18.1	FDD.....	323
8.5.18.2	1.28 Mcps TDD.....	324
8.5.19	Secondary CCPCH selection	325
8.5.19a	Secondary CCPCH and FACH selection for MCCH reception.....	325
8.5.20	Unsupported configuration	326
8.5.21	Actions related to Radio Bearer mapping	326
8.5.22	Actions when entering another RAT from connected mode.....	334
8.5.23	Measured results on RACH	334
8.5.24	Change of PLMN while in RRC connected mode	336
8.5.25	Actions related to HS_DSCH_RECEPTION variable.....	337
8.5.26	Service prioritisation.....	339
8.5.27	MBMS frequency selection	339
8.5.28	Actions related to E_DCH_TRANSMISSION variable	341
8.5.29	MBMS modification period identity calculation	344
8.5.30	Detecting MBMS service reception inability.....	344
8.5.31	Actions related to DEFERRED_MEASUREMENT_STATUS variable	344
8.5.32	Actions related to MIMO_PARAMS variable.....	345
8.5.33	Actions related to MIMO_STATUS variable	346
8.5.34	Actions related to DTX_DRX_STATUS variable (FDD only)	346
8.5.35	Actions related to HS_SCCH_LESS_STATUS variable (FDD only).....	347
8.5.36	Actions related to HS_DSCH_RECEPTION_CELL_FACH_STATE variable (FDD and 1.28 Mcps TDD only).....	348
8.5.37	Actions related to HS_DSCH_RECEPTION_OF_CCCH_ENABLED variable (FDD and 1.28 Mcps TDD only).....	350
8.5.37a	Actions related to HS_DSCH_RECEPTION_GENERAL	351
8.5.38	Common H-RNTI selection (FDD and 1.28 Mcps TDD only).....	351
8.5.39	PICH selection for HSDPA based paging (FDD and 1.28 Mcps TDD only)	351
8.5.40	HS_DSCH Reception in CELL_PCH and URA_PCH (FDD only)	352
8.5.40a	HS_DSCH Reception in CELL_PCH and URA_PCH (1.28 Mcps TDD only)	353
8.5.41	HS-PDSCH channelisation codes selection for paging reception (FDD and 1.28 Mcps TDD only)	354
8.5.42	Autonomous UTRAN DRX Cycle length coefficient change	355

8.5.43	Reception of MBMS from a cell operating in MBSFN mode	355
8.5.44	HS-DSCH CQI reporting tables.....	355
8.5.45	Enhanced Uplink in CELL_FACH state and Idle mode (FDD only)	356
8.5.45a	Enhanced Uplink in CELL_FACH state and Idle mode (1.28 Mcps TDD only)	357
8.5.46	Actions related to COMMON_E_DCH_TRANSMISSION variable (FDD and 1.28 Mcps TDD only).....	357
8.5.47	Actions related to READY_FOR_COMMON_EDCH variable (FDD and 1.28 Mcps TDD only)	359
8.5.48	Actions related to HS_DSCH_DRX_CELL_FACH_STATUS variable (FDD and 1.28 Mcps TDD only).....	361
8.5.49	CELL_FACH HS-DSCH DRX operation (FDD only).....	361
8.5.49a	CELL_FACH HS-DSCH DRX operation (1.28Mcps TDD only).....	362
8.5.50	Common E-RNTI selection (1.28 Mcps TDD only).....	362
8.5.51	Actions related to SECONDARY_CELL_HS_DSCH_RECEPTION variable (FDD only).....	363
8.5.52	Actions related to TARGET_CELL_PRECONFIGURATION variable (FDD only)	364
8.5.53	Actions related to CONTROL_CHANNEL_DRX_STATUS variable (1.28 Mcps TDD only).....	364
8.5.54	Actions related to E_DCH_SPS_STATUS variable (1.28 Mcps TDD only)	365
8.5.55	Actions related to HS_DSCH_SPS_STATUS variable (1.28 Mcps TDD only)	365
8.5.56	Actions related to HSPA_RNTI_STORED_CELL_PCH variable (FDD and 1.28 Mcps TDD only)	366
8.6	Generic actions on receipt and absence of an information element.....	367
8.6.1	CN information elements	367
8.6.1.1	Void.....	367
8.6.1.2	CN information info	367
8.6.1.3	Signalling connection release indication	367
8.6.2	UTRAN mobility information elements	368
8.6.2.1	URA identity	368
8.6.2.2	Mapping info.....	369
8.6.2.3	RNC support for change of UE capability	369
8.6.2.4	CSG PSC Split Information	369
8.6.2.5	E-UTRA detection	369
8.6.3	UE information elements	369
8.6.3.1	Activation time.....	369
8.6.3.1a	CN domain specific DRX cycle length coefficient.....	371
8.6.3.1b	H-RNTI	371
8.6.3.2	UTRAN DRX Cycle length coefficient.....	372
8.6.3.3	Generic state transition rules depending on received information elements	372
8.6.3.4	Ciphering mode info	373
8.6.3.5	Integrity protection mode info.....	376
8.6.3.5.1	Initialisation of Integrity Protection.....	376
8.6.3.5.2	Integrity Protection Re-configuration for SRNS Relocation, intra-RAT SR-VCC and handover from GERAN Iu mode.....	377
8.6.3.5.3	Integrity Protection modification in case of new keys or initialisation of signalling connection	378
8.6.3.6	Void.....	379
8.6.3.7	Void.....	379
8.6.3.8	Integrity check info	379
8.6.3.9	New C-RNTI.....	379
8.6.3.9a	New DSCH-RNTI.....	380
8.6.3.10	New U-RNTI.....	380
8.6.3.11	RRC transaction identifier.....	380
8.6.3.12	Capability Update Requirement	384
8.6.3.13	Group release information.....	385
8.6.3.14	New E-RNTI.....	386
8.6.3.15	SR-VCC Info.....	387
8.6.4	Radio bearer information elements	387
8.6.4.1	Signalling RB information to setup list.....	387
8.6.4.2	RAB information for setup.....	388
8.6.4.2a	RAB information to reconfigure	390
8.6.4.3	RB information to setup	390
8.6.4.4	RB information to be affected.....	393
8.6.4.4a	Void.....	393
8.6.4.5	RB information to reconfigure	393
8.6.4.6	RB information to release	393
8.6.4.7	RB with PDCP information	394

8.6.4.8	RB mapping info	394
8.6.4.9	RLC Info	397
8.6.4.10	PDCCP Info	401
8.6.4.11	PDCCP SN Info	402
8.6.4.12	NAS Synchronisation Indicator	402
8.6.4.13	PDCCP context relocation info	402
8.6.4.14	RLC Info MBMS	402
8.6.4.15	RAB information for MBMS ptp bearer	403
8.6.5	Transport channel information elements	403
8.6.5.1	Transport Format Set	403
8.6.5.2	Transport format combination set	405
8.6.5.3	Transport format combination subset	406
8.6.5.4	DCH quality target	408
8.6.5.5	Added or Reconfigured UL TrCH information	408
8.6.5.5a	Added or reconfigured MAC-d flow	409
8.6.5.6	Added or Reconfigured DL TrCH information	410
8.6.5.6a	Void	410
8.6.5.6b	HARQ Info	410
8.6.5.7	Deleted UL TrCH information	411
8.6.5.8	Deleted DL TrCH information	411
8.6.5.9	UL Transport channel information common for all transport channels	412
8.6.5.10	DL Transport channel information common for all transport channels	412
8.6.5.11	Void	413
8.6.5.12	TFCS Reconfiguration/Addition Information	413
8.6.5.12a	Additional RACH TFCS for CCCH	414
8.6.5.13	TFCS Removal Information	414
8.6.5.14	Void	414
8.6.5.15	TFCS Explicit Configuration	414
8.6.5.16	E-DCH Transmission Time Interval (FDD only)	414
8.6.5.17	HARQ Info for E-DCH	415
8.6.5.18	Added or reconfigured E-DCH MAC-d flow	415
8.6.5.19	SRB1 mapping info (FDD and 1.28 Mcps TDD only)	416
8.6.5.20	HARQ System Info (FDD and 1.28 Mcps TDD only)	416
8.6.5.21	CCCH mapping info (FDD and 1.28 Mcps TDD only)	417
8.6.5.22	Common MAC-ehs reordering queue (FDD and 1.28 Mcps TDD only)	417
8.6.5.23	Added or reconfigured MAC-ehs reordering queue	417
8.6.5.24	Common E-DCH MAC-d flows (FDD and 1.28 Mcps TDD only)	418
8.6.6	Physical channel information elements	418
8.6.6.1	Frequency info	418
8.6.6.2	Void	419
8.6.6.2a	PNBSCH allocation	420
8.6.6.3	Void	420
8.6.6.3a	Downlink information per radio link list	420
8.6.6.4	Downlink information for each radio link	421
8.6.6.5	Void	423
8.6.6.6	Uplink DPCH info	423
8.6.6.7	Void	424
8.6.6.8	Maximum allowed UL TX power	424
8.6.6.9	Void	425
8.6.6.10	Void	425
8.6.6.11	Uplink DPCH power control info	425
8.6.6.12	Secondary CPICH info	426
8.6.6.13	Primary CPICH usage for channel estimation	426
8.6.6.14	DPCH frame offset (FDD Only)	426
8.6.6.15	DPCH Compressed mode info	428
8.6.6.16	Repetition period, Repetition length, Offset (TDD only)	431
8.6.6.16a	Repetition period, Repetition length, Offset _{sub} (1.28 Mcps TDD non-scheduled transmission only)	432
8.6.6.17	Primary CCPCH info	433
8.6.6.18	Primary CPICH info	433
8.6.6.19	Void	433
8.6.6.20	Void	433