



Standard Test Method for Evaluation of Automotive Engine Oils in the Sequence IIIF, Spark-Ignition Engine¹

This standard is issued under the fixed designation D 6984; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

INTRODUCTION

This test method described can be used by any properly equipped laboratory; it does not require the assistance of anyone outside that laboratory. However, the ASTM Test Monitoring Center (TMC)² provides reference oils and an assessment of the test results obtained on those oils by the laboratory (see **Annex A1**). By these means, the laboratory will know whether their use of the test method gives results statistically similar to those obtained by other laboratories. Furthermore, various agencies require that a laboratory utilize the TMC services in seeking qualification of oils against specifications. For example, the U.S. Army imposes such a requirement in connection with several Army engine lubricating oil specifications.

Accordingly, this test method is written for use by laboratories that utilize the TMC services. Laboratories that choose not to use those services may simply ignore those portions of the test method that refer to the TMC.

This test method may be modified by means of Information Letters issued by the TMC. In addition, the TMC may issue supplementary memoranda related to the test method (see **A1.8**).

1. Scope

1.1 This test method covers an engine test procedure for evaluating automotive engine oils for certain high-temperature performance characteristics, including oil thickening, varnish deposition, oil consumption, as well as engine wear. Such oils include both single viscosity grade and multiviscosity grade oils that are used in both spark-ignition, gasoline-fueled engines, as well as in diesel engines.

NOTE 1—Companion test methods used to evaluate engine oil performance for specification requirements are discussed in SAE **J304**.

1.2 The values stated in SI or other units are to be regarded as the standard. The values given in parentheses are provided for information only.

1.3 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory requirements prior to use.*

¹ This test method is under the jurisdiction of ASTM Committee D02 on Petroleum Products and Lubricants and is the direct responsibility of Subcommittee D02.B0.01 on Passenger Car Engine Oils.

Current edition approved May 1, 2008. Published June 2008. Originally approved in 2003. Last previous edition approved in 2007 as D 6984–07a.

² Until the next revision of this test method, the ASTM Test Monitoring Center will update changes in the test method by means of information letters. Information letters may be obtained from the ASTM Test Monitoring Center, 6555 Penn Avenue, Pittsburgh, PA 15206-4489. Attention: Administrator. www.astmtmc.cmu.edu. This edition incorporates revisions contained in all information letters through 07-2.

appropriate safety and health practices and determine the applicability of regulatory requirements prior to use.

1.4 This test method is arranged as follows:

Subject	Section
Scope	1
Referenced Documents	2
Terminology	3
Summary of Test Method	4
Significance and Use	5
Apparatus	6
Laboratory	6.1
Drawings	6.2
Specified Equipment	6.3
Test Engine	6.4
Engine Parts	6.4.1
Engine Speed and Load Control	6.5
Sequence IIIF Fluid Conditioning Module	6.6
Engine Cooling System	6.6.1
Flushing Tank	6.7
Coolant Mixing Tank	6.8
Condenser Cooling Systems	6.9
Engine Oil-Cooling System	6.10
Fuel System	6.11
Induction Air Supply Humidity, Temperature, and Pressure	6.12
Temperature Measurement	6.13
Thermocouple Location	6.13.1
Air-to-Fuel Ratio Determination	6.14
Injector Flow Testing	6.14.1
Exhaust and Exhaust Back Pressure Systems	6.15
Blowby Flow Rate Measurement	6.16
Pressure Measurement and Sensor Location	6.17
Reagents and Materials	7
Test Fuel	7.1
Engine and Condenser Coolant	7.2

Subject	Section	Subject	Section
Coolant Additive	7.3	Temperature	10.8.3
Coolant Preparation	7.4	Pressure	10.8.4
Pre-Test Cleaning Materials	7.5	Flow	10.8.5
Sealing and Anti-seize Compounds	7.6	Speed	10.8.6
Test Oil Sample Requirements	8	Load	10.8.7
Preparation of Apparatus	9	Measurement Resolution	10.8.8
Condenser Cleaning	9.1	System Time Response	10.8.9
Intake Manifold Cleaning	9.3	Quality Index	10.8.10
Cleaning of Engine Parts (other than the block and heads)	9.4	Engine Operating Procedure	11
Engine Block Cleaning	9.5	Dipstick and Hole Plug	11.1
Cylinder Head Cleaning	9.6	Dipstick Hole O-ring	11.2
Engine Build-up Procedure	9.7	Engine Start-up and Shutdown Procedures	11.3
General Information	9.7.1	Start-up	11.4
Special Parts	9.7.2	Scheduled Shutdown	11.5
Hardware Information	9.7.3	Non-Scheduled Shutdowns	11.6
Fastener Torque Specifications and Torquing Procedures	9.7.4	Oil Sampling	11.7
Parts Replacement	9.8	Oil Leveling	11.8
Engine Block Preparation	9.9	Air-to-Fuel-Ratio Measurement and Control	11.9
Piston Fitting and Numbering	9.10	Air-to-Fuel Ratio Verification	11.10
Piston Ring Fitting	9.10.1	Blowby Flow Rate Measurement	11.11
Pre-Test Camshaft and Lifter Measurements	9.11	NO _x Determinations	11.12
Camshaft Bearing Installation	9.12	Data Recording	11.13
Camshaft Installation	9.13	Initial Run (10 min)	11.14
Main Bearings	9.14	Engine Oil Quality Testing (80 h)	11.15
Crankshaft Installation	9.14.1	Test Termination	11.16
Main Bearing Cap Installation	9.14.2	Determination of Test Results	12
Crankshaft Sprocket	9.15	Engine Disassembly	12.2
Camshaft Sprocket and Timing Chain	9.16	Preparation of Parts for Rating of Sticking, Deposits, and Plugging	12.3
Crankshaft End Play	9.17	Piston Deposit Rating	12.4
Piston Pin Installation	9.18	Post-Test Camshaft and Lifter Wear Measurements	12.5
Piston Installation	9.18.1	End-of Test Used Oil Sample Testing	12.6
Harmonic Balancer	9.19	Viscosity Test	12.7
Connecting Rod Bearings	9.20	Testing Oil Samples for Wear Metals	12.8
Engine Front Cover	9.21	Blowby Flow Rate Measurements	12.9
Coolant Inlet Adapter	9.22	Oil Consumption Computation	12.10
Oil Dipstick Hole	9.23	Photographs of Test Parts	12.11
Oil Pan	9.24	Retention of Representative Test Parts	12.12
Cylinder Head Assembly	9.25	Severity Adjustments	12.13
Adjustment of Valve Spring Loads	9.26	Determination of Operational Validity	12.14
Cylinder Head Installation	9.27	Report	13
Hydraulic Valve Lifters	9.28	Report Forms	13.1
Pushrods	9.29	Use of SI Units	13.2
Valve Train Loading	9.30	Precision of Reported Units	13.3
Intake Manifold	9.31	Deviations from Test Operational Limits	13.4
Rocker Covers	9.32	Precision and Bias	14.8
Water Inlet Adapter	9.33	Keywords	15
Condenser	9.34	Annexes	
Coolant Outlet Adapter	9.35	The Role of the ASTM Test Monitoring Center (TMC) and the Calibration Program	Annex A1
External Oil Cooling System	9.36	Sequence IIIF Test Parts Replacement Guidelines	Annex A2
Oil Sample Valve	9.37	Sequence IIIF Determination Volume of Engine Oil in Pan	Annex A3
Ignition System	9.38	Sequence IIIF Test Fuel Analysis	Annex A4
Throttle Body	9.39	Sequence IIIF Test Reporting	Annex A5
Accessory Drive Units	9.40	Sequence IIIF Test Air-to-Fuel Ratio Control Flow Chart	Annex A6
Exhaust Manifolds, Water-Cooled	9.41	Sequence IIIF Test Set Points and Control States	Annex A7
Engine Flywheel	9.42	Sequence IIIF Quality Index Upper and Lower Values	Annex A8
Pressure Checking of Engine Coolant System	9.43	Sequence IIIF Engine Oil Level Worksheet	Annex A9
Lifting of Assembled Engines	9.44	Blowby Flow Rate Determination	Annex A12
Mounting the Engine on the Test Stand	9.45	Safety Precautions	Annex A12
External Cooling System Cleaning	9.46	Sequence IIIF Blueprint Listing	Annex A13
Engine Coolant Jacket Cleaning (Flushing)	9.47	Fluid Conditioning Module Components	Annex A14
Coolant Charging	9.48	Appendix	
Test Oil Charging	9.49	Sequence IIIFHD Test Procedure	Appendix X1
Engine Oil Pump Priming	9.50	Sequence IIIFVIS Test Procedure	Appendix X2
Calibration	10		
Laboratory and Engine Test Stand Calibration	10.1		
Testing of Reference Oils	10.2		
Reference Oil Test Frequency	10.3		
Reporting of Reference Oil Test Results	10.4		
Evaluation of Reference Oil Test Results	10.5		
Status of Non-Reference Oil Tests Relative to Reference Oil Test	10.6		
Status of Test Stands Used for Non-Standard Tests	10.7		
Data Acquisition and Control	10.8		
Sample Rate	10.8.1		
Measurement Accuracy	10.8.2		

2. Referenced Documents

2.1 ASTM Standards:³

³ For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

- D 16** Terminology for Paint, Related Coatings, Materials, and Applications
- D 86** Test Method for Distillation of Petroleum Products at Atmospheric Pressure
- D 130** Test Method for Corrosiveness to Copper from Petroleum Products by Copper Strip Test
- D 235** Specification for Mineral Spirits (Petroleum Spirits) (Hydrocarbon Dry Cleaning Solvent)
- D 240** Test Method for Heat of Combustion of Liquid Hydrocarbon Fuels by Bomb Calorimeter
- D 323** Test Method for Vapor Pressure of Petroleum Products (Reid Method)
- D 381** Test Method for Gum Content in Fuels by Jet Evaporation
- D 445** Test Method for Kinematic Viscosity of Transparent and Opaque Liquids (and Calculation of Dynamic Viscosity)
- D 525** Test Method for Oxidation Stability of Gasoline (Induction Period Method)
- D 1319** Test Method for Hydrocarbon Types in Liquid Petroleum Products by Fluorescent Indicator Adsorption
- D 2699** Test Method for Research Octane Number of Spark-Ignition Engine Fuel
- D 2700** Test Method for Motor Octane Number of Spark-Ignition Engine Fuel
- D 3231** Test Method for Phosphorus in Gasoline
- D 3237** Test Method for Lead in Gasoline by Atomic Absorption Spectroscopy
- D 3338** Test Method for Estimation of Net Heat of Combustion of Aviation Fuels
- D 3343** Test Method for Estimation of Hydrogen Content of Aviation Fuels
- D 4052** Test Method for Density and Relative Density of Liquids by Digital Density Meter
- D 4175** Terminology Relating to Petroleum, Petroleum Products, and Lubricants
- D 4294** Test Method for Sulfur in Petroleum and Petroleum Products by Energy Dispersive X-ray Fluorescence Spectrometry
- D 4485** Specification for Performance of Engine Oils
- D 4684** Test Method for Determination of Yield Stress and Apparent Viscosity of Engine Oils at Low Temperature
- D 4815** Test Method for Determination of MTBE, ETBE, TAME, DIPE, tertiary-Amyl Alcohol and C₁ to C₄ Alcohols in Gasoline by Gas Chromatography
- D 5185** Test Method for Determination of Additive Elements, Wear Metals, and Contaminants in Used Lubricating Oils and Determination of Selected Elements in Base Oils by Inductively Coupled Plasma Atomic Emission Spectrometry (ICP-AES)
- D 5191** Test Method for Vapor Pressure of Petroleum Products (Mini Method)
- D 5293** Test Method for Apparent Viscosity of Engine Oils and Base Stocks Between –5 and –35°C Using Cold-Cranking Simulator
- D 5452** Test Method for Particulate Contamination in Aviation Fuels by Laboratory Filtration
- D 5453** Test Method for Determination of Total Sulfur in Light Hydrocarbons, Spark Ignition Engine Fuel, Diesel Engine Fuel, and Engine Oil by Ultraviolet Fluorescence
- D 5862** Test Method for Evaluation of Engine Oils in Two-Stroke Cycle Turbo-Supercharged 6V92TA Diesel Engine
- D 5967** Test Method for Evaluation of Diesel Engine Oils in T-8 Diesel Engine
- D 6557** Test Method for Evaluation of Rust Preventive Characteristics of Automotive Engine Oils
- E 29** Practice for Using Significant Digits in Test Data to Determine Conformance with Specifications
- E 191** Specification for Apparatus For Microdetermination of Carbon and Hydrogen in Organic and Organo-Metallic Compounds
- E 344** Terminology Relating to Thermometry and Hydrometry
- E 608/E 608M** Specification for Mineral-Insulated, Metal-Sheathed Base Metal Thermocouples
- E 1119** Specification for Industrial Grade Ethylene Glycol
- E 1316** Terminology for Nondestructive Examinations
- G 40** Terminology Relating to Wear and Erosion
- IEEE/ASTM SI-10 Standard for Use of the International System of Units (SI): The Modern Metric System⁴
- 2.2 *Military Specification*.⁴
- MIL-PRF-2104** Lubricating Oil, Internal Combustion Engine, Tactical Service
- 2.3 *SAE Standards*.⁵
- J183** Engine Oil Performance and Engine Service Classification (Other Than “Energy-Conserving”)
- J300** Engine Oil Viscosity Classification *HS-23/00*
- J304** Engine Oil Tests
- 2.4 *Other Document*.⁶
- CRC Manual 20** Rating Techniques and Breakdown Methods

3. Terminology

3.1 Definitions:

3.1.1 *blowby, n*—in internal combustion engines, the combustion products and unburned air-and-fuel mixture that enter the crankcase. **D 4175**

3.1.2 *BTDC, adj*—abbreviation for Before Top Dead Center; used with the degree symbol to indicate the angular position of the crankshaft relative to its position at the point of uppermost travel of the piston in the cylinder. **D 4175**

3.1.3 *calibrate, v*—to determine the indication or output of a measuring device with respect to that of a standard. **E 344**

3.1.4 *clogging, n*—the restriction of a flow path due to the accumulation of material along the flow path boundaries. **D 4175**

⁴ Available from Standardization Documents Order Desk, DODSSP, Bldg. 4, Section D, 700 Robbins Ave., Philadelphia, PA 19111-5098.

⁵ Available from Society of Automotive Engineers, 400 Commonwealth Dr., Warrendale, PA 15096-0001. These standards are not available separately. Order either SAE Handbook Vol. 3, or SAE Fuels and Lubricants Standards Manual HS-23.

⁶ Available from Coordinating Research Council, Inc., 219 Perimeter Center Parkway, Atlanta, GA 30346.

3.1.5 *cold-stuck piston ring, n*—in internal combustion engines, a piston ring that is stuck when the piston and ring are at room temperature, but inspection shows that it was free during engine operation.

3.1.5.1 *Discussion*—A cold-stuck piston ring cannot be moved with moderate finger pressure. It is characterized by a polished face over its entire circumference, indicating essentially no blowby passed over the ring face during engine operation. **D 4175**

3.1.6 *correction factor, n*—a mathematical adjustment to a test result to compensate for industry-wide shifts in severity. **D 4175**

3.1.7 *corrosion, n*—the chemical or electrochemical oxidation of the surface of metal, which can result in loss of material or accumulation of deposits. **E 1316**

3.1.8 *debris, n*—in internal combustion engines, solid contaminant materials unintentionally introduced into the engine or resulting from wear. **D 5862**

3.1.9 *engine oil, n*—a liquid that reduces friction or wear, or both, between the moving parts within an engine, and serves as a coolant. **D 4485**

3.1.10 *EWMA, n*—abbreviation for exponentially-weighted moving average. **D 4175**

3.1.11 *free piston ring, n*—in internal combustion engines, a piston ring that will fall in its groove under the force of its own weight when the piston, with the ring in a horizontal plane, is turned 90° (putting the ring in a vertical plane). **D 5862**

3.1.11.1 *Discussion*—In the determination of this condition, the ring may be touched slightly to overcome static friction.

3.1.12 *hot-stuck piston ring, n*—in internal combustion engines, a piston ring that is stuck when the piston and ring are at room temperature, and inspection shows that it was stuck during engine operation.

3.1.12.1 *Discussion*—The portion of the ring that is stuck cannot be moved with moderate finger pressure. A hot-stuck piston ring is characterized by varnish or carbon across some portion of its face, indicating that portion of the ring was not contacting the cylinder wall during engine operation. **D 4175**

3.1.13 *lubricant test monitoring system (LTMS), n*—an analytical system in which ASTM calibration test data are used to manage lubricant test precision and severity (bias). **D 4175**

3.1.14 *LTMS date, n*—the date the test was completed unless a different date is assigned by the TMC. **D 4175**

3.1.15 *LTMS time, n*—the time the test was completed unless a different time is assigned by the TMC. **D 4175**

3.1.16 *lubricant, n*—any material interposed between two surfaces that reduces the friction or wear, or both, between them. **D 5862**

3.1.17 *lubricating oil, n*—a liquid lubricant, usually comprising several ingredients, including a major portion of base oil and minor portions of various additives. **D 4175**

3.1.18 *material safety data sheet, (MSDS), n*—a fact sheet summarizing information about material identification; hazardous ingredients; health, physical, and fire hazards; first aid; chemical reactivities and incompatibilities; spill, leak, and disposal procedures; and protective measures required for safe handling and storage. **http://www.msdssearch.com**

3.1.19 *non-compounded engine oil, n*—a lubricating oil having a viscosity within the range of viscosities of oils normally used in engines, and that may contain anti-foam agents or pour depressants, or both, but not other additives.

3.1.19.1 *Discussion*—In this test method non-compounded oil is also known as build-up oil. **D 4175**

3.1.20 *non-reference oil, n*—any oil, other than a reference oil; such as a research formulation, commercial oil, or candidate oil. **D 4175**

3.1.21 *oxidation, n*—of engine oil, the reaction of the oil with an electron acceptor, generally oxygen, that can produce deleterious acidic components often manifested as sludge formation, varnish formation, viscosity increase, or corrosion, or combination thereof. **D 5967**

3.1.22 *quality index (QI), n*—a mathematical formula that uses data from controlled parameters to calculate a value indicative of control performance. **D 4175**

3.1.23 *reference oil, n*—an oil of known performance characteristics, used as a basis for comparison.

3.1.23.1 *Discussion*—Reference oils are used to calibrate testing facilities, to compare the performance of other oils, or to evaluate other materials (such as seals) that interact with oils. **D 4175**

3.1.24 *rust (coatings), n*—the reddish material, primarily hydrated iron oxide, formed on iron or its alloys, resulting from exposure to humid atmosphere or chemical attack. **D 16**

3.1.25 *SA, n*—abbreviation for severity adjustment.

3.1.26 *scoring, n*—in tribology, a severe form of wear characterized by the formation of extensive grooves and scratches in the direction of sliding. **G 40**

3.1.27 *scuffing, n*—in lubrication, surface damage resulting from localized welding at the interface of rubbing surfaces with subsequent fracture in the proximity of the weld area. **D 4175**

3.1.28 *test oil, n*—any oil subjected to evaluation in an established procedure. **D 6557**

3.1.28.1 *Discussion*—It can be any oil selected by the laboratory conducting the test. It could be an experimental product or a commercially available oil. Often, it is an oil that is a candidate for approval against engine oil specifications (such as manufacturers' or military specifications, and so forth).

3.1.29 *test procedure, n*—one where test parameters, apparatus, apparatus preparation, and measurements are principal items specified.

3.1.30 *used oil, n*—any oil that has been in a piece of equipment (for example, an engine, gearbox, transformer, or turbine), whether operated or not. **D 4175**

3.1.31 *varnish, n*—in internal combustion engines, a hard, dry, generally lustrous deposit that can be removed by solvents, but not by wiping with a cloth. **D 4175**

3.1.32 *wear, n*—the loss of material from, or relocation of material on, a surface.

3.1.32.1 *Discussion*—Wear generally occurs between two surfaces moving relative to each other, and is the result of mechanical or chemical action, or of a combination of mechanical and chemical actions. **D 4175**

3.2 *Definitions of Terms Specific to This Standard:*

3.2.1 *build-up oil*, *n*—EF-411, non-compounded, ISO VG 32 (SAE 10) oil used in lubricating some of the Sequence IIIF parts during engine assembly.

3.2.2 *calibrated test stand*, *n*—a test stand on which Sequence IIIF engine oil tests are conducted within the lubricant test monitoring system as administered by the TMC. (See 10.1).

3.2.3 *central parts distributor (CPD)*, *n*—the manufacturer and supplier of many of the parts and fixtures used in this test method.

3.2.3.1 *Discussion*—Because of the need for rigorous inspection and control of many of the parts used in this test method, and because of the need for careful manufacture of special parts and fixtures used, companies having the capabilities to provide the needed services have been selected as the official suppliers for the Sequence IIIF test method. These companies work closely with the original parts suppliers, with the Test Procedure Developer,⁷ and with the ASTM groups associated with the test method to help ensure that the equipment and materials used in the method function satisfactorily.

3.2.4 *critical parts (CP)*, *n*—those components used in the test which are known to affect test severity.

3.2.4.1 *Discussion*—Critical parts shall be obtained from the Central Parts Distributor or Special Parts Supplier, who will identify them with either a serial number or a batch/lot control number.

3.2.5 *EOT time (end of test time)*, *n*—Twenty minutes after the engine reaches 80 test h of operation, which allows 90 s for ramp-down, a 15-min wait for oil to drain into the sump, and allows the operator 3.5 min to measure oil level.

3.2.6 *non-production parts (NP)*, *n*—components used in the test, which are available only through the Central Parts Distributor, Special Parts Supplier, or the Test Procedure Developer.

3.2.7 *participating laboratory*, *n*—a laboratory equipped to conduct Sequence IIIF tests, which conducts reference oil tests in cooperation with the TMC, in order to have calibrated test stands available for non-reference oil testing.

3.2.8 *pinched piston ring*, *n*—an installed piston ring which will not move in its groove under moderate finger pressure, but which has a polished face over its entire circumference indicating that it was free during engine operation. The ring may be restricted over varying degrees of its circumference.

3.2.9 *reference oil test*, *n*—a standard Sequence IIIF engine oil test of a reference oil designated by the TMC.

3.2.10 *service parts operations parts (SPO)*, *n*—these test components are obtained from Service Parts Operations, a division of General Motors Corp.

3.2.11 *sluggish piston ring*, *n*—an installed piston ring which offers resistance to movement in its groove, but can be pressed into or out of the groove under moderate finger pressure; when so moved, it does not spring back (one that is neither free nor stuck).

3.2.12 *special parts supplier (SPS)*, *n*—the manufacturer and supplier of many of the parts and fixtures used in this test method.

3.2.13 *special test parts (stp)*, *n*—parts that do not meet all the definitions of critical parts, non-production parts, or SPO parts, but shall be obtained from the Special Parts Supplier.

3.2.14 *standard test, (valid test)*, *n*—an operationally valid, full-length Sequence IIIF test conducted on a calibrated test stand in accordance with the conditions listed in this test method.

3.2.15 *stuck piston ring*, *n*—one that is either partially or completely bound in its groove and cannot be readily moved with moderate finger pressure.

3.2.16 *test full mark*, *n*—the oil level established after the 10-min initial run-in.

3.2.17 *test procedure developer*, *n*—the group or agency which developed the Sequence IIIF test procedure before its standardization by ASTM, and which continues to be involved with the test in respect to modifications in the test method, development of Information Letters, supply of test parts, and so forth.

3.2.17.1 *Discussion*—In the case of the Sequence IIIF test, the Test Procedure Developer is General Motors Research and Development Center.

3.2.18 *test stand*, *n*—a suitable foundation (such as a bedplate) to which is mounted a dynamometer, and which is equipped with a suitable data acquisition system, fluids process control system, supplies of electricity, compressed air, and so forth, to provide a means for mounting and operating an engine in order to conduct a Sequence IIIF engine oil test.

3.2.19 *test start*, *n*—introduction of test oil into the engine after the final assembly and mounting in the test stand.

3.2.20 *test start time*, *n*—the time that test oil was introduced into the engine on the test stand.

4. Summary of Test Method

4.1 A 3800 Series II 3.8L (231-in.³) V-6 test engine block is solvent-cleaned, measured, and rebuilt using new parts installed as specified in this test method.

4.2 The engine is installed on a test stand equipped with an appropriate data acquisition system, the required fluids process control system, and all necessary accessories for controlling speed, load, and various other operating parameters.

4.3 The engine is charged with the test oil.

4.4 The engine is operated for a 10-min initial run-in period to check all test stand operating systems and to establish a zero hour oil level reading and initial oil viscosity sample.

4.5 Following the 10-min initial run-in and oil level, the engine is operated under non-cyclic, moderately high speed, load, and temperature conditions for 80 h, in 10-h segments.

4.6 The initial oil level in the oil pan is determined after the 10-min initial run-in, and subsequent oil level calculations are determined during the oil leveling period at the end of each 10-h segment.

4.7 Used oil samples are taken after the 10-min initial run-in and after each 10-h test segment; kinematic viscosity at 40°C (104°F) is determined for each of the ten samples; the percentage change in viscosity of the nine latter samples is

⁷ General Motors Corp., Research and Developmental Ctr., Mail Code 480-106-160, Sequence IIIF Test Coordinator, 30500 Mound Rd., Box 9055, Warren, MI 48090-9055.

determined relative to the viscosity of the first used oil sample (10-min initial run-in).

4.8 At the conclusion of the test, the engine is disassembled and the parts are visually rated to determine the extent of deposits formed. In addition, wear measurements are obtained.

5. Significance and Use

5.1 This test method was developed to evaluate automotive engine oils for protection against oil thickening and engine wear during moderately high-speed, high-temperature service.

5.2 The increase in oil viscosity obtained in this test method indicates the tendency of an oil to thicken because of oxidation. In automotive service, such thickening can cause oil pump starvation and resultant catastrophic engine failures.

5.3 The deposit ratings for an oil indicate the tendency for the formation of deposits throughout the engine, including those that can cause sticking of the piston rings in their grooves. This can be involved in the loss of compression pressures in the engine.

5.4 The camshaft and lifter wear values obtained in this test method provide a measure of the anti-wear quality of an oil under conditions of high unit pressure mechanical contact.

5.5 The test method was developed to correlate with oils of known good and poor protection against oil thickening and engine wear. Specially formulated oils that produce less than desirable results with unleaded fuels were also used during the development of this test method.

5.6 The Sequence IIIF engine oil test has replaced the Sequence IIIE test and can be used in specifications and classifications of engine lubricating oils, such as:

5.6.1 Specification **D 4485**,

5.6.2 Military Specification **MIL-PRF-2104**, and

5.6.3 SAE Classification **J183**.

6. Apparatus

6.1 *Laboratory*—Observe the following laboratory conditions to ensure good control of test operations and good repeatability:

6.1.1 Maintain the ambient laboratory atmosphere relatively free of dirt, dust, and other contaminants.

6.1.2 Control the temperature of the room in which parts measurements are made so that the temperature for after-test measurements is within a range of $\pm 3^{\circ}\text{C}$ ($\pm 5^{\circ}\text{F}$) relative to the temperature for the before-test measurements. If difficulties with parts fits are encountered, consider the effects of temperature coefficient of expansion. (See 6.2.)

6.1.3 Filter the air in the engine build-up area, and control its temperature and humidity to prevent accumulation of dirt or rust on engine parts.

6.1.4 If an engine is assembled in an area of controlled environment and moved to a non-controlled area, provide suitable protection of the engine so that moist air cannot enter the engine and promote rusting before the test.

6.1.5 Do not permit air from fans or ventilation systems to blow directly on an engine mounted on a test stand during test operation.

6.2 *Drawings*—Obtain the equipment drawings referenced in **Annex A13** of this test method from the TMC. Because the drawings may not be to scale or may not contain dimensions

when using them to fabricate special parts, do not use a dimensionless drawing as a pattern. Drawings supplied with dimensions are considered to be correct when the temperature of the equipment is $22 \pm 3^{\circ}\text{C}$ ($72 \pm 5^{\circ}\text{F}$), unless otherwise specified.

6.3 *Specified Equipment*—Use the equipment specified in the procedure whenever possible. Substitution of equivalent equipment is allowed, but only after equivalency has been proven to the satisfaction of the TMC, the Test Procedure Developer, and the ASTM Sequence IIIF Surveillance Panel.

6.3.1 Do not use heat lamps or fans directed at the engine, and do not use insulation on the engine for oil or coolant temperature control.

NOTE 2—For operator safety and the protection of test components, the use of shielding and insulation on the exhaust system may be incorporated downstream of the oxygen sensor elbow.

6.4 *Test Engine*—The test engine is based on a 1996-97 L36 3800 Series II 3.8L (231-in.³) V-6 engine with a 9.0:1 compression ratio, equipped with a production fuel injection system, a retrofit flat-tappet valvetrain, and a special Powertrain control module (PCM) for test specific dynamometer operation. Rebuild the engine as specified in this test method.

NOTE 3—Complete test engines are not available for purchase. Test engines can be rebuilt using parts and test kits. See Sequence IIIF Engine Assembly Manual²; see **Annex A2** and **Annex A13** for listings of parts and related equipment.

6.4.1 *Engine Parts*—Use the engine parts specified in the Sequence IIIF Engine Assembly Manual.

6.4.1.1 Use all engine parts as received from the supplier, Central Parts Distributor, Special Parts Supplier, or original equipment manufacturer, unless modifications are specified in this test method or the Sequence IIIF Engine Assembly Manual.

6.4.1.2 Any parts obtained for use in Sequence IIIF testing shall not be diverted to other applications.

6.4.1.3 Before disposing of any Sequence IIIF engine parts, destroy or otherwise render them useless for automotive engine applications.

6.5 *Engine Speed and Load Control*—Use dynamometer speed and load control systems that are capable of controlling the speed and load as specified in Section 11 of this procedure.

6.6 *Sequence IIIF Fluid Conditioning Module*—Use the Kundinger Fluid Conditioning Module⁸ to control the following parameters: engine coolant, condenser coolant, oil cooler coolant, exhaust manifold coolant, and the test fuel supply. The system incorporates the following features: pumps, flow meters, flow control and three-way control valves, external heating and cooling systems, pressure regulator, and low-point drains. The system integrates with the test stand data acquisition and control computer for process control. If a laboratory wishes to build its own Fluid Conditioning Module, a list of suitable equipment can be found in **Annex A14**.

6.6.1 *Engine Cooling System*—The fluid conditioning module system supplies non-pressurized coolant at a flow rate of

⁸ A suitable Fluid Conditioning Module is available from Kundinger Fluid Controls, 171 Harmon Rd., Auburn Hills, MI 48326.

160 L/min (42.3 gal/min) and controls temperature at 122°C (251.6°F) at the engine coolant outlet. The system incorporates the following features: pump, vortex-type flow meter, flow control and three-way control valves, external heating and cooling systems, and low-point drains. The system integrates with the test stand data acquisition and control computer for process control and maintains the specified engine coolant temperature and flow. The system should be flushed with clean water at least once each reference period.

6.7 *Flushing Tank*—Use a flushing tank such as that shown in drawings RX-116924-C, RX-117230-E, and RX-117231-C² to circulate the cleaning agents. Use plumbing materials that are impervious to the acidic cleaning agents (stainless steel is satisfactory).

6.8 *Coolant Mixing Tank*—Use a mixing tank such as that shown in drawing RX-117350-D² to premix the engine coolant.

6.9 *Condenser Cooling System*—Contained in the fluid conditioning module, supplies non-pressurized coolant at a flow rate of 10 ± 2 L/min (2.64 ± 0.53 gal/min) and temperature controlled at 40°C (104°F) (see [Annex A8](#)) at the condenser outlet. The system incorporates the following features: condenser heat exchanger, BX-212-1 or OHT3F-075-1^{9,10} condenser adapter fitting, pump, magnetic-type flow meter, flow control and three-way control valves, external heating and cooling systems, and low-point drains. The system integrates with the test stand data acquisition and control computer for process control and maintains the specified coolant temperature and flow.

6.10 *Engine Oil-Cooling System*—The system consists of an oil filter adapter, fitting adapter, oil cooler, and gaskets specified in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 3. The system uses engine coolant provided through the fluid conditioning module at a flow rate of approximately 12.0 L/min (3.17 gal/min) through a three-way valve as necessary to control the engine oil temperature. When testing high-oxidation sensitive oils, the oil cooling system may go into a bypass mode, causing the oil cooler to be bypassed. In this condition, the TMC may allow engineering judgment for the oil temperature quality index on reference oil tests.

6.10.1 Replace the oil cooler after every test.

6.10.2 Do not use cuprous lines or fittings in the oil system.

6.10.3 Do not use magnetic plugs in the oil system.

6.10.4 Use suitable hose and fittings when plumbing the oil-cooling system.

6.10.5 The oil cooler, oil filter, or both may be replaced once per test if the oil filter pressure differential is greater than 100 kPa during test operations or if bypass operation is detected.

6.10.5.1 Replacement of the oil cooler, oil filter, or both may be performed only once per test (that is, if a filter is replaced at 30 h, the cooler cannot be replaced at 50 h).

6.10.5.2 If the oil filter is replaced during the test, drain any oil contained in the old oil filter into the new oil filter before installing it on the test engine.

6.10.5.3 No new test oil may be added to the engine as a result of oil filter or oil cooler replacement. Consider as oil consumption any oil lost as a result of oil filter or oil cooler replacement.

6.10.5.4 If the oil cooler, oil filter, or both are replaced during a test, place a note in the test report detailing what components were replaced and when they were replaced.

6.11 *Fuel System*—Contained in the Fluid Conditioning Module is a pressurized, recirculating fuel system, including a pressure regulator to provide $377.5 \text{ kPa} \pm 12.5 \text{ kPa}$ (54.75 ± 1.83 psi) fuel pressure. The system should be switched off so no fuel pressure is present at the injector rail during engine shutdowns.

6.12 *Induction Air Supply Humidity, Temperature, and Pressure*—Maintain the throttle body intake air at a moisture content of 11.4 ± 0.7 g/kg (80.0 ± 5 grains/lb.) of dry air, a dry bulb temperature of $27^\circ\text{C} \pm 2^\circ\text{C}$ ($80.6^\circ\text{F} \pm 3.6^\circ\text{F}$), and a static pressure of 0.050 kPa (0.2 in. H₂O) (see [Annex A7](#)). Measure temperature and pressure at the inlet air adapter.

6.13 *Temperature Measurement*—Use 1/8-in. metal-sheathed, Specification [E 608/E 608M](#), iron-constantan (Type J) thermocouples for temperature measurements. The thermocouples used shall be as short as possible to meet the insertion depth requirements listed in this test method and minimize exposed thermocouple sheathing.

6.13.1 *Thermocouple Location*—Locate the sensing tip of all thermocouples in the center of the stream of the medium involved, unless otherwise specified.

6.13.1.1 *Oil Filter Adapter*—Install the thermocouple in the tapped hole in the oil filter adapter as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 3.

6.13.1.2 *Oil Pan (Sump)*—Install the thermocouple in the oil sump drain plug OHT3F-063-1 with the tip extending 19 to 25 mm (0.75 to 1.0 in.) beyond the end of the sump drain plug.

6.13.1.3 *Engine Coolant In*—Install the thermocouple in the coolant inlet adapter OHT3F-031-1 with the sensing tip centered in the coolant flow.

6.13.1.4 *Engine Coolant Out*—Install the thermocouple for the coolant outlet OHT3F-034-1 with the sensing tip centered in the coolant flow.

6.13.1.5 *Condenser Coolant Out*—Locate the thermocouple in the coolant-out fitting in the condenser with the sensing tip centered in the coolant flow.

6.13.1.6 *Blowby Gas*—Install the thermocouple at the outlet of the condenser with the sensing tip centered in the blowby gas flow.

6.13.1.7 *Fuel*—Install the thermocouple in the fuel rail fittings on the inlet side of the fuel rail.

6.13.1.8 *Inlet Air*—Install the thermocouple in the inlet air adapter, as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 4.

6.14 *Air-to-Fuel Ratio Determination*—Determine the engine air-to-fuel ratio (AFR) by measuring the CO, CO₂, and O₂ components of the exhaust gas sample with electronic exhaust gas analysis equipment. When using electronic exhaust gas

⁹ If you are aware of alternative suppliers, please provide this information to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, ¹ which you may attend.

¹⁰ The sole source of supply of the apparatus known to the committee at this time is OH Technologies Inc. P.O. Box 5039, Mentor, OH 44061-5039.

analyzers, exercise particular care to dry the exhaust gas sample prior to introducing it into the analyzer. Take the exhaust gas samples from the exhaust manifold exit flanges. (See [Annex A6](#) and Sequence IIIF Engine Assembly Manual, Section 8-Sheet 1.)

6.14.1 *Injector Flow Testing*—Flow test the fuel injectors before each test according to the following procedure:

6.14.1.1 Use aliphatic naphtha as the calibration fluid.

6.14.1.2 Apply 40 psi to the fuel rail.

6.14.1.3 Continuously apply 13 volts to the injector solenoid.

6.14.1.4 Allow the injector to spray into a graduated cylinder capable of holding at least 250 mL.

6.14.1.5 Volume-check all injectors for 60 s and note the volume produced by each injector.

6.14.1.6 Observe the spray pattern that each injector produces; if the injector has a straight stream or dribbles, it should be discarded.

6.14.1.7 The six injectors that are to be installed on an engine fuel rail shall produce volumes that are within 5 mL of each other.

6.14.2 Remove the solvent that is remaining in the injector from the flow check using compressed air.

6.15 *Exhaust and Exhaust Back Pressure Systems:*

6.15.1 *Exhaust Manifolds and Pipes*—Install water-cooled exhaust manifolds and stainless runners as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 2.

6.15.2 *Water-Jacketed Exhaust Pipes*—For safety, water-jacketed exhaust pipes or external water spray systems are allowed only when introduced beyond the Y pipe and after the system drops below the bedplate or enters the overhead loft.

6.15.3 *Exhaust Sample Lines*—Install exhaust sample lines in the two exhaust manifold exit flanges. Both left and right banks should use the same sample line location (inboard or outboard), as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 1. Use good laboratory practice to ensure that water does not accumulate in the lines during engine operation.

6.15.4 *Back-Pressure Lines*—Install exhaust-backpressure lines in the two exhaust manifold exit flanges. Both left and right banks should use the same backpressure measurement location (inboard or outboard), as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 1. Use good laboratory practice to ensure that water does not accumulate in the lines during engine operation.

6.16 *Blowby Flow Rate Measurement*—Use the sharp-edge orifice meter, part number RX-116169-A1, revision N, to measure engine blowby flow rates. (See [11.11](#).)

6.17 *Pressure Measurement and Pressure Sensor Location*—Use electronic pressure transducers located as indicated in this test method.

6.17.1 *Intake Manifold Vacuum*—Use a transducer having a range of 0 to 100 kPa (0 to 20 in. Hg). Connect the transducer to the vacuum outlet located on the intake plenum main vacuum port. Tee the transducer, manifold absolute pressure sensor, and fuel rail pressure regulator all together from the main port.

6.17.2 *Engine Oil Gallery Pressure*—Use a transducer having a range of 0 to 700 kPa (0 to 100 psi). Connect the transducer to the location shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 3 (OUT Port, oil to block).

6.17.3 *Oil Pump Outlet Pressure*—Use a transducer having a range of 0 to 700 kPa (0 to 100 psi). Connect the transducer to the location shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 3 (IN Port, oil to filter).

6.17.4 *Exhaust Back Pressure*—Use a transducer having a range of 0 to 10 kPa (0 to 40 in. H₂O). Attach the line to the exhaust end plate as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 1.

6.17.5 *Inlet Air Pressure*—Use a transducer having a range of 125 Pa (0.5 in. H₂O). Connect the transducer to the air inlet adapter as shown in the Sequence IIIF Engine Assembly Manual, Section 8-Sheet 4.

6.17.6 *Crankcase Pressure*—Use a transducer having a range of -125 to +125 Pa (-0.5 to +0.5 in. H₂O). Connect the transducer to the front of the lower intake manifold as shown in the Sequence IIIF Engine Assembly Manual, Section 6-Sheet 7.

6.18 *PCV Plug*—Block off the positive crankcase ventilation system during testing using a dummy PCV valve, part number OHT3F-002-1, as shown in the Sequence IIIF Engine Assembly Manual, Section 6-Sheet 11.

6.19 *Parts Modifications*—Modify the following parts according to the instructions listed in the Sequence IIIF Engine Assembly Manual:

6.19.1 *Throttle Body*, Section 7-Sheet 5.

6.19.2 *Intake Manifold*, Section 6-Sheet 7.

6.19.3 *Engine Block*, Section 1-Sheet 2.

7. Reagents and Materials

7.1 *Test Fuel*—Use only EEE unleaded fuel^{9,11} (**Warning**—Flammable. Health hazard) (see [Annex A4](#), [Fig. A4.1](#)), observing the following:

7.1.1 Make certain that all tanks used for transportation and storage are clean before filling with test fuel.

7.1.2 Verify that at least 2000 L (530 gal) of test fuel (**Warning**—Flammable. Health hazard) is available for use before initiating a test.

7.1.3 Analyze quarterly the contents of each storage tank that contains fuel used for qualified Sequence IIIF tests to ensure the fuel has not deteriorated or been contaminated in storage. Analyze the fuel for Distillation, Gravity, RVP, Sulfur, and Gums. Send the results from these analyses to the TMC for inclusion in the Sequence III Test Fuel database.

7.2 *Engine and Condenser Coolant*—Use ethylene glycol meeting Specification [E 1119](#) for industrial grade ethylene glycol (**Warning**—Combustible. Health hazard).

7.3 *Coolant Additive*—Use Nacool 2000 or Pencoool 2000 coolant additive^{9,12} for the engine and condenser coolant (**Warning**—Combustible. Health hazard. See appropriate MSDS).

¹¹ The sole source of supply of the apparatus known to the committee at this time is Haltermann Products, 3520 Okemos Rd., Suite 6-176, Okemos, MI.

¹² The sole source of supply of the apparatus known to the committee at this time is Penray Companies, Inc., 1801 Estes Ave, Elk Grove, IL 60007.

7.4 *Coolant Preparation*—Prepare the coolant blend for the engine coolant system, and for the oil cooler and condenser coolant system, in the following manner:

7.4.1 Do not apply heat either during, or following, the coolant preparation.

7.4.2 Use a container of a size adequate to hold the entire coolant blend required by both systems. See drawing RX-117350-D² for an example of a suitable container.

7.4.3 Add the required amount of glycol (**Warning**—Combustible. Health hazard) to the container.

7.4.4 Add the required amount of additive concentrate to the container to achieve a concentration of 15.625 mL/L (0.125 pt/gal) of coolant additive to glycol (**Warning**—See appropriate MSDS).

7.4.5 Mix the blend in the container for 30 min.

7.4.6 Add the blend to the engine coolant system and the condenser coolant system.

7.5 *Pre-Test Cleaning Materials*—Use the cleaning materials (**Warning**—See appropriate MSDS) specified in the following list for cleaning of parts to be used in the test. Do not use unapproved substitutes (See **Note 4**).

NOTE 4—Only these specific materials and sources have been found satisfactory. If chemicals other than these are proposed for use, equivalency shall be proven and approval obtained from the TMC.

7.5.1 Use Penmul L460 as the parts cleaning agent^{9,13} (**Warning**—Corrosive. Health hazard.).

7.5.2 *Solvent*—Use only mineral spirits meeting the requirements of Specification **D 235**, Type II, Class C for Aromatic Content (0-2% vol), Flash Point (142°F/61°C, min) and Color (not darker than +25 on Saybolt Scale or 25 on Pt-Co Scale). (**Warning**—Combustible. Health hazard.) Obtain a Certificate of Analysis for each batch of solvent from the supplier.

7.5.3 Sequence IIIF Test component cleaner, a mixture (by mass) of:

94 parts oxalic acid^{9,14} (**Warning**—Corrosive. Health hazard.), and

6 parts dispersant^{9,15} (**Warning**—Corrosive. Health hazard.).

NOTE 5—If permitted by the hazardous materials disposal practices in a laboratory, sodium carbonate can be used to neutralize the oxalic acid in used Sequence IIIF Test component cleaner.

7.5.4 Use NAT-50 or PDN-50 soap^{9,16} in automatic parts washers to clean Sequence IIIF engine parts. (See **9.4**.)

7.6 *Sealing and Anti-seize Compounds*—Use the sealing compounds specified in the following list.

7.6.1 Use Permatex No. 2 non-hardening sealer as the sealing compound for cylinder head bolts.¹⁷

7.6.2 Use Perfect Seal Number 4 brush-type sealing compound as the sealing compound for front and rear cover gaskets.^{9,18}

7.6.3 Only GM Autocare Assembly Adhesive,¹⁹ part number 12346141, Dow RTV Grade 3154 sealer,²⁰ or Permatex Ultra Black Sealer,²¹ part number 24105, are allowable for use on the oil pan gasket and intake manifold gasket only. (See Sequence IIIF Engine Assembly Manual, Section 4-Sheet 13 and Section 6-Sheet 6.)

8. Test Oil Sample Requirements

8.1 *Selection*—The supplier of the test oil sample shall determine that the test oil sample is representative of the lubricant formulation to be evaluated and that it is not contaminated.

8.2 *Quantity*—The supplier shall provide 15 L (4 gal) of the test oil sample.

NOTE 6—A Sequence IIIF test can be conducted with as little as 12 L (3.17 gal) of test oil, provided that no spillage or leakage occur during test preparation. The greater quantity is specified to accommodate minor spillage and leakage.

8.3 *Storage Prior to Test*—The test laboratory shall store the test oil sample in a covered building to prevent contamination by rainwater.

9. Preparation of Apparatus

9.1 *Condenser Cleaning*—Immediately after completing a Sequence IIIF test, remove the stainless steel condenser assembly, disassemble it, and soak it in parts cleaning agent. After the soaking, clean the inside of the tube with parts cleaning agent and a non-cuprous bristle brush. Rinse both the blowby gas and coolant sides of the condenser with clean solvent.

9.1.1 After ten tests, or more frequently if film is present, clean the coolant side of the condenser by flushing it for one-half hour with a water solution of 20 g/L of Sequence IIIF test component cleaner (see **7.4**). Rinse it thoroughly with tap water at 60°C (140°F).

9.2 After cleaning the coolant side of the condenser, pressure check it for leaks using air at 70 kPa (10 psi).

9.3 *Intake Manifold Cleaning*—Clean the intake manifold with solvent.

9.4 *Cleaning of Engine Parts*—Clean all engine parts (other than the block and heads; see **9.5** and **9.6**) thoroughly prior to engine assembly. Degrease them first, and then brush them with parts cleaning agent. Immediately remove the cleaner by spraying with hot tap water. Blow-dry the parts with clean, dry shop air and immediately coat them with a 50/50 mixture of build-up oil and solvent.

¹³ The sole source of supply of Penmul L 460 known to the committee at this time is Penetone Corp., 74 Hudson Ave., Tenafly, NJ 07670.

¹⁴ The sole source of supply of the oxalic acid (55-lb bags) and sodium carbonate (50-lb bags) known to the committee at this time is Ashland Chemical Co., P.O. Box 391, Ashland, KY 41114.

¹⁵ The sole source of supply of Petro Dispersant No. 425 Powder (50-lb bags) known to the committee at this time is Witco Corp., 3230 Brookfield, Houston, TX 77045.

¹⁶ The sole source of supply of the soap for the parts washing machine known to the committee at this time is Better Engineering Mfg., Inc., 8361 Town Center Ct., Baltimore, MD 21236.

¹⁷ Permatex No. 2 non-hardening sealer is available through local distributors of Permatex products.

¹⁸ The sole source of supply of Perfect Seal No. 4 Brush-Type Sealing Compound, part GM3D (16 oz container) known to the committee at this time is P.O.B. Sealants Inc., 11102 Kenwood Rd. Cincinnati, OH 45242.

¹⁹ GM Autocare Assembly Adhesive is available from local GM dealers.

²⁰ Dow RTV Grade 3154 sealer is available from commercial sources.

²¹ Permatex Ultra Black Sealer is available from commercial sources.

9.4.1 Clean the connecting rods by soaking in solvent for a minimum of 2 h. Spray the rods with a 50/50 mixture of solvent and EF-411.

9.5 *Engine Block Cleaning*—Clean the block according to the following:

9.5.1 Remove the debris in the head bolt and main bearing-cap bolt holes using class 2B bottoming taps of the appropriate sizes.

9.5.2 Physically remove from the water jacket all sand and slag deposits, and any other debris using a sharp-ended drill rod or a long straight slot screwdriver.

9.5.2.1 Check the camshaft tunnel for sharp edges on the front of each bore and along the cross-drilled oil gallery inside each bearing bore. Deburr as necessary. See the Sequence IIIF Engine Assembly Manual, Section 1-Sheet 2.

9.5.3 Thoroughly clean the block prior to honing as follows: In the case of a block used in a previous test, remove the crankshaft, main bearings, and bearing caps. In addition, remove all bushings, bearings, and oil gallery plugs prior to cleaning. With either a new or a used block, prevent cleaner or oil from entering the engine coolant passages. (See Sequence IIIF Engine Assembly Manual, Section 1-Sheet 5.)

9.5.3.1 Clean the block in a heated bath or temperature-controlled automated parts washer before and after honing. Follow these suggested guidelines as listed below to ensure there is no rusting of the engine block coolant jacket after this process:

(1) Use only NAT-50 or PDN-50 soap at a concentration of 16 lb of soap per 100 gal of water. Change the soap and water solution at least every six months.

(2) Set the water temperature to 60°C (140°F).

(3) Do not, in any manner, pre-condition the water that is being used.

(4) Prior to installing the engine in the parts washer, ensure that all coolant passages are blocked off to prevent cleaning solutions from entering the passages.

(5) Allow the block to run through the cleaning cycle for a period of 30 to 40 min.

(6) After the cycle is complete, immediately remove the block from the washer and spray it down with solvent.

(7) Wipe cylinder bores out with a lint free towel.

(8) Spray engine block with a mixture of 50:50 build-up oil and solvent.

(9) Do not remove the paint dot from the crankcase area of the block.

(10) Allow the block to cool to room temperature before honing the block.

9.5.3.2 See the Sequence IIIF Engine Assembly Manual, Section 2 for the honing procedure.

9.5.3.3 After honing the cylinder walls, clean the engine block again according to 9.5.3 and spray the engine block (including all oil galleries) first with solvent followed by a 50:50 mixture of solvent and build-up oil. Using this 50:50 mixture, wipe out the cylinder bores with clean cloth towels until all honing residue has been removed.

9.5.3.4 Air dry the engine block, using clean dry shop air, and coat the cylinder walls with build-up oil using soft, lint-free, clean cloths.

9.6 *Cylinder Head Cleaning*—Clean the cylinder heads according to the following:

9.6.1 Explore all accessible water passages with a flexible probe to detect any material that would interfere with coolant flow.

9.6.2 Using a 10-mm wire brush, extending two-thirds the length of the cylinder head from freeze plug hole to freeze plug hole, clean all core sand and casting slag from the cylinder heads to ensure unrestrained coolant flow.

9.6.3 Clean the cylinder heads according to the recommended engine block cleaning procedure (see 9.5.3.1) or clean with solvent. Spray the heads with a 50/50 mixture of solvent and EF-411. When cleaning the heads, do not remove the paint dot.

9.7 *Engine Build-up Procedure*—Laboratories should design and maintain engine-build data sheets in a format compatible with Microsoft Excel and record data for cylinder bore measurements, piston and ring sizing data, valve train spring load calibrations, camshaft and lifter measurements, and all critical part identification information. This data shall be available to the TMC and the Test Procedure Developer for investigative studies, as deemed necessary for hardware investigations during times of industry severity shifts or other problems.

9.7.1 *General Information*—Use only the listed service parts, special test parts, and special build-up procedures specific to this test as outlined in this test method and the Sequence IIIF Engine Assembly Manual. (See 6.4.) Make and record measurements, specified in this test method, of the cylinders, pistons, rings, valve train, cam, and lifters. These measurements will provide evidence of conformance to the specifications of the test method, and will provide baselines for determining engine wear that occurs during a Sequence IIIF test.

9.7.2 *Special Parts*—Use the special parts listed in the Sequence IIIF Engine Assembly Manual, Sections 8, 9, 10, and 11.

9.7.3 *Hardware Information*—Complete Form 12, Hardware Information, in standardized report form set (see Annex A5).

9.7.4 *Fastener Torque Specifications and Torquing Procedures*—Use the following specifications and torquing procedures when installing bolts in the engine:

9.7.4.1 *Main Bearing Cap Bolts*—Do not use air tools on bolts to seat the main bearing caps in the engine block. Use a rubber or plastic mallet to seat the main bearing caps to avoid misalignment and potential damage to the engine block. Apply build-up oil to the threads and to the surfaces of the bolts that contact the main bearing caps. In order to prevent hydraulic lock, do not apply oil to the tapped holes in the cylinder block. Install the bolts finger-tight and tighten them further with the SPS Torque Sensor I torque wrench^{9,22} or Ingersoll-Rand ETW-E180^{9,23} only, working from the center out in a crisscross

²² Available from Sunnen Products Co., 7910 Manchester Ave, St. Louis, MO 63143.

²³ Available from Ingersoll-Rand Assembly Solutions, 510 Hester Drive, White House, TN 37188.

pattern. See the Sequence IIIF Engine Assembly Manual for torquing instructions. (See Section 1-Sheet 6 for honing and Section 3-Sheet 6 for final assembly.)

9.7.4.2 *Cylinder Head Bolts*—Install the cylinder head bolts, GM Part No. 25527831 (long) and 25533811 (short), which are of special design for yield applications using the SPS Torque Sensor I or Ingersoll-Rand ETW-E180 torque wrench. See the Sequence IIIF Engine Assembly Manual for installation instructions. Replace the bolts after each test. (See Section 1-Sheet 7 for honing and Section 5 Sheet 3 for final assembly.)

9.7.4.3 *Torques for Miscellaneous Bolts, Studs, and Nuts*—Use the torques for miscellaneous bolts, studs, and nuts given in the Sequence IIIF Engine Assembly Manual.

9.8 *Parts Replacement*—See 9.8.1 for information regarding parts. Replace test parts as follows:

9.8.1 Install the new parts listed in Annex A2 (Table A2.1) for each test.

9.8.2 Install the new parts listed in Annex A2 (Table A2.2) only if the used part is no longer suitable for test purposes.

9.9 *Engine Block Preparation*—Prepare the engine block as follows:

9.9.1 Install new engine block freeze plugs; use a driver to facilitate this replacement.

9.9.2 Install the main bearing caps, without the bearings in place. Tighten the retaining bolts using the procedure in 9.7.4.1.

9.9.3 To prevent entry of honing fluid into the coolant passages of the engine block, cover and seal the coolant inlet passages and freeze plug openings. Close the petcocks if previously installed; if not, install ¼ in. NPT pipe plugs.

9.9.4 With a 30 cm (12 in.) smoothing file, deburr the surfaces of the block that mate with the cylinder heads to ensure adequate gasket seating.

9.9.5 Use the honing torque plates B-H-J GM 3.8L/3E-Rs_t-HT^{9,24} to pre-stress the engine block for honing. Install the torque plates with the proper hardened washers (supplied with the honing torque plates), single washers on top row and double washers on bottom row, to establish proper bolt depth. Clean the threaded bores for the cylinder head attachment bolts using a bottoming tap before each installation of the torque plates. The torque plates require the use of new head gaskets, SPO Part No. 24503801 left head and 24503802 right head, along with cylinder head, torque-to-yield fasteners, SPO Part No. 25527831 (long). Clean all sealing and thread locking compounds from the fasteners for the torque plate installation. Coat each fastener with build-up oil and see Section 1-Sheet 7 of the Sequence IIIF Engine Assembly Manual for installation instructions.

9.9.6 Use only the CV-616 honing machine to hone the cylinder walls. See the Sequence IIIF Engine Assembly Manual, Section 2, for all of the proper setup and operational procedures for each specific run on the Sequence IIIF engine block.

9.9.7 Replace the honing fluid, filters, and fiber mats used in the honing machine after every 15-h of honing machine

operation. Use the honing machine hour meter to determine hours of operation. See the Sequence IIIF Engine Assembly Manual, Section 2-Sheet 8.

9.9.8 The flow rate of the honing lubricant should be approximately 7 L/min (2 gal/min). In addition, do not introduce solvents into the honing fluid or use them to clean the honing stones or guides. Use only honing fluid to clean honing stones or guides.

9.9.9 Hone the cylinder walls without the main bearings in place, but with all bearing caps installed.

9.9.10 Clean the engine block following honing according to 9.5.3.1.

9.9.10.1 Allow cylinder block to cool for a minimum of 10 min before taking final bore measurements.

9.9.11 If desired, check the main bearing bore clearances using a mandrel, part BX-398-1, according to the following procedure:

9.9.11.1 Starting from the front of the block, slide the mandrel through all four main bearing bores. If excessive resistance is encountered while inserting the mandrel, remove the mandrel from the engine block and inspect the main bearing bores for burrs, nicks, dirt, alignment problems, or any abnormalities.

9.9.11.2 Carefully remove any nicks, burrs, scratches, or dirt with 400-grit paper or a fine stone. Then use a clean shop towel with mineral spirits to wipe the affected surfaces. Reinstall the mandrel to ensure that it can freely pass through all four main bearing bores. If the mandrel will not clear the bores after completing the above steps, do not use this block. Notify the Test Procedure Developer of the problem.

9.9.11.3 After honing, repeat the above procedure prior to final engine build. The mandrel is an alignment and clearance gage only, not an assembly tool. The mandrel should not be in the bores when installing the main bearing caps or torquing the main bearing bolts.

9.10 *Piston Fitting and Numbering*—Fit the pistons to the cylinders according to recommendations listed in the Sequence IIIF Engine Assembly Manual for the run sequence of the block. Use only the specified code pistons for each run sequence. Number the pistons with odd numbers in the left bank from front to rear and with even numbers in the right bank from front to rear.

9.10.1 *Piston Rings*—Pre-size the rings for each run and check the ring gaps in the cylinder bore for each test.

9.10.1.1 Prior to checking the piston ring gaps, remove any paint marks on the rings using acetone and a soft cloth, followed by a mineral spirits rinse.

9.10.1.2 The top ring gap shall be 1.067 ± 0.051 mm (0.042 ± 0.002 in.). The bottom ring gap shall be 0.965 ± 0.051 mm (0.038 ± 0.002 in.). The top ring gap shall be larger than the bottom ring gap and the difference between the two ring gaps shall be between 0.076 mm and 0.152 mm (0.003 in. and 0.006 in.). If the ring gap difference is below 0.076 mm (0.003 in.), contact the Test Procedure Developer. Check the ring gap with a Starrett Ring Taper Gage No. 270²⁵ with the ring positioned

²⁴ The sole source of supply of the apparatus known to the committee at this time is B-H-J Products Inc., 37530 Enterprise Ct., Newark, CA 94560.

²⁵ A Starrett Ring Taper Gage No. 270 has been found suitable and is available from commercial sources.

in the cylinder bore using a piston ring depth gage (drawing RX-118602-B²). Position the rings 23.67 mm (0.932 in.) below the cylinder-block deck surface during gap measurement.

9.10.1.3 Record the top and bottom ring gaps on Form 12, Hardware Information, in the standardized report form set (see [Annex A5](#)). Record and report ring gaps in mils (1 mil = 0.001 in. = 0.0254 mm).

9.11 *Pre-Test Camshaft and Lifter Measurements*—Measure the camshaft lobe height and lifter lengths, prior to engine assembly, according to the following procedure:

9.11.1 With the camshaft positioned in a set of V-blocks, remove any burrs around the outer edge of the camshaft thrust surface, if necessary.

9.11.2 Clean the camshaft with aliphatic naphtha and blow-dry it with clean, dry shop air.

9.11.3 Measure the maximum pre-test dimension of each camshaft lobe, transverse to the camshaft axis to the nearest 0.001 mm (0.00004 in.). This dimension is at the rear edge of all lobe positions (lobes are numbered from the front to the rear of the camshaft). Record the measurements on internal laboratory forms. (See [9.7](#).)

9.11.3.1 After measuring, coat the camshaft with build-up oil.

9.11.4 Measure the pre-test length of the lifters at the center of the lifter foot to the nearest 0.001 mm (0.00004 in.). Record the measurements on internal laboratory forms. (See [9.7](#).)

9.11.5 Record the unique serial number for each lifter on internal laboratory forms. (See [9.7](#).) Do not use electro-mechanical scribing devices. Do not place any marks on the lifter body or foot.

9.12 *Camshaft Bearing Installation*—The camshaft tunnel is specially processed and uses oversize bearings provided through the CPD. Install the camshaft bearings according to the Sequence IIIF Engine Assembly Manual, Section 3-Sheet 3. Always inspect the lifter and main bearing oil galleries for splintered babbitt materials that might have been shaved from the outside diameter of the bearings during installation. Remove any materials from the oil galleries with clean dry shop air.

9.13 *Camshaft Installation*—Install the camshaft according to the Sequence IIIF Engine Assembly Manual, Section 3-Sheet 11:

9.13.1 Coat the camshaft lobes and journals with a light film of test oil.

NOTE 7—Camshafts should not sit dry inside the engine block waiting for final assembly more than 24 h.

9.13.2 Install the camshaft in the engine block, exercising care to avoid damage to the lobes, journals, and bearings.

9.13.3 *Installation of Camshaft Thrust Plate*—Lubricate the thrust plate with build-up oil and install the thrust plate to the front of the engine using new Torx fasteners.

9.14 *Main Bearings*—Verify that the main bearing bore areas in the engine block and bearing caps are clean. Install new main bearings, part no. OHT3F-042-2, in the engine block and main bearing caps, and lightly oil the bearing surfaces with build-up oil. Use new main bearing cap bolts for each Sequence IIIF test engine build.

9.14.1 *Crankshaft*—Install the crankshaft.

9.14.2 *Main Bearing Cap Installation*—Install the main bearing caps using new bolts for each test. Do not remove the phosphate coating from the bolts. Do not use air tools on the main bearing cap bolts to seat the caps. Install the bolts finger-tight, and tighten them according to the procedure in [9.7.4.1](#). Use the main bearings as received.

9.15 *Crankshaft Sprocket*—Install a matched set two-piece crankshaft sprocket, part no. OHT3F-036-1.

9.16 *Camshaft Sprocket, and Timing Chain*—Install a new camshaft sprocket and timing chain.

9.17 *Crankshaft Endplay*—Measure the crankshaft endplay. It should be between 0.076 and 0.279 mm (0.003 and 0.011 in.).

9.18 *Piston Pin Installation*—Install new piston pins and retainers for each test. Clean piston pins using a clean lint-free cloth and oil with build-up oil. The piston pins are full floating and held in place by two retainers.

9.18.1 *Piston Installation*—Clean pistons using solvent and air dry. Wipe the pistons with a lint-free cloth prior to installation.

9.18.2 Use a piston ring expander to install the pre-gapped piston rings (see [9.10.1](#)) on the pistons.

9.18.3 Position the ring end gaps as shown in the Sequence IIIF Engine Assembly Manual, Section 3-Sheet 8.

9.18.4 Coat the cylinder walls with build-up oil and wipe them with a clean, lint-free soft cloth, repeating the process until clean; apply a final coat of build-up oil before installing the piston assembly.

9.18.5 Coat the pistons and rings with build-up oil.

9.18.6 Install the pistons in the cylinders, using a ring compressor tool.²⁶

9.19 *Harmonic Balancer*—Deburr the harmonic balancer keyway slot and the slot on the crankshaft with a mill file. Do not install the balancer until after performing the oil pump priming operation in the test stand just prior to test start.

NOTE 8—To make the balancer a slip-fit, remove the rolled edge on the inside diameter of the balancer until the balancer slips easily over the crankshaft.

9.20 *Connecting Rod Bearings*—Clean the bearings using a clean, lint-free cloth and oil with build-up oil prior to installation. Use new connecting rod bearings, part no. OHT3F-042-2, for each test, furnished as part of the engine bearing kit.

9.20.1 Install the bearings in the connecting rods, and install the bearing caps with the rods in place on the crankshaft.

9.20.1.1 Tighten the connecting rod bolts according to the specifications listed in the Sequence IIIF Engine Assembly Manual. Determine the torque specifications for the connecting rod bolts by the type of connecting rod: cast or powdered metal.

9.21 *Engine Front Cove*—Use a new front cover with each new engine block or if the oil pump gerotor housing is worn.

9.21.1 Install new oil pump gears or a new front cover and new gears, as deemed necessary, according to the Sequence IIIF Engine Assembly Manual inspection requirements Section 4-Sheet 2.

²⁶ Ring compressor tools are available from automotive tools suppliers.