

ETSI TS 124 380 V18.5.0 (2024-05)



**LTE;
Mission Critical Push To Talk (MCPTT) media plane control;
Protocol specification
(3GPP TS 24.380 version 18.5.0 Release 18)**

[ETSI TS 124 380 V18.5.0 \(2024-05\)](https://standards.itec.ai/catalog/standards/etsi/04a36796-62ce-4a54-9791-ad8a12d85f9d/etsi-ts-124-380-v18-5-0-2024-05)

<https://standards.itec.ai/catalog/standards/etsi/04a36796-62ce-4a54-9791-ad8a12d85f9d/etsi-ts-124-380-v18-5-0-2024-05>



ReferenceRTS/TSGC-0124380vi50

KeywordsLTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2024.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2024-05)

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	16
1 Scope	17
2 References	17
3 Definitions and abbreviations.....	18
3.1 Definitions	18
3.2 Abbreviations	19
4 General	20
4.1 Overview	20
4.1.1 Floor Control	20
4.1.1.1 General	20
4.1.1.2 On-network floor control	20
4.1.1.3 Off-network floor control.....	22
4.1.1.4 Determine on-network effective priority.....	22
4.1.1.5 Determine off-network effective priority	22
4.1.2 Pre-established session call control.....	23
4.1.2.1 General	23
4.1.2.2 Call setup over pre-established session.....	23
4.1.2.3 Release of a call which uses a pre-established session.....	24
4.1.3 MBMS subchannel control	24
4.1.3.1 General	24
4.1.3.2 Start of a conversation.....	24
4.1.3.3 During a conversation	25
4.1.3.4 Ending the conversation.....	25
4.1.3.5 Starting a call over unicast bearers.....	25
4.1.3.6 Moving a conversation to unicast bearers	25
4.1.3.7 MBMS bearer announcement over an MBMS bearer	25
4.1.4 MBS subchannel control.....	25
4.2 Internal structure of media plane control entities	25
4.2.1 Controlling MCPTT function	25
4.2.2 MCPTT client	27
4.2.3 Participating MCPTT function	29
4.2.3.1 General	29
4.2.3.2 Internal structure of the participating MCPTT function.....	29
4.2.3.3 The roles of the participating MCPTT function.....	30
4.2.3.3.1 For the floor control procedures	30
4.2.3.3.2 For the call over pre-established session procedures.....	30
4.2.3.3.3 For the use of MBMS bearer procedures.....	30
4.2.4 Non-controlling MCPTT function of an MCPTT group.....	31
4.3 The media plane control channel.....	32
4.3.1 General.....	32
4.3.2 Control channel realization.....	32
4.3.3 Establishing a media plane control channel.....	32
4.3.3.1 General	32
5 Entities.....	33
5.1 General	33
5.2 MCPTT client.....	33
5.2.1 Introduction.....	33
5.2.2 Floor participant in on-network mode	34
5.2.3 Floor participant in off-network mode.....	34
5.3 Controlling MCPTT function.....	35

5.4	Participating MCPTT function	35
5.5	Non-controlling MCPTT function	35
6	On-network floor control	36
6.1	General	36
6.2	Floor participant procedures	36
6.2.1	Floor participant procedures at MCPTT session initialization	36
6.2.2	Floor participant procedures at MCPTT call release	36
6.2.3	Floor participant procedures at MCPTT call modification	36
6.2.4	Floor participant state transition diagram for basic operation	37
6.2.4.1	General	37
6.2.4.2	State: 'Start-stop'	38
6.2.4.2.1	General	38
6.2.4.2.2	MCPTT call initiated, originating MCPTT user	38
6.2.4.2.3	MCPTT call established, terminating MCPTT user	38
6.2.4.3	State: 'U: has no permission'	38
6.2.4.3.1	General	38
6.2.4.3.2	Receive Floor Idle message (R: Floor Idle)	38
6.2.4.3.3	Receive Floor Taken message (R: Floor Taken)	39
6.2.4.3.4	Receive RTP media packets (R: RTP media)	39
6.2.4.3.5	Send Floor Request message (PTT button pressed)	39
6.2.4.3.6	Timer T103 (End of RTP media) expired	40
6.2.4.3.7	Receive Floor Release Multi Talker message (R: Floor Release Multi Talker)	40
6.2.4.3.8	Send Unicast Media Stop Request message (S: Unicast Media Flow Control)	40
6.2.4.3.9	Send Unicast Media Resume Request message (S: Unicast Media Flow Control)	40
6.2.4.4	State: 'U: pending Request'	41
6.2.4.4.1	General	41
6.2.4.4.2	Receive Floor Granted message (R: Floor Granted)	41
6.2.4.4.3	Void	41
6.2.4.4.4	Receive Floor Deny message (R: Floor Deny)	41
6.2.4.4.5	Timer T101 (Floor request) expired	42
6.2.4.4.6	Timer T101 (Floor Request) expired N times	42
6.2.4.4.7	Receive RTP media packets (R: RTP Media)	42
6.2.4.4.8	Send Floor Release message (PTT button released)	42
6.2.4.4.9	Receive Floor Queue Position Info message (R: Floor Queue Position Info)	43
6.2.4.4.10	Receive Floor Release Multi Talker message (R: Floor Release Multi talker)	43
6.2.4.4.11	Receive Floor Taken message (R: Floor Taken)	43
6.2.4.5	State: 'U: has permission'	44
6.2.4.5.1	General	44
6.2.4.5.2	Send RTP media packets (RTP media)	44
6.2.4.5.3	Send Floor Release message (PTT button released)	44
6.2.4.5.4	Receive Floor Revoke message (R: Floor Revoke)	44
6.2.4.5.5	Receive Floor Granted message (R: Floor Granted)	45
6.2.4.5.6	Receive RTP media packets (R: RTP Media)	45
6.2.4.5.7	Receive Floor Idle message (R: Floor Idle)	46
6.2.4.5.8	Receive Floor Taken message (R: Floor Taken)	46
6.2.4.5.9	Receive Floor Release Multi Talker message (R: Floor Release Multi talker)	46
6.2.4.6	State: 'U: pending Release'	47
6.2.4.6.1	General	47
6.2.4.6.2	Timer T100 (Floor Release) expired	47
6.2.4.6.3	Timer T100 (Floor release) expired N times	47
6.2.4.6.4	Receive Floor Idle message (R: Floor Idle)	47
6.2.4.6.5	Receive Floor Taken message (R: Floor Taken)	47
6.2.4.6.6	Receive RTP media packets (R: RTP Media)	48
6.2.4.6.7	Receive Floor Revoke message (R: Floor Revoke)	48
6.2.4.6.8	Receive Floor Granted message (R: Floor Granted)	48
6.2.4.6.9	Receive Floor Release Multi Talker message (R: Floor Release Multi talker)	49
6.2.4.7	In any state	49
6.2.4.7.1	General	49
6.2.4.7.2	Receive MCPTT call release – step 1 (R: MCPTT call release - 1)	49
6.2.4.7.3	void	49
6.2.4.7.4	Send Queued Floor Requests message (S: Send Queued Floor Requests)	49

6.2.4.7.5	Timer T134 (Queued Floor Requests) expired.....	50
6.2.4.7.6	Receive Queued Floor Requests message (R: Queued Floor Requests).....	50
6.2.4.8	State: 'Releasing'	50
6.2.4.8.1	General	50
6.2.4.8.2	Receive MCPTT call release – step 2 (R: MCPTT call release - 2)	50
6.2.4.9	State: 'U: queued'.....	50
6.2.4.9.1	General	50
6.2.4.9.2	Receive RTP media packets (R: RTP media).....	50
6.2.4.9.3	Receive Floor Taken message (R: Floor Taken)	51
6.2.4.9.4	Receive Floor Granted message (R: Floor Granted).....	51
6.2.4.9.5	Receive Floor Deny message (R: Floor Deny).....	51
6.2.4.9.6	Send Floor Release message (PTT button released).....	52
6.2.4.9.7	Receive Floor Queue Position Info message (R: Floor Queue Position Info)	52
6.2.4.9.8	Receive Floor Idle message (R: Floor Idle).....	52
6.2.4.9.9	Send Floor Queue Position Request message (S: Floor Queue Position Request)	53
6.2.4.9.10	Timer T104 (Floor Queue Position Request) expired.....	53
6.2.4.9.11	Timer T104 (Floor Queue Position Request) expired N times	53
6.2.4.9.12	User indication for accept of pending request	53
6.2.4.9.13	Timer T132 (Queued granted user action) expires	53
6.2.4.9.14	Receive Floor Release Multi Talker message (R: Floor Release Multi talker)	54
6.2.4.9.15	Receive Queued Floor Requests message (R: Queued Floor Requests).....	54
6.3	Floor control server procedures	54
6.3.1	General.....	54
6.3.2	Controlling MCPTT function procedures at MCPTT call initialization	54
6.3.2.1	General	54
6.3.2.2	Initial procedures.....	55
6.3.2.3	Switching from a non-controlling MCPTT function mode to a controlling MCPTT function mode.....	55
6.3.3	MCPTT floor control procedures at MCPTT call release.....	56
6.3.4	Floor control server state transition diagram for general floor control operation	56
6.3.4.1	General	56
6.3.4.2	State: 'Start-stop'	58
6.3.4.2.1	General	58
6.3.4.2.2	MCPTT call initialization.....	58
6.3.4.3	State: 'G: Floor Idle'	58
6.3.4.3.1	General	58
6.3.4.3.2	Enter the 'G: Floor Idle' state	59
6.3.4.3.3	Receive Floor Request message (R: Floor Request)	60
6.3.4.3.4	Timer T7 (Floor Idle) expired	60
6.3.4.3.5	Timer T4 (Inactivity) expired	60
6.3.4.3.6	Receive an implicit floor request (R: Implicit floor request).....	61
6.3.4.3.7	Receive a unicast media stop request (R: Unicast Media Flow Control)	61
6.3.4.3.8	Receive a unicast media resume request (R: Unicast Media Flow Control).....	61
6.3.4.4	State: 'G: Floor Taken'.....	62
6.3.4.4.1	General	62
6.3.4.4.2	Enter the 'G: Floor Taken' state	62
6.3.4.4.3	Timer T1 (End of RTP media) expired.....	63
6.3.4.4.4	Timer T2 (Stop talking) expired.....	63
6.3.4.4.5	Receive RTP media packets (R: RTP media).....	64
6.3.4.4.6	Receive Floor Release message (R: Floor Release)	64
6.3.4.4.7	Receive Floor Request message with pre-emptive priority (R: pre-emptive Floor Request)	64
6.3.4.4.7a	Receive Floor Request message multi-talker (R: multi-talker Floor Request)	65
6.3.4.4.8	Receive Floor request message from permitted floor participant (R: Floor Request)	66
6.3.4.4.9	Timer T20 (Floor Granted) expired.....	67
6.3.4.4.10	Timer T20 (Floor Granted) expired N times	67
6.3.4.4.11	Permitted MCPTT client release (R: client release)	67
6.3.4.4.12	Receive an implicit floor request (R: Implicit floor request).....	67
6.3.4.4.13	Receive Queued Floor Requests message (R: Queued Floor Requests).....	68
6.3.4.4.14	Receive a unicast media stop request (R: Unicast Media Flow Control)	69
6.3.4.4.15	Receive a unicast media resume request (R: Unicast Media Flow Control).....	69
6.3.4.5	State: 'G: pending Floor Revoke'.....	69
6.3.4.5.1	General	69

6.3.4.5.2	Enter the 'G: pending Floor Revoke' state	69
6.3.4.5.3	Receive RTP media packets (R: RTP media)	70
6.3.4.5.4	Receive Floor Release message (R: Floor Release)	70
6.3.4.5.5	Timer T3 (Stop talking grace) expired	71
6.3.4.5.6	Timer T1 (End of RTP media) expired.....	71
6.3.4.5.7	Receive Floor Queued Cancel Request message (R: Floor Queued Cancel Request).....	72
6.3.4.5.8	Receive a unicast media stop request (R: Unicast Media Flow Control)	72
6.3.4.5.9	Receive a unicast media resume request (R: Unicast Media Flow Control).....	72
6.3.4.6	In any state	72
6.3.4.6.1	General	72
6.3.4.6.2	Receive MCPTT call release - 1.....	72
6.3.4.6.3	Receive an instruction to merge group calls (R: Merge)	72
6.3.4.7	State: 'Releasing'	73
6.3.4.7.1	General	73
6.3.4.7.2	Receive MCPTT call release - 2.....	73
6.3.4.8	State: 'G: Floor Initialising'	73
6.3.4.8.1	General	73
6.3.4.8.2	Enter the 'G: Initialising' state.....	73
6.3.4.8.3	Receiving a floor request from a constituent MCPTT group (R: mcptt-floor-request)	73
6.3.4.8.4	All final SIP responses received (R: final SIP responses)	73
6.3.5	Floor control server state transition diagram for basic floor control operation towards the floor participant	74
6.3.5.1	General	74
6.3.5.2	State: 'Start-stop'.....	77
6.3.5.2.1	General	77
6.3.5.2.2	SIP Session initiated	77
6.3.5.3	State: 'U: not permitted and Floor Idle'	81
6.3.5.3.1	General	81
6.3.5.3.2	Enter state 'U: not permitted and Floor Idle'	81
6.3.5.3.3	Send Floor Taken message (S: Floor Taken).....	81
6.3.5.3.4	Receive Floor Request message (R: Floor Request)	81
6.3.5.3.5	Send Floor Granted message (S: Floor Granted).....	82
6.3.5.3.6	Send Floor Deny message (S: Floor Deny)	82
6.3.5.3.7	Receive Floor Release message (R: Floor Release)	82
6.3.5.3.8	Receive RTP media packets (R: media)	83
6.3.5.3.9	Receive an implicit floor request (R: Implicit floor request).....	83
6.3.5.3.10	Send Floor Idle message (S: Floor Idle)	83
6.3.5.4	State 'U: not permitted and Floor Taken'.....	84
6.3.5.4.1	General	84
6.3.5.4.2	Enter state 'U: not permitted and Floor Taken'	84
6.3.5.4.3	Send Floor Idle message (S: Floor Idle).....	84
6.3.5.4.4	Receive Floor Request message (R: Floor Request)	84
6.3.5.4.5	Receive Floor Release message (R: Floor Release)	88
6.3.5.4.6	Receive RTP media packets (R: media)	89
6.3.5.4.7	Send Floor Queue Position Info message (R: Floor Queue Position Request).....	90
6.3.5.4.8	Receive an implicit floor request (R: Implicit floor request).....	90
6.3.5.4.9	Send Floor Granted message (S: Floor Granted).....	90
6.3.5.4.10	Send Floor Taken message (S: Floor Taken).....	91
6.3.5.4.11	Send Floor Release Multi Talker message (S: Floor Release Multi Talker)	91
6.3.5.4.12	Receive Queued Floor Requests message (R: Queued Floor Requests).....	91
6.3.5.4.13	Send Queued Floor Requests message (S: Queued Floor Requests)	92
6.3.5.4.14	Void.....	92
6.3.5.5	State: 'U: permitted'	92
6.3.5.5.1	General	92
6.3.5.5.2	Enter state 'U: permitted'	92
6.3.5.5.3	Receive Floor Release message (R: Floor Release)	92
6.3.5.5.4	Send Floor Idle message (S: Floor Idle).....	93
6.3.5.5.5	Send Floor Revoke message (S: Floor Revoke)	93
6.3.5.5.6	Receive RTP media packets (R: media)	94
6.3.5.5.7	Receive Floor Request message (R: Floor Request)	94
6.3.5.5.8	Send RTP Media (S: media).....	94
6.3.5.5.9	Send Floor Taken message (S: Floor Taken).....	94

6.3.5.5.10	Send Floor Release Multi Talker message (S: Floor Release Multi Talker)	95
6.3.5.5.11	Receive Queued Floor Requests message (R: Queued Floor Requests)	95
6.3.5.5.12	Send Queued Floor Requests message (S: Queued Floor Requests)	95
6.3.5.5.13	Void	96
6.3.5.6	State: 'U: pending Floor Revoke'	96
6.3.5.6.1	General	96
6.3.5.6.2	Enter state 'U pending Floor Revoke'	96
6.3.5.6.3	Timer T8 (media Revoke) expired	96
6.3.5.6.4	Receive RTP media packets (R: media)	96
6.3.5.6.5	Receive Floor Release message (R: Floor Release)	97
6.3.5.6.6	Send Floor Idle message (S: Floor Idle)	97
6.3.5.6.7	Send Floor Taken message (S: Floor Taken)	98
6.3.5.6.8	Send Floor Release Multi Talker message (S: Floor Release Multi Talker)	98
6.3.5.7	State 'U: not permitted but sends media'	98
6.3.5.7.1	General	98
6.3.5.7.2	Enter state 'U: not permitted but sends media'	98
6.3.5.7.3	Timer T8 (Floor Revoke) expired	98
6.3.5.7.4	Receive Floor Release message (R: Floor Release)	99
6.3.5.7.5	Send Floor Taken message (S: Floor Taken)	100
6.3.5.7.6	Send Floor Release Multi Talker message (S: Floor Release Multi Talker)	100
6.3.5.8	In any state	100
6.3.5.8.1	General	100
6.3.5.8.2	Receive MCPTT call release – 1	100
6.3.5.8.3	Receiving a merging instruction (R: Merge)	100
6.3.5.9	State: 'Releasing'	101
6.3.5.9.1	General	101
6.3.5.9.2	Receive MCPTT call release - 2	101
6.3.5.10	State: 'U: not permitted and initiating'	101
6.3.5.10.1	General	101
6.3.5.10.2	Enter the 'U: not permitted and initiating' state	101
6.3.5.10.3	Send Floor Taken message (S: Floor Taken)	101
6.3.5.10.4	Send Floor Idle message (S: Floor Idle)	102
6.3.5.10.5	Receive Floor Request message (R: Floor Request)	102
6.3.5.10.6	Send Floor Granted message (S: Floor Granted)	102
6.3.5.10.7	Receive a Floor Release message (S: Floor Release)	103
6.3.5.10.8	Send Floor Release Multi Talker message (S: Floor Release Multi Talker)	103
6.3.6	Dual floor control	103
6.3.6.1	General	103
6.3.6.2	State: 'Start-stop'	104
6.3.6.2.1	General	104
6.3.6.2.2	Receive Floor Request message with overriding pre-emptive floor priority (R: Floor Request) ..	105
6.3.6.3	State: 'D: Floor Taken'	105
6.3.6.3.1	General	105
6.3.6.3.2	Enter state 'D: Floor Taken'	105
6.3.6.3.3	Timer T11 (End of RTP dual) expired	106
6.3.6.3.4	Timer T12 (Stop talking dual) expired	107
6.3.6.3.5	Receive RTP media packets (R: media)	108
6.3.6.3.6	Receive Floor Release message (R: Floor Release)	108
6.3.6.3.7	Receive Floor request message from permitted floor participant (R: Floor Request)	109
6.3.6.3.8	Permitted MCPTT client release	109
6.3.6.3.9	Receive Terminate (Terminate)	110
6.3.6.4	In any state	110
6.3.6.4.1	General	110
6.3.6.4.2	Receive MCPTT call release - 1	110
6.3.6.5	State: 'Releasing'	110
6.3.6.5.1	General	110
6.3.6.5.2	Receive MCPTT call release - 2	110
6.4	Participating MCPTT function floor control procedures	111
6.4.1	General	111
6.4.2	Receive floor control messages	111
6.4.3	Receive RTP media packets (R: RTP Media)	112
6.4.4	Release of session	112

6.5	Non-controlling MCPTT function of an MCPTT group	112
6.5.1	General.....	112
6.5.2	The MCPTT call initialization procedure in the non-controlling MCPTT function of an MCPTT group	113
6.5.2.1	General	113
6.5.2.2	Initial procedures when a new SIP session is establishing a group session	113
6.5.2.3	Switching from a controlling MCPTT function mode to a non-controlling MCPTT function mode.....	113
6.5.2.3.1	Overview	113
6.5.2.3.2	Preparing for the switch to non-controlling MCPTT function (Step 1).....	113
6.5.2.3.3	Start acting as a non-controlling MCPTT function (Step 2).....	114
6.5.3	The MCPTT call release procedure in the non-controlling MCPTT function of an MCPTT group.....	114
6.5.4	Floor control server interface procedures	115
6.5.4.1	General	115
6.5.4.2	Receiving a Floor Request message.....	115
6.5.4.3	Receive Floor Release message	115
6.5.4.4	Receive Floor Queue Position Request message.....	116
6.5.4.5	Receive Floor Ack message	116
6.5.4.6	Receive Floor Granted message.....	116
6.5.4.7	Receive Floor Deny message	118
6.5.4.8	Receive Floor Idle message.....	118
6.5.4.9	Receive Floor Taken message.....	119
6.5.4.10	Receive Floor Revoke message.....	120
6.5.4.11	Receive Floor Queue Position Info message.....	120
6.5.4.12	Receive RTP media packets from controlling MCPTT function	121
6.5.4.13	Receive RTP media packets from an MCPTT client	121
6.5.4.14	MCPTT session release step 1	121
6.5.4.15	MCPTT session release step 2	121
6.5.4.16	Receiving a split instruction (R: Split).....	122
6.5.4.17	Receive Floor Release Multi Talker message	122
6.5.5	Floor participant interface procedures	122
6.5.5.1	General	122
6.5.5.2	State: 'Start-Stop'	123
6.5.5.2.1	General	123
6.5.5.2.2	Participant invited to session	123
6.5.5.3	State: 'P: has no permission'	123
6.5.5.3.1	General	123
6.5.5.3.2	Receive Floor Idle message (R: Floor Idle).....	123
6.5.5.3.3	Receive Floor Taken message (R: Floor Taken)	123
6.5.5.3.4	Receive Floor Request message (R: Floor Request)	124
6.5.5.3.5	Receive Floor Granted message (R: Floor Granted).....	124
6.5.5.3.6	Receive Floor Deny message (R: Floor Deny).....	124
6.5.5.3.7	Receive Floor Queue Position Info message (R: Floor Queue Position Info)	124
6.5.5.3.8	Receive Floor Queue Position Request message (R: Floor Queue Position Request).....	124
6.5.5.3.9	Receive RTP media packets (R: RTP media).....	124
6.5.5.3.10	Receive Floor Release message (R: Floor Release)	125
6.5.5.3.11	Receive split instruction (R: Split)	125
6.5.5.3.12	Receive Floor Release Multi Talker message.....	125
6.5.5.4	State: 'P: has permission'	126
6.5.5.4.1	General	126
6.5.5.4.2	Receive RTP media packets	126
6.5.5.4.3	Receive Floor Release message.....	126
6.5.5.4.4	Receive Floor Ack message	126
6.5.5.4.5	Receive Floor Idle message.....	126
6.5.5.4.6	Receive Floor Taken message	126
6.5.5.4.7	Receive Floor Revoke message.....	127
6.5.5.4.8	Receive split instruction (R: Split)	127
6.5.5.4.9	Receive Floor Release Multi Talker message.....	127
6.5.5.5	In any state	127
6.5.5.5.1	General	127
6.5.5.5.2	Receive Floor Ack message (R: Floor Ack).....	127
6.5.5.5.3	MCPTT session release step 1 (MCPTT call release - 1).....	128

6.5.5.6	State: 'P: Releasing'	128
6.5.5.6.1	General	128
6.5.5.6.2	MCPTT session release step 2 (MCPTT call release - 2)	128
7	Off-network floor control	128
7.1	General	128
7.2	Floor participant procedures	129
7.2.1	Floor participant procedures at MCPTT session initialization	129
7.2.1.2	Determine off-network floor priority	129
7.2.2	Floor participant procedures at MCPTT call release	131
7.2.3	Floor participant state diagram – basic operation	131
7.2.3.1	General	131
7.2.3.2	State: 'Start-stop'	132
7.2.3.2.1	General	132
7.2.3.2.2	MCPTT call established – originating MCPTT user	133
7.2.3.2.3	MCPTT group call established – terminating MCPTT user	133
7.2.3.2.4	MCPTT private call established – terminating MCPTT user	133
7.2.3.2.5	Send Floor Request message (PTT button pressed)	133
7.2.3.2.6	Receive Floor Taken message (R: Floor Taken)	133
7.2.3.2.7	Receive Floor Granted message (R: Floor Granted to other)	134
7.2.3.2.8	Receive RTP media (R: RTP media)	134
7.2.3.2.9	MCPTT broadcast group call established – terminating MCPTT user	134
7.2.3.3	State: 'O: silence'	134
7.2.3.3.1	General	134
7.2.3.3.2	Send Floor Request message (PTT button pressed)	135
7.2.3.3.3	Receive RTP media (R: RTP media)	135
7.2.3.3.4	Receive Floor Granted message (R: Floor Granted to other)	135
7.2.3.3.5	Receive Floor Request message (R: Floor Request)	136
7.2.3.3.6	Receive Floor Taken message (R: Floor Taken)	136
7.2.3.3.7	Timer T230 (Inactivity) expired	136
7.2.3.4	State: 'O: has no permission'	136
7.2.3.4.1	General	136
7.2.3.4.2	Sending Floor Request message (PTT button pressed)	136
7.2.3.4.3	Receive Floor Release message (R: Floor Release)	137
7.2.3.4.4	Timer T203 (End of RTP media) expired	137
7.2.3.4.5	Receive Floor Granted message (R: Floor Granted to other)	137
7.2.3.4.6	Receive RTP media (R: RTP media)	137
7.2.3.5	State: 'O: has permission'	138
7.2.3.5.1	General	138
7.2.3.5.2	Send RTP Media packets (S: RTP Media)	138
7.2.3.5.3	Receive Floor Release message (R: Floor Release)	138
7.2.3.5.4	Receive Floor Request message (R: Floor Request)	138
7.2.3.5.5	Send Floor Release message (PTT button released with no pending request in queue)	139
7.2.3.5.6	Send Floor Granted message (PTT button released with pending request(s) in queue)	140
7.2.3.5.7	Receive Floor Request message with pre-emption indication (R: Floor Request with pre-emption)	140
7.2.3.5.8	Receive Floor Queue Position Request message (R: Floor Queue Position Request)	141
7.2.3.5.9	Transmission time limit warning (Timer T206 expires)	141
7.2.3.5.10	Transmission time limit reached with pending request(s) in queue (Timer T207 expires)	141
7.2.3.5.11	Transmission time limit reached with no pending request in queue (Timer T207 expires)	142
7.2.3.6	State: 'O: pending request'	142
7.2.3.6.1	General	142
7.2.3.6.2	Receive RTP media (R: RTP media)	142
7.2.3.6.3	Receive Floor Queue Position Info message (R: Floor Queue Position Info)	143
7.2.3.6.4	Receive Floor Deny message (R: Floor Deny)	144
7.2.3.6.5	Send Floor Release message (PTT button released)	144
7.2.3.6.6	Send Floor Taken message (Timer T201 expired N times)	145
7.2.3.6.7	Receive Floor Granted message (R: Floor Granted to me)	145
7.2.3.6.8	Receive Floor Granted message (R: Floor Granted to other)	146
7.2.3.6.9	Timer T201 (Floor Request) expired (Timer T201 expired)	147
7.2.3.6.10	Receive Floor Request message (R: Floor request)	147
7.2.3.6.11	Receive Floor Taken message (R: Floor Taken)	147

7.2.3.7	State: 'O: pending granted'	147
7.2.3.7.1	General	147
7.2.3.7.2	Receive RTP media (R: RTP Media)	148
7.2.3.7.3	Timer T205 (Floor Granted) expired (timer T205 expired).....	148
7.2.3.7.4	Timer T205 (Floor Granted) expired N times with pending request(s) in the queue (Timer T205 expired N times AND pending request(s) in queue)	148
7.2.3.7.5	Timer T205 (Floor Granted) expired N times with no pending request in the queue (Timer T205 expired N times AND no pending request in queue)	148
7.2.3.7.6	Timer T233 (Pending user action) expires with no pending request in the queue (Timer T233 expired AND no pending request in queue)	148
7.2.3.7.7	Timer T233 (Pending user action) expires with pending request(s) in the queue (Timer T233 expired AND pending request(s) in queue)	149
7.2.3.7.8	PTT button pressed.....	149
7.2.3.7.9	Receive Floor Release message (R: Floor Release)	149
7.2.3.7.10	Receive Floor Request message (R: Floor Request)	150
7.2.3.8	State: 'O: queued'.....	150
7.2.3.8.1	General	150
7.2.3.8.2	Receive RTP media (R: RTP media).....	150
7.2.3.8.3	Receive Floor Queue Position Info message (R: Floor Queue Position Info)	151
7.2.3.8.4	Receive Floor Deny message (R: Floor Deny)	151
7.2.3.8.5	User indication for release of pending request	152
7.2.3.8.6	Receive Floor Granted message (R: Floor Granted to me).....	152
7.2.3.8.7	Timer T233 (Pending user action) expires	152
7.2.3.8.8	User indication for accept of pending request	152
7.2.3.8.9	Receive Floor Granted message (R: Floor Granted to other)	153
7.2.3.8.10	Timer T203 (End of RTP media) expires	153
7.2.3.8.11	Send Floor Queue Position Request message (R: Request queue position info)	153
7.2.3.8.12	Timer T204 (Floor Queue Position request) expires	154
7.2.3.8.13	Timer T204 (Floor Queue Position request) expires N times	154
7.2.3.9	In any state	154
7.2.3.9.1	General	154
7.2.3.9.2	Receive MCPTT call release (R: MCPTT call release).....	154
8	Coding	155
8.1	Introduction	155
8.1.1	General.....	155
8.1.2	RTCP: APP message format	155
8.1.3	Application specific data field	156
8.1.4	Handling of unknown messages and fields.....	157
8.2	Floor control.....	157
8.2.1	Introduction.....	157
8.2.2	Floor control messages	157
8.2.2.1	General	157
8.2.2.2	Void.....	158
8.2.3	Floor control specific fields	158
8.2.3.1	Introduction	158
8.2.3.2	Floor Priority field	159
8.2.3.3	Duration field	160
8.2.3.4	Reject Cause field	160
8.2.3.5	Queue Info field	161
8.2.3.6	Granted Party's Identity field	161
8.2.3.7	Permission to Request the Floor field	161
8.2.3.8	User ID field.....	162
8.2.3.9	Queue Size field	162
8.2.3.10	Message Sequence Number field	163
8.2.3.11	Queued User ID field	163
8.2.3.12	Source field	164
8.2.3.13	Track Info field	164
8.2.3.14	Message Type field	165
8.2.3.15	Floor Indicator field	165
8.2.3.16	Audio SSRC of Granted Participant field	166
8.2.3.17	List of Granted Users field	167

8.2.3.18	List of SSRCS field	168
8.2.3.19	Functional Alias field	168
8.2.3.20	List of Functional Aliases field	169
8.2.3.21	Location field	169
8.2.3.22	List of Locations field	170
8.2.3.23	Queued Floor Requests Purpose field	171
8.2.3.24	List of Queued Users field	171
8.2.3.25	Queued Floor Requests Result field	172
8.2.3.26	Media Flow Control Indicator field	173
8.2.4	Floor Request message	174
8.2.5	Floor Granted message	175
8.2.6	Floor Deny message	177
8.2.6.1	General	177
8.2.6.2	Rejection cause codes and rejection cause phrase	178
8.2.7	Floor Release message	178
8.2.8	Floor Idle message	179
8.2.9	Floor Taken message	180
8.2.10	Floor Revoke message	182
8.2.10.1	General	182
8.2.10.2	Floor revoke cause codes and revoke cause phrases	183
8.2.11	Floor Queue Position Request message	184
8.2.12	Floor Queue Position Info message	185
8.2.13	Floor Ack message	186
8.2.14	Floor Release Multi Talker message	187
8.2.15	Queued Floor Requests message	188
8.2.16	Unicast Media Flow Control message	189
8.3	Pre-established session call control	190
8.3.1	Introduction	190
8.3.2	Pre-established session call control message	190
8.3.3	Pre-established session call control fields	191
8.3.3.1	Introduction	191
8.3.3.2	Media Streams field	191
8.3.3.3	MCPTT Session Identity field	192
8.3.3.4	Warning Text field	192
8.3.3.5	MCPTT Group Identity field	193
8.3.3.6	Answer State field	193
8.3.3.7	Inviting MCPTT User Identity field	194
8.3.3.8	Reason Code field	194
8.3.3.9	Handling of unknown fields and messages	195
8.3.3.10	PCK I_MESSAGE field	195
8.3.3.11	Reason Cause field	196
8.3.3.12	Invited MCPTT User Identity field	196
8.3.4	Connect message	197
8.3.5	Disconnect message	198
8.3.6	Acknowledge message	199
8.4	MBMS subchannel control	200
8.4.1	Introduction	200
8.4.2	MBMS subchannel control messages	200
8.4.3	MBMS subchannel control specific fields	200
8.4.3.1	Introduction	200
8.4.3.2	MCPTT Group ID field	201
8.4.3.3	MBMS Subchannel field	201
8.4.3.4	TMGI field	202
8.4.3.5	Void	202
8.4.3.6	Monitoring state	202
8.4.4	Map Group To Bearer message	203
8.4.5	Unmap Group To Bearer message	203
8.4.6	Application Paging message	204
8.4.7	Bearer Announcement message	205
8.5	MBMS notifications	205
8.5.1	Introduction	205
8.5.2	MBMS notifications control messages	206

8.5.3	MBMS notifications control specific fields	206
8.5.3.1	Introduction	206
8.5.3.2	Status field	206
8.5.3.3	Status changing MCPTT User Identity field	207
8.5.3.4	Group call ongoing field	207
8.5.3.5	Group broadcast alias field	208
8.5.3.6	Group regroup alias field	208
8.5.4	Group Dynamic Data Notify message	209
8.6	MBS subchannel control	210
8.6.1	Introduction	210
8.6.2	MBS subchannel control messages	210
8.6.3	MBS subchannel control specific fields	210
8.6.3.1	Introduction	210
8.6.3.2	MCPTT Group ID field	211
8.6.3.3	MBS Subchannel field	211
8.6.3.4	MBS Session ID field	212
8.6.3.5	Monitoring state	212
8.6.4	MapGroupToSessionStream message	212
8.6.5	UnMapGroupFromSessionStream message	213
8.6.6	MBS Application Paging message	214
8.6.7	Session Announcement message	214
9	Call setup control over pre-established session	215
9.1	General	215
9.2	MCPTT client	216
9.2.1	General	216
9.2.2	Call setup control over pre-established session state machine	216
9.2.2.1	General	216
9.2.2.2	State: 'Start-stop'	217
9.2.2.2.1	General	217
9.2.2.2.2	Pre-established session started	217
9.2.2.3	State: 'U: Pre-established session not in use'	217
9.2.2.3.1	General	217
9.2.2.3.2	Receive Connect message (R: Connect)	217
9.2.2.3.3	Pre-established session stopped	217
9.2.2.3.4	Receive Disconnect message (R: Disconnect)	217
9.2.2.3.5	Receive SIP 2xx response (R: 2xx response)	218
9.2.2.3.6	Receive SIP re-INVITE request (R: re-INVITE)	218
9.2.2.4	State: 'U: Pre-established session in use'	218
9.2.2.4.1	General	218
9.2.2.4.2	Receive Connect message (R: Connect)	218
9.2.2.4.3	Receive other floor control message (R: other message)	218
9.2.2.4.4	Receive RTP media packets (R: RTP packet)	218
9.2.2.4.5	Receive Disconnect message (R: Disconnect)	219
9.2.2.4.6	Receive SIP 2xx response (R: 2xx response)	219
9.3	Participating MCPTT function	219
9.3.1	General	219
9.3.2	Call setup control over pre-established session state machine for the participating MCPTT function	219
9.3.2.1	General	219
9.3.2.2	State: 'Start-stop'	220
9.3.2.2.1	General	220
9.3.2.2.2	Pre-established session started	220
9.3.2.3	State: 'G: Pre-established session not in use'	220
9.3.2.3.1	General	220
9.3.2.3.2	Receive SIP REFER request (R: SIP REFER)	221
9.3.2.3.3	Receive SIP INVITE request (R: SIP INVITE)	221
9.3.2.3.4	Pre-established session stopped	222
9.3.2.3.5	Receive SIP 200 (OK) response to the SIP re-INVITE request (R: 200 OK)	222
9.3.2.4	State: 'G: Pre-established session in use'	223
9.3.2.4.1	General	223
9.3.2.4.2	Receive floor control message (R: Floor control message)	223
9.3.2.4.3	Receive RTP media packets (R: RTP Media)	223

9.3.2.4.4	Receive call session release indication from MCPTT client (R: Call Release from MCPTT client).....	223
9.3.2.4.5	Receive call session release indication from the controlling MCPTT function (R: Call Release from MCPTT server).....	223
9.3.2.4.6	Receive pre-established session stopped indication from the MCPTT client (R: Pre-established Session Stopped from MCPTT client)	224
9.3.2.4.7	Receive Acknowledge message ((R: successful Ack) or (R: failure Ack))	224
9.3.2.4.8	Timer T55 (Connect) expired	224
9.3.2.4.9	Timer T55 (Connect) expired N times.....	225
9.3.2.4.10	Receive SIP 200 (OK) response (R: 200 OK)	225
9.3.2.4.11	Receive failed SIP response from the controlling MCPTT function (R: Call Release from the MCPTT server).....	225
9.3.2.5	State: 'G: Call releasing'	226
9.3.2.5.1	General	226
9.3.2.5.2	Receive Acknowledge message (R: Ack).....	226
9.3.2.5.3	Timer T56 (Disconnect) expired	226
9.3.2.5.4	Timer T56 (Disconnect) expired N times	226
10	MBMS subchannel control procedure.....	226
10.1	General	226
10.2	MBMS subchannel control procedure for the participating MCPTT function	227
10.2.1	General.....	227
10.2.2	State: 'Start-stop'	228
10.2.2.1	General	228
10.2.2.2	Send Map Group To Bearer message (R: Floor Request or Floor Taken)	228
10.2.3	State: 'M: A conversation is active'	228
10.2.3.1	General	228
10.2.3.2	Send Floor Idle message (R: Floor Idle)	229
10.2.3.3	Send Floor Taken message (R: Floor Taken).....	229
10.2.3.3a	Send Floor Release Multi Talker (R: Floor Release Multi Talker)	230
10.2.3.4	Send any other floor control message (R: Any other message).....	230
10.2.3.5	Send RTP media packet over the MBMS subchannel (R: RTP packet).....	231
10.2.3.6	Timer T15 (Conversation) expired.....	231
10.2.3.7	Timer T16 (Map Group To Bearer) expired	231
10.2.3.8	Timer T17 (Unmap Group To Bearer) expired	232
10.2.3.9	Timer T17 (Unmap Group To Bearer) expired Nth time	232
10.2.3.10	End conversation over the MBMS bearer (End conversation).....	232
10.2.3.11	Group call released.....	232
10.2.3.12	Move conversation to unicast.....	232
10.3	MBMS subchannel control procedure for the MCPTT client	233
10.3.1	General.....	233
10.3.2	Conversation over a pre-activated MBMS bearer is started	233
10.3.3	Receive floor control messages and RTP media packets over a MBMS subchannel	233
10.3.4	Conversation ended.....	233
10.3.5	Receive Application Paging message	233
10.3.6	Receive MBMS bearer announcement over MBMS bearer.....	233
10.4	Header compression	234
10.4.1	General.....	234
10.4.2	Participating MCPTT function procedure for ROHC	234
10.4.3	MCPTT client procedure for ROHC.....	234
10A	Additional MBMS procedures	234
10A.1	Group dynamic data notifications	234
10B	MBS subchannel control procedure	235
11	Configurable parameters	235
11.1	Timers	235
11.1.1	Timers in the on-network floor participant	235
11.1.2	Timers in the off-network floor participant	236
11.1.3	Timers in the floor control server	239
11.1.4	Timers in the participating MCPTT function.....	243
11.2	Counters	246